

---

# Operation Maintenance

---



---

## AMICO

---

### **SDAW SUAW**

Direct expansion models

0151-0251-0331-0351-0501-0601

### **SDC/SUC**

Chilled water models

0200-0250-0300-0400-0600

R407C 6/22 kW

---

 **UNIFLAIR™**



---

**Release : 2.4**

**Date: May 2008**

---

UNIFLAIR SpA policy is one of continuous technological innovation. The Company therefore reserves the right to amend any data herein without prior notice.

# Index

|  | Page      |
|--|-----------|
| <b>GENERAL CHARACTERISTICS</b>                                     | <b>4</b>  |
| Documentation enclosed with the unit                               | 4         |
| Unit description and intended use of the unit                      | 4         |
| Data Plate   | 5         |
| <b>START-UP AND COMMISSIONING</b>                                  | <b>6</b>  |
| Evacuation of refrigerant lines and refrigerant charging           | 6         |
| Thermostatic valve regulation                                      | 7         |
| Start-up procedure   | 8         |
| <b>FUNCTION AND REGULATION</b>                                     | <b>9</b>  |
| Water cooled units   | 9         |
| Measurement and alarm devices                                      | 10        |
| Regulating the condensation pressure (remote air-cooled condenser) | 12        |
| Setting the pressostatic valve                                     | 12        |
| Setting the regulation and safety devices                          | 13        |
| Fan speed regulation   | 14        |
| Setting the airflow sensor   | 14        |
| Setting the dirty filter sensor                                    | 15        |
| Room temperature and humidity sensor                               | 15        |
| Valve and servomotor   | 16        |
| <b>TECHNICAL DATA</b>  | <b>18</b> |
| General characteristics  | 18        |
| Nominal airflow  | 18        |
| Electrical data  | 19        |
| <b>MAINTENANCE</b>   | <b>21</b> |
| Preventive maintenance   | 21        |
| Humidifier   | 22        |
| <b>PROBLEM SOLVING</b>   | <b>25</b> |
| Temperature control  | 25        |
| Humidity control   | 26        |
| Ventilation  | 27        |
| Refrigerant circuit  | 28        |
| Compressors  | 29        |
| Electric re-heat   | 29        |

**IMPORTANT:** the description regarding the Control System and the Operating Logic of the unit are described in the Control System Instruction Manual.

# GENERAL CHARACTERISTICS

## DOCUMENTATION ENCLOSED WITH THE UNIT



Every unit is supplied complete with the following documentation:

- Installation manual;
- Operation and maintenance manual;
- Microprocessor Control Instruction manual;
- Electrical diagram;
- Spare parts list
- CE declaration with list of European directives and norms to which the unit conforms
- Guarantee conditions.

## UNIT DESCRIPTION AND INTENDED USE OF THE UNIT

Direct expansion precision air conditioning AMICO units ([SDA-SDW](#), [SUA-SUW](#)) or chilled water AMICO units (SDC, SUC) are designed for high-technology applications such as computer rooms, telephone exchanges, control rooms, laboratories and clean rooms.

Air-cooled direct-expansion units must be connected to UNIFLAIR 'CAL'-series condensers.

AMICO units are fully assembled and tested in the factory and are built for applications where safety and reliability cannot be compromised.

### ACTIVE SAFETY

UNIFLAIR control systems provide monitoring and prevention functions via:

- function status indication
- continuous reading and display of the temperature measured by the sensors.
- indication of fault and alarm situations
- automatic stopping of unit components in the event of risk;
- (for Direct expansion units) compressor management to reduce the start-up frequency of each compressor and to avoid compressors being started at the same time.

### PASSIVE SAFETY

The essential functions of UNIFLAIR air conditioning units are protected against faults and potentially dangerous conditions the control systems which includes:

- (for Direct expansion units) high and low-pressure pressostats to protect the refrigerant circuit (HP with manual re-set);
- low airflow differential pressostat
- safety thermostat on units with electric heater
- (for Direct expansion units ) compressor electric motor protection.

### PERSONAL SAFETY

The design and wiring of UNIFLAIR air conditioning units conform to 2006/95/EEC electrical norms. The electrical panels, are equipped with an auxiliary 24V circuit and include individual short circuit protection using automatic circuit

**DATA PLATE**

The units identification plate is located in the electrical panel compartment and gives the following information:

- Model and unit serial number;
- Voltage, number of phases and frequency of the power supply;
- Power absorbed by the unit and the individual components;
- Current absorbed by the unit and by the single components: OA (Operating current), FLA (Full load current) and LRA (Locked rotor current);
- (for Direct expansion models) Settings of the pressure switches of the refrigerant circuit (high and low pressure) and safety valve;
- (for Direct expansion models) Refrigerant type used and charging of refrigerant circuit.

|  |                   |
|--|-------------------|
| <i>MODEL</i>   | <i>SERIAL No.</i> |
| <i>POWER SUPPLY VOLTAGE</i>                              |                   |
| <i>ELECTRICAL CURRENT</i><br><i>OA FLA LRA KW TOTALI</i> |                   |
| <i>SETTING OF SAFETY DEVICES</i>                         |                   |
| <i>REFRIGERANT</i>                                       |                   |

Fig. 1.

# START-UP AND COMMISSIONING

## EVACUATION OF REFRIGERANT LINES AND REFRIGERANT CHARGING

(Air-cooled models)

Water-cooled units (SDW, SUW) are supplied charged with refrigerant R407C or R22.

Air-cooled units (SDA, SUA) contain a holding charge of dry nitrogen (N<sub>2</sub>) to prevent the presence of humidity within the refrigerant circuits. Evacuation and refrigerant charging is the responsibility of the installer who must read carefully the information enclosed in this paragraph.

|    | R22  | R407C   |
|----|--|---|
| 1. | Open any taps located within the machine or system in order to ensure that all of the components will be evacuated;  |   |
| 2. | Connect a high efficiency vacuum pump to the Schrader connections or to the ¼" SAE connections positioned on the intake and delivery side of the compressors;  |   |
| 3. | Arrange a connection with a coolant bottle onto the loading connections.   |   |
| 4. | <b>Create the vacuum</b> within the lines whilst maintaining for a <b>long time</b> the pressure below 100 Pa absolute (0.7 mm Hg) in order to evacuate the air as well as any trace of humidity.  | <b>Create the vacuum</b> within the lines whilst maintaining for a <b>long time</b> the pressure below 10 Pa absolute (0.07 mm Hg) in order to evacuate the air as well as any trace of humidity.   |
| 5. | It is preferable that the vacuum be reached slowly and maintained for a long period of time rather than periods that are too brief.<br>Await a "build-up period" of 100 seconds and check that the pressure has not exceeded 200 Pa absolute.  |   |
| 6. | Generally, in the case of suspicion of strong hydration of the circuit or extremely extensive system, it will be necessary to proceed to the "breaking" of the vacuum with anhydrous nitrogen and then repeat the evacuation procedure as described.   |   |
| 7. | Break the vacuum by performing a <b>preload</b> from the R22 coolant bottle.   | Break the vacuum by performing a <b>preload in liquid phase</b> from the R407C coolant bottle.  |
| 8. | After having started the compressor, <b>slowly complete the loading phase</b> until the pressure within the lines has been stabilised and the gaseous bubbles have disappeared from the flow window;   |   |
| 9. | The loading process must be controlled in design environmental conditions and with a delivery pressure of approximately 18 bar (equivalent to a saturated temperature of 48°C); in the case of units with on-off condensation controls, avoid switching-on and switching-off the condenser fan, which may partially obstruct the intake surface.<br><i>It is wise to check that the sub-cooling of the liquid at the entry of the thermostatic valve is between 3 and 5°C below the condensation temperature read on the scale of the pressure gauge and that the overheating of the vapour at the exit of the evaporator is equal to approximately 5-8°C.</i> | The loading process must be controlled in design environmental conditions and with a delivery pressure of approximately 18 bar (equivalent to a dew temperature of 48°C and bubble temperature of 43°C); in the case of units with on-off condensation controls, avoid switching-on and switching-off the condenser fan, which may partially obstruct the intake surface.<br><i>It is wise to check that the sub-cooling of the liquid at the entry of the thermostatic valve is between 3 and 5°C below the condensation temperature read on the scale of the pressure gauge and that the overheating of the vapour at the exit of the evaporator is equal to approximately 5-8°C.</i> |

| Refrigerant              | Recommended Oil type (*)  |                     |          |
|--------------------------|---------------------------|---------------------|----------|
| <b>R22</b> (Mineral oil) | Suniso 3 GS               | Texaco WF 32        | Fuchs KM |
| <b>R407C</b> (POE)       | Mobil EAL<br>Arctic 22 CC | ICI EMKARATE RL 32S |          |

(\*) recommended on COPELAND compressors.

In the case where it is necessary create the vacuum on a circuit already loaded with coolant, the first operation to perform is the removal of the coolant from the circuit by means of an appropriate device with a dry compressor which can recover the fluid.

**THERMOSTATIC VALVE REGULATION**

The expansion valve is regulated by using the regulation screws shown in the diagram below. The regulation of the valve has been pre-set in the factory on [SDW and SUW models](#)

- Check that liquid supercooling at the condenser output is around 3°C - 5°C;
- Check that thermostatic valve superheating is around 5°C - 8°C;
- Check that the sensor bulb of the valve is correctly positioned, fixed and insulated.

If superheating is higher than the consented level, increase the valve opening; if it is lower, reduce the opening.




Fig. 2.

The table below shows the approximate changes in superheating resulting from one full turn of the expansion valve regulation screw.

| Model<br>AMICO | Valve |       | Pressure change per turn [bar] | Evaporation Temperature                       |     |       |
|----------------|-------|-------|--------------------------------|---|-----|-------|
|                |       |       |                                | -10°C   | 0   | +10°C |
|                |       |       |                                | Change in superheating from one turn [Kelvin] |     |       |
| 0151...0601    | TX3   | R22   | 0.25                           | 2.0   | 1.5 | 1.2   |
| 0151...0601    | TX3   | R407C | 0.25                           | 2.0   | 1.5 | 1.2   |

**THERMOSTATIC ELECTRONIC REGULATION : see control manual Mp40**

## START-UP PROCEDURE

Power up the air-conditioner's control board: close the switch on the machine, set the auxiliary circuits' automatic circuit breaker, supply power and make sure the yellow light on the board or control keypad lights.

**Arm** all the automatic switches on the electrical panel.

**Wait at least 12 hours** after having turned on the power supply in order to heat up the oil in the compressors sufficiently (in units with optional crankcase heaters).

Refrigerant liquid may collect in the compressor crankcase during long periods of unit shut-down. At the start of the compressor this may cause foaming of the oil, leading to possible damage due to poor lubrication. It is therefore recommended to leave the power supply on for all but the longest of shut-downs.

**Open** all shut-off valves on the refrigerant circuits (air-cooled models).

**Open** all shut-off valves on the refrigerant circuit (on chilled-water models).


**Check** that power is on to the remote air-cooled condensers.


**Check** the water flow direction (on water-cooled models.).

**Check** that the condensation water shut-off valves are open (water-cooled models).

**Check** that the cooling water circulating pump is working and power is on to the external radiators (water-cooled models).

**AT LEAST 12 HOURS AFTER TURNING ON THE POWER SUPPLY:**

Start the unit by pressing enter button on the user terminal; after a short delay the fan will start and the symbol  on the control panel will appear.

If there is an Alarm signaling  also from the red flashing ALARM Key consult the Microprocessor Control instruction manual.



# FUNCTION AND REGULATION

## WATER-COOLED UNITS

### OPEN WATER CIRCUIT

If the cooling water temperature is not controlled and may go below 25°C, a pressostatic valve must be fitted for each condenser; in this case the supply pressure must not go above 200 kPa (2 bar).

**IMPORTANT:** do not use water cooled by an evaporative tower since the condensers would quickly become blocked with scale.

### CLOSED WATER CIRCUIT

The condensers are supplied with water in a closed circuit cooled by external dry-coolers ; check that the diameter of the piping and the performance of the pump are sufficient. An inadequate water flow reduces the performance of the air conditioning unit.

The cooling water temperature must be controlled so that it does not go below 25°C as per fig. 3.

The microprocessor control system can perform this function by; measuring the water temperature with optional sensor **A** and modulating the valve of the servomotor **B** or by controlling the fans **C** of the external dry-coolers.

If the temperature of the cooling water is not controlled, a constant water flow condensation pressure regulation system must be used (available as an option) on each cooling circuit.

**IMPORTANT:** the cooling water must contain a percentage of ethylene glycol (of the passive, non-corrosive type) in proportion to the likely minimum outdoor temperature.

|                                |      |       |       |       |       |
|--------------------------------|------|-------|-------|-------|-------|
| Percentage of glycol by weight | 10%  | 20%   | 30%   | 40%   | 50%   |
| Freezing temperature           | -4°C | -10°C | -17°C | -25°C | -37°C |




Fig. 3.

**MEASUREMENT AND ALARM DEVICES**


The unit is equipped with the following devices (see fig. 4.):

- **ST Temperature sensor**;
- **STU Room temperature and humidity sensor** (in units with humidity control);
- **FS Air flow sensor** (differential pressure switch);
- **PFS dirty filter sensor** (differential pressure switch);
- **High pressure switch AP** - with manual reset push-button ;
- **Low pressure switch BP** - with automatic re-set;
- **Electric heater safety thermostat TSR**; the re-set button is in the coil housing;

The following optional devices can be connected to the microprocessor control:

- **Under floor water detector** consisting of:
  - a) **SAS device** inserted in the appropriate socket of the electrical panel;
  - b) **RAS sensor** (or sensors, connected in parallel) installed at the points to be monitored;
- **High/low room temperature sensor**: to be installed close to the unit;
- **Room temperature and humidity sensor**: to be installed close to the room unit;
- **Fire and smoke sensors** to be installed in the room or under the raised floor, in a low air-speed zone.

Fig. 4.



Some versions might have the following probes:

- **External air temperature** read-only sensor to be installed outdoors, in the shade;
- **Closed circuit water temperature** sensor (for reading and control of water and glycol supply temperature) to be inserted in a measuring point on the water supply pipe to the unit;
- **Hot water temperature** sensor (for reading and control of hot water re-heating) to be inserted in a measuring point on the hot water supply pipe to the unit;
- **Air delivery temperature** sensor for monitoring and regulation of the room unit cooling capacity as a function of the air delivery temperature, to be installed near the fan output.

SLM DELIVERY TEMPERATURE LIMIT SENSOR




Fig. 5.

**REMOTE AIR-COOLED CONDENSER**

(regulation of condensation pressure)

Unit condensation pressure must be between:

- minimum 40°C (for correct thermostatic valve function and to avoid freezing of the coil in partial operation);
- maximum 63°C.

in order to control the condensation pressure, remote UNIFLAIR condensers belonging to the CAL series matched with AMICO air conditioners can be fitted with:

- pressostat **PV** which measures condensation pressure and activates the fan of the air-cooled condenser;
- regulator **RV** which modulates the speed of the fan as a function of condensation pressure.

The table below shows the settings of the two systems:

|    | Description     | Intervention        | Differential | Reset               |
|----|-----------------|---------------------|--------------|---------------------|
| PV | Fan Pressostat  | 18 bar (closing)    | 4 bar        | 14 bar              |
| RV | Speed Regulator | 20 bar (max. speed) | 4 bar        | 16 bar (min. speed) |

When setting the pressostat or the regulator, check the condensation pressure with a manometer connected to the pressure connector of the gas output valve.

**SETTING THE PRESSOSTATIC VALVE**

(Optional - water cooled models only)

The pressostatic valve controls the water flow to prevent that the condensate pressure falls too low and reduces water consumption.

Set the pressostatic valve with the regulation knob (clockwise to increase the pressure) until the pressure is stable at the recommended value of 17 bar (equivalent to a saturation temperature of around 45°C in the case of R22). Check the pressure with a manometer fitted on the pressure connector of the output valve.




Fig. 6.

## SETTING THE REGULATION AND SAFETY DEVICES

After having started the unit, set the following set points :

- **Room temperature:** (cooling and heating set points); see Microprocessor Control Manual;
- **Room relative humidity:** (humidity and dehumidification set point) (C and D versions):see Microprocessor Control Manual;
- **Fan speed:** see section on Fan Speed Regulation;
- **Dirty filter differential pressure switch :** see paragraph 'SETTING THE DIRTY FILTER SENSOR'.

**IMPORTANT:** The setting of the safety devices are set in the factory, as shown in the table below, and must not be modified.

*Check that safety devices are set at the values shown in the table below.*

### SETTING VALUES

| Rif | Description | Intervention | Differential | Re-set |
|-----|-------------|--------------|--------------|--------|
|-----|-------------|--------------|--------------|--------|

#### DIRECT EXPANSION MODELS

|    |                    |                       |         |                  |
|----|--------------------|-----------------------|---------|------------------|
| AP | HP Pressure switch | 27.5 bar<br>(opening) | -       | Re-set<br>manual |
| BP | LP Pressure switch | 2.0 bar<br>(opening)  | 1.5 bar | 3.5 bar          |

#### T and H VERSIONS

|     |                                 |                     |   |                 |
|-----|---------------------------------|---------------------|---|-----------------|
| TSR | Safety Thermostat<br>(optional) | 320 °C<br>(opening) | - | Manual<br>reset |
|-----|---------------------------------|---------------------|---|-----------------|

#### WATER-COOLED MODELS

|    |                    |        |   |   |
|----|--------------------|--------|---|---|
| VP | Pressostatic Valve | 15 bar | - | - |
|----|--------------------|--------|---|---|

### MAXIMUM AND MINIMUM WATER TEMPERATURES

Max. and minimum water temperatures for chilled water circuits and for hot water reheat circuits are: 5°C ÷ 90°C.  
The max. amount of ethylene glycol accepted equal to 50%.

## FAN SPEED REGULATION

Fan speed rotation can be adjusted according to environmental factors (a low speed corresponds to low noise levels and reduced unit capacity and vice versa). The fans speed is set between the maximum speed (mains voltage) and a minimum speed, the regulation has been pre-set in the factory.

### Models with regulator 4 A

|         |         |         |                 |                                   |
|---------|---------|---------|-----------------|-----------------------------------|
| S**0151 | S**0251 | S**0200 | nominal voltage | 192V ( 155V in dehumidification ) |
| S**0300 |         |         | nominal voltage | 200V ( 170V in dehumidification ) |
| S**0331 | S**0250 |         | nominal voltage | 205V ( 180V in dehumidification ) |

### Models with regulator 8 A

|         |         |         |                 |                                   |
|---------|---------|---------|-----------------|-----------------------------------|
| S**0351 | S**0400 |         | nominal voltage | 192V ( 155V in dehumidification ) |
| S**0501 | S**0601 | S**0600 | nominal voltage | 198V ( 165V in dehumidification ) |

N.B.: minimum speed is set automatically in units with humidity control during the dehumidification cycle.

**With electronic thermostatic valve see control manual Mp40**

## SETTING THE AIRFLOW SENSOR

The **FS** differential pressostat should intervene if the fan is not working (if the unit has **one** fan only) or if one of the fans is not running (in the case of multiple fans).

Since the difference in pressure between the fan intake and delivery depends on the airflow, it is necessary to set the pressostat after installation, making sure that the contact closes when the fan is in normal operation.

To set the pressostat:

- simulate a fan fault (stop the fan, or one of the fans if multiple); check that the pressostat intervenes;
- if the pressostat does not intervene, gradually lower the setting until it does.

The FS differential pressostat can be set on a scale from 0.5 to 5.0 mbar (from 50 to 500 Pa).

## SETTING THE DIRTY FILTER SENSOR

The PFS pressostat must be set as a function of the pressure drop; this depends not only on how dirty the filter is but also on the airflow and therefore on the setting of the fan speed regulator. The setting must be adjusted when the filter is clean:

- set the fan speed regulator at the desired value (see Fan Speed Regulation);
- set the pressostat intervention at 1.5 mbar;
- gradually cover the surface of the air filter and check that the pressostat intervenes when the filter is about 50-60% covered;
- if the pressostat does not intervene, gradually lower its setting; if it cuts in too soon, increase the setting.

## TEMPERATURE AND HUMIDITY SENSOR

The number and type of humidity sensors fitted on the units may vary according to the model :

- cooling only (**C**);
- cooling + electric re-heat (**T**);
- cooling + humidity control (humidification + dehumidification) (**D**);
- cooling + electric re-heat + humidity control (**H**).

The figure shows a horizontal temperature and humidity sensor, that must be connected as shown in the electric diagram.




Fig. 8.

**VALVE AND SERVOMOTOR**

**IMPORTANT:** Disconnect the power supply before working on the servomotor.

With 24V AC power supply the servomotor moves in accordance with the control signal that varies between 0 and 10V DC. The servomotor automatically stops:

- at the end of its travel;
- in the position corresponding to the control signal;
- in the position in which it is situated whenever power is disconnected.

**OPERATION OF SERVOMOTOR SSC619 (with Mp40 Microprocessor Control) AND SSC819 (with mP30 Microprocessor control) (\*)**

The degree of opening of the valve can be checked by looking at the indicator on top of the motor (see detail A in the diagram).


(\*) except for units with mP30 version T-H, with hot water valve.

**MANUAL EMERGENCY FUNCTION**


If there is a malfunction in the servomotor or in the control system, the valve can be moved manually by turning the control knob positioned next to the servomotor.

If necessary:


- Turn the knob clockwise to open the valve, and anti-clockwise to close it;



- If necessary remove the servomotor from the valve by unscrewing the locking nut (B); the servomotor is unscrewed manually, no tools are needed;





- After having removed the servomotor (2) the valve stem (1) will be raised completely, excluding the coil from the water flow; in three-way valves the water flow will be completely by-passed;





- Install the manual control knob on the valve (3); turn the knob clockwise to lower the valve stem (valve open), anti-clockwise to raise the valve stem (valve closed);
- With 3-way valves turn completely the knob and the by-pass will be completely obstructed. The hot water coil will then be supplied 100% by the water flow.
- In order to replace the servomotor: turn the manual control knob anti-clockwise and position the servomotor, then turn it clockwise with the locking nut.



# TECHNICAL DATA

## GENERAL CHARACTERISTICS

These characteristics refer to standard units and may be different on special or modified versions.

|   |                                   | S*.A-W             |      |      |      | SD*  | SU*  | SD*  | SU*  |
|---|-----------------------------------|--------------------|------|------|------|------|------|------|------|
|   |                                   | 0151               | 0251 | 0331 | 0351 | 0501 | 0501 | 0601 | 0601 |
| STANDARD FANS                             | NUMBER                            | 1                  | 1    | 1    | 2    | 2    | 3    | 2    | 3    |
|   | NUMBER OF POLES                   | 6                  | 6    | 6    | 6    | 6    | 6    | 6    | 6    |
| HIGH POWER FANS                           | NUMBER                            | 1                  | 1    | 1    | 2    | 3    | 3    | 3    | 3    |
|   | NUMBER OF POLES                   | 4                  | 4    | 4    | 4    | 4    | 4    | 4    | 4    |
| COMPRESSOR                                | NOMINAL POWER (ARI standard) - kW | 1.8                | 2.5  | 2.9  | 3.7  | 4.5  | 4.5  | 5.2  | 5.2  |
| RESIST. ELETTRICHE STANDARD (T-H vers.)   | TOTAL POWER kW                    | 2                  | 2    | 2    | 3    | 6    | 6    | 6    | 6    |
|   | NUMBER OF ELEMENTS                | 1                  | 1    | 1    | 1    | 2    | 2    | 2    | 2    |
| HUMIDIFIER                                | MAX CAPACITY kg/h                 | 1,5                | 1,5  | 1,5  | 1,5  | 3    | 3    | 3    | 3    |
|   | NOMINAL POWER kW                  | 1.5                | 1.5  | 1.5  | 1.5  | 2.2  | 2.2  | 2.2  | 2.2  |
| HOT WATER VALVE (optional)                |                                   | 1/2"               | 1/2" | 1/2" | 1/2" | 3/4" | 3/4" | 3/4" | 3/4" |
| FUSE F1                                   |                                   | 5x20 250V 4A - 'F' |      |      |      |      |      |      |      |
| FUSE F3 (WITH OPT. CONDENSATE DRAIN PUMP) |                                   | 5x20 250V 1A - 'T' |      |      |      |      |      |      |      |

|  |                     | S°C                |      |      |      | SDC  | SUC  |
|--|---------------------|--------------------|------|------|------|------|------|
|  |                     | 0200               | 0250 | 0300 | 0400 | 0600 | 0600 |
| STANDARD FANS                                | NUMBER              | 1                  |      |      |      | 2    | 3    |
|  | NUMBER OF POLES     | 6                  |      |      |      | 6    | 6    |
| HIGH POWER FANS                              | NUMBER              | 1                  |      |      |      | 2    | 3    |
|  | NUMBER OF POLES     | 4                  |      |      |      | 4    | 4    |
| STANDARD ELECTRICAL RE-HEAT (T - H versions) | TOTAL POWER - kW    | 2                  |      | 3    |      | 6    | 6    |
|  | NUMBER OF ELEMENTS  | 1                  |      | 1    |      | 2    | 2    |
| HUMIDIFIER                                   | MAX CAPACITY - kg/h | 1,5                |      |      |      | 3    | 3    |
|  | NOMINAL POWER - kW  | 1.5                |      |      |      | 2.3  | 2.3  |
| CHILLED WATER VALVE                          |                     | 1/2"               | 3/4" |      |      | 1"   | 1"   |
| HOT WATER VALVE (optional)                   |                     | 1/2"               |      |      |      | 3/4" | 3/4" |
| FUSE F1                                      |                     | 5x20 250V 4A - 'F' |      |      |      |      |      |
| FUSE F3 (WITH OPT. CONDENSATE DRAIN PUMP)    |                     | 5x20 250V 1A - 'T' |      |      |      |      |      |

## NOMINAL AIRFLOW

| m <sup>3</sup> /h <sup>(1)</sup> | 0151 | 0251 | 0331 | 0351 | 0501 | 0601 |
|----------------------------------|------|------|------|------|------|------|
| SD*                              | 1580 | 1580 | 1940 | 3020 | 4970 | 4970 |
| SU*                              | 1580 | 1580 | 1940 | 3020 | 4720 | 4720 |

<sup>(1)</sup> data refers to static delivery pressure of 10 Pa.

## ELECTRICAL DATA

### COMPONENTS

| MODEL                | VOLTAGE   | FANS |      |         | COMPRESSOR |          |          |        | HEATERS |          | HUMIDIFIER |         |
|----------------------|-----------|------|------|---------|------------|----------|----------|--------|---------|----------|------------|---------|
|                      |           | No.  | kW   | OA      | kW         | OA       | FLA      | LRA    | kW      | OA       | kW         | OA      |
| SD* 0151<br>SU* 0151 | 230/1 (*) | 1    | 0.25 | 1.3 (s) | 1.8        | 8.7 (s)  | 10.0 (s) | 55 (s) | 2.0     | 8.7 (s)  | 1.5        | 6.3 (s) |
| SD* 0251<br>SU* 0251 | 230/1 (*) | 1    | 0.25 | 1.3 (s) | 2.5        | 12.1 (s) | 15.0 (s) | 86 (s) | 2.0     | 8.7 (s)  | 1.5        | 6.3 (s) |
| SD* 0331<br>SU* 0331 | 400/3+N   | 1    | 0.25 | 1.3 (s) | 2.9        | 5.0 (t)  | 5.7 (t)  | 44 (t) | 2.0     | 8.7 (s)  | 1.5        | 6.3 (s) |
| SD* 0351<br>SU* 0351 | 400/3+N   | 2    | 0.25 | 1.3 (s) | 3.6        | 6.2 (t)  | 6.8 (t)  | 51 (t) | 3.0     | 13.0 (s) | 1.5        | 6.3 (s) |
| SU* 0501             | 400/3+N   | 3    | 0.25 | 1.3 (s) | 4.5        | 7.7 (t)  | 8.5 (t)  | 60 (t) | 6.0     | 13.0 (s) | 2.2        | 9.5 (s) |
| SD* 0501             | 400/3+N   | 2    | 0.57 | 2.9 (s) | 4.5        | 7.7 (t)  | 8.5 (t)  | 60 (t) | 6.0     | 13.0 (s) | 2.2        | 9.5 (s) |
| SU* 0601             | 400/3+N   | 3    | 0.25 | 1.3 (s) | 5.2        | 9.3 (t)  | 10.6 (t) | 70 (t) | 6.0     | 13.0 (s) | 2.2        | 9.5 (s) |
| SD* 0601             | 400/3+N   | 2    | 0.57 | 2.9 (s) | 5.2        | 9.3 (t)  | 10.6 (t) | 70 (t) | 6.0     | 13.0 (s) | 2.2        | 9.5 (s) |

**KEY**

kW: nominal power;  
 OA: current absorbed nominal conditions;  
 FLA: current absorbed maximum conditions  
 LRA: start-up current.

(\*) for 0151-0251 models, the standard current supplied is monophase 230V/1/50Hz; triphase current is supplied on request 400V/3+N/50Hz.

**NOTES**

(s): monophase current  
 (t): triphase current.

### CURRENT ABSORPTION OF COMPLETE UNIT

| MODEL       | VOLTAGE | C VERSION |      | T VERSION (*) |      | D VERSION |      | H VERSION (*) |      |
|-------------|---------|-----------|------|---------------|------|-----------|------|---------------|------|
|             |         | kW        | OA   | kW            | OA   | Kw        | OA   | kW            | OA   |
| S*.A-W 0151 | 230/1   | 2.1       | 10.0 | 2.3           | 10.0 | 3.6       | 16.3 | 4.1           | 18.7 |
| S*.A-W 0251 | 230/1   | 2.8       | 13.4 | 2.8           | 13.4 | 4.3       | 19.7 | 4.8           | 22.1 |
| S*.A-W 0331 | 400/3+N | 3.2       | 6.3  | 3.2           | 8.7  | 4.7       | 11.3 | 5.2           | 13.7 |
| S*.A-W 0351 | 400/3+N | 4.1       | 8.8  | 4.1           | 13.0 | 5.6       | 12.5 | 7.1           | 19.2 |
| SU.A-W 0501 | 400/3+N | 5.3       | 11.6 | 6.8           | 12.6 | 7.5       | 17.2 | 11.3          | 20.3 |
| SD.A-W 0501 | 400/3+N | 5.6       | 12.9 | 7.1           | 13.9 | 7.8       | 17.2 | 11.6          | 21.6 |
| SU.A-W 0601 | 400/3+N | 6.0       | 13.2 | 6.8           | 13.2 | 8.2       | 18.8 | 12.0          | 21.9 |
| SD.A-W 0601 | 400/3+N | 6.3       | 14.5 | 7.1           | 14.5 | 8.5       | 18.8 | 12.3          | 23.2 |

**NOTE** : Maximum current absorption of the most heavily loaded phase in operational conditions;

**KEY**

**VERSION C**: cooling only  
**VERSION T**: cooling + electric re-heat  
**VERSION D**: cooling + humidity control (humidification and dehumidification)  
**VERSION H**: cooling + electric re-heat + humidity control.

(\*) data referred to units with standard electric resistances.

**IMPORTANT**: Units with high capacity electrical resistances all have triphase voltage: 400V/3+N/50Hz.

| MODEL           | VOLTAGE | FANS |      |         | HEATERS |          | HUMIDIFIER |         |
|-----------------|---------|------|------|---------|---------|----------|------------|---------|
|                 |         | No.  | kW   | OA      | kW      | OA       | kW         | OA      |
| <b>S*C 0200</b> | 230/1   | 1    | 0.25 | 1.3 (s) | 2.0     | 8.7 (s)  | 1.5        | 6.3 (s) |
| <b>S*C 0250</b> | 230/1   | 1    | 0.25 | 1.3 (s) | 2.0     | 8.7 (s)  | 1.5        | 6.3 (s) |
| <b>S*C 0300</b> | 230/1   | 1    | 0.25 | 1.3 (s) | 3.0     | 13.0 (s) | 1.5        | 6.3 (s) |
| <b>S*C 0400</b> | 230/1   | 2    | 0.25 | 1.3 (s) | 3.0     | 13.0 (s) | 2.2        | 9.5 (s) |
| <b>S*C 0600</b> | 230/1   | 2    | 0.57 | 2.9 (s) |         |          | 2.2        | 9.5 (s) |
|                 | 400/3+N |      |      |         | 6.0     | 13.0 (t) |            |         |

**KEY**

kW: nominal power;  
 OA: current absorption in nominal conditions;

**NOTES**

(s): monophasic current  
 (t): triphasic current.

| MODEL           | VOLTAGE | C VERSION (*) |     | T VERSION |      | D VERSION |      | H VERSION (*) |      |
|-----------------|---------|---------------|-----|-----------|------|-----------|------|---------------|------|
|                 |         | kW            | OA  | kW        | OA   | kW        | OA   | kW            | OA   |
| <b>S*C 0200</b> | 230/1   | 0.3           | 1.3 | 2.3       | 10.0 | 1.8       | 7.6  | 3.8           | 16.3 |
| <b>S*C 0250</b> | 230/1   | 0.3           | 1.3 | 2.3       | 10.0 | 1.8       | 7.6  | 3.8           | 16.3 |
| <b>S*C 0300</b> | 230/1   | 0.3           | 1.3 | 3.3       | 14.3 | 1.8       | 7.6  | 4.8           | 20.6 |
| <b>S*C 0400</b> | 230/1   | 0.5           | 2.6 | 3.5       | 15.6 | 2.0       | 8.9  | 5.0           | 21.9 |
| <b>SUC 0600</b> | 230/1   | 0.8           | 3.9 | --        | --   | 3.0       | 13.4 | --            | --   |
|                 | 400/3+N | --            | --  | 6.8       | 12.6 | --        | --   | 9.0           | 22.1 |
| <b>SDC 0600</b> | 230/1   | 1.2           | 5.2 | --        | --   | 3.3       | 14.7 | --            | --   |
|                 | 400/3+N | --            | --  | 7.1       | 13.9 | --        | --   | 9.3           | 23.4 |

**NOTE** : Maximum current absorbed during heavily loaded phases under operating conditions;

**KEY**

**VERSION C:** cooling only  
**VERSION T:** cooling + electric re-heat  
**VERSION D:** cooling + humidity control (humidification and dehumidification)  
**VERSION H:** cooling + electric re-heat + humidity control.

(\*) data referred to units with standard electric resistances.

**IMPORTANT:** Units with high capacity electrical resistances all have triphase voltage: 400V/3+N/50Hz.

# MAINTENANCE

## PREVENTIVE MAINTENANCE

The following maintenance operations should be done regularly.

### WEEKLY:

- check that room conditions on the control panel display are normal;
- (for Direct expansion units ) check the refrigerant charge and the sight flow glass (the presence of a few bubbles is normal);
- check normal room temperature and noise levels of compressor and fans;
- check the air filters; clean or change the filters when the dirty filter alarm comes on;
- check that the power supply voltage is within design limits.

### MONTHLY:

- check normal condensation and evaporation pressures;
- check the cylinder and the feed and drain valves of the humidifier: replace the cylinder when the specific alarm comes on (see microprocessor instruction manual);
- check the flow of condensate to the drain;
- check remote condensers or external radiators: remove all foreign objects (leaves, seeds, dust, etc.) uses an air compressor or water;
- check the correct functioning of the chilled water valve (on SDC-SUC models).
- check correct pressostatic valve operation (option for water-cooled models).

### YEARLY:

- check that electrical terminals are tight and in good condition;
- check that the concentration of ethylene glycol and passivating inhibitor complies with the supplier's instructions (water-cooled models).


**HUMIDIFIER**

**SYSTEMS COMPONENTS**

On request, D and H versions can be fitted with an immersed-electrode humidifier. The steam production group consists of the following components.



1. Humidifier interface board: **SIU**;  
( at internal of the electrical panel ) .
2. Current transformer **TAM** for measuring the current flowing between the electrodes in the boiler cylinder;
3. Water supply filling tray;
4. High water level detector electrodes in the boiler cylinder;
5. Overflow pipe;
6. Boiler cylinder;
7. Feed water solenoid valve: **EVC**;
8. Boiler cylinder drain solenoid valve: **EVS**.
9. Control board: **MP40**;
10. Temperature and humidity probe: **STU**;



## OPERATING PRINCIPLE OF THE HUMIDIFIER

In the electrode boiler humidifier, the current flowing between the electrodes in the water in the cylinder generates the heat necessary to boil the water (see fig. 11.).

The rate of current flow, and therefore of steam production measured by the transformer (2.), is controlled by controlling both the water level and the concentration of salts in the cylinder (6.) by means of the fill (7.) and drain (8.) solenoid valve.

On a call for humidification, the CU humidifier contact (see electrical diagram) is closed, providing power to the immersed electrodes. When the current falls below the value required as a result of a fall in the water level, the feed water solenoid valve (7.) is opened.

The drain solenoid valve (8.) is opened at intervals depending upon the characteristics of the feed water supply, in order to maintain the optimum concentration of dissolved salts in the water in the cylinder (6.).

The only maintenance required is periodic inspection and cleaning of the steam boiler components. This should be carried out at least once a year, preferably before summer holiday shutdown.

## BOILER CYLINDER

Scale deposits must be cleaned periodically from the electrodes and particles of scale must be removed from the filter at the base of the cylinder.

To dismantle the cylinder:

- drain all the water from the cylinder (see the section on Manual Controls in the microprocessor control instruction manual);
  
- cut the power supply by opening the main isolator on the electrical panel;
- disconnect the steam distributor hose from the top of the cylinder;
- disconnect the power connections to the electrodes by unscrewing the terminal connectors and pull off the connectors of the high level electrodes;
- unclip the cylinder fixing strap ;
- pull the cylinder vertically upwards out of its seat.

The boiler cylinder can be re-used many times after cleaning of the electrodes. However it will eventually require replacement when the electrode meshes are too worn to make further cleaning worth while. The standard spare part comprises only the cylinder itself .

## FILL AND DRAIN CONNECTIONS

Periodic inspections of the fill and drain connections are also advisable in order to guarantee trouble-free operation of the humidifier.

Proceed as follows:

- drain all the water from the cylinder using the MANUAL CONTROL on the microprocessor control;
- cut the power supply by opening the main isolator on the electrical panel;
- disconnect the feed line at the  $\frac{3}{4}$  " connection to the inlet solenoid valve connection;
- extract, clean and replace the filter located inside the solenoid valve connection;
- remove the drain solenoid valve assembly (shown in fig. 13.), clean out the water pathways and remove any particles of scale from the drain syphon.



Fig. 13



## PROBLEM SOLVING

Problem solving is made easier by the control panel display, if there is an alarm, consult the Control panel instruction manual. If necessary, call the nearest service centre describing the nature of the fault displayed on the control.

| PROBLEM   | POSSIBLE CAUSE                                | CHECK / REMEDY  |
|---|---|---|
| NO POWER<br><br>(the yellow power line light on the mother board or on the terminal is unlit) | A) No power to the unit electrical panel      | Check that power is on and the unit main switch on the electrical panel is closed.                                    |
|   | B) No power to the auxiliary circuit          | 1) Check that the IM automatic circuit breaker on the AUX circuit is set.<br>2) Check the auxiliary circuit 24V fuse. |
| THE UNIT DOES NOT WORK  | A) The control panel does not start the unit. | Check that the control panel connectors are correctly located in their sockets; see control panel instruction manual. |
|   | B) Check the control panel for alarms         | See the control panel instruction manual  |

### TEMPERATURE CONTROL

| PROBLEM  | POSSIBLE CAUSE  | CHECK / REMEDY   |
|--|---|--|
| ROOM TEMPERATURE TOO HIGH<br><br>(high room temperature alarm) | A) The parameter settings on the control panel are not correct    | Check the room temperature setting; see control panel instruction manual.  |
|  | B) Lack or zero air flow.   | See "Lack Of Air Flow".  |
|  | C) The compressor does not work when called by the control panel. | See "The Compressor Does Not Work".  |
|  | D) Insufficient compressor output                                 | See "Compressor High Output Pressure", "Compressor Low Intake Pressure".   |
|  | E) The control system does not work properly                      | See the control panel instruction manual; check that the control panel and sensors work properly.                      |
|  | F) Heat load higher than expected.                                | Check: fresh air conditions and volume, external air infiltration and latent load, particularly with dehumidification. |
|  | G) The 3-way valve is not working                                 | Check the electrical connections of the servomotor valve (see paragr. SERVOMOTOR VALVE)                                |
|  | H) Insufficient chilled water flow.                               | Check the chilled water supply; check that the shut-off valves are open.   |
|  | I) Chilled water temperature too high                             | Check the chilled water function.  |

TEMPERATURE CONTROL

| PROBLEM   | POSSIBLE CAUSE   | CHECK / REMEDY   |
|---|--|--|
| ROOM TEMPERATURE TOO LOW<br>(Low room temperature alarm)                  | A) The parameter settings on the control panel are not correct.                              | Check the room temperature setting; see the control panel instruction manual     |
|   | B) Insufficient power supply to the electric heaters or the heaters are not working.         | 1) Check electric heater operation   |
|   |  | 2) Check electric heater power supply  |
|   |  | 3) If there is a heater alarm, remove the cause and re-set the safety thermostat |
|   | C) The hot gas coil (if fitted) is not working during dehumidification with re-heat.         | 1) Check the hot gas three-way valve function                                    |
|   |  | 2) Check the compressor serving the re-heat: see "The Compressor Doesn't Work"   |
|   | D) The hot water coil is not working properly.   | 1) Check the flow of hot water   |
| 2) Check the function of the regulation valve (see Valve and Servomotor). |  |  |
| E) The control system is not working properly.                            | See control panel instruction manual; check that control panel and/or sensors work properly. |  |
| F) Thermal leakage higher than expected                                   | Check thermal leakage and entry of external air.   |  |
| G) The 3-way valve of the chilled water circuit is blocked open.          | Check the functioning of the 3-way valve (see paragr. VALVE AND SERVOMOTOR)                  |  |

HUMIDITY CONTROL

| PROBLEM  | POSSIBLE CAUSE   | CHECK / REMEDY   |
|--|--|--|
| ROOM HUMIDITY TOO HIGH<br>(High room humidity alarm) | A) The parameter settings on the control panel are not correct.                              | Check room humidity settings; see the control panel instruction manual.                                    |
|  | B) Latent load higher than expected  | Check: latent load, fresh air conditions and volume, external air infiltration                             |
|  | C) The compressor does not function during dehumidification.                                 | See "The Compressor Doesn't Work"  |
|  | D) Dehumidification valve does not close.  | Check the function of the dehumidification circuit solenoid valve.   |
|  | E) The control system is not working.  | See control panel instruction manual; check that control panel and sensors work properly.                  |
|  | F) Chilled water not sufficiently cold for the dehumidification function                     | Lower the chilled water temperature until condensate is present on the surface of the coil.                |
| ROOM HUMIDITY TOO LOW<br>(Low room humidity alarm)   | A) The parameter settings on the control panel are not correct.                              | Check the room temperature setting; see also the control panel instruction manual.                         |
|  | B) Latent load lower than expected.  | Check: quantity of the latent load, fresh air conditions and volume, external air infiltration             |
|  | C) The humidifier is not working.  | 1) Check water supply pressure   |
|  |  | 2) Check function of manual control system and steam production group (see microprocessor control manual). |
| D) The control system is not working.                | See control panel instruction manual; check that control panel and/or sensors work properly. |  |

**VENTILATION**

| PROBLEM   | POSSIBLE CAUSE  | CHECK/REMEDY   |
|---|---|--|
| LACK OF AIRFLOW   | A) No power to the fans   | Check power supply to the fan motors   |
|   | B) The filters are dirty  | Shake dust out of the cartridge and clean with a vacuum cleaner. Change filter if blocked. Check correct setting of the dirty filter pressostat. |
|   | C) The fans are rotating in the wrong direction   | Swap two power supply phases and check correct rotation direction. (See electrical diagrams, RSF phase sequence relay).                          |
|   | D) The airflow is obstructed  | Read the section on Air Distribution   |
|   | E) Intervention of fan thermal protection.  | Check the resistance of the fan windings. Re-set then measure voltage and current.   |
|   | F) The fan speed control is incorrectly set   | See Fan Speed Regulation and Setting the Fan Speed Regulator   |
|   | G) The pressure drop on the air distribution system (ducts, suspended ceiling, raised floor, etc.) is too high. | 1) Check the dimensions and characteristics of the air distribution system   |
|   |   | 2) Increase the fan rotation speed (See Fan Speed Regulation)  |
| 3) If the unit has standard 6-pole fans, substitute high-power 4-pole fans.   |   |  |
| H) The control system signals an alarm even though the airflow is correct; the microprocessor control and/or the airflow sensor is not working; | See the microprocessor control manual.  |  |

**REFRIGERANT CIRCUIT**

| PROBLEM  | POSSIBLE CAUSE  | CHECK/REMEDY   |
|--|---|--|
| HIGH COMPRESSOR OUTPUT PRESSURE  | A) Non-condensable air or gas in the circuit, with bubbles in the flow sight glass; supercooling of the liquid is high. | Evacuate the refrigerant circuit and re-charge   |
|  | B) Airflow is insufficient or air in the remote condenser is too warm.  | 1) Check fan operation and rotation direction in the remote heat exchanger. (See condenser/radiator instruction manual). |
|  |   | 2) Remove any obstructions from the remote condenser with compressed air or water.                                       |
|  |   | 3) Check pressure drop if air output is ducted   |
|  |   | 4) Check for obstructions to unit airflow and for recirculation of air;  |
|  |   | 5) Check that the temperature of the cooling air is within the projected limits  |
| C) Water flow to remote condenser insufficient or too warm.  | 1) Check condensation water flow, pressure and temperature;<br>2) Check pressostatic valve setting and function.        |  |
| D) Too much refrigerant in the circuit; condenser partially flooded. Refrigerant supercooling too high at condenser output | Remove some refrigerant from the circuit.   |  |
| E) High-pressure valves partially closed   | Check the opening of the valves.  |  |

REFRIGERANT CIRCUIT

| PROBLEM   | POSSIBLE CAUSE  | CHECK/REMEDY  |
|---|---|---|
| HIGH PRESSURE PRESSOSTAT INTERVENES                               | A) The condensation pressure control system is not functioning efficiently. (air-cooled models).  | 1) Check condenser fan and fuses; re-set or replace the faulty fans;<br>2) Check setting and function of the condenser fan pressostat and the speed regulator |
|   | B) The HP pressostat is incorrectly set.  | Re-set the pressostat to the value shown on the unit data plate.  |
|   | C) System output pressure is too high.  | See High Compressor Output Pressure   |
| LOW COMPRESSOR OUTPUT PRESSURE                                    | A) The condensation pressure control system is not working (see microprocessor control instruction manual).   | 1) Check the function and setting of the condenser fan pressostat and speed regulator   |
|   | B) Water flow to the condenser is too high or too cold.   | 1) Check the temperature of the water supply to the condenser   |
|   |   | 2) Check the setting and function of the pressostatic valve (if fitted)   |
| C) Intake pressure too low  | 3) Install a pressostatic regulation valve to control the water flow as a function of condensation pressure.<br>See Low Compressor Intake Pressure. |   |
| HIGH COMPRESSOR INTAKE PRESSURE                                   | A) Thermal load higher than expected  | Check: room thermal load especially during dehumidification; the flow and conditions of external air; external air leaks                                      |
|   | B) System output pressure is too high   | See High Compressor Output Pressure   |
|   | C) Too much refrigerant in the circuit  | Remove some refrigerant from the circuit.   |
|   | D) Liquid refrigerant return to compressor intake   | Check correct thermostatic valve superheating (around 8-10°C); Check that the valve sensor bulb is correctly positioned, fixed and insulated                  |
| LOW COMPRESSOR INTAKE PRESSURE<br>(possible freezing of the coil) | A) Room temperature too low   | See "Room temperature too low"  |
|   | B) Low or zero airflow  | See "Lack of airflow"   |
|   | C) Liquid receiver output valve not fully open  | Check the opening of the valve  |
|   | D) Refrigerant filter blocked   | Check the refrigerant filter  |
|   | E) Thermostatic valve incorrectly set or defective  | Check correct thermostatic valve superheating (around 8-10°C); Check that the valve sensor bulb is correctly positioned, fixed and insulated.                 |
|   | F) Insufficient refrigerant charge  | Check for leaks and re-charge the unit until supercooling at the condenser output is 3-5°C.   |

**REFRIGERANT CIRCUIT**

| PROBLEM   | POSSIBLE CAUSE                                     | CHECK/REMEDY  |
|---|--|---|
| COMPRESSOR INTAKE LP PRESSOSTAT INTERVENES (low compressor intake pressure) | A) Thermostatic valve incorrectly set or defective | Check that superheating of the thermostatic valve is correct (around 8-10°C).   |
|   | B) The filter dryer cartridge is dirty             | Check whether the cartridge needs to be changed; temperature difference before and after the cartridge should be less than 2°C. |
|   | C) The low pressure pressostat is incorrectly set. | Re-set low pressure pressostat.   |
|   | D) System output pressure is too low               | See "Low compressor output pressure".   |

**COMPRESSORS**

| PROBLEM                                   | POSSIBLE CAUSE                                      | CHECK/REMEDY  |
|---|---|---|
| THE COMPRESSOR DOESN'T WORK               | A) Short circuit protection has intervened          | Re-set the automatic switch and check the cause of the short circuit. Before starting the compressor check the resistance and continuity of the compressor winding. |
|   | B) Intervention of compressor's internal protection | See Compressor Internal Protection has Intervened   |
|   | C) The contactor is not working                     | Check the contacts and the contactor coil.  |
| COMPRESSOR INTERNAL PROTECTION INTERVENES | A) A phase is missing                               | Check the resistance of the compressor winding. After re-setting, measure the voltage and current of the three phases.  |
|   | B) The motor is overloaded                          | Check that unit is operating within normal limits   |
|   | C) Power supply voltage too high or too low         | Check that the difference between the three power supply phases is less than 2%. With monophase units, voltage must be within -10% and +6% of the nominal value.    |
|   | D) The rotor is blocked                             | Replace the compressor  |
| THE COMPRESSOR IS NOISY                   | A) The compressor is damaged                        | Call an authorised service centre to replace the compressor.  |
|   | B) Liquid return to the compressor                  | Check expansion valve function and superheating.  |

**ELECTRIC RE-HEAT**

| PROBLEM                                      | POSSIBLE CAUSE                               | CHECK / REMEDY  |
|--|--|---|
| ELECTRIC HEATER SAFETY THERMOSTAT INTERVENES | A) Insufficient airflow                      | See Low Airflow   |
|  | B) Thermostat connection wire is interrupted | Check the continuity of the connection between the safety thermostat and the control system |
|  | C) The safety thermostat is faulty           | Change the thermostat.  |





**UNIFLAIR S.p.A.**

Sede legale ed amministrativa: Viale della Tecnica 2,  
35026

Conselve (PD) Italy

Tel +39 049 5388211 Fax +39 049 5388212 - [uniflair.com](mailto:info@uniflair.com)  
[info@uniflair.com](mailto:info@uniflair.com)

P.IVA 02160760282 C.C.I.A.A. di PD R.E.A. 212586 del  
21/04/1988 - R.I.N. 02160760282 M. PD004505

Capitale Sociale € 19.550.000 interamente versato

