



A NAME YOU CAN TRUST

CANOPY LOOM DIAGRAM (WITHOUT DEFORSTER)

- RED CONNECT TO THE BRAKE
 LAMP OF THE VEHICLE
- BLUE CONNECT TO THE ROOM
 LAMP OF THE VEHICLE
- BLACK CONNECT TO THE GROUND/EARTH
 OF THE VEHICLE

