

trendwoo®
Follow Your Passion
www.trendwoo.com

FREEMAN X6

USER MANUAL

Wireless Bluetooth Speaker



www.trendwoo.com

ACCESSORIES:

1x FreemanX6 Bluetooth Speaker
1x User Manual
1x USB Charging Cable
1x AUX 3.5mm Audio Cable

THANK YOU FOR USING FREEMAN-X6 BLUETOOTH
BICYCLE SPEAKER

BEFORE OPERATING THIS UNIT, PLEASE READ THIS MANUAL COMPLETELY

Warning:

- Please don't shoot the eyes directly, it would effect the eyesight or may cause permanent loss of eyesight.
 - When using the torch, the LED chip will generate enormous thermal energy and the shell can get hot. Please use it carefully to prevent from being burnt.
 - Do not take apart the speaker by yourself. It will damage the inner parts.
 - Do not expose the speaker to fire, high temperatures, water or corrosive substances.
 - To prevent from electronic interference, please turn it off at places where Bluetooth devices are prohibited, such as inside a flight, army base, hospitals, rehabilitation centers.
-

- Take out the battery if you do not use it for a long time.
- Suggest to use 18650 Li-ion battery which positive and negative is flat.
- The surface of the product is prohibited to expose to certain chemical class of solvents, which will likely lead to the oxidized layer of surface bleaching.

INTRODUCTION

X6 is a multifunctional Bluetooth speaker which has torch, music play, selfie, wireless phone, AUX, battery charger functions. It's designed in a mixture of modern stylish and reliable techniques.


X6 has adopted the standard features of Bluetooth 2.0+EDR (A2DP) and offers you the wireless convenience when you use it. You can enjoy freely within the operating range of the Bluetooth A2DP (note 1) source, such as live stereo music of MP3, PC or PDA. X6 is interchangeable for playing music or using telephone, so far as your cell-phone supports the functions of Bluetooth. (note 2). Therefore, you may pick up or dial a telephone and switch back to the music just in few seconds.

Note:

- ①: The broadcast installation or Bluetooth transmitter which contacted is required to be Bluetooth A2DP supportive.


- ②: Cellphones are required to support the Bluetooth headset or hands-free function with Bluetooth A2DP.
- ③: Some cellphones may not be able to release the connection of Bluetooth automatically, thus disable the speaker from the interchange.

INSTALL BATTERY & CHARGING



- Battery capacity display the button (B) with blue backlight can display the battery capacity as followed:
 - strobe 1 time, 25% power
 - strobe 2 time, 50% power
 - strobe 3 time, 75% power
 - strobe 4 time, 100% power
- The button (B) with blue backlight can be lighted when Bluetooth is working or being charged. When using the torch, it can't be lighted.
- Aux port just can support aux function or charging function, not earphone.

KEY OPERATION



- Torch Button:** Flashlight is separate operating system. Each push, High > Low > Slow Strobe > Fast Strobe > SOS > Off, switching cycle, long-press can turn off the flashlight at any status.

BLUETOOTH SEARCHING & CONNECTING

- Power Button:** Long press it for 3 seconds and the Bluetooth function is activated. The blue LED in the torch button will blink and other buttons will strobe red. Then the auto search begins. Later, four buttons keep red unless it's connected with a Bluetooth device. The Bluetooth name is Trendwoo.

- Short press it to pause or play;
- Long press it for 4 seconds to turn off the speaker;
- Short press it to answer incoming calls and during the call, short press it to hang up;
- Long press it to reject incoming calls.

- Volume up/Next:** Short press it to increase the volume and long press it to next song.
- Volume down/Previous:** Short press it to decrease the volume and long press it to previous song.
- Selfie Button:** Short press it to take a photo.

Note:

The selfie function apply to most of  system and  system mobile phones, but not everyone. Different brands of mobile phones have different system, some mobile can not support selfie function, please contact your mobile agent.

TECHNIQUE

- If the battery is installed falsely, the reverse polarity protection will run automatically.
- The machine will shut down automatically after 30 minutes if no Bluetooth connection is done.
- Keep the Bluetooth working in your mobile phone. Even X6 is restarted, the auto connection will be recognized.
- Please release the re-charge USB as long as the speaker is fully recharged. The excessive recharge will deteriorate the battery life.

ELECTRICAL SPECIFICATIONS

- Material: Aluminum
- Working Voltage: 3.5-3.8 V/0.9A
- Speaker: 16 core double magnets
- Speaker unit: diameter 36mm, inner magnetic 4Ω, 3W

-
- Play Time: 12-15 Hours (2600mAh)
 - Charging Time: up to 3~4 hours
 - S/N ratio: ≥ 70 dB
 - LED Brand: USA CREE LED
 - LED Model: XPE-R3
 - Dust&Waterproof: IP65
 - Size: 155*39*39mm

FAILURE DETECTION

- Confirm whether the negative and the positive of the battery is placed right or not.
 - If it shuts down suddenly, take out the battery, then, install the battery and restart.
 - If no sound, check if the volume is 0 or whether the Bluetooth is connected.
 - If no response, check the lamp part to be tight or not.
 - If sound distortion, check whether battery power is low and needs charging.
 - When the connection fails. Please check and confirm if both cellphones and Bluetooth speaker are turned on and stay in Bluetooth mode.
 - When the volume is too high or too low. Please check if the volume of the cell phone is set properly. (the output setup is vary from types of cellphones).
 - When interruption happens. please check if the distance between the speaker and the cell phone exceeds 10 meters (30 feet) or if any obstacles between two equipment.
-

Customer Remedies

Trendwoo's entire liability and customer's exclusive remedy shall be at Trendwoo's option - either to refund the price paid or to repair or replace the hardware. This is provided that the hardware meets all of the conditions of this limited warranty and is returned to the point of purchase, with a copy of the sales receipt.

Shipping and handling charges may apply except where prohibited by applicable law. Any replacement hardware product will be warranted for the remainder of the original warranty period or for thirty (30) days, whichever is longer.

This warranty covers the functionality of the "FreemanX6" speaker for its normal, intended use as specified in the User Manual and does not cover problems of damage that have resulted from:

- (1) Improper or unreasonable use, maintenance or connection to an improper voltage supply.
 - (2) Accident or damage caused by excess moisture.
 - (3) Improper packing.
 - (4) Lightning.
 - (5) Power surges.
 - (6) Accident, abuse, misapplication, or any unauthorized repair, modification or disassembly.
-

No Other Warranties

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY (INCLUDING CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ON THIS HARDWARE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY PERIOD FOR YOUR PRODUCT.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply.

No Trendwoo dealer or employee is authorized to make any modification, extension, or addition to this warranty.

Limitation of Liability

Trendwoo SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE OR DATA (WHETHER DIRECT OR INDIRECT) OR COMMERCIAL LOSS FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON YOUR PRODUCT EVEN IF Trendwoo HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Trendwoo's entire liability under any provision of this agreement shall be limited to the actual amount paid by you for the hardware product. Some jurisdictions do not allow the exclusion or limitation of special, indirect, incidental or consequential damages. Therefore the above limitation might not apply.

Warranty Support

Before submitting a warranty claim, we recommend you review the contents of the user manual for technical assistance. Valid warranty claims will be processed through the point of purchase during the first thirty (30) days after purchase. Warranty claims that cannot be processed through the point of purchase and any other product related questions should be sent to: www.trendwoo.com
