


Лодочный мотор SeaPro 9.9 New

[заказ запчастей на www.riverplanet.ru](http://www.riverplanet.ru)

1	TOP & bottom cowling (Капот)
2	CYLINDER & CRANKCASE (Поршневая)
3	CRANKSHAFT & PISTON (Поршень, Коленвал)
4	INTAKE (Впускная система)
5	CARBURETOR (Карбюратор)
6	FUEL (Топливная система)
7	STARTER (Стартер)
8	Generator (Генератор)
9	Electrical (Электрика)
10	Control (Рулевое управление)
11	Bracket (Крепление)
12	Upper casing (Дейдвуд)
13	Lower casing 1 (Редуктор)
14	Lower casing 2 (Редуктор)




TOP & bottom cowling (Капот)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-01000100	TOP COWLING ASSY	1
2	ALT8-01000102	HOOK	1
3	ALT8-01000103	HOLDER,CLAMP BAND	1
4	ALT8-01000001	SEAL	1
5	GB/T6170-2000	NUTM4	1
6	ALT8-01000002	SEAL, RUBBER 1	1
7	ALT8-01000101	TOP COWLING	1
8	GB/T818-20000	SCREW	6
9	ALT8-02000001	BUSH	2
10	ALT8-02000002	LEVER,CLAMP	1
11	GB/T7246-87	WASHER, WAVE	1
12	ALT8-02000003	HOLDER,SHEAR PIN	1
13	ALT8-02000004	WASHER	1
14	ALT8-02000005	LEVER,CLAMP	1
15	GB/T971-85	WASHER,PLATE	1
16	GB93-87	WASHER	1

17	GB/T5789-84	BOLT	1
18	ALT8-02000006	GROMMET	1
19	ALT8-02000007	COWLING,BOTTOM 1	1
20	ALT8-00000100	CAP	1
21	ALT8-00000200	STOPER	1
22	ALT8-02000008	GROMMET	1


CYLINDER & CRANKCASE (Поршневая)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03000000	CRANK CYLINDER ASSY	1
2	ALT8-03020000	CRANKCASE ASSY	1
3	ALT8-03020001	NIPPLE,HOSE	1
4	ALT8-03020002	CHECK VALVE ASSY	1
5	ALT8-03020003	CHECK VALVE ASSY	2
6	ALT8-03020004	PIN,DOWEL	2
7	ALT8-03020005	CLIP A	6
8	ALT8-03020006	CLAMP A	1
9	GB/T5789-84	BOLT,WITH WASHER	8
10	ALT8-03020007	HOSE(L240)	1
11	ALT8-03020008	CLIP	2
12	ALT8-03020009	HOSE(L200)	2
13	ALT8-03020010	HOSE(L167)	1
14	ALT8-03020011	OIL SEAL	1
15	GB/T3452.1-92	O-RING	1
16	ALT8-03020012	HOUSING, OIL SEAL	1


17	GB/T5789-84	BOLT	4
18	ALT8-03020013	PIN,DOWEL	1
19	ALT8-03020014	GASKET,COVER	1
20	ALT8-03020015	COVER,THERMOSTAT	1
21	GB/T5783-2000	BOLT,WITH WASHER	3
22	NGK BBPR7HS	PLUG,SPARK(NGK BPR7HS-10)	2
23	GB/T5789-84	BOLT,WITH WASHER	13
24	ALT8-03020016	HEAD,CYLINDER1	1
25	ALT8-03020017	GASKET,COVER	1
26	ALT8-03020005	CLIP	1
27	ALT8-03020018	ANODE	1
28	GB/T819-2000	SCREW,COUNTERSUNK	1
29	ALT8-03020019	GASKET,EXHAUST INNER COVER	1
30	ALT8-03020020	INNER COVER,EXHAUST	1
31	ALT8-03020021	GASKET,EXHAUST OUTER COVER	1
32	ALT8-03020022	OUTER COVER,EXHAUST	1
33	GB/T5789-84	BOLT,WITH WASHER	11
34	GB/T97.1-85	WASHER,PLATE	1
35	GB/T3452.1-92	O-RING	1
36	ALT8-03020023	OIL SEAL	1
37	ALT8-03020024	OIL SEAL	1
38	ALT8-03020025	SEAL,CRANKCASE	1
39	ALT8-03020026	HOUSING,OIL SEAL	1
40	GB/T5789-84	BOLT	2

CRANKSHAFT & PISTON (Поршень, Коленвал)




REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03030000	CRANKSHAFT ASSY	1
2	GB/T276-96	BEARING	3
3	ALT8-03030001	PIN,CRANK 1	2
4	ALT8-03030002	WASHER	4
5	GB/T273-96	BEARING	2
6	ALT8-03030003	ROD,CONNECTING	2
7	ALT8-03030004	SEAL,LABYRINTH 1	1
8	ALT8-03030005	WASHER,PLATE	4
9	ALT8-03030006	PIN,DOWEL	56
10	ALT8-03030007	CIRCLIP	4
11	ALT8-03030008	PISTON	2
12	ALT8-03030009	PISTON RING SET	4
13	ALT8-03030010	PIN,SPRING	2

INTAKE (Впускная система)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03000001	GASKET, VALVE SET	1
2	ALT8-03000100	REED VALVE ASSY	1
3	ALT8-03000002	BOLT,STUD	1
4	GB/T5789-84	BOLT	3
5	ALT8-03000003	GASKET	1
6	ALT8-03000004	BOLT,STUD	1
7	GB/T91-2000	CLIP	1
8	ALT8-03000005	ROD, CHOKE	1
9	GB/T6170-2000	NUT	2
10	ALT8-03000006	GROMMET	1
11	ALT8-03000007	KNOB,CHOKE	1
12	GB/T8191-2000	SCREW,PAN HEAD	2
13	ALT8-03000008	SILENCER,INTAKE	1
14	ALT8-03000009	SILENCER,INTAKE	1
15	GB/T6170-2000	NUT	2
16	ALT8-030000010	WASHER,PLATE	1


CARBURETOR (Карбюратор)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
	ALT8-03040000	CARBURETOR ASSY	1
1	ALT8-03040001	PIN,FLOAT	1
2	ALT8-03040002	GASKET	1
3	ALT8-03040003	JET,MAIN(#80)	1
4	ALT8-03040004	GASKET	1
5	GB/T818-2000	SCREW,PAN HEAD	1
6	ALT8-03040005	CASKET,FLOAT CHAMBER	1
7	ALT8-03040006	FLOAT	1
8	ALT8-03040007	GASKET	1
9	ALT8-03040008	COVER,MIXING	1
10	GB/T5789-84	SCREW,WITH WASHER	2
11	ALT8-03040009	DIAPHRAGM	1
12	GB/T8191-2000	SCREW,PAN HEAD	2
13	ALT8-03040010	VALVE,CHECK	2
14	ALT8-03040011	GASKET,BODY 2	1
15	ALT8-03040012	DIAPHRAGM	1


16	GB/T818-2000	SCREW	4
----	--------------	-------	---

FUEL (Топливная система)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03000200	FUEL PIPE JOINT COMP.1	1
2	GB/T5789-84	BOLT	1
3	ALT8-03020005	CLIP A	4
4	ALT8-03000011	HOSE(L150)	1
5	ALT8-03000300	FILTER ASSY	1
6	ALT8-03000301	BRACKET,FILTER	1
7	GB/T6170-2000	NUT	1
8	ALT8-03000302	ELEMENT,FILTER	1
9	GB/T3452-92	O-RING	1
10	ALT8-03000303	CLIP,FILTER	1
11	ALT8-03000012	HOSE(L235)	1


STARTER (Стартер)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03010000	STARTER ASSY	1
2	ALT8-03010001	CASE,STARTER	1
3	GB/T6170-2000	NUT	1
4	ALT8-03010002	STAY	4
5	ALT8-03010003	SPRING, SPIRAL	1
6	ALT8-03010004	DRUM, SHEAVE	1
7	ALT8-03010005	PIN, SPRING	1
8	ALT8-03010006	PAWL, DRIVE	1
9	GB894.1-86	CIRCLIP	1
10	GB/T5789-84	BOLT, WITH WASHER	1
11	ALT8-03010007	SHAFT, STARTER	1
12	ALT8-03010100	SPRING, DRIVE PAWL	1
13	ALT8-03010008	WIRE (L1650)	1
14	ALT8-03010009	GUIDE, ROPE	1
15	GB/T5789-84	BOLT	2
16	ALT8-03010010	SEAL, RUBBER	2

17	ALT8-03010011	DAMPER	1
18	ALT8-03010012	HANDLE,STARTER	1
19	ALT8-03010013	COVER	1
20	GB/T5789-84	BOLT	4
21	ALT8-03010014	STAY	2
22	GB/T5789-84	BOLT	2
23	GB/T5789-84	BOLT	1
24	GB/T97.1-85	WASHER,PLATE	1
25	GB/T5789-84	BOLT	3
26	ALT8-03010015	PULLEY,STARTER	1
27	ALT8-03010016	SET PIN	2
28	GB/T97.1-85	WASHER,PLATE	1
29	GB/T91-2000	CLIP	2
30	ALT8-03010017	STAY	1
31	ALT8-03010018	PLUNGER,STARTER STOP	1
32	ALT8-03010019	SPRING,COMPRESSION	1
33	ALT8-03010100	CABLE COMP,STARTER STOP	1
34	ALT8-03010020	LINK	1
35	ALT8-03010021	ARM	1
36	GB/T5789-84	BOLT,WITH WASHER	1
37	ALT8-03010022	COLLAR	1


Generator (Генератор)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03040100	ROTOR ASSY	1
2	ALT8-03040200	BASE ASSY	1
3	ALT8-03040001	BASE,MAGNETO	1
4	ALT8-03040300	COIL,CHARGE ASSY	1
5	GB/T5789-84	SCREW,WITH WASHER	2
6	ALT8-03040400	COIL,PULSER ASSY	1
7	GB/T818-94	SCREW,WITH WASHER	1
8	GB/T818-94	SCREW,PAN HEAD	2
9	GBP3--76	WASHER,SPRING	2
10	ALT8-03040500	COIL,LIGHTING	1
11	GB/T818-94	SCREW,PAN HEAD	1
12	ALT8-03040002	HOLDER	2
13	ALT8-03040600	LEAD WIRE ASSY	1
14	ALT8-03040003	CAM,ACCEL	1
15	GB/T5789-84	BOLT,WITH WASHER	2
16	GB/T818-94	SCREW,PAN HEAD	3


17	GB/T97.1-85	WASHER	3
18	ALT8-03040004	RETAINER,MAGNETO BASE	1
19	ALT8-03040005	RETAINER,MAGNETO BASE	1
20	GB/T1099.1-2003	KEY,WOODRUFF	1
21	GB/T5789-84	BOLT	2
22	ALT8-03040006	STOPPER,MAGNETO BASE	1
23	ALT8-03040007	NUT	1
24	GB/T97.1-85	WASHER,PLATE	1

Electrical (Электрика)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03000400	C.D.I UNIT ASSY	1
2	GB/T5789-84	BOLT,WITH WASHER	2
3	ALT8-03000013	COVER	1
4	GB/T5789-84	BOLT	2
5	ALT8-03000014	TUBE	1
6	ALT8-03000500	IGNITION ASSY	1
7	GB/T5789-84	BOLT	2
8	ALT8-03000600	PLUG CAP ASSY	2
9	ALT8-03000015	GROMMET	1
10	ALT8-03000016	BRACKET	1
11	GB/T5789-84	BOLT	1


Control (Рулевое управление)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-04000001	HANDLE,STEERING	1
2	ALT8-04000002	SPACER	1
3	GB/T3452.1-92	O-RING	1
4	ALT8-04000003	SPACER	1
5	GB/T848-85	WASHER,PLATE	2
6	ALT8-04000004	SPRING,COMPRESSION	1
7	GB/T827-86	SCREW,COUNTERSUNK	1
8	ALT8-04000005	INDICATOR,THROTTLE	1
9	ALT8-04000006	GRIP,STEERING HANDLE	1
10	ALT8-04000007		1
11	GB/T819-94	BOLT	1
12	ALT8-04000008	BUSH	1
13	ALT8-04000009	SPACER,HANDLE	2
14	ALT8-04000010	HANDLE,STEERING	1
15	GB/T5789-84	BOLT	1
16	GB/T5789-84	BOLT	1

17	ALT8-04000011	FRICTION,STEERING HANDLE GRIP	1
18	GB943-88	NUT,SELF-LOCKING	1
19	GB/T819-94	BOLT	1
20	GB/T17445-98	BALL	1
21	ALT8-04000012	SPRING,COMPRESSION	1
22	ALT8-04000013	BUSHING	1
23	GB/T3452.1-92	O-RING	2
24	ALT8-04000014	LEVER,SHIFT ROD	1
25	GB/T97.1-85	WASHER,PLAIN	2
26	GB/T5789-84	BOLT	1
27	ALT8-04000015	CONNECTOR,SHIFT ROD	1
28	ALT8-04000016	CONNECTOR,SHIFT ROD	1
29	ALT8-04000017	ROD,SHIFT	1
30	GB/T91-2000	PIN,COTTER	1
31	GB93-76	WASHER,SPRING	1
32	GB/T5789-84	BOLT	1
33	ALT8-04000018	BUSHING,SHIFT ROD LEVER	1
34	ALT8-04000100	SHAFT,CHANGE	1
35	ALT8-04000019	HANDLE,GEAR SHIFT	1
36	GB/T5789-84	BOLT	1
37	ALT8-04000200	LEVER,THROTTLE ASSY	1
38	ALT8-04000300	THROTTLE CABLE ASSY	2
39	ALT8-04000301	THROTTLE CABCE	2
40	GB/T6170-2000	NUT	4
41	ALT8-04000020	GROMMET	1
42	ALT8-04000021	STAY,THROTTLE WIRE	1
43	GB/T5789-84	BOLT	2
44	GB/T879.2-2000	PIN,SPRING	1
45	ALT8-04000022	STAY	1
46	ALT8-04000023	BRACKET 1	1
47	ALT8-04000024	BUSH	2
48	ALT8-04000400	PULLEY ASSY	1
49	ALT8-04000025	SET PIN	1
50	ALT8-04000026	PIN,CLEVIS	1
51	ALT8-04000027	LEVER,MAGNETO CONTROL	1
52	GB955-87	WASHER,WAVE	2
53	GB/97.1-85	WASHER,PLAIN	2
54	GB/T91-2000	CLIP	2
55	GB/T6170-2000	NUT,HEXAGON	1
56	GB93-76	WASHER,SPRING	1
57	GB/T97.1-85	WASHER,PLATE	1
58	ALT8-04000028	LEVER,MAGNETO CONTROL	1


Bracket (Крепление)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-05000001	SPACER,FRICTION	2
2	ALT8-05000002	DAMPER	4
3	ALT8-05000003	BUSHING,PIVOT SHAFT	2
4	ALT8-05000004	BUSHING,PIVOT SHAFT	4
5	GB/T5789-84	BOLT	4
6	ALT8-05000005	BRACKET,SWIVEL	1
7	ALT8-05000006	PLATE,FRICTION	1
8	ALT8-050000100	NUT ASSY	1
9	ALT8-05000007	COVER	1
10	ALT8-05000008	PLATE,FRICTION	1
11	GB871-86	RIVET	4
12	ALT8-05000009	COVER	1
13	GB/T5789-84	BOLT	2
14	ALT8-05000010	PIPE	2
15	ALT8-05000011	BRACKET,STEERING	1
16	GB953-88	NUT,SELF-LOCKING	1


17	ALT8-05000012	PLATE,CLAMP BRACKET	1
18	ALT8-05000201	BRACKET,CLAMP	1
19	ALT8-05000013	WASHER,PLATE	2
20	ALT8-05000014	NIPPLE,GREASE	1
21	ALT8-05000015	BRACKET,SWIVEL	1
22	ALT8-05000016	SCREW,FRICTION PIECE	1
23	GB/T91-2000	CIRCLIP	1
24	ALT8-05000017	PIN	2
25	ALT8-05000301	BRACKET,CLAMP 1	1
26	GB/T5789-84	BOLT	1
27	GB/T5789-84	BOLT	1
28	ALT8-05000018	BUSHING,PIVOT SHAFT	2
29	ALT8-05000019	COLLAR	1
30	ALT8-05000202	SCREW,TRANSOM CLAMP	2
31	ALT8-05000203	PIN	2
32	ALT8-05000204	HANDLE,TRANSOM CLAMP	2
33	ALT8-05000205	PAD,TRANSOM CLAMP	2
34	GB/T6170-2000	NUT,HEXAGON	1
35	ALT8-05000020	WASHER,PLATE	1
36	ALT8-05000021	SPRING,COMPRESSION A	1
37	ALT8-05000400	TILT LEVER ASSY	1
38	ALT8-05000022	PLATE,TILT LOCK	1
39	ALT8-05000023	BUSHING	2
40	ALT8-05000024	SPRING,TORSION A	1
41	ALT8-05000025	KNOB,TILT	1
42	ALT8-05000500	LEVER,TILT STOP	1
43	ALT8-05000026	SPRING,TORSION B	1
44	ALT8-05000027	BRACKET,SWIVEL	2
45	GB/T5789-84	BOLT	2
46	ALT8-05000028	SHAFT,REVERSE LOCK	1
47	GB/T91-2000	CLIP	2
48	ALT8-05000601	SPRING,CONICAL	1
49	ALT8-05000602	PLATE,TILT LOCK	1
50	GB871-86	PIN,SPRING	1
51	ALT8-05000600	TILT LEVER ASSY	1
52	ALT8-05000029	ARM,TILT LOCK	2
53	ALT8-05000030	STOPPER	2
54	ALT8-05000031	SPRING,TORSION	1
55	ALT8-05000032	SPRING,COMPRESSION B	2
56	ALT8-05000700	PLATE,TILT LOCK	2
57	GB/T91-2000	CLIP	1
58	ALT8-05000033	PIN,CLEVIS	1
59	ALT8-05000034	PLATE,TILT LOCK	1

Upper casing (Дейдвуд)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-06000001	GASKET,UPPER CASING	1
2	GB/T119.1-2000	PIN,DOWEL	2
3	ALT8-06000002	CASING,UPPER	1
4	GB/T5789-84	BOLT,WITH WASHER	4
5	ALT8-05000014	NIPPLE,GREASE	1
6	GB/T5789-84	BOLT,WITH WASHER	7
7	ALT8-06000003	COVER,UPPER CASING	1
8	GB/T119.2-2000	PIN,DOWEL	2
9	ALT8-06000004	EXTENSION	1
10	GB/T5789-84	BOLT,WITH WASHER	4


Lower casing 1 (Редуктор)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-07000000	LOWER UNIT ASSY	1
	ALT8-07000000	LOWER UNIT ASSY	1
2	ALT8-07000100	LOWER CASING ASSY	1
3	ALT8-07000101	BUSHING,DRIVE SHAFT	1
4	ALT8-07000001	GASKET	3
5	GB/T5782-2000	PLUG,STRAIGHT SCREW	3
6	ALT8-07000002	GASKET	1
7	ALT8-07000003	SCREW	1
8	ALT8-07000004	COVER,WATER INLET 1	1
9	GB/819-94	SCREW,COUNTERSUNK	2
10	ALT8-07000005	PACKING,LOWER CASING	1
11	ALT8-07000006	COLLAR	1
12	GB/T5789-86	BOLT	2
13	ALT8-07000200	HOUSING,BEARING	1
14	ALT8-07000201	BUSHING,DRIVE SHAFT	1
15	ALT8-07000007	OIL SEAL	2

16	ALT8-07000300S	DRIVE SHAFT COMP S	1
	ALT8-07000300L	DRIVE SHAFT COMP L	1
17	GB/T1099.1-2003	KEY,WOODRUFF	1
18	ALT8-07000401S	SHIFT CAM ASSY S	1
	ALT8-07000401L	SHIFT CAM ASSY L	1
19	ALT8-07000008	BOOT,SHIFT ROD	1
20	ALT8-07000009	DAMPER WATER SEAL2	1
21	GB/T5789-86	BOLT	3
22	ALT8-07000011	HOUSING,WATER PUMP	1
23	GB/T119.1-2000	PIN,DOWEL	2
24	ALT8-07000012	INSERT CARTRIDGE	1
25	ALT8-07000500	IMPELLER	1
26	ALT8-07000013	GASKET,WATER PUMP	1
27	ALT8-07000014	OUTER PLATE,CARTRIDGE	1
28	ALT8-07000102	COVER,WATER INLET 2	1
29	ALT8-07000103	PLUG,STRAIGHT	1
30	ALT8-07000015	SHAFT,PROPELLER	1
31	ALT8-07000016	PIN,STRAIGHT	1
32	ALT8-07000017	WASHER,PLATEB A	1
33	ALT8-07000600	GEAR,FORWARD	1
34	ALT8-07000018	SHIM(T : 0.10MM)	1
35	GB/T276-96	BEARING	1
36	GB/T3452.1-92	O-RING	1
37	ALT8-07000019	OIL,SEAL	2
38	ALT8-07000020	CAP,LOWER CASING	1
39	GB/T5789-86	BOLT	3
40	GB/T119.1-2000	PIN,DOWEL	1
41	ALT8-07000021	SPRING,COMPRESSION	1
42	ALT8-07000022	CLUTCH,DOG	1
43	ALT8-07000023	CIRCLIP	1
44	ALT8-07000024	WASHER,PLATEB	1
45	ALT8-07000700	GEAR,REVERSE	1
46	ALT8-07000025	WASHER,PLATE	1
47	GB/T276-96	BEARING	1
48	ALT8-07000026	PLUNGER,SHIFT	1
49	ALT8-07000027	ANODE	1
50	GB861.1-86	WASHER,INTERNAL TOOTH	1
51	GB/T5789-86	BOLT,FLANGE	1
52	ALT8-07000028	SHIM(T:0.10MM)	1
53	ALT8-07000029	PINION(13T)	1
54	GB896-86	CIRCLIP	1

Lower casing 2 (Винт)



REF NO	Артикул	Наименование	Кол-во в комплекте, шт
1	ALT8-03000200	FUEL PIPE JOINT COMP.1	1
2	GB/T5789-84	BOLT	1
3	ALT8-03020005	CLIP A	4
4	ALT8-03000011	HOSE(L150)	1
5	ALT8-03000300	FILTER ASSY	1
6	ALT8-03000301	BRACKET,FILTER	1
7	GB/T6170-2000	NUT	1
8	ALT8-03000302	ELEMENT,FILTER	1
9	GB/T3452-92	O-RING	1
10	ALT8-03000303	CLIP,FILTER	1
11	ALT8-03000012	HOSE(L235)	1