






ROBO KIDS 1 - Parts List

Parts List	Part Name / Code	Quantity
	Funny Card Pack 1 (PV0K-N010)	1
	DC Motor - 100 RPM (PM0D-N008)	2
	LED Block [Red] (PC1D-N007)	1
	LED Block [Blue] (PC1D-N010)	1
	Wheel - Ø50 (PW0K-N002)	2
	Cable 450mm (PL0M-N002)	3
	Connection Axle (PB0S-N001)	5
	Wheel Axle (PB0S-N005)	2
	1 x 10 Hole Block (PB0H-N004)	2
	1 x 6 Hole Block (PB0H-N003)	2
	1 x 4 Hole Block (PB0H-N002)	4
	1 x 2 Hole Block (PB0H-N001)	2
	2 x 8 Block (PB0N-N010)	6
	2 x 6 Block (PB0N-N009)	11

	2 x 4 Block (PB0N-N008)	15
	2 x 3 Block (PB0N-N007)	5
	2 x 2 Block (PB0N-N006)	12
	1 x 12 Block (PB0N-N005)	2
	1 x 8 Block (PB0N-N004)	4
	1 x 6 Block (PB0N-N003)	4
	1 x 4 Block (PB0N-N002)	4
	1 x 2 Block (PB0N-N001)	4
	2 x 4 Flat Block (PB0F-N002)	4
	Support Block (PB0S-N009)	1
	Main Block (PB0F-N001)	2
	Wheel Block (PB0H-N007)	2
	Buzzer Sensor (PC1D-N011)	1
	Contact Sensor (PC0S-N005)	3
	IR Sensor (PC0S-N004)	1
	Card Reader (PC1R-N001)	1

	CPU Block (PC0M-N009)	1
	Cable 200mm (PL0M-N001)	7
	Double Sided Tape (PA1S-N002)	4
	Wheel - Ø50 (PW0N-N001)	1
	Tire - Ø50 (PW1N-N002)	2