

How to set two way audio in Browser

- 1, Make sure the audio settings are enabled,
Our camera only support the audio type is G711.

Audio Settings	
Audio Type:	G711 ▼
First stream	
Audio Output:	<input checked="" type="radio"/> On <input type="radio"/> Off
Second stream	
Audio Output:	<input checked="" type="radio"/> On <input type="radio"/> Off
Audio Input	
Input Options:	MIC ▼
Input volume:	80 (1-100)
Output volume:	95 (1-100)


Apply Cancel

[Device information](#)
[Time set](#)
[Video settings](#)
[Audio Settings](#)
[Record Settings](#)
[Alarm Service Settings](#)
[Email](#)
[FTP](#)
[System Log](#)
[Network Settings](#)
[Wireless](#)
[DDNS Settings](#)
[PTZ set](#)
[Multiple settings](#)
[User Settings](#)
[Maintain](#)
[ONVIF](#)
[Motion detection](#)
[Auto Snap](#)
[Video mask](#)
[Image](#)
[Back](#)

- 2, Turn on the listen and audio button on the interface


IP Camera

2016-12-13 15:38:26



Digital zoom





wanscam



↓ ↑

Video format 50Hz ▼
Dpi First stre: ▼
PTZrate Medium ▼
Brightness 50
Contrast 50
Saturation 125
Sharpness 70

Call set presetting 1 ▼

Defaults

