



Your Expert
in Parts

Solenoids

6 Volt				
	CAR GO	Ampere	Intermittent load	Terminals
	130503	130		3

12 Volt

	CAR GO	Ampere	Intermittent load	Terminals
	235593			
	235594			
	235595			
	235596			
	139860			3
	234070			3
	333010			3
	139856			4
	139859			4
	333020			4
	234860			6
	333006	120 Amp		4
	130493	150 Amp		4
	131080	50	500 Amp	3
	131253	60	500 Amp	4
	231526	80		3

	CAR GO	Ampere	Intermittent load	Terminals
	234071	80		3
	234073	80		3
	231525	80		4
	231527	80		4
	234072	80		4
	132939	80	150 Amp	4
	133616	80	150 Amp	6
	333160	80	500 Amp	4
	133695	100	500 Amp	4
	139858	100	600 Amp	4
	133855	100	800 Amp	3
	133856	100	800 Amp	4
	133857	100	800 Amp	4
	333009	150		4
	235442	150	300 Amp	4
	333012	150	300 Amp	5
	333004	150	300 Amp	6
	333153	150	800 Amp	4

	CAR GO	Ampere	Intermittent load	Terminals
	231809	200	800 Amp	3
	231807	200	800 Amp	4


24 Volt

	CAR GO	Ampere	Intermittent load	Terminals
	132140			4
	333007			4
	333013		1000 Amp	4
	333015	50	50 Amp	5
	133617	50	50 Amp	6
	130492	50	500 Amp	3
	131254	50	500 Amp	4
	132940	60	100 Amp	4
	333005	75	150 Amp	6
	131371	80	500 Amp	4
	333156	80	500 Amp	4
	333018	100		3

	CAR GO	Ampere	Intermittent load	Terminals
	138685	100		4
	333017	100		4
	235443	100	200 Amp	4
	133697	100	500 Amp	4
	333008	150		4
	333484	150		4
	333152	150	800 Amp	4
	333531	150		4
	231810	200	800 Amp	3
	230964	200	800 Amp	4
	231808	200	800 Amp	4

36 Volt

	CAR GO	Ampere	Intermittent load	Terminals
	235646	50	100 Amp	4
	235647	60	150 Amp	4



14033EXEM_Solenoids_01_17