



CATALOGUE SUPPLEMENT
IGNITION COILS
AND IGNITION MODULES



www.hella.com

Pictograms and Abbreviations

Productdetails

PC applications

Cross references

Overview of order numbers







Ignition System

Control Unit

Switch Unit, ignition system.....4

Ignition Coil

Ignition Coil.....9

	from Chassis No. to Chassis No.
	Engine Code
...	Manufacturer Restriction
... ports	Number of ports
...x	Required quantity
+ ABS	Braking / Drive Dynamics, for vehicles with ABS
+ autom.	Vehicle Equipment, for vehicles with auto- matic transmission
BE	Country Version, Belgium
+ CH	Country Version, Switzerland
+ D	Country Version, Germany
engine ...	from Engine Number to Engine No.
+ Europe	Country Version, Europe
FI	Country Version, Finland
IT	Country Version, Italy
+ J	Country Version, Japan
Japan-made	Vehicle Production Country, Japan
LHD	Driver Position, for left-hand drive vehicles
Model ...	from model year to model year
+Model ...	for model year
+ N	Country Version, Norway
NL	Country Version, The Netherlands
Orga ...	from RP number to RP number
RHD	Driver Position, for right-hand drive vehi- cles
+ servo	Vehicle Equipment, for vehicles with pow- er steering
SV	Country Version, Sweden
+ UK	Country Version, Great Britain
UK-made	Vehicle Production Country, Great Britain
+ USA	Country Version, USA
VET ...	from VET Number to VET Number

Control Unit - Switch Unit, ignition system

5DA 006 623-001



Rated Voltage [V]	12
-------------------	----

5DA 006 623-041



Rated Voltage [V]	12
-------------------	----

5DA 006 623-051



Rated Voltage [V]	12
-------------------	----

5DA 006 623-161



Rated Voltage [V]	12
-------------------	----

5DA 006 623-181



Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	with bolted-on plate

Control Unit - Switch Unit, ignition system

5DA 006 623-191



Rated Voltage [V]	12
-------------------	----

5DA 006 623-201



Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	with bolted-on plate

5DA 006 623-231



Mounting Type	Plug Connection
Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	without ignition coil

5DA 006 623-251



Rated Voltage [V]	12
-------------------	----



Control Unit - Switch Unit, ignition system

5DA 006 623-331



Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	without ignition coil

5DA 006 623-401



Rated Voltage [V]	12
-------------------	----

5DA 006 623-421



Rated Voltage [V]	12
-------------------	----

5DA 006 623-431



Rated Voltage [V]	12
-------------------	----

Control Unit - Switch Unit, ignition system

5DA 006 623-471



Rated Voltage [V]	12
-------------------	----

5DA 006 623-511



Rated Voltage [V]	12
-------------------	----

5DA 006 623-581



Rated Voltage [V]	12
-------------------	----

5DA 006 623-591



Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	with bolted-on plate



Control Unit - Switch Unit, ignition system

5DA 006 623-601



Rated Voltage [V]	12
-------------------	----

5DA 006 623-771



Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	with bolted-on plate

5DA 006 623-781



Rated Voltage [V]	12
-------------------	----

5DA 006 623-931



Mounting Type	Bolted
New to range items (calendar month)	20150601
Number of Poles	7
Rated Voltage [V]	12

Control Unit - Switch Unit, ignition system

5DA 006 623-941



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	7
Rated Voltage [V]	12
Vehicle Equipment	for vehicles with distributor

Ignition Coil

5DA 006 623-671



for OE number	<ul style="list-style-type: none"> • S102020001C • S102030002A
Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	with integrated switch

5DA 006 623-951



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	3
Rated Voltage [V]	12
Vehicle Equipment	for vehicles with distributor



Ignition Coil

5DA 193 175-061



for OE number	46403328
Required quantity	5

5DA 193 175-081



Number of ports	4
Required quantity	1

5DA 193 175-181



Number of ports	4
Rated Voltage [V]	12
Required quantity	5

5DA 193 175-331



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	6
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-341



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-351



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-361



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	1
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-371



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-381



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-391



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-401



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	3
Rated Voltage [V]	12
Supplementary Article/Supplementary Info 2	with integrated switch

5DA 193 175-411



for OE number	1 319 929
Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-421



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12



Ignition Coil

5DA 193 175-431



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-441



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-451



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-461



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-471



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	5
Rated Voltage [V]	12

5DA 193 175-481



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-491



Mounting Type	Plugged
New to range items (calendar month)	20150601
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-501



Mounting Type	Plugged
New to range items (calendar month)	20150301
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-511



Mounting Type	Plugged
New to range items (calendar month)	20150301
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-521



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-531



Mounting Type	Bolted
New to range items (calendar month)	20150301
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-541



Mounting Type	Bolted
New to range items (calendar month)	20150601
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-551



Mounting Type	Bolted
New to range items (calendar month)	20150601
Number of Poles	3
Rated Voltage [V]	12



Ignition Coil

5DA 193 175-561



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-581



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-591



Mounting Type	Plugged
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-641



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	6
Rated Voltage [V]	12

5DA 193 175-651



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-661



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-671



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-681



Mounting Type	Bolted
New to range items (calendar month)	20150501
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-691



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-701



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-711



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-721



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-731



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-741



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-751



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-761



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-781



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-791



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-801



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-811



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-821



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-831



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-841



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-851



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-861



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	6
Rated Voltage [V]	12

5DA 193 175-871



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

5DA 193 175-881



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-891



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-901



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-911



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-921



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-931



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-941



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-951



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-961



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	2
Rated Voltage [V]	12

5DA 193 175-971



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	2
Rated Voltage [V]	12

Ignition Coil

5DA 193 175-981



Mounting Type	Bolted
New to range items (calendar month)	20150801
Number of Poles	4
Rated Voltage [V]	12

5DA 193 175-991



Mounting Type	Bolted
New to range items (calendar month)	20150801
Number of Poles	3
Rated Voltage [V]	12

5DA 358 000-001



Mounting Type	Plugged
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

Ignition Coil

5DA 358 000-011



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-021



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	1
Rated Voltage [V]	12

5DA 358 000-031



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-041



Mounting Type	Bolted
New to range items (calendar month)	20151001
Number of Poles	5
Rated Voltage [V]	12

Ignition Coil

5DA 358 000-051

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	3
Rated Voltage [V]	12

5DA 358 000-061

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	3
Rated Voltage [V]	12

5DA 358 000-071

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-101

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-111



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	3
Rated Voltage [V]	12

Ignition Coil

5DA 358 000-121



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-171

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-181

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	6
Rated Voltage [V]	12

5DA 358 000-191



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	3
Rated Voltage [V]	12

5DA 358 000-201



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	5
Rated Voltage [V]	12

Ignition Coil

5DA 358 000-231



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	7
Rated Voltage [V]	12

5DA 358 000-241



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	7
Rated Voltage [V]	12

5DA 358 000-251



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-281



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	5
Rated Voltage [V]	12

Ignition Coil

5DA 358 000-291



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-301

Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	4
Rated Voltage [V]	12

5DA 358 000-331



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	6
Rated Voltage [V]	12

5DA 358 000-341



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	7
Rated Voltage [V]	12

Ignition Coil

5DA 358 000-351



Mounting Type	Bolted
New to range items (calendar month)	20151201
Number of Poles	5
Rated Voltage [V]	12

5DA 749 475-091



Rated Voltage [V]	12
Required quantity	1

5DA 749 475-101



Fitting Position	<ul style="list-style-type: none"> • to cylinder 1 • to cylinder 4
Rated Voltage [V]	12
Required quantity	1

Ignition Coil

5DA 749 475-111



Fitting Position	<ul style="list-style-type: none"> • to cylinder 1 • to cylinder 4
Rated Voltage [V]	12
Required quantity	1

5DA 749 475-131



Rated Voltage [V]	12
Required quantity	4

5DA 749 475-201



Fitting Position	<ul style="list-style-type: none"> • to cylinder 2 • to cylinder 3
Rated Voltage [V]	12
Required quantity	1

Ignition Coil

5DA 749 475-211



Fitting Position	<ul style="list-style-type: none"> • to cylinder 2 • to cylinder 3
Rated Voltage [V]	12
Required quantity	1

5DA 749 475-261



Rated Voltage [V]	12
-------------------	----

5DA 749 475-341



Rated Voltage [V]	12
-------------------	----

5DA 749 475-351



Rated Voltage [V]	12
-------------------	----

Ignition Coil

5DA 749 475-371



Rated Voltage [V] | 12

5DA 749 475-401



Rated Voltage [V] | 12

5DA 749 475-471



Rated Voltage [V] | 12

5DA 749 475-511



Rated Voltage [V] | 12



Ignition Coil

5DA 749 475-601



Rated Voltage [V] | 12

5DA 749 475-611



Rated Voltage [V] | 12

5DA 749 475-951



Rated Voltage [V] | 12

5DA 749 475-961



Rated Voltage [V] | 12

Ignition Coil

5DA 749 475-971



Rated Voltage [V]

12











ALFA ROMEO.....	43	SMART.....	187
ALPINA.....	47	SSANGYONG.....	188
AUDI.....	48	TALBOT.....	189
AUTOBIANCHI.....	64	TOYOTA.....	190
BMW.....	65	VOLVO.....	192
BMW MOTORCYCLES.....	76	VW.....	197
CHRYSLER.....	77	WARTBURG.....	215
CITROËN.....	78	ZASTAVA.....	216
DACIA.....	87		
DAEWOO.....	88		
FERRARI.....	89		
FIAT.....	90		
FORD.....	96		
FORD USA.....	108		
FSO.....	109		
HONDA.....	110		
HYUNDAI.....	111		
INFINITI.....	113		
KIA.....	114		
LADA.....	115		
LANCIA.....	116		
LAND ROVER.....	119		
LEXUS.....	120		
LOTUS.....	121		
MAZDA.....	122		
MERCEDES-BENZ.....	124		
MG.....	132		
MINI.....	133		
MITSUBISHI.....	135		
NISSAN.....	137		
OPEL.....	139		
PEUGEOT.....	152		
PORSCHE.....	163		
PUCH.....	164		
RENAULT.....	165		
ROLLS-ROYCE.....	172		
ROVER.....	173		
SAAB.....	175		
SEAT.....	176		
SKODA.....	182		

				13				412			
ALFA ROMEO - 33 (905)										06/84→12/89	
1.3 (905.A1A, 905.A1C, 905.A1D, 905.A1F, 905.A1H)	63 kW	1.3 l	10/84→12/89	AR 30168; LHD	5DA 006 623-001	Switch Unit, ignition system	4				
1.5 4x4 (905.A2M, 905.A2T)	77 kW	1.5 l	09/86→12/89	09/88→; AR30508	5DA 006 623-041	Switch Unit, ignition system	4				
1.5 QV (905.A2N, 905.A2V)	77 kW	1.5 l	06/84→12/89		5DA 006 623-001	Switch Unit, ignition system	4				
1.7 i.e. (905.A3D)	77 kW	1.7 l	09/88→12/89	LHD	5DA 006 623-001	Switch Unit, ignition system	4				
ALFA ROMEO - 33 (907A)										01/90→09/94	
1.4 i.e. (907.A3A, 907.A3B)	65 kW	1.4 l	06/91→09/94	LHD; for vehicles with catalytic converter; L-Jetronic	5DA 006 623-001	Switch Unit, ignition system	4				
				AR 30753; 2x	5DA 193 175-341	Ignition Coil	11				
1.4 i.e. (907.A3A, 907.A3B)	66 kW	1.4 l	06/91→09/94	AR 30755; LHD; for vehicles with catalytic converter; L-Jetronic	5DA 006 623-001	Switch Unit, ignition system	4				
				AR 30753; 2x	5DA 193 175-341	Ignition Coil	11				
1.5 i.e. (907A2A)	74 kW	1.5 l	07/90→08/91	LHD	5DA 006 623-001	Switch Unit, ignition system	4				
1.7 16V (907.A1C)	95 kW	1.7 l	01/90→09/94								
1.7 16V (907.A1C)	97 kW	1.7 l	01/90→03/92								
1.7 16V 4x4 (907.A1G)	95 kW	1.7 l	01/90→09/94								
1.7 16V 4x4 (907.A1G)	97 kW	1.7 l	01/90→09/94								
1.7 i.e. (907.A1A)	79 kW	1.7 l	01/90→09/94								
1.7 i.e. 4x4	79 kW	1.7 l	01/90→03/92								
1.7 i.e. (907.A1A)	77 kW	1.7 l	04/92→09/94		5DA 006 623-601	Switch Unit, ignition system	8				
ALFA ROMEO - 33 Sportwagon (905A)										12/86→12/89	
1.5 4x4 (905.A2U)	77 kW	1.5 l	12/86→03/89	03/88→; AR30508	5DA 006 623-001	Switch Unit, ignition system	4				
1.7 i.e.	77 kW	1.7 l	09/88→12/89	LHD	5DA 006 623-001	Switch Unit, ignition system	4				
					5DA 006 623-041	Switch Unit, ignition system	4				
1.7 i.e. 4x4	77 kW	1.7 l	09/88→12/89	LHD	5DA 006 623-001	Switch Unit, ignition system	4				
ALFA ROMEO - 33 Sportwagon (907B)										01/90→09/94	
1.5 i.e.	71 kW	1.5 l	01/90→09/94	with 3 way catalyst; LHD	5DA 006 623-001	Switch Unit, ignition system	4				
1.7 16V (907.B1G)	95 kW	1.7 l	01/90→09/94	LHD	5DA 006 623-001	Switch Unit, ignition system	4				
1.7 16V (907.B1G)	97 kW	1.7 l	01/90→09/94								
1.7 16V 4x4 (907.B1H)	95 kW	1.7 l	01/90→09/94								
1.7 16V 4x4 (907.B1H)	97 kW	1.7 l	01/90→03/92								
1.7 i.e. (907.B1A)	79 kW	1.7 l	01/90→03/92								
1.7 i.e. 4x4 (907.B1E)	79 kW	1.7 l	01/90→03/92								
1.7 i.e. (907.B1A)	77 kW	1.7 l	04/92→09/94	LHD; for vehicles with catalytic converter	5DA 006 623-001	Switch Unit, ignition system	4				
ALFA ROMEO - 75 Saloon (162B)										05/85→02/92	
1.6 (162.B2B, 162.B2C)	81 kW	1.6 l	05/85→09/89	06/88→; LHD; Carburettor	5DA 006 623-001	Switch Unit, ignition system	4				
1.8 (162.B1A, 162.B1B)	85 kW	1.8 l	09/85→06/89								
2.5 V6 (162.B3)	115 kW	2.5 l	05/85→08/86	02/86→; AR01911	5DA 006 623-001	Switch Unit, ignition system	4				
3.0 V6 (162.B6A) CAT	136 kW	3 l	01/87→02/92	06/88→; LHD	5DA 006 623-001	Switch Unit, ignition system	4				
ALFA ROMEO - 145 (930)										07/94→01/01	
1.4 i.e.	66 kW	1.4 l	07/94→12/96	2x	5DA 193 175-341	Ignition Coil	11				
1.4 i.e. 16V T.S.	76 kW	1.4 l	12/96→01/01	AR 33503; →Model 1999; →VET 3174687	5DA 749 475-261	Ignition Coil	38				
				AR 33503; →Model 2000; VET 0165088→	5DA 749 475-341	Ignition Coil	38				
1.6 i.e.	76 kW	1.6 l	10/94→12/96	→12/94; Multipoint Injection	5DA 006 623-601	Switch Unit, ignition system	8				
				AR 33201; →11/94	5DA 193 175-691	Ignition Coil	20				
1.6 i.e. 16V T.S.	88 kW	1.6 l	12/96→01/01	AR 67601; →Model 1999; →VET 3174687	5DA 749 475-261	Ignition Coil	38				
				AR 67601; →Model 2000; VET 3174687→	5DA 749 475-341	Ignition Coil	38				
1.7 i.e. 16V	95 kW	1.7 l	10/94→12/96	AR 33401	5DA 193 175-691	Ignition Coil	20				

ALFA ROMEO - 145 (930)										07/94→01/01			
1.8 i.e. 16V	106 kW	1.8 l	03/98→01/01	⊗ AR 32201; →Model 2000	5DA 749 475-341 Ignition Coil								38
1.8 i.e. 16V T.S.	103 kW	1.8 l	12/96→12/98	⊗ AR 67106	5DA 749 475-261 Ignition Coil								38
2.0 16V Quadrifoglio	114 kW	2 l	03/98→01/01	⊗ AR 32301; →Model 2000	5DA 749 475-341 Ignition Coil								38
2.0 16V T.S.	110 kW	2 l	10/95→01/01	⊗ AR 67204; →Model 1999	5DA 749 475-261 Ignition Coil								38
ALFA ROMEO - 146 (930)										12/94→01/01			
1.4 i.e.	66 kW	1.4 l	12/94→12/96	2x	5DA 193 175-341 Ignition Coil								11
1.4 i.e. 16V T.S.	76 kW	1.4 l	11/96→01/01	⊗ AR 33503; →Model 1999; →VET 0165088	5DA 749 475-261 Ignition Coil								38
				⊗ AR 33503; →Model 2000; VET 0165088→	5DA 749 475-341 Ignition Coil								
1.6 i.e.	76 kW	1.6 l	12/94→12/96		5DA 006 623-601 Switch Unit, ignition system								8
				⊗ AR 33201	5DA 193 175-691 Ignition Coil								20
1.6 i.e. 16V T.S.	88 kW	1.6 l	11/96→01/01	⊗ AR 67601; →Model 1999; →VET 0165088	5DA 749 475-261 Ignition Coil								38
				⊗ AR 67601; →Model 2000; VET 0165088→	5DA 749 475-341 Ignition Coil								38
1.7 i.e. 16V	95 kW	1.7 l	12/94→12/96	⊗ AR 33401	5DA 193 175-691 Ignition Coil								20
1.8 i.e. 16V T.S.	103 kW	1.8 l	11/96→01/01	⊗ AR 67106; →Model 1999	5DA 749 475-261 Ignition Coil								38
1.8 i.e. 16V T.S.	106 kW	1.8 l	03/98→01/01	⊗ AR 32201; →Model 2000	5DA 749 475-341 Ignition Coil								38
2.0 16V Quadrifoglio	114 kW	2 l	03/98→01/01	⊗ AR 32301; →Model 2000	5DA 749 475-341 Ignition Coil								38
2.0 16V T.S.	110 kW	2 l	10/95→01/01	⊗ AR 67204; →Model 1999	5DA 749 475-261 Ignition Coil								38
ALFA ROMEO - 147 (937)										01/01→03/10			
1.6 16V T.SPARK (937AXB1A)	88 kW	1.6 l	01/01→03/10		5DA 749 475-131 Ignition Coil								37
1.6 16V T.SPARK ECO (937AXA1A)	77 kW	1.6 l	01/01→03/10										
2.0 16V T.SPARK (937AXC1_)	110 kW	2 l	01/01→03/10										
3.2 GTA	184 kW	3.2 l	02/03→03/10	⊗ 932 A.000	5DA 193 175-671 Ignition Coil								20
ALFA ROMEO - 155 (167)										01/92→12/97			
1.6 16V T.S.	88 kW	1.6 l	05/96→12/97	⊗ AR 67601	5DA 749 475-261 Ignition Coil								38
1.7 T.S. (167.A4D, 167.A4H)	85 kW	1.7 l	04/93→04/96		5DA 006 623-601 Switch Unit, ignition system								8
				⊗ AR 67105; 2	5DA 193 175-691 Ignition Coil							20	
1.7 T.S. 16V	103 kW	1.7 l	05/96→12/97	⊗ AR 67106	5DA 749 475-261 Ignition Coil								38
1.8 T.S.	95 kW	1.8 l	02/92→06/93		5DA 006 623-601 Switch Unit, ignition system								8
1.8 T.S. Sport (167.A4A, 167.A4C, 167.A4E)	93 kW	1.8 l	01/92→12/96		5DA 006 623-601 Switch Unit, ignition system								8
				⊗ AR 67102; 2	5DA 193 175-691 Ignition Coil						20		
				⊗ AR 67101; 2	5DA 193 175-691 Ignition Coil						20		
2.0 16V Turbo Q4	140 kW	2 l	01/92→12/97	2x	5DA 193 175-341 Ignition Coil							11	
2.0 16V Turbo Q4 (167.A2B, 167.A2C, 167.A2E)	137 kW	2 l	01/92→12/97										
2.0 T.S. (167.A2)	106 kW	2 l	02/92→04/93		5DA 006 623-601 Switch Unit, ignition system								8
				⊗ AR 67201; 2	5DA 193 175-691 Ignition Coil						20		
2.0 T.S. (167.A2A)	104 kW	2 l	02/92→02/95		5DA 006 623-601 Switch Unit, ignition system								8
				⊗ AR 67202; 2	5DA 193 175-691 Ignition Coil						20		
2.0 T.S. 16V (167.A2G)	110 kW	2 l	03/95→12/97	⊗ AR 67204	5DA 749 475-261 Ignition Coil								38

				13	i	412			
ALFA ROMEO - 156 (932)						09/97→09/05			
1.6 16V T.SPARK (932A4)	88 kW	1.6 l	09/97→09/05	AR 32103 / AR 32104; →Model 2002	5DA 749 475-131	Ignition Coil	37		
				AR 67601; →Model 2002; →VET 0084340	5DA 749 475-261	Ignition Coil	38		
				AR 67601; →Model 2002; VET 0084340→ AR 32102; →Model 2002	5DA 749 475-341	Ignition Coil	38		
1.8 16V T.SPARK (932A3)	106 kW	1.8 l	09/97→10/00	AR 32201	5DA 749 475-341	Ignition Coil	38		
1.8 16V T.SPARK (932A31__)	103 kW	1.8 l	10/00→09/05		5DA 749 475-131	Ignition Coil	37		
2.0 16V T.SPARK (932A21__)	110 kW	2 l	10/00→03/02						
2.0 16V T.SPARK (932A2)	114 kW	2 l	09/97→10/00	AR 32301	5DA 749 475-341	Ignition Coil	38		
2.5 V6 24V (932A1)	140 kW	2.5 l	09/97→12/01	AR 32401	5DA 193 175-671	Ignition Coil	20		
2.5 V6 24V (932A11__)	141 kW	2.5 l	10/00→09/05	AR 32405	5DA 193 175-671	Ignition Coil	20		
3.2 GTA (932AXB)	184 kW	3.2 l	03/02→09/05	932 A.000	5DA 193 175-671	Ignition Coil	20		
ALFA ROMEO - 156 Sportwagon (932)						05/00→05/06			
1.6 16V T.SPARK (932A4)	88 kW	1.6 l	05/00→05/06	AR 32103 / AR 32104; Model 2001→Model 2005	5DA 749 475-131	Ignition Coil	37		
				AR 67601; →Model 2002; →VET 0084340	5DA 749 475-261	Ignition Coil	38		
				AR 67601; →Model 2002; VET 0084340→ AR 32102; →Model 2002	5DA 749 475-341	Ignition Coil	38		
1.8 16V T.SPARK (932A3)	106 kW	1.8 l	05/00→10/00	AR 32201	5DA 749 475-341	Ignition Coil	38		
1.8 16V T.SPARK (932B31__)	103 kW	1.8 l	10/00→05/06		5DA 749 475-131	Ignition Coil	37		
2.0 16V T.SPARK (932B21__)	110 kW	2 l	10/00→03/02						
2.0 16V T.SPARK (932A2)	114 kW	2 l	05/00→06/02	AR 32301	5DA 749 475-341	Ignition Coil	38		
2.5 V6 24V (932A1)	140 kW	2.5 l	05/00→08/03	AR 32401	5DA 193 175-671	Ignition Coil	20		
2.5 V6 24V (932B11__)	141 kW	2.5 l	10/00→05/06	AR 32405; →Model 2002	5DA 193 175-671	Ignition Coil	20		
ALFA ROMEO - 164 Saloon (164)						09/92→09/98			
2.0 T.S. (164.H3)	106 kW	2 l	09/92→09/98		5DA 006 623-601	Switch Unit, ignition system	8		
				AR 64103; 2	5DA 193 175-691	Ignition Coil	20		
3.0	168 kW	3 l	04/93→02/95	AR 64304	5DA 193 175-671	Ignition Coil	20		
3.0 24V (164.K1)	155 kW	3 l	09/92→09/98	AR 66301 / AR 66302	5DA 193 175-671	Ignition Coil	20		
3.0 24V Q4 (164.K1M, 164.K1C)	170 kW	3 l	02/94→09/98	AR 64307 / AR 64308	5DA 193 175-671	Ignition Coil	20		
3.0 24V QV All-wheel Drive	171 kW	3 l	11/92→10/97	66304	5DA 193 175-671	Ignition Coil	20		
ALFA ROMEO - 166 Saloon (936)						09/98→06/07			
2.0 T.Spark (936A3A__)	114 kW	2 l	09/98→10/00	AR 34103	5DA 749 475-341	Ignition Coil	38		
2.0 T.Spark (936A3B__)	110 kW	2 l	10/00→06/07		5DA 749 475-131	Ignition Coil	37		
2.5 V6 24V (936A2__)	140 kW	2.5 l	09/98→10/00	AR 34201	5DA 193 175-671	Ignition Coil	20		
2.5 V6 24V (936A21__)	138 kW	2.5 l	10/00→06/07	AR 36201	5DA 193 175-671	Ignition Coil	20		
3.0 V6 24V (936A1__)	166 kW	3 l	09/98→10/00	AR 34301	5DA 193 175-671	Ignition Coil	20		
3.0 V6 24V (936A11__)	162 kW	3 l	10/00→06/07	AR 36101	5DA 193 175-671	Ignition Coil	20		
ALFA ROMEO - ARNA (920)						03/83→12/86			
1.2	46 kW	1.2 l	03/83→12/86	01/85→	5DA 006 623-051	Switch Unit, ignition system	4		
1.2 (920.AA)	44 kW	1.2 l	01/85→12/86		5DA 006 623-051	Switch Unit, ignition system	4		
1.2 (920.AB, 920.AC)	50 kW	1.2 l	01/85→12/86						

ALFA ROMEO - GIULIETTA Saloon (116)						10/77→12/85
1.6 (116.50B)	79 kW	1.6 l	10/77→04/85	01/81→	5DA 006 623-051 Switch Unit, ignition system	4
1.8 (116.AA, 116.AB)	90 kW	1.8 l	04/79→04/85			
2.0 (116.A1A)	96 kW	2 l	06/80→04/85			
1.8 Turbo	110 kW	1.8 l	01/84→12/85	→04/85	5DA 006 623-051 Switch Unit, ignition system	4
2.0 Turbo	125 kW	2 l	07/83→06/84		5DA 006 623-051 Switch Unit, ignition system	4
ALFA ROMEO - GT (937)						11/03→09/10
1.8 TS	103 kW	1.8 l	11/03→09/10		5DA 749 475-131 Ignition Coil	37
3.2 GTA	176 kW	3.2 l	11/03→09/10	936 A.000	5DA 193 175-671 Ignition Coil	20
ALFA ROMEO - GTV (916C_)						06/95→10/05
1.8 16V (916C3)	106 kW	1.8 l	05/98→10/05	AR 32201; →Model 2005	5DA 749 475-341 Ignition Coil	38
2.0 T.SPARK 16V (916.C2_, 916C2C00)	110 kW	2 l	06/95→10/05	AR 32310	5DA 749 475-131 Ignition Coil	37
				AR 16201; →Model 1998	5DA 749 475-261 Ignition Coil	38
2.0 T.SPARK 16V (916C2C)	114 kW	2 l	05/98→08/00	AR 32301	5DA 749 475-341 Ignition Coil	38
3.0 V6 24V (916.C1)	162 kW	3 l	10/96→10/00	AR 16102	5DA 193 175-671 Ignition Coil	20
3.0 V6 24V (916.C1B_)	160 kW	3 l	10/00→10/05	AR 16105; →Model 2005	5DA 193 175-671 Ignition Coil	20
3.2 V6 24V	176 kW	3.2 l	04/03→10/05	936 A6.000; →Model 2005	5DA 193 175-671 Ignition Coil	20
ALFA ROMEO - SPIDER (115)						01/90→12/93
1600	79 kW	1.6 l	01/90→12/93	Carburettor; LHD	5DA 006 623-001 Switch Unit, ignition system	4
ALFA ROMEO - SPIDER (916S_)						09/94→04/05
1.8 16V (916S3)	106 kW	1.8 l	05/98→04/05	AR 32201	5DA 749 475-341 Ignition Coil	38
2.0 T.SPARK 16V (916S2B)	114 kW	2 l	05/98→08/00	AR 32301	5DA 749 475-341 Ignition Coil	38
2.0 T.SPARK 16V (916S2C00)	110 kW	2 l	06/95→04/05	AR 32310	5DA 749 475-131 Ignition Coil	37
				AR 16201; →Model 1998	5DA 749 475-261 Ignition Coil	38
3.0 V6 (916S1B00)	160 kW	3 l	09/94→08/00	AR 16105	5DA 193 175-671 Ignition Coil	20
3.2 V6 24V	176 kW	3.2 l	04/03→04/05	936 A6.000	5DA 193 175-671 Ignition Coil	20

							
ALPINA - ROADSTER (Z8)						06/02→10/03	
4.8 V8	280 kW	4.8 l	06/02→10/03	5DA 193 175-551 Ignition Coil		17	



				13	i	412			
AUDI - 80 Avant (8C, B4)							09/91→01/96		
2.0 E	85 kW	2 l	07/92→01/96	ABK; 8C-N-000001→8C-N-300000	5DA 006 623-951	Ignition Coil		9	
2.0 E 16V	103 kW	2 l	02/93→01/96		5DA 006 623-331	Switch		6	
2.0 E 16V quattro	103 kW	2 l	12/92→07/95			Unit, ignition system			
2.3 E quattro	98 kW	2.3 l	09/91→11/94						
2.3 E	98 kW	2.3 l	07/92→01/96	→11/94	5DA 006 623-331	Switch		6	
						Unit, ignition system			
2.6	110 kW	2.6 l	07/92→01/96		5DA 006 623-591	Switch		7	
2.6 quattro	110 kW	2.6 l	07/92→07/95			Unit, ignition system			
2.8	128 kW	2.8 l	09/91→01/96						
2.8 quattro	128 kW	2.8 l	08/92→07/95						
AUDI - 80 Saloon (8C, B4)							09/91→12/94		
2.0 E	85 kW	2 l	09/91→12/94	ABK; 8C-N-000001→8C-N-300000	5DA 006 623-951	Ignition Coil		9	
2.0 E 16V	103 kW	2 l	08/92→12/94		5DA 006 623-331	Switch		6	
2.3 E	98 kW	2.3 l	09/91→12/94			Unit, ignition system			
2.3 E quattro	98 kW	2.3 l	09/91→12/94						
2.0 E 16V quattro	103 kW	2 l	04/92→12/94	07/92→	5DA 006 623-331	Switch		6	
						Unit, ignition system			
2.0 E quattro	85 kW	2 l	09/91→12/94	ABK; →8C-P-300000	5DA 006 623-951	Ignition Coil		9	
2.6	110 kW	2.6 l	07/92→12/94		5DA 006 623-591	Switch		7	
2.6 quattro	110 kW	2.6 l	06/92→12/94			Unit, ignition system			
2.8	128 kW	2.8 l	09/91→12/94						
2.8 quattro	128 kW	2.8 l	09/91→12/94						
AUDI - 80 Saloon (81, 85, B2)							08/78→08/86		
1.3	40 kW	1.3 l	09/78→07/81		5DA 006 623-931	Switch		8	
1.3	44 kW	1.3 l	09/78→07/81			Unit, ignition system			
1.6	54 kW	1.6 l	02/86→07/86						
1.8	65 kW	1.8 l	02/86→07/86						
1.8	66 kW	1.8 l	01/83→08/86						
1.8	68 kW	1.8 l	08/83→08/86						
1.8 CC quattro (85Q)	66 kW	1.8 l	08/84→08/86						
1.8 CC quattro (85Q)	68 kW	1.8 l	08/85→08/86						
1.8 GTE	81 kW	1.8 l	08/85→07/86						
1.8 GTE	82 kW	1.8 l	10/84→08/86						
1.8 GTE quattro (85Q)	81 kW	1.8 l	03/85→08/86						
1.9 CD-5S	85 kW	1.9 l	09/81→07/83						
2.2 quattro (85Q)	100 kW	2.2 l	08/82→07/84						
1.3	44 kW	1.3 l	09/78→07/86	08/81→	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.6	55 kW	1.6 l	08/78→07/86	→07/83	5DA 006 623-931	Switch		8	
						Unit, ignition system			
				08/81→	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.6	63 kW	1.6 l	08/78→02/83	09/78→12/82	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.6 GLE	81 kW	1.6 l	08/78→07/82	→07/82	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.8 GTE quattro (85Q)	82 kW	1.8 l	08/84→08/86	03/85→	5DA 006 623-931	Switch		8	
						Unit, ignition system			
2.0	85 kW	2 l	10/83→09/84	→07/84	5DA 006 623-931	Switch		8	
2.0 quattro (85Q)	85 kW	2 l	10/83→09/84			Unit, ignition system			
AUDI - 80 Saloon (89, 89Q, 8A, B3)							06/86→10/91		
1.4	48 kW	1.4 l	08/86→07/88		5DA 006 623-931	Switch		8	
1.6	51 kW	1.6 l	08/87→09/91			Unit, ignition system			
1.6	55 kW	1.6 l	09/86→08/91						
1.6	75 kW	1.6 l	08/90→10/91						
1.8	55 kW	1.8 l	10/86→01/90						
1.8 E quattro	82 kW	1.8 l	09/86→08/91						
1.8 S	66 kW	1.8 l	09/86→10/91						
1.8 S quattro	65 kW	1.8 l	09/86→07/90						
2.0	82 kW	2 l	10/90→08/91						
2.0 E	83 kW	2 l	08/88→10/90						
2.0 E 16V	101 kW	2 l	03/90→09/91						
1.8	83 kW	1.8 l	09/86→07/88	02/87→	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.8 E	82 kW	1.8 l	06/86→08/91	09/86→	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.8 quattro	83 kW	1.8 l	09/86→08/90	→07/88	5DA 006 623-931	Switch		8	
						Unit, ignition system			
1.8 S	65 kW	1.8 l	08/86→01/90	→01/90	5DA 006 623-931	Switch		8	
						Unit, ignition system			

				13	i	412	
AUDI - 80 Saloon (89, 89Q, 8A, B3)							06/86→10/91
1.8 S quattro	66 kW	1.8 l	09/86→09/91			5DA 006 623-931 Switch Unit, ignition system	8
				08/87→07/90;	☼ JN / NE / PM	5DA 006 623-941 Switch Unit, ignition system	9
2.0 quattro	85 kW	2 l	10/90→08/91			5DA 006 623-941 Switch Unit, ignition system	9
AUDI - 90 Saloon (81, 85, B2)							10/84→03/87
2.0	83 kW	2 l	03/86→03/87			5DA 006 623-931 Switch Unit, ignition system	8
2.0	85 kW	2 l	10/84→03/87				
2.2	85 kW	2.2 l	01/85→03/87				
2.2	100 kW	2.2 l	10/84→03/87				
2.2 E quattro	88 kW	2.2 l	08/85→03/87				
AUDI - 90 Saloon (89, 89Q, 8A, B3)							04/87→09/91
2.0	85 kW	2 l	07/88→09/91			5DA 006 623-931 Switch Unit, ignition system	8
2.0 20 V	118 kW	2 l	08/89→07/91				
2.2 E	100 kW	2.2 l	04/87→07/91				
2.3 E	98 kW	2.3 l	04/87→09/91				
2.3 E 20V	123 kW	2.3 l	04/90→07/91				
2.3 E 20V	125 kW	2.3 l	08/88→07/91				
2.2 E quattro	100 kW	2.2 l	04/87→09/91			5DA 006 623-931 Switch Unit, ignition system	8
				08/87→		5DA 006 623-941 Switch Unit, ignition system	9
2.3 E	100 kW	2.3 l	04/87→07/91			5DA 006 623-331 Switch Unit, ignition system	6
						5DA 006 623-931 Switch Unit, ignition system	8
AUDI - 100 (44, 44Q, C3)							08/82→11/90
1.8	55 kW	1.8 l	08/82→12/87			5DA 006 623-931 Switch Unit, ignition system	8
1.9	74 kW	1.9 l	08/82→07/84				
2.0	83 kW	2 l	08/86→11/87				
2.1	100 kW	2.1 l	08/82→07/84				
2.2	79 kW	2.2 l	08/82→07/84				
2.2	85 kW	2.2 l	10/84→09/86				
2.2	101 kW	2.2 l	08/84→12/88				
2.2 E quattro	88 kW	2.2 l	08/85→07/86				
2.2 Turbo	121 kW	2.2 l	08/86→11/90				
2.3 E	100 kW	2.3 l	10/86→11/90				
1.8	65 kW	1.8 l	02/86→07/88	08/86→		5DA 006 623-931 Switch Unit, ignition system	8
1.8	66 kW	1.8 l	08/83→07/89			5DA 006 623-931 Switch Unit, ignition system	8
				10/86→;	☼ DS	5DA 006 623-941 Switch Unit, ignition system	9
1.8 CAT	66 kW	1.8 l	03/85→11/90	04/85→		5DA 006 623-931 Switch Unit, ignition system	8
				→10/89;	☼ 4B / NP	5DA 006 623-941 Switch Unit, ignition system	9
1.8 quattro	65 kW	1.8 l	08/86→07/90	→07/88		5DA 006 623-931 Switch Unit, ignition system	8
1.8 quattro	66 kW	1.8 l	10/84→07/88	08/85→		5DA 006 623-931 Switch Unit, ignition system	8
				10/86→;	☼ NP	5DA 006 623-941 Switch Unit, ignition system	9
1.8 quattro CAT	66 kW	1.8 l	08/85→11/90	☼ PH; →07/88		5DA 006 623-931 Switch Unit, ignition system	8
				→07/88;	☼ NP	5DA 006 623-941 Switch Unit, ignition system	9
2.0	85 kW	2 l	08/84→12/87			5DA 006 623-931 Switch Unit, ignition system	8
				10/86→10/87		5DA 006 623-941 Switch Unit, ignition system	9
2.0 CAT	85 kW	2 l	01/88→11/90			5DA 006 623-931 Switch Unit, ignition system	8
						5DA 006 623-941 Switch Unit, ignition system	9
2.2 CAT	101 kW	2.2 l	06/89→11/90	☼ KU		5DA 006 623-931 Switch Unit, ignition system	8
2.2 quattro	101 kW	2.2 l	08/84→12/88			5DA 006 623-931 Switch Unit, ignition system	8
				10/86→		5DA 006 623-941 Switch Unit, ignition system	9

				13	i	412		
AUDI - 100 (44, 44Q, C3)								08/82→11/90
2.2 quattro CAT	101 kW	2.2 l	06/89→11/90	☉ KU			5DA 006 623-931 Switch Unit, ignition system	8
							5DA 006 623-941 Switch Unit, ignition system	9
AUDI - 100 Avant (4A, C4)								09/91→06/94
2.3 E	98 kW	2.3 l	09/91→06/94				5DA 006 623-331 Switch Unit, ignition system	6
2.3 E quattro	98 kW	2.3 l	09/91→06/94					
2.6	110 kW	2.6 l	03/92→06/94				5DA 006 623-591 Switch Unit, ignition system	7
2.6 quattro	110 kW	2.6 l	07/92→06/94					
2.8 E	128 kW	2.8 l	09/91→06/94					
2.8 E quattro	128 kW	2.8 l	09/91→06/94					
S4 Turbo quattro	169 kW	2.2 l	09/91→06/94					
AUDI - 100 Avant (43, C2)								07/77→02/83
2.1	85 kW	2.1 l	07/77→02/83	☉ WB; 01/78→07/82			5DA 006 623-931 Switch Unit, ignition system	8
2.1	100 kW	2.1 l	07/77→02/83	→07/82			5DA 006 623-931 Switch Unit, ignition system	8
AUDI - 100 Avant (44, 44Q, C3)								08/82→11/90
1.8	55 kW	1.8 l	08/82→12/87	05/83→			5DA 006 623-931 Switch Unit, ignition system	8
2.1	100 kW	2.1 l	08/82→07/84					
1.8	65 kW	1.8 l	02/86→07/90	01/88→07/88			5DA 006 623-931 Switch Unit, ignition system	8
1.8	66 kW	1.8 l	08/83→07/89				5DA 006 623-931 Switch Unit, ignition system	8
				10/86→; ☉ DS			5DA 006 623-941 Switch Unit, ignition system	9
1.8 CAT	66 kW	1.8 l	03/85→11/90	08/86→07/89			5DA 006 623-931 Switch Unit, ignition system	8
1.8 quattro	65 kW	1.8 l	08/86→07/90	→07/88			5DA 006 623-931 Switch Unit, ignition system	8
1.8 quattro	66 kW	1.8 l	10/84→07/88	☉ JW; →12/87			5DA 006 623-931 Switch Unit, ignition system	8
				10/86→; ☉ NP			5DA 006 623-941 Switch Unit, ignition system	9
1.8 quattro CAT	66 kW	1.8 l	08/85→10/90	☉ PH; →07/88			5DA 006 623-931 Switch Unit, ignition system	8
				☉ NP			5DA 006 623-941 Switch Unit, ignition system	9
1.9	74 kW	1.9 l	02/83→07/84	05/83→07/83			5DA 006 623-931 Switch Unit, ignition system	8
2.0	83 kW	2 l	09/86→11/87				5DA 006 623-931 Switch Unit, ignition system	8
2.2	85 kW	2.2 l	10/84→09/86					
2.2	101 kW	2.2 l	08/84→12/88					
2.2 E quattro	88 kW	2.2 l	08/85→07/86					
2.0 E	85 kW	2 l	01/85→12/87	08/86→			5DA 006 623-931 Switch Unit, ignition system	8
				10/86→10/87			5DA 006 623-941 Switch Unit, ignition system	9
2.0 E CAT	85 kW	2 l	01/88→11/90				5DA 006 623-931 Switch Unit, ignition system	8
2.2 quattro	101 kW	2.2 l	08/84→12/88				5DA 006 623-941 Switch Unit, ignition system	9
2.2 CAT	101 kW	2.2 l	06/89→11/90	☉ KU; →07/89			5DA 006 623-931 Switch Unit, ignition system	8
2.2 quattro CAT	101 kW	2.2 l	06/89→11/90	☉ KU			5DA 006 623-931 Switch Unit, ignition system	8
2.2 Turbo	121 kW	2.2 l	08/86→11/90	08/88→07/89			5DA 006 623-931 Switch Unit, ignition system	8
2.3	100 kW	2.3 l	08/86→11/90	01/88→07/89			5DA 006 623-931 Switch Unit, ignition system	8
AUDI - 100 Coupe (C1)								08/71→12/76
1.9	82 kW	1.9 l	08/71→12/76	09/71→07/76			5DA 006 623-931 Switch Unit, ignition system	8
AUDI - 100 Saloon (4A, C4)								12/90→06/94
2.0 E 16V	103 kW	2 l	01/92→06/94				5DA 006 623-331 Switch Unit, ignition system	6
2.3 E	98 kW	2.3 l	12/90→06/94					
2.3 E quattro	98 kW	2.3 l	12/90→06/94					

AUDI - 100 Saloon (4A, C4)				12/90→06/94		
2.6	110 kW	2.6 l	03/92→06/94		5DA 006 623-591 Switch	7
2.6 quattro	110 kW	2.6 l	04/92→06/94		Unit, ignition system	
2.8 E	128 kW	2.8 l	12/90→06/94			
2.8 E quattro	128 kW	2.8 l	12/90→06/94			
S4 Turbo quattro	169 kW	2.2 l	08/91→06/94			
AUDI - 100 Saloon (43, C2)				03/77→07/82		
2.1	85 kW	2.1 l	10/77→07/82	WB; 01/78→	5DA 006 623-931 Switch	8
					Unit, ignition system	
2.1	100 kW	2.1 l	03/77→07/82		5DA 006 623-931 Switch	8
					Unit, ignition system	
AUDI - 100 Saloon (C1)				09/71→07/76		
1.9	82 kW	1.9 l	09/71→07/76		5DA 006 623-931 Switch	8
					Unit, ignition system	
AUDI - 200 Avant (44, 44Q)				09/83→12/91		
2.1 Turbo quattro	134 kW	2.1 l	09/83→01/88	KG; 11/84→12/87	5DA 006 623-931 Switch	8
					Unit, ignition system	
2.2 Turbo	121 kW	2.2 l	08/85→09/91		5DA 006 623-931 Switch	8
					Unit, ignition system	
2.2 Turbo quattro	121 kW	2.2 l	09/83→12/90	01/85→11/90	5DA 006 623-931 Switch	8
					Unit, ignition system	
2.2 Turbo quattro	147 kW	2.2 l	02/88→12/91	→11/90	5DA 006 623-931 Switch	8
					Unit, ignition system	
AUDI - 200 Saloon (43)				10/79→09/82		
2.1 5E	100 kW	2.1 l	10/79→09/82		5DA 006 623-931 Switch	8
					Unit, ignition system	
2.1 5T	125 kW	2.1 l	10/79→08/82	for transistor ignition (TI)	5DA 006 623-931 Switch	8
					Unit, ignition system	
AUDI - 200 Saloon (44, 44Q)				08/83→12/91		
2.1 5E	100 kW	2.1 l	08/83→07/84		5DA 006 623-931 Switch	8
					Unit, ignition system	
2.1 Turbo	134 kW	2.1 l	08/83→01/88			
2.2	101 kW	2.2 l	08/84→07/85			
2.2 Turbo	121 kW	2.2 l	08/85→09/91			
2.2 Turbo	140 kW	2.2 l	02/88→12/90			
2.2 Turbo	147 kW	2.2 l	02/88→12/90			
2.2 Turbo quattro	147 kW	2.2 l	02/88→11/90			
2.1 Turbo quattro	134 kW	2.1 l	08/83→09/86	11/84→	5DA 006 623-931 Switch	8
					Unit, ignition system	
2.2 Turbo quattro	121 kW	2.2 l	01/85→12/91	→12/90	5DA 006 623-931 Switch	8
					Unit, ignition system	
AUDI - A1 (8X1, 8XF)				05/10→		
1.2 TFSI	63 kW	1.2 l	05/10→		5DA 358 000-171 Ignition	33
					Coil	
1.4 TFSI	90 kW	1.4 l	05/10→	CAXA; 4x	5DA 193 175-501 Ignition	16
					Coil	
1.4 TFSI	103 kW	1.4 l	04/12→	CPTA; 4 ports; 4x	5DA 193 175-951 Ignition	29
					Coil	
2.0 TFSI quattro	188 kW	2 l	03/12→	CDLH; 4	5DA 193 175-921 Ignition	28
					Coil	
AUDI - A1 Sportback (8XA, 8XK)				11/11→		
1.2 TFSI	63 kW	1.2 l	01/12→		5DA 358 000-171 Ignition	33
					Coil	
1.4 TFSI	90 kW	1.4 l	11/11→	CAXA; 4x	5DA 193 175-501 Ignition	16
					Coil	
1.4 TFSI	103 kW	1.4 l	04/12→	CPTA; 4 ports; 4x	5DA 193 175-951 Ignition	29
					Coil	
AUDI - A2 (8Z0)				02/00→08/05		
1.4	55 kW	1.4 l	02/00→08/05	BBY; 4x	5DA 193 175-501 Ignition	16
					Coil	
					5DA 358 000-171 Ignition	33
					Coil	
1.6 FSI	81 kW	1.6 l	05/02→08/05	BAD; 4x	5DA 193 175-501 Ignition	16
					Coil	
AUDI - A3 (8L1)				09/96→05/03		
1.6	74 kW	1.6 l	09/96→05/03		5DA 358 000-171 Ignition	33
					Coil	
1.6	75 kW	1.6 l	08/00→05/03			
1.8	92 kW	1.8 l	09/96→05/03			

AUDI - A3 (8L1)				09/96→05/03	
1.8 T	110 kW	1.8 l	12/96→05/03	AGU; →Model 2000 AUM / AGU; Model 2001→Model 2003; 4x ARZ / AQA; →Model 2000; 4x AGU	5DA 006 623-771 Switch Unit, ignition system 8 5DA 193 175-911 Ignition Coil 27 5DA 193 175-981 Ignition Coil 30 5DA 358 000-051 Ignition Coil 32
1.8 T	132 kW	1.8 l	12/98→05/03	ARY / AUQ; Model 2001→Model 2003; 4x AJQ / APP; →Model 2000; 4x	5DA 193 175-911 Ignition Coil 27 5DA 193 175-981 Ignition Coil 30
1.8 T quattro	110 kW	1.8 l	12/96→05/03	AGU; →Model 2000 ARX / AGU; Model 2001→Model 2003; 4x AQA; →Model 2000; 4x AGU	5DA 006 623-771 Switch Unit, ignition system 8 5DA 193 175-911 Ignition Coil 27 5DA 193 175-981 Ignition Coil 30 5DA 358 000-051 Ignition Coil 32
1.8 T quattro	132 kW	1.8 l	10/98→05/03	ARY; Model 2001→Model 2003; 4x AJQ; →Model 2000; 4x	5DA 193 175-911 Ignition Coil 27 5DA 193 175-981 Ignition Coil 30
S3 quattro	154 kW	1.8 l	03/99→04/02	AMK; Model 2001→Model 2003; 4x APY / AMK; →Model 2000; 4x	5DA 193 175-911 Ignition Coil 27 5DA 193 175-981 Ignition Coil 30
S3 quattro	165 kW	1.8 l	10/01→05/03	BAM; →Model 2003; 4x	5DA 193 175-911 Ignition Coil 27
AUDI - A3 (8P1)				05/03→08/12	
1.2 TSI	77 kW	1.2 l	04/10→08/12		5DA 358 000-171 Ignition Coil 33
1.6	75 kW	1.6 l	05/03→08/12		
1.6 E-Power	75 kW	1.6 l	01/11→08/12		
1.4 TFSI	92 kW	1.4 l	09/07→08/12	CAXC / CMSA; 4x	5DA 193 175-501 Ignition Coil 16
1.6 FSI	85 kW	1.6 l	08/03→09/07	BAG / BLF / BLP; 4x	5DA 193 175-501 Ignition Coil 16
1.8 TFSI	118 kW	1.8 l	11/06→08/12	BZB / BYT / CDAA; 4	5DA 193 175-921 Ignition Coil 28
1.8 TFSI quattro	118 kW	1.8 l	07/08→08/12	CDAA; 4	5DA 193 175-921 Ignition Coil 28
2.0 FSI	110 kW	2 l	05/03→06/08	BLX / BVZ / BLY / AXW / BVY / BMB / BLR; 4	5DA 193 175-921 Ignition Coil 28
2.0 TFSI	147 kW	2 l	09/04→08/12	CAWB / CCZA / AXX / BWA; 4	5DA 193 175-921 Ignition Coil 28
2.0 TFSI quattro	147 kW	2 l	09/04→08/12	BWA / AXX / CCTA / CCZA; 4	5DA 193 175-921 Ignition Coil 28
S3 quattro	188 kW	2 l	02/07→08/12	CDLC / BZC; 4	5DA 193 175-921 Ignition Coil 28
S3 quattro	195 kW	2 l	11/06→08/12	CDLA / BHZ	5DA 193 175-921 Ignition Coil 28
AUDI - A3 (8V1)				04/12→	
1.2 TFSI	77 kW	1.2 l	02/13→	CJZA; 4 ports; 4x	5DA 193 175-951 Ignition Coil 29
1.4 TFSI	90 kW	1.4 l	04/12→	CMBA; 4 ports; 4x	5DA 193 175-951 Ignition Coil 29
1.4 TFSI	103 kW	1.4 l	03/13→	CPTA; 4 ports; 4x	5DA 193 175-951 Ignition Coil 29
AUDI - A3 Convertible (8P7)				04/08→05/13	
1.2 TFSI	77 kW	1.2 l	03/10→05/13		5DA 358 000-171 Ignition Coil 33
1.6	75 kW	1.6 l	09/08→05/10		
1.8 TFSI	118 kW	1.8 l	04/08→05/13	CDAA / BZB; 4	5DA 193 175-921 Ignition Coil 28
2.0 TFSI	147 kW	2 l	04/08→05/13	CCZA / CAWB; 4	5DA 193 175-921 Ignition Coil 28
AUDI - A3 Sportback (8PA)				09/04→03/13	
1.2 TSI	77 kW	1.2 l	04/10→03/13		5DA 358 000-171 Ignition Coil 33
1.6	75 kW	1.6 l	09/04→03/13		
1.6 E-Power	75 kW	1.6 l	01/11→03/13		

				13	i	412		
AUDI - A3 Sportback (8PA)								09/04→03/13
1.4 TFSI	92 kW	1.4 l	09/07→03/13	⊗ CAXC / CMSA; 4x		5DA 193 175-501	Ignition Coil	16
1.6 FSI	85 kW	1.6 l	09/04→09/07	⊗ BLF / BLP; →Model 2008; 4x		5DA 193 175-501	Ignition Coil	16
1.8 TFSI	118 kW	1.8 l	11/06→03/13	⊗ BYT / BZB / CDAA; 4		5DA 193 175-921	Ignition Coil	28
1.8 TFSI quattro	118 kW	1.8 l	07/08→03/13	⊗ CDAA; 4		5DA 193 175-921	Ignition Coil	28
2.0 FSI	110 kW	2 l	09/04→06/08	⊗ BLX / BVY / BLY / BLR / BVZ / AXW / BMB; 4		5DA 193 175-921	Ignition Coil	28
2.0 TFSI	147 kW	2 l	09/04→03/13	⊗ CAWB / CCZA / CBFA / BPY / BWA / AXX; 4		5DA 193 175-921	Ignition Coil	28
2.0 TFSI quattro	147 kW	2 l	09/04→03/13	⊗ BWA / AXX / CCZA / BPY; 4		5DA 193 175-921	Ignition Coil	28
RS3 quattro	250 kW	2.5 l	01/11→12/12	⊗ CEPA; 5		5DA 193 175-921	Ignition Coil	28
S3 quattro	188 kW	2 l	07/08→03/13	⊗ CDLC; 4		5DA 193 175-921	Ignition Coil	28
S3 quattro	195 kW	2 l	06/08→03/13	⊗ CDLA / BHZ		5DA 193 175-921	Ignition Coil	28
AUDI - A3 Sportback (8VA)								09/12→
1.4 TFSI	90 kW	1.4 l	09/12→	⊗ CMBA; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
1.4 TFSI	103 kW	1.4 l	03/13→	⊗ CPTA; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
AUDI - A4 (8E2, B6)								11/00→12/04
1.6	75 kW	1.6 l	11/00→12/04			5DA 358 000-171	Ignition Coil	33
1.8 T	110 kW	1.8 l	11/00→07/02	⊗ AVJ; ⚡ 8E-1-000001→8E-5-400000		5DA 006 623-771	Switch Unit, ignition system	8
1.8 T quattro	110 kW	1.8 l	11/00→07/02	⊗ AVJ; ⚡ 8E-1-000001→8E-5-400000; 4x		5DA 193 175-911	Ignition Coil	27
1.8 T	120 kW	1.8 l	07/02→12/04	⊗ BFB; ⚡ 8E-1-000001→; 4x		5DA 193 175-911	Ignition Coil	27
1.8 T quattro	120 kW	1.8 l	07/02→12/04			5DA 193 175-911	Ignition Coil	27
1.8 T	140 kW	1.8 l	11/02→12/04	⊗ BEX; ⚡ 8E-1-000001→8E-5-400000		5DA 193 175-911	Ignition Coil	27
1.8 T quattro	140 kW	1.8 l	11/02→12/04	⊗ BEX; ⚡ 8E-1-000001→8E-5-400000; 4x		5DA 193 175-911	Ignition Coil	27
2.0	96 kW	2 l	11/00→12/04	⊗ ALT; ⚡ 8E-1-000001→8E-5-400000; 4x		5DA 193 175-701	Ignition Coil	21
				⊗ ALT; ⚡ 8E-5-400001→; 4x		5DA 193 175-911	Ignition Coil	27
2.4	120 kW	2.4 l	09/01→12/04	⊗ AMM; ⚡ 8E-1-000001→8E-5-400000		5DA 749 475-471	Ignition Coil	39
2.4	125 kW	2.4 l	09/01→12/04	⊗ BDV; ⚡ 8E-1-000001→8E-5-400000		5DA 749 475-471	Ignition Coil	39
3.0	160 kW	3 l	04/01→12/04	⊗ BBJ; ⚡ 8E-1-000001→8E-5-400000; 6x		5DA 193 175-701	Ignition Coil	21
3.0 quattro	160 kW	3 l	04/01→12/04			5DA 193 175-701	Ignition Coil	21
3.0	162 kW	3 l	11/00→12/04	⊗ ASN; ⚡ 8E-1-000001→8E-5-400000; 6x		5DA 193 175-701	Ignition Coil	21
3.0 quattro	162 kW	3 l	11/00→12/04			5DA 193 175-701	Ignition Coil	21
S4 quattro	253 kW	4.2 l	03/03→12/04	⊗ BBK; 8x		5DA 193 175-591	Ignition Coil	18
AUDI - A4 Allroad Estate (8KH, B8)								04/09→
2.0 TFSI quattro	155 kW	2 l	04/09→	⊗ CDNC / CPMA; 4		5DA 193 175-921	Ignition Coil	28
2.0 TFSI quattro	162 kW	2 l	05/13→	⊗ CPMB; 4		5DA 193 175-921	Ignition Coil	28
AUDI - A4 Avant (8D5, B5)								11/94→09/01
1.6	74 kW	1.6 l	11/94→09/01	⊗ AHL / ARM / ANA		5DA 358 000-171	Ignition Coil	33
1.6	75 kW	1.6 l	07/00→09/01			5DA 358 000-171	Ignition Coil	33
1.8	92 kW	1.8 l	02/96→09/01	⊗ ADR ⊗ APT / ARG / AVV; ⚡ 8D-X-200001→		5DA 749 475-351	Ignition Coil	38
1.8 quattro	92 kW	1.8 l	01/96→09/01	⊗ ADR ⊗ ARG / APT; ⚡ 8D-X-200001→		5DA 749 475-351	Ignition Coil	38

				13	i	412			
AUDI - A4 Avant (8D5, B5)							11/94→09/01		
1.8 T	110 kW	1.8 l	03/96→09/01	⊗ AEB; →Model 1999 ⊗ ANB / APU / ARK; →8D-X-200001→	5DA 006 623-771 Switch Unit, ignition system	8			
				⊗ AWT; →8D-X-200001→; 4x	5DA 193 175-911 Ignition Coil	27			
				⊗ AEB / APU / ARK / ANB	5DA 358 000-051 Ignition Coil	32			
1.8 T	132 kW	1.8 l	12/97→09/01	⊗ AJL; →8D-X-200001→	5DA 006 623-771 Switch Unit, ignition system	8			
					5DA 358 000-051 Ignition Coil	32			
1.8 T quattro	110 kW	1.8 l	01/96→09/01	⊗ AEB; →Model 1999 ⊗ ANB / APU / ARK; →8D-X-200001→	5DA 006 623-771 Switch Unit, ignition system	8			
				⊗ AWT; →8D-X-200001→; 4x	5DA 193 175-911 Ignition Coil	27			
				⊗ AEB / ARK / APU / ANB	5DA 358 000-051 Ignition Coil	32			
1.8 T quattro	132 kW	1.8 l	12/97→09/01	⊗ AJL	5DA 006 623-771 Switch Unit, ignition system	8			
					5DA 358 000-051 Ignition Coil	32			
2.4	120 kW	2.4 l	08/97→09/01	⊗ AJG; →8D-X-199999 ⊗ APZ; →8D-X-200001→	5DA 749 475-471 Ignition Coil	39			
2.4	121 kW	2.4 l	03/97→09/01	⊗ ALF / AGA; →8D-X-199999 ⊗ AML / ARJ / APS; →8D-X-200001→	5DA 749 475-471 Ignition Coil	39			
2.4 quattro	120 kW	2.4 l	08/97→09/01	⊗ APZ; →8D-X-200001→	5DA 749 475-471 Ignition Coil	39			
2.4 quattro	121 kW	2.4 l	03/97→09/01	⊗ AGA / ALF; →8D-X-199999 ⊗ AML / ARJ / APS; →8D-X-200001→	5DA 749 475-471 Ignition Coil	39			
2.6	110 kW	2.6 l	02/96→09/01		5DA 006 623-591 Switch Unit, ignition system	7			
2.6 quattro	110 kW	2.6 l	01/96→09/01						
2.8	128 kW	2.8 l	03/96→09/96						
2.8 quattro	128 kW	2.8 l	01/96→09/96						
2.8	142 kW	2.8 l	10/96→09/01	⊗ ACK / ALG; →8D-X-199999	5DA 749 475-471 Ignition Coil	39			
2.8 quattro	142 kW	2.8 l	10/96→09/01	⊗ APR / AQD / AMX; →8D-X-200001→					
RS4 quattro	280 kW	2.7 l	05/00→09/01		5DA 358 000-051 Ignition Coil	32			
S4 quattro	195 kW	2.7 l	09/97→09/01		5DA 006 623-591 Switch Unit, ignition system	7			
					5DA 358 000-051 Ignition Coil	32			
AUDI - A4 Avant (8E5, B6)							04/01→12/04		
1.6	75 kW	1.6 l	09/01→12/04		5DA 358 000-171 Ignition Coil	33			
1.8 T	110 kW	1.8 l	09/01→07/02	⊗ AVJ; →8E-1-000001→8E-5-400000	5DA 006 623-771 Switch Unit, ignition system	8			
1.8 T quattro	110 kW	1.8 l	09/01→07/02						
				⊗ AVJ; →8E-1-000001→8E-5-400000	5DA 193 175-911 Ignition Coil	27			
1.8 T	120 kW	1.8 l	07/02→12/04	⊗ BFB; →8E-1-000001→; 4x	5DA 193 175-911 Ignition Coil	27			
1.8 T quattro	120 kW	1.8 l	07/02→12/04						
1.8 T	140 kW	1.8 l	11/02→12/04	⊗ BEX; →8E-1-000001→8E-5-400000; 4x	5DA 193 175-911 Ignition Coil	27			
1.8 T quattro	140 kW	1.8 l	11/02→12/04						
2.0	96 kW	2 l	09/01→12/04	⊗ ALT; →8E-1-000001→8E-5-400000; 4x	5DA 193 175-701 Ignition Coil	21			
				⊗ ALT; →8E-5-400001→; 4x	5DA 193 175-911 Ignition Coil	27			
2.4	120 kW	2.4 l	09/01→12/04	⊗ AMM; →8E-1-000001→8E-5-400000	5DA 749 475-471 Ignition Coil	39			
2.4	125 kW	2.4 l	09/01→12/04	⊗ BDV; →8E-1-000001→8E-5-400000	5DA 749 475-471 Ignition Coil	39			
3.0	160 kW	3 l	04/01→12/04	⊗ BBJ; →8E-1-000001→8E-5-400000; 6x	5DA 193 175-701 Ignition Coil	21			
3.0 quattro	160 kW	3 l	04/01→12/04						
3.0	162 kW	3 l	09/01→12/04	⊗ ASN; →8E-1-000001→8E-5-400000; 6x	5DA 193 175-701 Ignition Coil	21			
3.0 quattro	162 kW	3 l	09/01→12/04						
S4 quattro	253 kW	4.2 l	03/03→12/04	⊗ BBK; 8x	5DA 193 175-591 Ignition Coil	18			
AUDI - A4 Avant (8ED, B7)							11/04→06/08		
1.6	75 kW	1.6 l	11/04→06/08		5DA 358 000-171 Ignition Coil	33			
1.8 T	120 kW	1.8 l	11/04→06/08	⊗ BFB; →8E-1-000001→; →Model 2008; 4x	5DA 193 175-911 Ignition Coil	27			

				13	i	412		
AUDI - A4 Avant (8ED, B7)								11/04→06/08
1.8 T quattro	120 kW	1.8 l	11/04→06/08	⊗ BFB; ↗ 8-1-000001→; →Model 2008; 4x			5DA 193 175-911 Ignition Coil	27
2.0	96 kW	2 l	11/04→06/08	⊗ ALT; ↗ 8E-5-400001→; →Model 2008; 4x			5DA 193 175-911 Ignition Coil	27
2.0 TFSI	125 kW	2 l	10/06→06/08	⊗ BYK / BPJ; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	147 kW	2 l	11/04→06/08	⊗ BGB / BWE; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	162 kW	2 l	06/05→06/08	⊗ BUL; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI quattro	162 kW	2 l	06/05→06/08					
2.0 TFSI quattro	147 kW	2 l	11/04→06/08	⊗ BGB / BWT / BWE; 4			5DA 193 175-921 Ignition Coil	28
3.0	160 kW	3 l	11/04→05/06	⊗ BBJ; ↗ 8E-5-400001→; 6x			5DA 193 175-701 Ignition Coil	21
3.0 quattro	160 kW	3 l	11/04→07/06					
RS4 quattro	309 kW	4.2 l	09/05→06/08	⊗ BNS; 8			5DA 193 175-921 Ignition Coil	28
S4 quattro	253 kW	4.2 l	11/04→06/08	⊗ BBK; →Model 2008; 8x			5DA 193 175-591 Ignition Coil	18
AUDI - A4 Avant (8K5, B8)								11/07→
1.8 TFSI	88 kW	1.8 l	04/08→	⊗ CDHA; 4			5DA 193 175-921 Ignition Coil	28
1.8 TFSI	118 kW	1.8 l	11/07→	⊗ CDHB / CABB; 4			5DA 193 175-921 Ignition Coil	28
1.8 TFSI quattro	118 kW	1.8 l	09/08→	⊗ CDHB; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	132 kW	2 l	06/08→	⊗ CAEA / CDN B / CFKA; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	155 kW	2 l	06/08→	⊗ CDNC; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI flexible fuel	132 kW	2 l	11/09→	⊗ CFKA; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI flexible fuel quattro	132 kW	2 l	11/09→					
2.0 TFSI quattro	155 kW	2 l	06/08→	⊗ CAEB / CDNC; 4			5DA 193 175-921 Ignition Coil	28
RS4 quattro	331 kW	4.2 l	05/12→	⊗ CFSA; 8			5DA 193 175-921 Ignition Coil	28
AUDI - A4 Convertible (8H7, B6, 8HE, B7)								04/02→03/09
1.8 T	120 kW	1.8 l	07/02→03/09	⊗ BFB; →Model 2009; 4x			5DA 193 175-911 Ignition Coil	27
1.8 T quattro	120 kW	1.8 l	05/03→03/09	⊗ BFB; 4x			5DA 193 175-911 Ignition Coil	27
2.0	96 kW	2 l	09/04→12/05	⊗ ALT; 4x			5DA 193 175-701 Ignition Coil	21
2.0 TFSI 16V	147 kW	2 l	01/06→03/09	⊗ BWE / BWT; 4			5DA 193 175-921 Ignition Coil	28
2.4	120 kW	2.4 l	04/02→12/05	⊗ AMM; Model 2003→			5DA 749 475-471 Ignition Coil	39
2.4	125 kW	2.4 l	04/02→12/05	⊗ BDV; Model 2003→			5DA 749 475-471 Ignition Coil	39
3.0	162 kW	3 l	04/02→12/05	⊗ ASN; 6x			5DA 193 175-701 Ignition Coil	21
3.0 quattro	162 kW	3 l	05/03→12/05					
RS4 quattro	309 kW	4.2 l	06/06→03/09	⊗ BNS; 8			5DA 193 175-921 Ignition Coil	28
S4 quattro	253 kW	4.2 l	03/04→03/09	⊗ BBK; →Model 2008			5DA 193 175-591 Ignition Coil	18
AUDI - A4 Saloon (8D2, B5)								11/94→09/01
1.6	74 kW	1.6 l	11/94→10/00	⊗ ANA / AHL / ARM			5DA 358 000-171 Ignition Coil	33
1.6	75 kW	1.6 l	07/00→11/00				5DA 358 000-171 Ignition Coil	33
1.8	92 kW	1.8 l	01/95→11/00	⊗ ADR			5DA 749 475-351 Ignition Coil	38
1.8 quattro	92 kW	1.8 l	01/95→11/00	⊗ ARG / AVV / APT; ↗ 8D-X-200001→			5DA 749 475-351 Ignition Coil	38
1.8 T	110 kW	1.8 l	01/95→11/00	⊗ AEB; →Model 1999			5DA 006 623-771 Switch Unit, ignition system	8
				⊗ ANB / APU / ARK; ↗ 8D-X-200001→				
				⊗ AWT; ↗ 8D-X-200001→; 4x			5DA 193 175-911 Ignition Coil	27
				⊗ AEB / ANB / ARK / APU			5DA 358 000-051 Ignition Coil	32

				13	i	412		
AUDI - A4 Saloon (8D2, B5)								11/94→09/01
1.8 T	132 kW	1.8 l	12/97→11/00	⊗ AJL; ↗ 8D-X-200001→			5DA 006 623-771 Switch Unit, ignition system	8
							5DA 358 000-051 Ignition Coil	32
1.8 T quattro	110 kW	1.8 l	01/95→11/00	⊗ AEB; →Model 1999 ⊗ ANB / APU / ARK; ↗ 8D-X-200001→ ⊗ AWT; ↗ 8D-X-200001→; 4x			5DA 006 623-771 Switch Unit, ignition system	8
							5DA 193 175-911 Ignition Coil	27
							5DA 358 000-051 Ignition Coil	32
1.8 T quattro	132 kW	1.8 l	12/97→11/00	⊗ AJL			5DA 006 623-771 Switch Unit, ignition system	8
							5DA 358 000-051 Ignition Coil	32
2.4	120 kW	2.4 l	08/97→11/00	⊗ AJG; ↗ 8D-X-199999 ⊗ APZ; ↗ 8D-X-200001→			5DA 749 475-471 Ignition Coil	39
2.4	121 kW	2.4 l	03/97→11/00	⊗ ALF / AGA; ↗ 8D-X-199999 ⊗ AML / ARJ / APS; ↗ 8D-X-200001→			5DA 749 475-471 Ignition Coil	39
2.4 quattro	120 kW	2.4 l	08/97→11/00	⊗ APZ; ↗ 8D-X-200001→			5DA 749 475-471 Ignition Coil	39
2.4 quattro	121 kW	2.4 l	03/97→11/00	⊗ AGA / ALF; ↗ 8D-X-199999 ⊗ AML / ARJ / APS; ↗ 8D-X-200001→			5DA 749 475-471 Ignition Coil	39
2.6	110 kW	2.6 l	01/95→11/00				5DA 006 623-591 Switch Unit, ignition system	7
2.6 quattro	110 kW	2.6 l	01/95→11/00					
2.8	128 kW	2.8 l	09/95→07/97					
2.8 quattro	128 kW	2.8 l	01/95→07/97					
2.8	142 kW	2.8 l	10/96→11/00	⊗ ALG / ACK; ↗ 8D-X-199999 ⊗ APR / AQD / AMX; ↗ 8D-X-200001→			5DA 749 475-471 Ignition Coil	39
2.8 quattro	142 kW	2.8 l	10/96→08/01	⊗ ACK / ALG; ↗ 8D-X-199999 ⊗ APR / AQD / AMX; ↗ 8D-X-200001→			5DA 749 475-471 Ignition Coil	39
S4 quattro	195 kW	2.7 l	09/97→09/01				5DA 006 623-591 Switch Unit, ignition system	7
							5DA 358 000-051 Ignition Coil	32
AUDI - A4 Saloon (8EC, B7)								11/04→06/08
1.6	75 kW	1.6 l	11/04→06/08				5DA 358 000-171 Ignition Coil	33
1.8 T	120 kW	1.8 l	11/04→06/08	⊗ BFB; ↗ 8E-1-000001→; →Model 2008; 4x			5DA 193 175-911 Ignition Coil	27
1.8 T quattro	120 kW	1.8 l	11/04→06/08					
2.0	96 kW	2 l	11/04→06/08	⊗ ALT; ↗ 8E-5-400001→; →Model 2008; 4x			5DA 193 175-911 Ignition Coil	27
2.0 TFSI	125 kW	2 l	10/06→06/08	⊗ BYK / BPJ; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	147 kW	2 l	11/04→06/08	⊗ BWT / BPG / BGB / BWE; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	162 kW	2 l	06/05→06/08	⊗ BUL; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI quattro	162 kW	2 l	06/05→06/08					
2.0 TFSI quattro	147 kW	2 l	11/04→06/08	⊗ BWE / BPG / BGB / BWT; 4			5DA 193 175-921 Ignition Coil	28
3.0 quattro	160 kW	3 l	11/04→07/06	⊗ BBJ; ↗ 8E-5-400001→; 6x			5DA 193 175-701 Ignition Coil	21
RS4 quattro	309 kW	4.2 l	09/05→06/08	⊗ BNS; 8			5DA 193 175-921 Ignition Coil	28
S4 quattro	253 kW	4.2 l	11/04→06/08	⊗ BBK; →Model 2008; 8x			5DA 193 175-591 Ignition Coil	18
AUDI - A4 Saloon (8K2, B8)								11/07→
1.8 TFSI	88 kW	1.8 l	01/08→	⊗ CDHA / CABA; 4			5DA 193 175-921 Ignition Coil	28
1.8 TFSI	118 kW	1.8 l	11/07→	⊗ CABB / CDHB; 4			5DA 193 175-921 Ignition Coil	28
1.8 TFSI quattro	118 kW	1.8 l	09/08→	⊗ CDHB; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	132 kW	2 l	06/08→	⊗ CFKA / CDNB / CAEA; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	155 kW	2 l	06/08→	⊗ CAEB / CDNC; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI	162 kW	2 l	05/13→	⊗ CAED; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI flexible fuel	132 kW	2 l	11/09→	⊗ CFKA; 4			5DA 193 175-921 Ignition Coil	28
2.0 TFSI flexible fuel quattro	132 kW	2 l	11/09→					

AUDI - A4 Saloon (8K2, B8)													11/07→		
2.0 TFSI quattro	155 kW	2 l	06/08→	CPMA / CAEB / CDNC; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	162 kW	2 l	05/13→	CPMB / CAED; 4	5DA 193 175-921	Ignition Coil	28								
AUDI - A5 (8T3)													10/07→		
1.8 TFSI	118 kW	1.8 l	05/09→	CDHB; 4	5DA 193 175-921	Ignition Coil	28								
1.8 TFSI	125 kW	1.8 l	10/07→	CABD; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	132 kW	2 l	11/08→	CDNB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	155 kW	2 l	06/08→	CDNC; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	155 kW	2 l	06/08→	CDNC / CAEB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	162 kW	2 l	03/12→	CPMB / CAED; 4	5DA 193 175-921	Ignition Coil	28								
RS 5 quattro	331 kW	4.2 l	03/10→	CFSA; 8	5DA 193 175-921	Ignition Coil	28								
AUDI - A5 Convertible (8F7)													03/09→		
1.8 TFSI	118 kW	1.8 l	09/09→	CDHB; 4	5DA 193 175-921	Ignition Coil	28								
1.8 TFSI	125 kW	1.8 l	10/11→	CABD; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	132 kW	2 l	03/09→	CAEA; 4	5DA 193 175-921	Ignition Coil	28								
				CDNB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	155 kW	2 l	03/09→	CAEB / CDNC; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	155 kW	2 l	03/09→												
2.0 TFSI	162 kW	2 l	05/13→	CAED; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	162 kW	2 l	03/12→	CPMB; 4	5DA 193 175-921	Ignition Coil	28								
RS 5 quattro	331 kW	4.2 l	02/13→	CFSA; 8	5DA 193 175-921	Ignition Coil	28								
AUDI - A5 Sportback (8TA)													09/09→		
1.8 TFSI	118 kW	1.8 l	11/09→	CDHB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	132 kW	2 l	09/09→	CDNB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	155 kW	2 l	09/09→	CDNC; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	155 kW	2 l	09/09→												
AUDI - A6 (4G2, C7, 4GC)													03/11→05/13		
2.0 TFSI	132 kW	2 l	05/11→	CDNB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI	155 kW	2 l	03/11→05/13	CAEB; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	155 kW	2 l	05/12→05/13												
2.0 TFSI	162 kW	2 l	05/13→	CAED; 4	5DA 193 175-921	Ignition Coil	28								
2.0 TFSI quattro	162 kW	2 l	05/13→												
2.0 TFSI hybrid	155 kW	2 l	11/11→	CHJA; 4	5DA 193 175-921	Ignition Coil	28								
AUDI - A6 Avant (4A, C4)													06/94→12/97		
1.8	92 kW	1.8 l	12/95→12/97	ADR	5DA 749 475-351	Ignition Coil	38								
1.8 quattro	92 kW	1.8 l	12/95→12/97												
2.6	110 kW	2.6 l	06/94→12/97	ACK	5DA 006 623-591	Switch Unit, ignition system	7								
2.6 quattro	110 kW	2.6 l	06/94→12/97												
2.8	128 kW	2.8 l	06/94→12/97												
2.8 quattro	128 kW	2.8 l	06/94→12/97												
S6 Turbo quattro	169 kW	2.2 l	06/94→12/97												
2.8	142 kW	2.8 l	12/95→12/97	ACK	5DA 749 475-471	Ignition Coil	39								
2.8 quattro	142 kW	2.8 l	12/95→12/97												
S6 Plus quattro	240 kW	4.2 l	04/96→12/97	AHK; +Model 1997	5DA 006 623-771	Switch Unit, ignition system	8								
								5DA 358 000-051	Ignition Coil	32					

AUDI - A6 Avant (4B5, C5)				12/97→01/05	
1.8	92 kW	1.8 l	12/97→01/05	⊗ AJP / AQE / ARH; →Model 2001; 4x	5DA 193 175-981 Ignition Coil 30
1.8 T	110 kW	1.8 l	12/97→01/05	⊗ AEB; →Model 2001	5DA 006 623-771 Switch Unit, ignition system 8
				⊗ AWT; 4x	5DA 193 175-911 Ignition Coil 27
				⊗ ANB / AEB / APU	5DA 358 000-051 Ignition Coil 32
1.8 T	132 kW	1.8 l	04/99→01/05		5DA 358 000-051 Ignition Coil 32
1.8 T quattro	132 kW	1.8 l	12/97→01/05		5DA 358 000-051 Ignition Coil 32
1.8 T quattro	110 kW	1.8 l	12/97→01/05	⊗ AEB; →Model 2001	5DA 006 623-771 Switch Unit, ignition system 8
				⊗ AWT; 4x	5DA 193 175-911 Ignition Coil 27
				⊗ APU / AEB / ANB	5DA 358 000-051 Ignition Coil 32
2.0	96 kW	2 l	08/01→01/05	⊗ ALT; →4B-5-050000; 4x	5DA 193 175-701 Ignition Coil 21
2.4	100 kW	2.4 l	07/98→01/05	⊗ ALW; →Model 2001 ⊗ ASM; Model 2002→	5DA 749 475-471 Ignition Coil 39
2.4	120 kW	2.4 l	12/97→01/05	⊗ AJG; Model 1998→Model 2001 ⊗ AMM; Model 2002→	5DA 749 475-471 Ignition Coil 39
2.4	121 kW	2.4 l	12/97→01/05	⊗ AGA / ALF; →Model 2001	5DA 749 475-471 Ignition Coil 39
2.4	125 kW	2.4 l	08/01→01/05	⊗ BDV	5DA 749 475-471 Ignition Coil 39
2.4 quattro	125 kW	2.4 l	08/01→01/05		5DA 749 475-471 Ignition Coil 39
2.4 quattro	115 kW	2.4 l	08/98→05/01	⊗ APC	5DA 749 475-471 Ignition Coil 39
2.4 quattro	120 kW	2.4 l	12/97→01/05	⊗ AJG / APZ; →Model 2001	5DA 749 475-471 Ignition Coil 39
2.4 quattro	121 kW	2.4 l	12/97→01/05	⊗ AGA / ALF / AML / APS / ARJ; →Model 2001	5DA 749 475-471 Ignition Coil 39
2.7 T	169 kW	2.7 l	02/99→01/05		5DA 006 623-591 Switch Unit, ignition system 7
2.7 T quattro	169 kW	2.7 l	12/97→01/05		5DA 358 000-051 Ignition Coil 32
2.7 T quattro	184 kW	2.7 l	08/01→01/05	⊗ BES; 6x	5DA 193 175-911 Ignition Coil 27
				⊗ ARE	5DA 358 000-051 Ignition Coil 32
2.8	132 kW	2.8 l	12/97→05/00	⊗ AGE	5DA 749 475-471 Ignition Coil 39
2.8	142 kW	2.8 l	12/97→01/05	⊗ ACK / ALG; →Model 2001	5DA 749 475-471 Ignition Coil 39
2.8 quattro	142 kW	2.8 l	12/97→01/05	⊗ ACK / ALG / AMX / APR / AQD; →Model 2001	5DA 749 475-471 Ignition Coil 39
3.0	162 kW	3 l	08/01→01/05	⊗ ASN; →4B-5-050000; 6x	5DA 193 175-701 Ignition Coil 21
3.0 quattro	162 kW	3 l	08/01→01/05		5DA 193 175-701 Ignition Coil 21
4.2 quattro	220 kW	4.2 l	11/98→01/05	⊗ ARS / ASG; 8x	5DA 193 175-981 Ignition Coil 30
RS6 plus quattro	353 kW	4.2 l	04/04→01/05	⊗ BRV; 8x	5DA 193 175-981 Ignition Coil 30
RS6 quattro	331 kW	4.2 l	07/02→01/05	⊗ BCY; 8x	5DA 193 175-981 Ignition Coil 30
S6 quattro	250 kW	4.2 l	09/99→01/05	⊗ AQJ / ANK; 8x	5DA 193 175-981 Ignition Coil 30
AUDI - A6 Avant (4F5, C6)				03/05→08/11	
2.0 TFSI	125 kW	2 l	06/05→08/11	⊗ BPJ; 4	5DA 193 175-921 Ignition Coil 28
3.0	160 kW	3 l	03/05→05/06	⊗ BBJ; →4F-5-000001→; 6x	5DA 193 175-701 Ignition Coil 21
3.0 quattro	160 kW	3 l	03/05→05/06		5DA 193 175-701 Ignition Coil 21
4.2 quattro	246 kW	4.2 l	03/05→05/06	⊗ BAT; →4F-5-000001→4F-6-250000; 8x	5DA 193 175-591 Ignition Coil 18
AUDI - A6 Avant (4G5, C7, 4GD)				06/11→	
2.0 TFSI	132 kW	2 l	06/11→	⊗ CDN; 4	5DA 193 175-921 Ignition Coil 28
AUDI - A6 Saloon (4A, C4)				06/94→10/97	
1.8	92 kW	1.8 l	12/95→10/97	⊗ ADR	5DA 749 475-351 Ignition Coil 38
1.8 quattro	92 kW	1.8 l	12/95→10/97		5DA 749 475-351 Ignition Coil 38

				13	i	412		
AUDI - A6 Saloon (4A, C4)								06/94→10/97
2.0 16V	103 kW	2 l	06/94→10/97				5DA 006 623-331 Switch Unit, ignition system	6
2.0 16V quattro	103 kW	2 l	06/94→10/97					
2.3	98 kW	2.3 l	06/94→12/95					
2.3 quattro	98 kW	2.3 l	06/94→12/95	08/94→06/95			5DA 006 623-331 Switch Unit, ignition system	6
2.6	110 kW	2.6 l	06/94→10/97					
2.6 quattro	110 kW	2.6 l	06/94→10/97				5DA 006 623-591 Switch Unit, ignition system	7
2.8	128 kW	2.8 l	06/94→10/97					
2.8 quattro	128 kW	2.8 l	06/94→10/97					
S6 Turbo quattro	169 kW	2.2 l	06/94→10/97					
2.8	142 kW	2.8 l	12/95→10/97		ACK		5DA 749 475-471 Ignition Coil	39
2.8 quattro	142 kW	2.8 l	12/95→10/97					
S6 Plus quattro	240 kW	4.2 l	04/96→10/97		AHK; +Model 1997		5DA 006 623-771 Switch Unit, ignition system	8
							5DA 358 000-051 Ignition Coil	32
AUDI - A6 Saloon (4B2, C5)								01/97→01/05
1.8	92 kW	1.8 l	07/97→01/05		AJP / AQE / ARH; →Model 2001; 4x		5DA 193 175-981 Ignition Coil	30
1.8 T	110 kW	1.8 l	01/97→01/05		AEB; Model 1998→Model 2001		5DA 006 623-771 Switch Unit, ignition system	8
							5DA 193 175-911 Ignition Coil	27
							5DA 358 000-051 Ignition Coil	32
1.8 T	132 kW	1.8 l	12/97→01/05				5DA 358 000-051 Ignition Coil	32
1.8 T quattro	132 kW	1.8 l	12/97→01/05					
1.8 T quattro	110 kW	1.8 l	02/97→01/05		AEB; Model 1998→Model 2001		5DA 006 623-771 Switch Unit, ignition system	8
							5DA 193 175-911 Ignition Coil	27
							5DA 358 000-051 Ignition Coil	32
2.0	96 kW	2 l	08/01→01/05		ALT; →4B-5-050000; 4x		5DA 193 175-701 Ignition Coil	21
2.4	100 kW	2.4 l	07/98→01/05		ALW; →Model 2001		5DA 749 475-471 Ignition Coil	39
							5DA 749 475-471 Ignition Coil	39
2.4	120 kW	2.4 l	02/97→01/05		AJG; Model 1998→Model 2001		5DA 749 475-471 Ignition Coil	39
							5DA 749 475-471 Ignition Coil	39
2.4	121 kW	2.4 l	02/97→01/05		AGA / ALF; Model 1998→Model 2001		5DA 749 475-471 Ignition Coil	39
2.4	125 kW	2.4 l	08/01→01/05		BDV		5DA 749 475-471 Ignition Coil	39
2.4 quattro	125 kW	2.4 l	08/01→01/05					
2.4 quattro	115 kW	2.4 l	08/98→07/99		APC		5DA 749 475-471 Ignition Coil	39
2.4 quattro	120 kW	2.4 l	02/97→01/05		AJG / APZ; Model 1998→Model 2001		5DA 749 475-471 Ignition Coil	39
2.4 quattro	121 kW	2.4 l	02/97→01/05		AGA / ALF / AML / APS / ARJ; Model 1998→Model 2001		5DA 749 475-471 Ignition Coil	39
2.7 T	169 kW	2.7 l	02/99→01/05				5DA 006 623-591 Switch Unit, ignition system	7
2.7 T quattro	169 kW	2.7 l	12/97→01/05				5DA 358 000-051 Ignition Coil	32
2.7 T quattro	184 kW	2.7 l	08/01→01/05		BES; 6x		5DA 193 175-911 Ignition Coil	27
							5DA 358 000-051 Ignition Coil	32
2.8	132 kW	2.8 l	10/97→05/00		AGE		5DA 749 475-471 Ignition Coil	39
2.8	142 kW	2.8 l	02/97→01/05		ACK / ALG; Model 1998→Model 2001		5DA 749 475-471 Ignition Coil	39
2.8 quattro	142 kW	2.8 l	02/97→01/05		ACK / ALG / AMX / APR / AQD; Model 1998→Model 2001		5DA 749 475-471 Ignition Coil	39
3.0	162 kW	3 l	08/01→01/05					
3.0 quattro	162 kW	3 l	08/01→01/05		ASN; →4B-5-050000; 6x		5DA 193 175-701 Ignition Coil	21
4.2 quattro	220 kW	4.2 l	11/98→01/05		ARS / ASG; 8x		5DA 193 175-981 Ignition Coil	30
RS6 quattro	331 kW	4.2 l	07/02→01/05		BCY; 8x		5DA 193 175-981 Ignition Coil	30
S6 quattro	250 kW	4.2 l	09/99→01/05		AQJ / ANK; 8x		5DA 193 175-981 Ignition Coil	30

AUDI - A6 Saloon (4F2, C6)						05/04→03/11
2.0 TFSI	125 kW	2 l	06/05→03/11	⊗ BPJ / BYK; 4	5DA 193 175-921 Ignition Coil	28
3.0 quattro	160 kW	3 l	05/04→05/06	⊗ BBJ; ⚡ 4F-5-000001→; 6x	5DA 193 175-701 Ignition Coil	21
4.2 quattro	246 kW	4.2 l	05/04→05/06	⊗ BAT; ⚡ 4F-5-000001→4F-6-250000; 8x	5DA 193 175-591 Ignition Coil	18
AUDI - A8 (4H_)						02/12→
2.0 TFSI hybrid	155 kW	2 l	02/12→	⊗ CHJA; 4	5DA 193 175-921 Ignition Coil	28
AUDI - A8 Saloon (4D2, 4D8)						03/94→09/02
2.8	128 kW	2.8 l	03/94→03/96		5DA 006 623-591 Switch Unit, ignition system	7
2.8 quattro	128 kW	2.8 l	03/94→03/96			
2.8	142 kW	2.8 l	04/96→09/02	⊗ ACK / ALG; ⚡ →4D-X-004999 ⊗ AMX / APR / AQD; ⚡ 4D-X-005001→	5DA 749 475-471 Ignition Coil	39
2.8 quattro	142 kW	2.8 l	04/96→09/02	⊗ ACK; ⚡ →4D-X-004999 ⊗ AMX / APR / AQD; ⚡ 4D-X-005001→	5DA 749 475-471 Ignition Coil	39
3.7	169 kW	3.7 l	07/95→12/98	⊗ AEW; 2x	5DA 006 623-771 Switch Unit, ignition system	8
					5DA 358 000-051 Ignition Coil	32
3.7	191 kW	3.7 l	11/98→09/02	⊗ AKC / AQG; 8x	5DA 193 175-981 Ignition Coil	30
3.7 quattro	169 kW	3.7 l	07/95→11/98	⊗ AEW / AKJ; 2x	5DA 006 623-771 Switch Unit, ignition system	8
					5DA 358 000-051 Ignition Coil	32
3.7 quattro	191 kW	3.7 l	11/98→09/02	⊗ AKC / AQG; ⚡ 4D-X-005001→; 8x	5DA 193 175-981 Ignition Coil	30
4.2 quattro	175 kW	4.2 l	02/99→04/00	⊗ ARU; 8x	5DA 193 175-981 Ignition Coil	30
4.2 quattro	180 kW	4.2 l	03/94→07/96		5DA 358 000-051 Ignition Coil	32
4.2 quattro	220 kW	4.2 l	03/94→11/98	⊗ AKG; 2x	5DA 006 623-771 Switch Unit, ignition system	8
				⊗ ABZ; ⚡ 4D-X-005001→; 8x	5DA 193 175-981 Ignition Coil	30
					5DA 358 000-051 Ignition Coil	32
4.2 quattro	228 kW	4.2 l	11/98→09/02	⊗ AQF / AUW; ⚡ 4D-X-005001→; 8x	5DA 193 175-981 Ignition Coil	30
S 8 quattro	250 kW	4.2 l	07/96→06/99	⊗ AKH; 2x	5DA 006 623-771 Switch Unit, ignition system	8
					5DA 358 000-051 Ignition Coil	32
S 8 quattro	265 kW	4.2 l	06/99→09/02	⊗ AQH / AVP; 8x	5DA 193 175-981 Ignition Coil	30
AUDI - A8 Saloon (4E_)						10/02→07/10
3.0	160 kW	3 l	07/03→05/06	⊗ BBJ; →Model 2007; 6x	5DA 193 175-701 Ignition Coil	21
3.0	162 kW	3 l	07/03→05/05	⊗ ASN; →Model 2007; 6x	5DA 193 175-701 Ignition Coil	21
3.7 quattro	206 kW	3.7 l	10/02→05/06	⊗ BFL; ⚡ →4E-6-030000; 8x	5DA 193 175-591 Ignition Coil	18
4.2 quattro	246 kW	4.2 l	10/02→07/10	⊗ BFM; ⚡ →4E-6-030000; 8x	5DA 193 175-591 Ignition Coil	18
AUDI - ALLROAD Estate (4BH, C5)						05/00→08/05
2.7 T quattro	184 kW	2.7 l	05/00→08/05	⊗ BES; 6x	5DA 193 175-911 Ignition Coil	27
				⊗ ARE	5DA 358 000-051 Ignition Coil	32
4.2 V8 quattro	220 kW	4.2 l	07/02→08/05	⊗ BAS; 8x	5DA 193 175-591 Ignition Coil	18
AUDI - CABRIOLET (8G7, B4)						05/91→08/00
1.8	92 kW	1.8 l	01/97→08/00	⊗ ADR	5DA 749 475-351 Ignition Coil	38
1.9 TDI	66 kW	1.9 l	06/95→08/00	⊗ 1Z / AHU; ⚡ →8G-P-015000	5DA 006 623-951 Ignition Coil	9
2.0 16V	103 kW	2 l	06/95→07/96		5DA 006 623-331 Switch Unit, ignition system	6
2.3 E	98 kW	2.3 l	05/91→07/94			

AUDI - CABRIOLET (8G7, B4)						05/91→08/00
2.0 E	85 kW	2 l	01/93→07/98	⊗ ABK; →8G-P-015000	5DA 006 623-951 Ignition Coil	9
2.6	110 kW	2.6 l	06/93→08/00	01/94→	5DA 006 623-591 Switch Unit, ignition system	7
2.8	128 kW	2.8 l	11/92→08/00		5DA 006 623-591 Switch Unit, ignition system	7
AUDI - COUPE (81, 85)						07/80→10/88
1.6	55 kW	1.6 l	07/80→08/81	04/81→07/81	5DA 006 623-931 Switch Unit, ignition system	8
1.8	55 kW	1.8 l	08/81→07/83	→07/82	5DA 006 623-931 Switch Unit, ignition system	8
1.8 GT	65 kW	1.8 l	04/86→10/88	→07/88	5DA 006 623-931 Switch Unit, ignition system	8
1.8 GT	82 kW	1.8 l	08/86→10/88			
2.3	100 kW	2.3 l	01/87→10/88		5DA 006 623-931 Switch Unit, ignition system	8
1.8 GT	66 kW	1.8 l	09/82→10/88	→07/88		
1.8 GT	68 kW	1.8 l	01/85→07/88		5DA 006 623-941 Switch Unit, ignition system	9
1.8 GT	79 kW	1.8 l	08/86→10/87		5DA 006 623-931 Switch Unit, ignition system	8
1.9	85 kW	1.9 l	08/80→07/83			
2.0	85 kW	2 l	09/83→07/86		5DA 006 623-931 Switch Unit, ignition system	8
2.0	83 kW	2 l	03/86→04/88	→07/86		
2.1 GT	96 kW	2.1 l	09/82→10/87	→08/84	5DA 006 623-931 Switch Unit, ignition system	8
2.2 GT	85 kW	2.2 l	07/81→10/87	01/84→	5DA 006 623-931 Switch Unit, ignition system	8
				10/86→	5DA 006 623-941 Switch Unit, ignition system	9
2.2 GT	100 kW	2.2 l	09/84→10/88	→07/88	5DA 006 623-931 Switch Unit, ignition system	8
				10/86→	5DA 006 623-941 Switch Unit, ignition system	9
2.2 quattro	88 kW	2.2 l	08/85→10/88	→12/87	5DA 006 623-931 Switch Unit, ignition system	8
2.2 quattro	100 kW	2.2 l	10/84→10/88	12/84→12/87	5DA 006 623-931 Switch Unit, ignition system	8
				12/84→	5DA 006 623-941 Switch Unit, ignition system	9
AUDI - COUPE (89, 8B)						11/88→12/96
1.8	82 kW	1.8 l	08/89→07/91		5DA 006 623-931 Switch Unit, ignition system	8
					5DA 006 623-941 Switch Unit, ignition system	9
2.0	85 kW	2 l	05/89→12/96	⊗ ABK; →06/94	5DA 006 623-951 Ignition Coil	9
2.0 16 V	103 kW	2 l	08/92→12/96	→12/95	5DA 006 623-331 Switch Unit, ignition system	6
2.2 quattro	100 kW	2.2 l	11/88→07/91		5DA 006 623-931 Switch Unit, ignition system	8
2.6	110 kW	2.6 l	08/92→12/96		5DA 006 623-591 Switch Unit, ignition system	7
2.6 quattro	110 kW	2.6 l	08/92→12/96			
2.8	128 kW	2.8 l	09/91→12/96		5DA 006 623-931 Switch Unit, ignition system	8
2.8 quattro	128 kW	2.8 l	08/91→12/96			
AUDI - Q3 (8U)						06/11→
2.0 TFSI quattro	125 kW	2 l	06/11→	⊗ CCZC; 4	5DA 193 175-921 Ignition Coil	28
2.0 TFSI quattro	155 kW	2 l	06/11→	⊗ CPSA; 4	5DA 193 175-921 Ignition Coil	28
RS 2.5 quattro	228 kW	2.5 l	10/13→	⊗ CTSA; 5	5DA 193 175-921 Ignition Coil	28
AUDI - Q5 (8R)						11/08→
2.0 TFSI hybrid quattro	155 kW	2 l	06/11→	⊗ CHJA; 4	5DA 193 175-921 Ignition Coil	28
2.0 TFSI quattro	132 kW	2 l	08/09→	⊗ CDNB; 4	5DA 193 175-921 Ignition Coil	28
2.0 TFSI quattro	155 kW	2 l	11/08→	⊗ CAEB / CDNC / CPMA; 4	5DA 193 175-921 Ignition Coil	28

AUDI - Q5 (8R)							11/08→
2.0 TFSI quattro	162 kW	2 l	05/13→	CPMB; 4	5DA 193 175-921 Ignition Coil	28	
AUDI - QUATTRO (85)							07/80→07/87
2.1 Turbo	147 kW	2.1 l	07/80→07/87	GV	5DA 006 623-931 Switch Unit, ignition system	8	
AUDI - R8							11/10→07/15
5.2 FSI quattro	412 kW	5.2 l	11/10→07/15	CMPA; 10	5DA 193 175-921 Ignition Coil	28	
AUDI - R8 Spyder							11/11→07/15
5.2 FSI quattro	412 kW	5.2 l	11/11→07/15	CMPA; 10	5DA 193 175-921 Ignition Coil	28	
AUDI - TT (8J3)							08/06→06/14
1.8 TFSI	118 kW	1.8 l	06/08→06/14	CDA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI	147 kW	2 l	08/06→06/10	BWA / BPY / CCTA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI	155 kW	2 l	05/10→06/14	CESA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI quattro	147 kW	2 l	06/08→06/10	CCZA / BWA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI quattro	155 kW	2 l	05/10→06/14	CETA / CESA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TTS quattro	195 kW	2 l	05/08→06/14	CDLA / CDMA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TTS quattro	200 kW	2 l	05/08→06/14	CDLB; 4	5DA 193 175-921 Ignition Coil	28	
2.5 RS quattro	250 kW	2.5 l	07/09→06/14	CEPA; 5	5DA 193 175-921 Ignition Coil	28	
2.5 RS quattro	265 kW	2.5 l	05/11→06/14	CEPB; 5	5DA 193 175-921 Ignition Coil	28	
AUDI - TT (8N3)							10/98→06/06
1.8 T	110 kW	1.8 l	09/02→06/06	AUM; 8N-1-010001→; 4x	5DA 193 175-911 Ignition Coil	27	
				AUM; 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil	30	
1.8 T	120 kW	1.8 l	09/05→06/06	BVP; 8N-5-004501→; 4x	5DA 193 175-911 Ignition Coil	27	
1.8 T	132 kW	1.8 l	10/98→06/06	ATC / APP / AUQ / AJQ; 8N-1-010001→; 4x	5DA 193 175-911 Ignition Coil	27	
				AJQ / APP / ATC / AUQ; 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil	30	
1.8 T	140 kW	1.8 l	09/05→06/06	BVR; 8N-5-004501→; 4x	5DA 193 175-911 Ignition Coil	27	
1.8 T quattro	140 kW	1.8 l	09/05→06/06				
1.8 T quattro	132 kW	1.8 l	10/98→06/06	AJQ / ARY; 8N-1-010001→; 4x	5DA 193 175-911 Ignition Coil	27	
				AJQ / ARY; 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil	30	
1.8 T quattro	165 kW	1.8 l	10/98→06/06	APX / BAM; 8N-1-010001→; 4x	5DA 193 175-911 Ignition Coil	27	
				APX / BAM; 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil	30	
1.8 T quattro	176 kW	1.8 l	03/05→06/06	BFV; 8N-5-004501→; 4x	5DA 193 175-911 Ignition Coil	27	
AUDI - TT Roadster (8J9)							03/07→06/14
1.8 TFSI	118 kW	1.8 l	06/08→06/14	CDA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI	147 kW	2 l	03/07→06/10	BWA / CCTA / BPY; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI	155 kW	2 l	05/10→06/14	CESA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI quattro	147 kW	2 l	06/08→06/10	CCZA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TFSI quattro	155 kW	2 l	05/10→06/14	CETA / CESA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TTS quattro	195 kW	2 l	05/08→06/14	CDLA / CDMA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TTS quattro	200 kW	2 l	05/08→06/14	CDLB; 4	5DA 193 175-921 Ignition Coil	28	

		13	i	412	
AUDI - TT Roadster (8J9)					03/07 → 06/14
2.5 RS quattro	250 kW	2.5 l	07/09 → 06/14	⊗ CEPA; 5	5DA 193 175-921 Ignition Coil 28
2.5 RS quattro	265 kW	2.5 l	03/12 → 06/14	⊗ CEPB; 5	5DA 193 175-921 Ignition Coil 28
AUDI - TT Roadster (8N9)					10/99 → 06/06
1.8 T	110 kW	1.8 l	01/01 → 06/06	⊗ AUM; 8N-1-010001 →	5DA 193 175-911 Ignition Coil 27
				⊗ AUM; → 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil 30
1.8 T	120 kW	1.8 l	09/05 → 06/06	⊗ BVP; 8N-5-004501 →; 4x	5DA 193 175-911 Ignition Coil 27
1.8 T	132 kW	1.8 l	10/99 → 06/06	⊗ APP / AJQ / AUQ; 8N-1-010001 →; 4x	5DA 193 175-911 Ignition Coil 27
				⊗ AJQ / APP / AUQ; → 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil 30
1.8 T	140 kW	1.8 l	09/05 → 06/06	⊗ BVR; 8N-5-004501 →; 4x	5DA 193 175-911 Ignition Coil 27
1.8 T quattro	140 kW	1.8 l	09/05 → 06/06		
1.8 T quattro	132 kW	1.8 l	02/00 → 06/06	⊗ AJQ / ARY; 8N-1-010001 →; 4x	5DA 193 175-911 Ignition Coil 27
				⊗ AJQ / ARY; → 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil 30
1.8 T quattro	165 kW	1.8 l	10/99 → 06/06	⊗ APX / BAM; 8N-1-010001 →; → Model 2002; 4x	5DA 193 175-911 Ignition Coil 27
				⊗ APX / BAM; → 8N-1-010000; 4x	5DA 193 175-981 Ignition Coil 30

AUTOBIANCHI - A 112							01/74→12/85
1.0 Abarth	51 kW	1 l	01/74→12/84	01/79→02/84	5DA 006 623-051 Switch		4
1.0 E,Elite,LX	35 kW	1 l	11/77→12/85		Unit, ignition system		



				13	i	412		
BMW - 1 (E81)								09/06→09/12
116 i	85 kW	1.6 l	03/07→09/12	⊗ N45 B16 A; 4x	5DA 193 175-491	Ignition	15	
				⊗ N43 B16 A; 4	5DA 193 175-711	Ignition	21	
					Coil			
116 i	89 kW	1.6 l	08/07→09/12	⊗ N43 B16 A; 4	5DA 193 175-711	Ignition	21	
116 i	90 kW	1.6 l	03/07→09/12		Coil			
116 i	90 kW	2 l	11/08→09/12	⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
120 i	120 kW	2 l	09/06→09/12		Coil			
120 i	125 kW	2 l	09/06→09/12					
118 i	105 kW	2 l	09/06→09/12	4x	5DA 193 175-491	Ignition	15	
					Coil			
				⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
					Coil			
130 i	190 kW	3 l	09/06→09/12	⊗ N52 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
130 i	195 kW	3 l	09/06→09/12	⊗ N52 B30 B / N52 B30 A / N52 B30 BF; 6x	5DA 193 175-491	Ignition	15	
					Coil			
BMW - 1 (E87)								11/03→09/12
116 i	85 kW	1.6 l	11/03→09/12	⊗ N43 B16 A; 4	5DA 193 175-711	Ignition	21	
116 i	89 kW	1.6 l	08/07→09/12		Coil			
116 i	90 kW	1.6 l	11/03→09/12	⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
					Coil			
				⊗ N43 B16 A; 4	5DA 193 175-711	Ignition	21	
					Coil			
118 d	90 kW	2 l	11/03→09/12	⊗ M47 D20 (204D4); 4	5DA 193 175-711	Ignition	21	
118 d	100 kW	2 l	11/03→09/12		Coil			
118 d	105 kW	2 l	11/03→09/12					
118 i	95 kW	2 l	07/04→09/12	⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
118 i	105 kW	2 l	07/04→09/12		Coil			
120 i	125 kW	2 l	02/07→09/12					
120 i	110 kW	2 l	11/03→09/12	⊗ N46 B20 BD; 4	5DA 193 175-711	Ignition	21	
120 i	115 kW	2 l	11/03→09/12		Coil			
120 i	120 kW	2 l	11/03→09/12	⊗ N46 B20 BD; 4	5DA 193 175-711	Ignition	21	
					Coil			
				⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
					Coil			
BMW - 1 (F20)								08/11→
125 i	160 kW	2 l	08/11→	⊗ N20 B20 A; 4x	5DA 193 175-491	Ignition	15	
					Coil			
M 135 i	235 kW	3 l	11/11→	⊗ N55 B30 A; 6x	5DA 193 175-491	Ignition	15	
M 135 i xDrive	235 kW	3 l	02/12→		Coil			
BMW - 1 Convertible (E88)								03/08→
118 i	105 kW	2 l	03/08→	⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
120 i	120 kW	2 l	03/08→		Coil			
120 i	125 kW	2 l	03/08→					
120 i	115 kW	2 l	03/08→	⊗ N46 B20 B / N46 B20 C; 4x	5DA 193 175-491	Ignition	15	
					Coil			
123 d	150 kW	2 l	09/08→	⊗ N47 D20 D; 4	5DA 193 175-711	Ignition	21	
					Coil			
125 i	160 kW	3 l	03/08→	⊗ N52 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
135 i	225 kW	3 l	03/08→	⊗ N54 B30 A / N55 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
135 i	240 kW	3 l	03/08→	⊗ N55 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
BMW - 1 Coupe (E82)								10/07→06/12
120 i	125 kW	2 l	10/07→	⊗ N43 B20 A; 4	5DA 193 175-711	Ignition	21	
					Coil			
125 i	160 kW	3 l	10/07→	⊗ N52 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
135 i	225 kW	3 l	10/07→	⊗ N54 B30 A / N55 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
M	250 kW	3 l	04/11→06/12	⊗ N54 B30 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			
BMW - 3 (F30, F35, F80)								10/11→
320 i	135 kW	2 l	02/12→	⊗ N20 B20 A; 4x	5DA 193 175-491	Ignition	15	
320 i xDrive	135 kW	2 l	11/11→		Coil			
328 i	180 kW	2 l	10/11→	⊗ N26 B20 A / N20 B20 A; 6x	5DA 193 175-491	Ignition	15	
					Coil			

BMW - 3 (F30, F35, F80)							10/11→
328 i xDrive	180 kW	2 l	10/11→	⊗ N20 B20 A; 6x	5DA 193 175-491 Ignition Coil	15	
335 i	225 kW	3 l	10/11→	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
335 i xDrive	225 kW	3 l	10/11→				
ActiveHybrid	250 kW	3 l	01/12→				
BMW - 3 Compact (E36)							03/94→08/00
316 g	75 kW	1.6 l	03/94→08/00		5DA 193 175-641 Ignition Coil	19	
316 i	75 kW	1.6 l	03/94→08/00				
316 i	77 kW	1.9 l	12/98→08/00				
318 ti	103 kW	1.8 l	11/94→08/95				
318 ti	103 kW	1.9 l	07/95→08/00				
323 ti	125 kW	2.5 l	08/97→08/00		5DA 193 175-551 Ignition Coil	17	
BMW - 3 Compact (E46)							06/01→02/05
316 ti	85 kW	1.6 l	06/02→02/05	⊗ N45 B16 A / N40 B16 A; 4x	5DA 193 175-491 Ignition Coil	15	
316 ti	85 kW	1.8 l	06/01→02/05	⊗ N46 B18 A; 4x	5DA 193 175-491 Ignition Coil	15	
318 ti	105 kW	2 l	09/01→02/05	4x	5DA 193 175-491 Ignition Coil	15	
325 ti	141 kW	2.5 l	06/01→02/05	⊗ M54 B25 (256S5); 6x; 09/02→	5DA 193 175-491 Ignition Coil	15	
				→09/02	5DA 193 175-551 Ignition Coil	17	
BMW - 3 Convertible (E36)							03/93→04/99
318 i	85 kW	1.8 l	01/94→04/99		5DA 193 175-641 Ignition Coil	19	
320 i	110 kW	2 l	12/93→04/99	⊗ M50 B20 (206S2); →12/95	5DA 193 175-541 Ignition Coil	17	
				⊗ M52 B20 (206S3); 09/94→	5DA 193 175-551 Ignition Coil	17	
323 i	125 kW	2.5 l	06/95→04/99		5DA 193 175-551 Ignition Coil	17	
328 i	142 kW	2.8 l	03/95→04/99				
M3 3.2	236 kW	3.2 l	10/95→04/99				
325 i	141 kW	2.5 l	03/93→03/95		5DA 193 175-541 Ignition Coil	17	
							M3 3.0
BMW - 3 Convertible (E46)							04/00→09/00
318 Ci	105 kW	2 l	09/01→	⊗ N42 B20 A / N46 B20 A; 4x	5DA 193 175-491 Ignition Coil	15	
318 Ci	110 kW	2 l	02/05→	⊗ N46 B20 B; 4x	5DA 193 175-491 Ignition Coil	15	
320 Ci	125 kW	2.2 l	09/00→	⊗ M54 B22 (226S1); 6x; 10/02→	5DA 193 175-491 Ignition Coil	15	
				→09/02	5DA 193 175-551 Ignition Coil	17	
323 Ci	125 kW	2.5 l	04/00→09/00		5DA 193 175-551 Ignition Coil	17	
325 Ci	141 kW	2.5 l	09/00→	⊗ M54 B25 (256S5); 6x; 10/02→	5DA 193 175-491 Ignition Coil	15	
				→09/02	5DA 193 175-551 Ignition Coil	17	
330 Ci	170 kW	3 l	06/00→	⊗ M54 B30 (306S3); 6x; 10/02→	5DA 193 175-491 Ignition Coil	15	
				→09/02	5DA 193 175-551 Ignition Coil	17	
M3 3.2	252 kW	3.2 l	04/01→	⊗ S54 B32 (326S4); 6x	5DA 193 175-491 Ignition Coil	15	
BMW - 3 Convertible (E93)							10/06→
318 i	105 kW	2 l	03/10→	⊗ N43 B20 A; 4	5DA 193 175-711 Ignition Coil	21	
320 i	120 kW	2 l	01/07→				
320 i	125 kW	2 l	03/07→				
320 i	115 kW	2 l	03/07→	4	5DA 193 175-711 Ignition Coil	21	
325 i	160 kW	2.5 l	03/07→	⊗ N52 B25 A; 6x	5DA 193 175-491 Ignition Coil	15	
				⊗ N53 B30 A; 6	5DA 193 175-711 Ignition Coil	21	
325 i	155 kW	3 l	10/06→	⊗ N53 B30 A; 6	5DA 193 175-711 Ignition Coil	21	
330 i	200 kW	3 l	03/07→				

				13	i	412		
BMW - 3 Convertible (E93)								10/06→
330 i	190 kW	3 l	03/07→	⊗ N52N B30 B; 6x		5DA 193 175-491	Ignition	15
						Coil		
335 i	225 kW	3 l	03/07→	⊗ N54 B30 B / N55 B30 A / N54 B30 A; 6x		5DA 193 175-491	Ignition	15
						Coil		
BMW - 3 Coupe (E36)								03/92→04/99
316 i	75 kW	1.6 l	09/93→04/99			5DA 193 175-641	Ignition	19
318 is	103 kW	1.9 l	09/95→04/99			Coil		
318 is	103 kW	1.8 l	03/92→10/95	→09/93		5DA 193 175-541	Ignition	17
						Coil		
				09/93→		5DA 193 175-641	Ignition	19
						Coil		
320 i	110 kW	2 l	03/92→04/99	⊗ M50 B20 (206S2) / M50 B20 (206S1); →12/95		5DA 193 175-541	Ignition	17
						Coil		
				⊗ M52 B20 (206S3); 09/94→		5DA 193 175-551	Ignition	17
						Coil		
323 i	125 kW	2.5 l	03/95→04/99			5DA 193 175-551	Ignition	17
328 i	142 kW	2.8 l	01/95→04/99			Coil		
M3 3.2	236 kW	3.2 l	10/95→04/99					
325 i	141 kW	2.5 l	03/92→04/99	→12/95		5DA 193 175-541	Ignition	17
						Coil		
M3 3.0	210 kW	3 l	10/92→01/95			5DA 193 175-541	Ignition	17
M3 3.0	217 kW	3 l	01/95→10/95			Coil		
BMW - 3 Coupe (E46)								04/99→07/06
316 Ci	77 kW	1.6 l	04/00→07/06			5DA 193 175-641	Ignition	19
318 Ci	87 kW	1.9 l	11/99→09/01			Coil		
316 Ci	85 kW	1.6 l	06/02→07/06	⊗ N45 B16 A; 4x		5DA 193 175-491	Ignition	15
						Coil		
318 Ci	105 kW	2 l	09/01→07/06	4x		5DA 193 175-491	Ignition	15
						Coil		
320 Ci	110 kW	2 l	08/99→09/00			5DA 193 175-551	Ignition	17
323 Ci	125 kW	2.5 l	04/99→09/00			Coil		
328 Ci	142 kW	2.8 l	04/99→06/00					
320 Ci	125 kW	2.2 l	09/00→07/06	⊗ M54 B22 (226S1); 6x; 10/02→		5DA 193 175-491	Ignition	15
						Coil		
325 Ci	141 kW	2.5 l	09/00→07/06	⊗ M54 B25 (256S5); 6x; 10/02→		5DA 193 175-491	Ignition	15
						Coil		
				→09/02		5DA 193 175-551	Ignition	17
						Coil		
330 Ci	170 kW	3 l	06/00→07/06	⊗ M54 B30 (306S3); 6x; 10/02→		5DA 193 175-491	Ignition	15
						Coil		
				→09/02		5DA 193 175-551	Ignition	17
						Coil		
330 xi	170 kW	3 l	06/00→07/06	⊗ M54 B30 (306S3); 6x; 10/02→		5DA 193 175-491	Ignition	15
						Coil		
				⊗ M54 B30 (306S3); →09/02		5DA 193 175-551	Ignition	17
						Coil		
M3 3.2	252 kW	3.2 l	06/00→07/06	⊗ S54 B32 (326S4); 6x		5DA 193 175-491	Ignition	15
M3 CSL	265 kW	3.2 l	06/03→07/06			Coil		
BMW - 3 Coupe (E92)								09/06→06/07
316 i	90 kW	1.6 l	09/07→	⊗ N43 B16 A; 4		5DA 193 175-711	Ignition	21
						Coil		
318 i	105 kW	2 l	03/10→	⊗ N43 B20 A; 4		5DA 193 175-711	Ignition	21
320 i	120 kW	2 l	01/07→			Coil		
320 i	125 kW	2 l	03/07→					
320 i	110 kW	2 l	11/06→06/07	⊗ N46 B20 A / N46N B20 B; 4x		5DA 193 175-491	Ignition	15
						Coil		
320 i	115 kW	2 l	06/07→	4		5DA 193 175-711	Ignition	21
						Coil		
325 i	160 kW	2.5 l	09/06→	⊗ N52 B25 A; 6x		5DA 193 175-491	Ignition	15
325 xi	160 kW	2.5 l	09/06→			Coil		
325 i	155 kW	3 l	07/07→	⊗ N53 B30 A; 6		5DA 193 175-711	Ignition	21
325 i	160 kW	3 l	09/07→			Coil		
325 i xDrive	160 kW	3 l	09/08→					
325 xi	160 kW	3 l	09/07→					
330 i	200 kW	3 l	09/06→					
330 i xDrive	200 kW	3 l	09/08→					
330 i	190 kW	3 l	09/06→	⊗ N52 B30 A; 6x		5DA 193 175-491	Ignition	15
330 xi	200 kW	3 l	09/06→			Coil		
335 i	225 kW	3 l	09/06→	⊗ N54 B30 A / N55 B30 A; 6x		5DA 193 175-491	Ignition	15
						Coil		

BMW - 3 Coupe (E92)						09/06→06/07
335 i xDrive	225 kW	3 l	09/08→	⊗ N55 B30 A / N54 B30 A; 6x	5DA 193 175-491 Ignition	15
335 xi	225 kW	3 l	09/06→		Coil	
BMW - 3 Saloon (E21)						06/75→03/84
315	55 kW	1.6 l	03/81→03/84		5DA 006 623-001 Switch	4
316	66 kW	1.8 l	09/80→08/82		Unit, ignition system	
318 i	77 kW	1.8 l	11/79→08/82	→09/80; SV	5DA 006 623-001 Switch	4
					Unit, ignition system	
320/6	90 kW	2 l	09/77→08/82	09/80→	5DA 006 623-001 Switch	4
					Unit, ignition system	
320 i	92 kW	2 l	06/75→08/82	09/79→; + USA	5DA 006 623-001 Switch	4
					Unit, ignition system	
323 i	105 kW	2.3 l	01/78→08/82	09/80→; + Europe	5DA 006 623-001 Switch	4
					Unit, ignition system	
BMW - 3 Saloon (E30)						09/82→08/87
318 i	77 kW	1.8 l	09/82→08/87	→12/84; + Europe; LHD; for vehicles with catalytic converter	5DA 006 623-001 Switch	4
					Unit, ignition system	
320 i	92 kW	2 l	09/82→12/85	→09/84; + Europe; for vehicles without catalytic converter	5DA 006 623-001 Switch	4
323 i	110 kW	2.3 l	09/83→08/86		Unit, ignition system	
323 i	102 kW	2.3 l	09/82→08/83	+ Europe; for vehicles without catalytic converter	5DA 006 623-001 Switch	4
					Unit, ignition system	
BMW - 3 Saloon (E36)						09/90→02/98
316 i	75 kW	1.6 l	07/93→02/98		5DA 193 175-641 Ignition	19
318 i	85 kW	1.8 l	10/93→02/98		Coil	
318 is	103 kW	1.9 l	09/95→02/98			
318 is	103 kW	1.8 l	03/93→02/98	→09/93	5DA 193 175-541 Ignition	17
					Coil	
				09/93→	5DA 193 175-641 Ignition	19
					Coil	
320 i	110 kW	2 l	09/90→02/98	⊗ M50 B20 (206S1) / M50 B20 (206S2); →12/95	5DA 193 175-541 Ignition	17
					Coil	
				⊗ M52 B20 (206S3); 09/94→	5DA 193 175-551 Ignition	17
					Coil	
323 i 2.5	125 kW	2.5 l	03/95→02/98		5DA 193 175-551 Ignition	17
328 i	142 kW	2.8 l	01/95→02/98		Coil	
M3 3.2	236 kW	3.2 l	09/95→02/98			
325 i	141 kW	2.5 l	09/90→09/95	⊗ M50 B25 (256S1) / M50 B25 (256S2)	5DA 193 175-541 Ignition	17
					Coil	
M3 3.0	210 kW	3 l	08/94→09/95		5DA 193 175-541 Ignition	17
					Coil	
BMW - 3 Saloon (E46)						02/98→02/05
316 i	77 kW	1.6 l	04/00→02/05		5DA 193 175-641 Ignition	19
316 i	77 kW	1.9 l	09/98→02/05		Coil	
318 i	87 kW	1.9 l	02/98→09/01			
316 i	85 kW	1.6 l	06/02→02/05	⊗ N45 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
316 i	85 kW	1.8 l	02/02→02/05	⊗ N42 B18 A / N46 B18 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
318 i	105 kW	2 l	09/01→02/05	4x	5DA 193 175-491 Ignition	15
					Coil	
320 i	110 kW	2 l	03/98→09/00		5DA 193 175-551 Ignition	17
323 i	125 kW	2.5 l	03/98→09/00		Coil	
328 i	142 kW	2.8 l	02/98→06/00			
320 i	125 kW	2.2 l	09/00→02/05	⊗ M54 B22 (226S1); 6x; 09/02→	5DA 193 175-491 Ignition	15
					Coil	
				→09/02	5DA 193 175-551 Ignition	17
					Coil	
325 i	141 kW	2.5 l	09/00→02/05	⊗ M54 B25 (256S5); 6x; 09/02→	5DA 193 175-491 Ignition	15
325 xi	141 kW	2.5 l	09/00→02/05		Coil	
				→09/02	5DA 193 175-551 Ignition	17
					Coil	
330 i	170 kW	3 l	06/00→02/05	⊗ M54 B30 (306S3); 6x; 09/02→	5DA 193 175-491 Ignition	15
330 xi	170 kW	3 l	06/00→02/05		Coil	
				→09/02	5DA 193 175-551 Ignition	17
					Coil	
BMW - 3 Saloon (E90)						01/05→12/11
316 i	85 kW	1.6 l	02/06→12/11	⊗ N45 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
316 i	90 kW	1.6 l	09/07→12/11	⊗ N43 B16 A; 4	5DA 193 175-711 Ignition	21
					Coil	

BMW - 3 Saloon (E90)						01/05→12/11
318 i	95 kW	2 l	09/05→03/07	⊗ N46 B20 B; 4x	5DA 193 175-491 Ignition Coil	15
318 i	105 kW	2 l	09/07→12/11	⊗ N43 B20 A; 4	5DA 193 175-711 Ignition Coil	21
320 i	125 kW	2 l	09/07→12/11			
320 i	110 kW	2 l	01/05→03/07	⊗ N46 B20 A / N46 B20 C / N46 B20 B; 4x	5DA 193 175-491 Ignition Coil	15
320 si	127 kW	2 l	05/06→12/11	⊗ N45 B20 A; 4x	5DA 193 175-491 Ignition Coil	15
325 i	160 kW	2.5 l	01/05→12/11	6x	5DA 193 175-491 Ignition Coil	15
330 i	190 kW	3 l	01/05→08/07			
325 i	160 kW	3 l	09/07→12/11	⊗ N53 B30 A; 6	5DA 193 175-711 Ignition Coil	21
325 i xDrive	160 kW	3 l	09/08→12/11			
325 xi	160 kW	3 l	09/07→12/11			
330 i	200 kW	3 l	09/07→12/11			
330 i xDrive	200 kW	3 l	09/08→12/11			
325 xi	160 kW	2.5 l	01/05→12/11	⊗ N52 B25 A; 6x	5DA 193 175-491 Ignition Coil	15
330 xi	190 kW	3 l	01/05→08/07	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
				⊗ N52 B30 A; 4	5DA 193 175-711 Ignition Coil	21
330 xi	200 kW	3 l	09/07→12/11	⊗ N53 B30 A; 4	5DA 193 175-711 Ignition Coil	21
335 i	225 kW	3 l	09/06→12/11	⊗ N54 B30 A / N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
335 xi	225 kW	3 l	09/07→12/11			
BMW - 3 Touring (E36)						01/95→10/99
316 i	75 kW	1.6 l	01/96→10/99		5DA 193 175-641 Ignition Coil	19
318 i	85 kW	1.8 l	07/95→10/99		5DA 193 175-551 Ignition Coil	17
320 i	110 kW	2 l	01/95→10/99		5DA 193 175-551 Ignition Coil	17
323 i	125 kW	2.5 l	09/95→10/99		5DA 193 175-551 Ignition Coil	17
328 i	142 kW	2.8 l	01/95→10/99		5DA 193 175-551 Ignition Coil	17
BMW - 3 Touring (E46)						10/99→02/05
316 i	85 kW	1.6 l	06/02→02/05	⊗ N45 B16 A; 4x	5DA 193 175-491 Ignition Coil	15
316 i	85 kW	1.8 l	03/02→02/05	4x	5DA 193 175-491 Ignition Coil	15
318 i	105 kW	2 l	09/01→02/05			
318 i	87 kW	1.9 l	10/99→09/01		5DA 193 175-641 Ignition Coil	19
320 i	110 kW	2 l	10/99→09/00		5DA 193 175-551 Ignition Coil	17
328 i	142 kW	2.8 l	10/99→06/00		5DA 193 175-551 Ignition Coil	17
320 i	125 kW	2.2 l	09/00→02/05	⊗ M54 B22 (226S1); 6x; 09/02→	5DA 193 175-491 Ignition Coil	15
				→09/02	5DA 193 175-551 Ignition Coil	17
325 i	141 kW	2.5 l	09/00→02/05	⊗ M54 B25 (256S5); 6x; 09/02→	5DA 193 175-491 Ignition Coil	15
				→09/02	5DA 193 175-551 Ignition Coil	17
330 i	170 kW	3 l	06/00→02/05	⊗ M54 B30 (306S3); 6x; 09/02→	5DA 193 175-491 Ignition Coil	15
				→09/02	5DA 193 175-551 Ignition Coil	17
BMW - 3 Touring (E91)						09/05→06/12
316 i	90 kW	1.6 l	05/08→05/12	⊗ N43 B16 A; 4	5DA 193 175-711 Ignition Coil	21
318 i	95 kW	2 l	01/06→06/12	4x	5DA 193 175-491 Ignition Coil	15
318 i	100 kW	2 l	09/07→06/12	⊗ N46 B20 B; 4x	5DA 193 175-491 Ignition Coil	15
				⊗ N43 B20 A; 4	5DA 193 175-711 Ignition Coil	21
318 i	105 kW	2 l	09/07→06/12	⊗ N43 B20 A; 4	5DA 193 175-711 Ignition Coil	21
320 i	125 kW	2 l	09/07→06/12			
320 i	110 kW	2 l	09/05→06/12	⊗ N46 B20 A / N46 B20 C; 4x	5DA 193 175-491 Ignition Coil	15
325 i	160 kW	2.5 l	09/05→06/12	⊗ N52 B25 A; 6x	5DA 193 175-491 Ignition Coil	15

				13	i	412		
BMW - 3 Touring (E91)								09/05→06/12
325 i	160 kW	3 l	09/07→06/12	⊗ N53 B30 A; 6			5DA 193 175-711 Ignition	21
325 i xDrive	160 kW	3 l	09/07→06/12				Coil	
325 xi	160 kW	3 l	09/07→06/12					
330 i	200 kW	3 l	09/07→06/12					
330 i xDrive	200 kW	3 l	09/07→06/12					
330 i	190 kW	3 l	09/05→08/07	6x			5DA 193 175-491 Ignition	15
							Coil	
330 xi	190 kW	3 l	09/05→08/07	⊗ N52 B30 A; 6x			5DA 193 175-491 Ignition	15
							Coil	
				⊗ N52 B30 A; 4			5DA 193 175-711 Ignition	21
							Coil	
330 xi	200 kW	3 l	09/07→06/12	⊗ N53 B30 A; 4			5DA 193 175-711 Ignition	21
							Coil	
335 i	225 kW	3 l	09/06→06/12	⊗ N54 B30 A / N55 B30 A; 6x			5DA 193 175-491 Ignition	15
335 i xDrive	225 kW	3 l	09/08→06/12				Coil	
335 xi	225 kW	3 l	03/07→06/12					
BMW - 3 Touring (F31)								06/12→
320 i	135 kW	2 l	06/12→	⊗ N20 B20 B; 4x			5DA 193 175-491 Ignition	15
							Coil	
328 i	180 kW	2 l	06/12→	⊗ N20 B20 A; 6x			5DA 193 175-491 Ignition	15
							Coil	
BMW - 5 (F10, F18)								12/09→
520 i	120 kW	2 l	09/11→	⊗ N20 B20 A; 4x			5DA 193 175-491 Ignition	15
520 i	135 kW	2 l	09/11→				Coil	
528 i	180 kW	2 l	09/11→					
528 i xDrive	180 kW	2 l	09/11→					
523 i	150 kW	3 l	12/09→	⊗ N53 B30 A; 6			5DA 193 175-711 Ignition	21
528 i	190 kW	3 l	02/10→				Coil	
530 i	200 kW	3 l	09/11→					
535 i	225 kW	3 l	12/09→	⊗ N55 B30 A; 6x			5DA 193 175-491 Ignition	15
535 i xDrive	225 kW	3 l	03/11→				Coil	
ActiveHybrid	250 kW	3 l	09/11→					
550 i	300 kW	4.4 l	02/10→	⊗ N63 B44 A; 8x			5DA 193 175-491 Ignition	15
550 i xDrive	300 kW	4.4 l	08/10→				Coil	
M5	412 kW	4.4 l	06/11→	⊗ S63 B44 B; 8x			5DA 193 175-491 Ignition	15
							Coil	
BMW - 5 Gran Turismo (F07)								10/09→
535 i	225 kW	3 l	10/09→	⊗ N55 B30 A; 6x			5DA 193 175-491 Ignition	15
535 i xDrive	225 kW	3 l	09/10→				Coil	
550 i	300 kW	4.4 l	10/09→	⊗ N63 B44 A; 8x			5DA 193 175-491 Ignition	15
550 i xDrive	300 kW	4.4 l	09/10→				Coil	
550 i	330 kW	4.4 l	05/12→	⊗ N63 B44 B; 8x			5DA 193 175-491 Ignition	15
550 i xDrive	330 kW	4.4 l	05/12→				Coil	
BMW - 5 Saloon (E12)								07/74→05/81
518	66 kW	1.8 l	07/74→05/81	09/80→; + Europe; Manual Transmission			5DA 006 623-001 Switch	4
							Unit, ignition system	
BMW - 5 Saloon (E28)								06/81→12/87
518	66 kW	1.8 l	06/81→08/84	→08/83; + Europe			5DA 006 623-001 Switch	4
							Unit, ignition system	
520 i	92 kW	2 l	06/81→12/87	→09/83; for vehicles without catalytic converter; + Europe			5DA 006 623-001 Switch	4
				→09/83; RHD; + Europe			Unit, ignition system	
525 i	110 kW	2.5 l	06/81→12/87	+ Europe			5DA 006 623-001 Switch	4
							Unit, ignition system	
528 i	135 kW	2.8 l	06/81→12/87	+ Europe / Africa			5DA 006 623-001 Switch	4
							Unit, ignition system	
BMW - 5 Saloon (E34)								08/89→09/95
518 i	85 kW	1.8 l	08/89→09/95				5DA 193 175-641 Ignition	19
							Coil	
520 i 24V	110 kW	2 l	09/89→09/95				5DA 193 175-541 Ignition	17
525 i 24V	141 kW	2.5 l	09/89→09/95				Coil	
525 iX 24V	141 kW	2.5 l	10/91→09/95					
530 i V8	160 kW	3 l	09/92→09/95					
540 i V8	210 kW	4 l	09/92→09/95					
M 3.8	250 kW	3.8 l	03/92→09/95					

				13	i	412			
BMW - 5 Saloon (E39)							11/95→06/03		
520 i	100 kW	2 l	04/99→06/03				5DA 193 175-551	Ignition	17
520 i	110 kW	2 l	01/96→09/00				Coil		
523 i	125 kW	2.5 l	11/95→09/00						
528 i	142 kW	2.8 l	11/95→09/00						
535 i	173 kW	3.5 l	04/96→03/99						
535 i	180 kW	3.5 l	04/99→06/03						
540 i	210 kW	4.4 l	04/96→06/03						
M 4.9	294 kW	4.9 l	10/98→06/03						
520 i	125 kW	2.2 l	09/00→06/03	6x; 09/02→			5DA 193 175-491	Ignition	15
525 i	141 kW	2.5 l	09/00→06/03				Coil		
530 i	170 kW	3 l	09/00→06/03	→09/02			5DA 193 175-551	Ignition	17
							Coil		
BMW - 5 Saloon (E60)							07/03→03/10		
520 i	120 kW	2 l	12/06→03/10	⊖ N43 B20 A; 4			5DA 193 175-711	Ignition	21
520 i	125 kW	2 l	09/07→03/10				Coil		
520 i	125 kW	2.2 l	07/03→03/10	⊖ M54 B22 (226S1); 6x			5DA 193 175-491	Ignition	15
							Coil		
523 i	130 kW	2.5 l	07/05→03/10	6x			5DA 193 175-491	Ignition	15
525 i	160 kW	2.5 l	07/05→03/10				Coil		
523 i	140 kW	2.5 l	01/07→03/10	⊖ N52 B25 A; 6x			5DA 193 175-491	Ignition	15
							Coil		
				⊖ N53 B25 A; 6			5DA 193 175-711	Ignition	21
							Coil		
525 i	141 kW	2.5 l	09/03→03/10	⊖ M54 B25 (256S5); 6x			5DA 193 175-491	Ignition	15
							Coil		
525 i	160 kW	3 l	01/07→03/10	⊖ N53 B30 A; 6			5DA 193 175-711	Ignition	21
525 i xDrive	160 kW	3 l	09/08→03/10				Coil		
525 xi	160 kW	3 l	01/07→03/10						
530 i	200 kW	3 l	01/07→03/10						
530 i xDrive	200 kW	3 l	09/08→03/10						
530 xi	200 kW	3 l	01/07→03/10						
525 xi	160 kW	2.5 l	07/05→03/10	⊖ N52 B25 A; 6x			5DA 193 175-491	Ignition	15
							Coil		
530 i	170 kW	3 l	07/03→03/10	⊖ M54 B30 (306S3); 6x			5DA 193 175-491	Ignition	15
							Coil		
530 i	190 kW	3 l	07/05→03/10	⊖ N52 B30 A; 6x			5DA 193 175-491	Ignition	15
530 xi	190 kW	3 l	07/05→03/10				Coil		
540 i	225 kW	4 l	07/05→03/10	⊖ N62 B40 A; 8x			5DA 193 175-491	Ignition	15
							Coil		
545 i	245 kW	4.4 l	09/03→03/10	⊖ N62 B44 A; 8x			5DA 193 175-491	Ignition	15
							Coil		
550 i	270 kW	4.8 l	07/05→03/10	⊖ N62 B48 B; 8x			5DA 193 175-491	Ignition	15
							Coil		
BMW - 5 Touring (E34)							11/91→01/97		
518 g	85 kW	1.8 l	11/95→06/96				5DA 193 175-641	Ignition	19
518 i	85 kW	1.8 l	09/94→01/97				Coil		
520 i	110 kW	2 l	11/91→01/97	→12/96			5DA 193 175-541	Ignition	17
525 i	141 kW	2.5 l	11/91→01/97				Coil		
525 ix	141 kW	2.5 l	02/92→01/97						
530 i V8	160 kW	3 l	09/92→01/97						
540 i	210 kW	4 l	09/93→01/97						
M 3.8	250 kW	3.8 l	09/94→01/97				5DA 193 175-541	Ignition	17
							Coil		
BMW - 5 Touring (E39)							01/97→05/04		
520 i	100 kW	2 l	04/99→05/04				5DA 193 175-551	Ignition	17
520 i	110 kW	2 l	01/97→09/00				Coil		
523 i	125 kW	2.5 l	01/97→09/00						
528 i	142 kW	2.8 l	01/97→09/00						
540 i	210 kW	4.4 l	01/97→05/04						
520 i	125 kW	2.2 l	09/00→05/04	⊖ M54 B22 (226S1); 6x; 09/02→			5DA 193 175-491	Ignition	15
							Coil		
				→09/02			5DA 193 175-551	Ignition	17
							Coil		
525 i	141 kW	2.5 l	09/00→05/04	⊖ M54 B25 (256S5); 6x; 09/02→			5DA 193 175-491	Ignition	15
							Coil		
				→09/02			5DA 193 175-551	Ignition	17
							Coil		
530 i	170 kW	3 l	09/00→05/04	⊖ M54 B30 (306S3); 6x; 09/02→			5DA 193 175-491	Ignition	15
							Coil		
				→09/02			5DA 193 175-551	Ignition	17
							Coil		









BMW - 5 Touring (E61)						06/04→
520 i	120 kW	2 l	07/07→08/10	⊗ N43 B20 A; 4	5DA 193 175-711 Ignition Coil	21
520 i	125 kW	2 l	09/07→			
523 i	130 kW	2.5 l	07/05→	6x	5DA 193 175-491 Ignition Coil	15
525 i	141 kW	2.5 l	06/04→			
525 i	160 kW	2.5 l	07/05→			
523 i	140 kW	2.5 l	01/07→			
				⊗ N52 B25 A; 6x	5DA 193 175-491 Ignition Coil	15
				⊗ N53 B25 A; 6	5DA 193 175-711 Ignition Coil	21
				⊗ N53 B30 A; 6	5DA 193 175-711 Ignition Coil	21
525 i	160 kW	3 l	01/07→			
525 i xDrive	160 kW	3 l	09/08→			
525 xi	160 kW	3 l	01/07→			
530 i	200 kW	3 l	01/07→			
530 i xDrive	200 kW	3 l	09/08→			
530 xi	200 kW	3 l	01/07→			
525 xi	160 kW	2.5 l	07/05→	⊗ N52 B25 A; 6x	5DA 193 175-491 Ignition Coil	15
530 i	190 kW	3 l	07/05→	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
530 xi	190 kW	3 l	07/05→			
545 i	245 kW	4.4 l	06/04→	⊗ N62 B44 A; 8x	5DA 193 175-491 Ignition Coil	15
550 i	270 kW	4.8 l	07/05→	⊗ N62 B48 B / N62 B48 A; 8x	5DA 193 175-491 Ignition Coil	15
BMW - 5 Touring (F11)						09/10→
520 i	135 kW	2 l	09/11→	⊗ N20 B20 A; 4x	5DA 193 175-491 Ignition Coil	15
528 i	180 kW	2 l	09/11→			
528 i xDrive	180 kW	2 l	09/11→			
523 i	150 kW	3 l	09/10→	⊗ N53 B30 A; 6	5DA 193 175-711 Ignition Coil	21
528 i	190 kW	3 l	09/10→			
530 i	200 kW	3 l	09/11→			
535 i	225 kW	3 l	09/10→	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
535 i xDrive	225 kW	3 l	09/11→			
550 i	300 kW	4.4 l	09/10→	⊗ N63 B44 A; 8x	5DA 193 175-491 Ignition Coil	15
BMW - 6 (E24)						09/79→08/87
628 CSi	135 kW	2.8 l	09/79→08/87	04/81→; + Europe	5DA 006 623-001 Switch Unit, ignition system	4
BMW - 6 (E63)						01/04→
630 i	190 kW	3 l	09/04→	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
645 Ci	245 kW	4.4 l	01/04→	⊗ N62 B44 A; 8x	5DA 193 175-491 Ignition Coil	15
650 i	270 kW	4.8 l	07/05→	⊗ N62 B48 B; 8x	5DA 193 175-491 Ignition Coil	15
BMW - 6 Convertible (E64)						04/04→
630 i	190 kW	3 l	09/04→	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
630 i	200 kW	3 l	07/07→	⊗ N52 B30 B; 6	5DA 193 175-711 Ignition Coil	21
				⊗ N52 B30 BF; 6	5DA 193 175-711 Ignition Coil	21
645 Ci	245 kW	4.4 l	04/04→	⊗ N62 B44 A; 8x	5DA 193 175-491 Ignition Coil	15
650 i	270 kW	4.8 l	07/05→	⊗ N62 B48 B; 8x	5DA 193 175-491 Ignition Coil	15
BMW - 6 Convertible (F12)						03/11→
640 i	235 kW	3 l	03/11→	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15
650 i	300 kW	4.4 l	03/11→	⊗ N63 B44 A; 8x	5DA 193 175-491 Ignition Coil	15
650 i xDrive	300 kW	4.4 l	06/11→			
650 i xDrive	330 kW	4.4 l	11/11→			
650 i	330 kW	4.4 l	10/11→	⊗ N63 B44 B; 8x	5DA 193 175-491 Ignition Coil	15
M6	412 kW	4.4 l	01/12→	⊗ S63 B44 B; 8x	5DA 193 175-491 Ignition Coil	15
BMW - 6 Coupe (F13)						11/10→
640 i	235 kW	3 l	11/10→	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15

BMW - 6 Coupe (F13)							11/10→
650 i	300 kW	4.4 l	11/10→	⊖ N63 B44 A; 8x	5DA 193 175-491 Ignition	15	
650 i xDrive	300 kW	4.4 l	06/11→		Coil		
650 i	330 kW	4.4 l	10/11→	⊖ N63 B44 B; 8x	5DA 193 175-491 Ignition	15	
650 i xDrive	330 kW	4.4 l	11/11→		Coil		
M6	412 kW	4.4 l	01/12→	⊖ S63 B44 B; 8x	5DA 193 175-491 Ignition	15	
					Coil		
BMW - 7 Saloon (E23)							07/78→08/86
728 i	135 kW	2.8 l	07/78→08/86	04/81→; + Europe	5DA 006 623-001 Switch Unit, ignition system	4	
BMW - 7 Saloon (E32)							04/92→09/94
730 i,iL V8	160 kW	3 l	04/92→09/94		5DA 193 175-541 Ignition	17	
740 i,iL V8	210 kW	4 l	04/92→09/94		Coil		
BMW - 7 Saloon (E38)							10/94→11/01
728 i,iL	142 kW	2.8 l	08/95→11/01		5DA 193 175-551 Ignition	17	
735 i,iL	173 kW	3.5 l	01/96→11/01		Coil		
740 i,iL	210 kW	4.4 l	01/96→11/01				
750 i,iL	240 kW	5.4 l	12/94→11/01				
730 i,iL	155 kW	3 l	10/94→11/01	→12/96	5DA 193 175-541 Ignition	17	
730 i,iL	160 kW	3 l	10/94→11/01		Coil		
740 i,iL	210 kW	4 l	10/94→11/01	→06/96	5DA 193 175-541 Ignition	17	
					Coil		
BMW - 7 Saloon (E65, E66, E67)							11/01→
730 i,Li	170 kW	3 l	03/03→	⊖ M54 B30 (306S3); 6x	5DA 193 175-491 Ignition	15	
					Coil		
730 i,Li	190 kW	3 l	03/05→	⊖ N52 B30 A; 6x	5DA 193 175-491 Ignition	15	
					Coil		
735 i,Li	200 kW	3.6 l	11/01→	⊖ N62 B36 A; 8x	5DA 193 175-491 Ignition	15	
					Coil		
740 i,Li	225 kW	4 l	07/05→	⊖ N62 B40 A; 8x	5DA 193 175-491 Ignition	15	
					Coil		
745 i,Li	245 kW	4.4 l	11/01→	⊖ N62 B44 A; 8x	5DA 193 175-491 Ignition	15	
					Coil		
750 i,Li	270 kW	4.8 l	07/05→	⊖ N62 B48 B; 8x	5DA 193 175-491 Ignition	15	
					Coil		
BMW - 7 Saloon (F01, F02, F03, F04)							06/08→
730 i	190 kW	3 l	06/08→	⊖ N52 B30 A / N52 B30 BF; 6x	5DA 193 175-491 Ignition	15	
					Coil		
740 i	235 kW	3 l	07/12→	⊖ N55 B30 A; 6x	5DA 193 175-491 Ignition	15	
ActiveHybrid	260 kW	3 l	07/12→		Coil		
740 i	240 kW	3 l	10/08→	⊖ N54 B30 A; 6x	5DA 193 175-491 Ignition	15	
					Coil		
750 i	300 kW	4.4 l	10/08→	⊖ N63 B44 A; 8x	5DA 193 175-491 Ignition	15	
750 i xDrive	300 kW	4.4 l	09/09→		Coil		
ActiveHybrid	330 kW	4.4 l	10/10→				
ActiveHybrid	342 kW	4.4 l	10/10→				
750 i	330 kW	4.4 l	10/12→	⊖ N63 B44 B; 8x	5DA 193 175-491 Ignition	15	
750 i xDrive	330 kW	4.4 l	10/12→		Coil		
760 i	400 kW	6 l	09/09→	⊖ N74 B60 A; 12x	5DA 193 175-491 Ignition	15	
					Coil		
BMW - 8 (E31)							02/93→12/99
840 Ci	210 kW	4.4 l	01/96→12/99		5DA 193 175-551 Ignition	17	
850 Ci	240 kW	5.4 l	09/94→12/99		Coil		
840 i	210 kW	4 l	02/93→02/96		5DA 193 175-541 Ignition	17	
					Coil		
BMW - X1 Estate (E84)							10/09→
sDrive 18 i	110 kW	2 l	01/10→	⊖ N46 B20 B; 4x	5DA 193 175-491 Ignition	15	
					Coil		
sDrive 20 i	135 kW	2 l	09/11→	⊖ N20 B20 A; 4x	5DA 193 175-491 Ignition	15	
xDrive 20 i	135 kW	2 l	09/11→		Coil		
xDrive 28 i	180 kW	2 l	04/11→				
xDrive 25 i	160 kW	3 l	01/10→	⊖ N52 B30 A; 6x	5DA 193 175-491 Ignition	15	
xDrive 28 i	190 kW	3 l	10/09→		Coil		
BMW - X3 (E83)							01/04→
2.0 i	110 kW	2 l	07/05→	4x	5DA 193 175-491 Ignition	15	
					Coil		

BMW - X3 (E83)							01/04→
2.5 i	141 kW	2.5 l	01/04→	⊗ M54 B25 (256S5); 6x	5DA 193 175-491 Ignition Coil	15	
2.5 si	160 kW	2.5 l	09/06→	⊗ N52 B25 A; 6x	5DA 193 175-491 Ignition Coil	15	
xDrive 25 i	160 kW	2.5 l	09/08→				
3.0 i xDrive	170 kW	3 l	01/04→	⊗ M54 B30 (306S3); 6x	5DA 193 175-491 Ignition Coil	15	
3.0 si	200 kW	3 l	09/06→	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
xDrive 30 i	200 kW	3 l	09/08→				
xDrive 20 i	110 kW	2 l	09/08→	⊗ N46 B20 B; 4x	5DA 193 175-491 Ignition Coil	15	
BMW - X3 (F25)							09/10→
xDrive 20 i	135 kW	2 l	09/11→	⊗ N20 B20 A; 4x	5DA 193 175-491 Ignition Coil	15	
xDrive 28 i	180 kW	2 l	08/11→				
xDrive 28 i	190 kW	3 l	04/11→	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
xDrive 35 i	225 kW	3 l	09/10→	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
BMW - X5 (E53)							05/00→12/06
3.0 i	163 kW	3 l	05/00→12/06	⊗ M54 B30 (306S3); 6x; 10/02→	5DA 193 175-491 Ignition Coil	15	
				⊗ M54 B30 (306S3); →10/02	5DA 193 175-551 Ignition Coil	17	
3.0 i	170 kW	3 l	05/00→12/06	⊗ M54 B30 (306S3); 6x; 10/02→	5DA 193 175-491 Ignition Coil	15	
4.4 i	210 kW	4.4 l	05/00→12/03		5DA 193 175-551 Ignition Coil	17	
4.6 is	255 kW	4.6 l	02/02→12/03				
4.4 i	235 kW	4.4 l	12/03→09/06	⊗ N62 B44 A / N62 B44; 8x	5DA 193 175-491 Ignition Coil	15	
4.8 is	265 kW	4.8 l	04/04→09/06	⊗ N62 B48 A; 8x	5DA 193 175-491 Ignition Coil	15	
BMW - X5 (E70)							02/07→06/13
3.0 si	200 kW	3 l	02/07→09/08	⊗ N52 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
xDrive 30 i	200 kW	3 l	09/08→03/10				
4.8 i xDrive	261 kW	4.8 l	02/07→09/08	⊗ N62 B48 B; 8x	5DA 193 175-491 Ignition Coil	15	
xDrive 48 i	261 kW	4.8 l	09/08→06/13				
M	408 kW	4.4 l	09/09→06/13	⊗ S63 B44 A; 8x	5DA 193 175-491 Ignition Coil	15	
xDrive 35 i	225 kW	3 l	09/10→06/13	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
xDrive 50 i	300 kW	4.4 l	06/10→06/13	⊗ N63 B44 A; 8x	5DA 193 175-491 Ignition Coil	15	
BMW - X6 (E71, E72)							05/08→
35 i	225 kW	3 l	05/08→	⊗ N54 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
50 i	300 kW	4.4 l	05/08→	⊗ N63 B44 A; 8x	5DA 193 175-491 Ignition Coil	15	
ActiveHybrid	357 kW	4.4 l	10/10→				
xDrive 50 i	300 kW	4.4 l	09/08→				
M	408 kW	4.4 l	09/09→	⊗ S63 B44 A; 8x	5DA 193 175-491 Ignition Coil	15	
xDrive 35 i	225 kW	3 l	09/08→	⊗ N55 B30 A / N54 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
xDrive 35 i	235 kW	3 l	01/12→	⊗ N55 B30 A; 6x	5DA 193 175-491 Ignition Coil	15	
BMW - Z3 (E36)							10/95→01/03
1.8	85 kW	1.8 l	10/95→10/98		5DA 193 175-641 Ignition Coil	19	
1.9	87 kW	1.9 l	07/98→01/03				
1.9	103 kW	1.9 l	10/95→03/99				
2.0	110 kW	2 l	04/99→01/03		5DA 193 175-551 Ignition Coil	17	
2.8	141 kW	2.8 l	04/97→06/00				
2.2	125 kW	2.2 l	08/00→01/03	→09/02	5DA 193 175-551 Ignition Coil	17	
3.0	170 kW	3 l	06/00→01/03	→12/02	5DA 193 175-551 Ignition Coil	17	
M 3.2	236 kW	3.2 l	03/97→06/01	→12/00	5DA 193 175-551 Ignition Coil	17	
M 3.2	239 kW	3.2 l	06/01→01/03	⊗ S54 B32 (326S4); 6x	5DA 193 175-491 Ignition Coil	15	

BMW - Z3 Coupe (E36)													07/97→06/03		
2.8	141 kW	2.8 l	07/97→06/00										5DA 193 175-551 Ignition Coil	17	
3.0	170 kW	3 l	06/00→06/03	→12/02									5DA 193 175-551 Ignition Coil	17	
M	236 kW	3.2 l	02/98→06/01	→12/00									5DA 193 175-551 Ignition Coil	17	
M	239 kW	3.2 l	06/01→06/03		⊗ S54 B32 (326S4); 6x								5DA 193 175-491 Ignition Coil	15	
BMW - Z4 (E85)													02/03→		
2.0 i	110 kW	2 l	04/05→		⊗ N46 B20 B / N46 B20 A; 4x								5DA 193 175-491 Ignition Coil	15	
2.2 i	125 kW	2.2 l	10/03→		⊗ M54 B22 (226S1); 6x								5DA 193 175-491 Ignition Coil	15	
2.5 i	130 kW	2.5 l	01/06→		⊗ N52 B25 A; 6x								5DA 193 175-491 Ignition Coil	15	
2.5 si	160 kW	2.5 l	01/06→												
2.5 i	141 kW	2.5 l	02/03→		⊗ M54 B25 (256S5); 6x								5DA 193 175-491 Ignition Coil	15	
3.0 i	170 kW	3 l	02/03→		⊗ M54 B30 (306S3); 6x								5DA 193 175-491 Ignition Coil	15	
3.0 si	195 kW	3 l	01/06→		⊗ N52 B30 A; 6x								5DA 193 175-491 Ignition Coil	15	
M	252 kW	3.2 l	03/06→		⊗ S54 B32 (326S4); 6x								5DA 193 175-491 Ignition Coil	15	
BMW - Z4 (E89)													05/09→		
sDrive 20 i	135 kW	2 l	09/11→		⊗ N20 B20 A; 4x								5DA 193 175-491 Ignition Coil	15	
sDrive 28 i	180 kW	2 l	09/11→												
sDrive 23 i	150 kW	2.5 l	05/09→		⊗ N52 B25 A; 6x								5DA 193 175-491 Ignition Coil	15	
sDrive 30 i	190 kW	3 l	05/09→		⊗ N52 B30 A; 6x								5DA 193 175-491 Ignition Coil	15	
sDrive 35 i	225 kW	3 l	05/09→		⊗ N54 B30 A; 6x								5DA 193 175-491 Ignition Coil	15	
sDrive 35 is	250 kW	3 l	09/10→												
BMW - Z4 Coupe (E86)													03/06→		
3.0 si	195 kW	3 l	03/06→		⊗ N52 B30 A; 6x								5DA 193 175-491 Ignition Coil	15	
M	252 kW	3.2 l	03/06→		⊗ S54 B32 (326S4); 6x								5DA 193 175-491 Ignition Coil	15	
BMW - Z8 (E52)													06/00→06/03		
4.9	294 kW	4.9 l	06/00→06/03										5DA 193 175-551 Ignition Coil	17	

BMW MOTORCYCLES - R 100						03/76→12/96
R 100 CS	51 kW	0.98 l	01/80→09/84	09/80→	5DA 006 623-931 Switch	8
R 100 RS (247)	51 kW	0.98 l	03/76→12/84		Unit, ignition system	
R 100 RT (247)	51 kW	0.98 l	01/78→12/84			
R 100 GS (247E)	44 kW	0.98 l	12/86→07/90	09/87→07/88	5DA 006 623-931 Switch	8
					Unit, ignition system	
R 100 GS (247E)	44 kW	0.98 l	08/90→12/96	01/92→02/96	5DA 006 623-931 Switch	8
					Unit, ignition system	
R 100 GS Paris Dakar (247E)	44 kW	0.98 l	01/89→07/90		5DA 006 623-931 Switch	8
R 100 R Mystic (247E)	44 kW	0.98 l	12/93→01/96		Unit, ignition system	
R 100 GS Paris Dakar Classic (247E)	44 kW	0.98 l	01/90→02/96	01/95→	5DA 006 623-931 Switch	8
					Unit, ignition system	
BMW MOTORCYCLES - R 65						01/80→09/88
R 65 (248)	37 kW	0.65 l	01/81→09/83		5DA 006 623-931 Switch	8
R 65 LS	37 kW	0.65 l	03/81→03/85		Unit, ignition system	
R 65 G/S (247E)	20 kW	0.65 l	01/80→09/88	11/87→07/88	5DA 006 623-931 Switch	8
					Unit, ignition system	
BMW MOTORCYCLES - R 80						03/80→12/96
R 80 G/S (247)	25 kW	0.8 l	03/80→09/87	08/86→	5DA 006 623-931 Switch	8
R 80 G/S (247)	37 kW	0.8 l	03/80→09/87		Unit, ignition system	
R 80 GS (247E)	25 kW	0.8 l	03/87→09/90	10/87→	5DA 006 623-931 Switch	8
R 80 GS (247E)	37 kW	0.8 l	01/87→09/90		Unit, ignition system	
R 80 GS (247E)	25 kW	0.8 l	03/90→09/95	10/90→	5DA 006 623-931 Switch	8
R 80 GS (247E)	37 kW	0.8 l	03/90→12/95		Unit, ignition system	
R 80 GS Paris Dakar (247E)	25 kW	0.8 l	02/90→09/95			
R 80 GS Paris Dakar (247E)	37 kW	0.8 l	02/90→12/95			
R 80 GS Basic (247E)	37 kW	0.8 l	01/96→12/96		5DA 006 623-931 Switch	8
					Unit, ignition system	

       							
CHRYSLER - CROSSFIRE						07/03→12/08	
3.2	160 kW	3.2 l	07/03→12/08	6x	5DA 193 175-991 Ignition	30	
SRT-6	246 kW	3.2 l	09/04→12/07		Coil		
CHRYSLER - CROSSFIRE Roadster						05/04→12/08	
3.2	160 kW	3.2 l	05/04→12/08	6x	5DA 193 175-991 Ignition	30	
SRT-6	246 kW	3.2 l	09/04→12/06		Coil		



CITROËN - AX (ZA-)				07/86→12/98		
1.3 Sport	70 kW	1.3 l	04/87→12/88		5DA 006 623-041 Switch Unit, ignition system	4
10 E	30 kW	1 l	12/86→12/88			
11	40 kW	1.1 l	12/86→04/94			
11 CAT	40 kW	1.1 l	09/88→12/89			
14	44 kW	1.4 l	12/86→12/88			
14	49 kW	1.4 l	06/88→12/89			
14	62 kW	1.4 l	01/88→12/92			
1.4 GTi	66 kW	1.4 l	08/91→12/96		5DA 006 623-601 Switch Unit, ignition system	8
				☉ KFY (TU3FJ2)	5DA 193 175-721 Ignition Coil	21
1.4 GTi	69 kW	1.4 l	06/91→12/96		5DA 006 623-601 Switch Unit, ignition system	8
				☉ KFZ (TU3FJ2)	5DA 193 175-721 Ignition Coil	21
1.4 GTi	74 kW	1.4 l	06/91→12/92	☉ KFZ (TU3FJ2)	5DA 193 175-721 Ignition Coil	21
10	33 kW	1 l	07/86→12/98	☉ CDY (TU9M)	5DA 193 175-721 Ignition Coil	21
10	37 kW	1 l	02/87→12/98	☉ CDZ (TU9M)	5DA 193 175-721 Ignition Coil	21
11	44 kW	1.1 l	09/86→12/97	→04/92	5DA 006 623-041 Switch Unit, ignition system	4
				☉ HDZ (TU1M); 05/92→	5DA 193 175-721 Ignition Coil	21
14	55 kW	1.4 l	04/87→04/97	☉ KDX (TU3M/Z); 01/93→	5DA 193 175-721 Ignition Coil	21
14 4x4	55 kW	1.4 l	08/91→12/96	☉ KDY (TU3FM); 01/93→	5DA 193 175-721 Ignition Coil	21
CITROËN - BERLINGO (B9)				04/08→		
1.6	66 kW	1.6 l	04/08→	☉ NFR (TU5JP4B)	5DA 193 175-731 Ignition Coil	22
1.6	80 kW	1.6 l	04/08→	☉ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
1.6 VTi 120	88 kW	1.6 l	11/09→	☉ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15
1.6 VTi 95	72 kW	1.6 l	07/10→	☉ 5FK (EP6CB); 4x	5DA 193 175-491 Ignition Coil	15
CITROËN - BERLINGO (MF)				07/96→		
1.1 i (MFHDZ, MFHFX)	44 kW	1.1 l	07/96→	☉ HDZ	5DA 193 175-421 Ignition Coil	13
				☉ TU1JP	5DA 193 175-441 Ignition Coil	14
1.4 bivalent	48 kW	1.4 l	11/02→	☉ TU3JP	5DA 193 175-441 Ignition Coil	14
1.4 i bivalent (MFKFW)	55 kW	1.4 l	04/03→			
1.4 i (MFKFX, MFKFW)	55 kW	1.4 l	07/96→	→Orga 07874; CEE95, CEE W2	5DA 193 175-421 Ignition Coil	13
				☉ KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95, 15-04	5DA 193 175-431 Ignition Coil	14
				☉ KFW (TU3JP) / KFX (TU3JP); CEE 2000; L4, W4		
				06/98→; ☉ TU3JP	5DA 193 175-441 Ignition Coil	14
1.6 16V (MFNFU)	80 kW	1.6 l	10/00→	☉ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
1.8 i (MFLFX)	66 kW	1.8 l	05/97→		5DA 193 175-421 Ignition Coil	13
1.8 i 4WD (MFLFX)	66 kW	1.8 l	04/97→		5DA 193 175-421 Ignition Coil	13
CITROËN - BERLINGO I Box (M_)				07/96→		
1.1 i (MAHDZ, MBHDZ, MBHFX)	44 kW	1.1 l	07/96→		5DA 193 175-421 Ignition Coil	13
1.8 i	66 kW	1.8 l	08/99→10/02			
1.4 bivalent	48 kW	1.4 l	11/02→	☉ TU3JP	5DA 193 175-441 Ignition Coil	14
1.4 i bivalent (MBKFW)	55 kW	1.4 l	04/03→			
1.4 i (MBKFX, MBKFW)	55 kW	1.4 l	07/96→	→Orga 07874; CEE95, CEE W2	5DA 193 175-421 Ignition Coil	13
				☉ KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95, 15-04	5DA 193 175-431 Ignition Coil	14
				☉ KFW (TU3JP) / KFX (TU3JP); CEE 2000; L4, W4		
				06/98→; ☉ TU3JP	5DA 193 175-441 Ignition Coil	14
1.6 16V (MBNFU)	80 kW	1.6 l	10/00→	☉ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22

CITROËN - BERLINGO Box (B9)											04/08→			
1.6	66 kW	1.6 l	04/08→		NFR (TU5JP4B)	5DA 193 175-731 Ignition Coil						22		
1.6	80 kW	1.6 l	04/08→		NFU (TU5JP4)	5DA 193 175-731 Ignition Coil						22		
1.6 VTi 120	88 kW	1.6 l	11/09→		5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil						15		
1.6 VTi 95	72 kW	1.6 l	07/10→		5FK (EP6CB); 4x	5DA 193 175-491 Ignition Coil						15		
CITROËN - BX (XB-_)											10/82→02/93			
14 E	45 kW	1.4 l	10/82→06/88	→04/88		5DA 006 623-001 Switch Unit, ignition system						4		
14 E	49 kW	1.4 l	09/85→02/93			5DA 006 623-041 Switch Unit, ignition system						4		
14 E	52 kW	1.4 l	04/83→07/89			5DA 006 623-041 Switch Unit, ignition system						4		
14 E	53 kW	1.4 l	04/83→02/93			5DA 006 623-041 Switch Unit, ignition system						4		
16	53 kW	1.6 l	01/87→02/93	→03/88		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
16	55 kW	1.6 l	09/88→02/93	IT 11/89→; FI / Greece		5DA 006 623-001 Switch Unit, ignition system						4		
16	64 kW	1.6 l	07/85→02/93	IT 11/89→; FI / Greece		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
16	66 kW	1.6 l	10/82→06/88	IT		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
16	68 kW	1.6 l	10/82→12/92			5DA 006 623-001 Switch Unit, ignition system						4		
19	75 kW	1.9 l	07/86→05/89			5DA 006 623-001 Switch Unit, ignition system						4		
16 E	65 kW	1.6 l	05/89→02/93	IT 11/89→; IT / Greece / FI		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
						BDY; 04/91→; Orga 05285→	5DA 193 175-421 Ignition Coil						13	
19	70 kW	1.9 l	09/86→11/89	→05/89		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
19	77 kW	1.9 l	07/86→05/89	→05/89		5DA 006 623-001 Switch Unit, ignition system						4		
19 E	80 kW	1.9 l	06/88→02/93	07/88→; + D / NL / + CH / SV / Austria / BE / + UK		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
				05/90→; Orga 04924→		5DA 193 175-421 Ignition Coil						13		
19 E 4x4	80 kW	1.9 l	04/89→02/93	→06/90; + D / NL / + CH / SV / Austria / BE / + UK		5DA 006 623-001 Switch Unit, ignition system						4		
19 GTi	88 kW	1.9 l	06/88→02/93	07/88→; + D / NL / + CH / SV / Austria / BE / + UK		5DA 006 623-001 Switch Unit, ignition system						4		
				05/90→; Orga 04924→		5DA 193 175-421 Ignition Coil						13		
19 GTi	90 kW	1.9 l	07/86→02/93			5DA 006 623-041 Switch Unit, ignition system						4		
				05/90→; Orga 04924→		5DA 193 175-421 Ignition Coil						13		
19 GTi 16V	108 kW	1.9 l	03/88→02/93	07/88→; + D / NL / + CH / SV / Austria / BE / + UK		5DA 006 623-001 Switch Unit, ignition system						4		
						5DA 006 623-041 Switch Unit, ignition system						4		
19 GTi 16V	116 kW	1.9 l	09/87→12/88	07/88→; + D / NL / + CH / SV / Austria / BE / + UK / + J		5DA 006 623-001 Switch Unit, ignition system						4		
19 GTi 4x4	88 kW	1.9 l	06/88→02/93	07/88→; + D / NL / + CH / Austria / BE / + UK		5DA 006 623-001 Switch Unit, ignition system						4		
				05/90→; Orga 04924→		5DA 193 175-421 Ignition Coil						13		
CITROËN - BX Break (XB-_)											06/85→12/94			
15	59 kW	1.6 l	10/87→05/92	→10/89		5DA 006 623-001 Switch Unit, ignition system						4		
16	53 kW	1.6 l	09/88→12/94			5DA 006 623-041 Switch Unit, ignition system						4		
16	76 kW	1.6 l	03/86→12/94			5DA 006 623-041 Switch Unit, ignition system						4		

CITROËN - BX Break (XB-_)					06/85→12/94	
16	64 kW	1.6 l	07/85→12/94	IT 11/89→; IT / Greece / FI	5DA 006 623-001 Switch Unit, ignition system	4
					5DA 006 623-041 Switch Unit, ignition system	4
16	65 kW	1.6 l	05/89→12/94	IT 11/89→; IT / Greece / FI	5DA 006 623-001 Switch Unit, ignition system	4
					5DA 006 623-041 Switch Unit, ignition system	4
				⊗ BDY; 04/91→; Orga 05285→	5DA 193 175-421 Ignition Coil	13
16	66 kW	1.6 l	06/85→06/88	IT	5DA 006 623-001 Switch Unit, ignition system	4
19	70 kW	1.9 l	12/87→12/89	→05/89; Carburettor	5DA 006 623-001 Switch Unit, ignition system	4
19	75 kW	1.9 l	07/86→12/94	→05/88; Carburettor	5DA 006 623-001 Switch Unit, ignition system	4
					5DA 006 623-041 Switch Unit, ignition system	4
19	80 kW	1.9 l	06/88→12/94	07/88→; + D / NL / + CH / SV / Austria / BE / + UK	5DA 006 623-001 Switch Unit, ignition system	4
				05/90→; Orga 04924→	5DA 193 175-421 Ignition Coil	13
19	88 kW	1.9 l	06/88→12/94	07/88→; + D / NL / + CH / SV / Austria / BE / + UK	5DA 006 623-001 Switch Unit, ignition system	4
					5DA 006 623-041 Switch Unit, ignition system	4
				05/90→; Orga 04924→	5DA 193 175-421 Ignition Coil	13
19 4x4	80 kW	1.9 l	10/90→05/91	+ D / NL / + CH / SV / Austria / BE / + UK	5DA 006 623-001 Switch Unit, ignition system	4
				Orga 04924→	5DA 193 175-421 Ignition Coil	13
19 CAT	75 kW	1.9 l	07/86→12/94	07/88→; + D / NL / SV / Austria / BE / + UK	5DA 006 623-001 Switch Unit, ignition system	4
				05/90→; Orga 04924→	5DA 193 175-421 Ignition Coil	13
CITROËN - C2 (JM_)					09/03→	
1.1	44 kW	1.1 l	09/03→	⊗ TU1JP	5DA 193 175-441 Ignition Coil	14
1.4	54 kW	1.4 l	09/03→	⊗ TU3JP	5DA 193 175-441 Ignition Coil	14
1.6	80 kW	1.6 l	09/03→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
1.6 VTS	90 kW	1.6 l	01/05→	⊗ NFS (TU5JP4S)	5DA 193 175-731 Ignition Coil	22
CITROËN - C3 I (FC_)					02/02→	
1.1 i	44 kW	1.1 l	02/02→	⊗ TU1JP	5DA 193 175-441 Ignition Coil	14
1.4 i	54 kW	1.4 l	02/02→	⊗ TU3JP	5DA 193 175-441 Ignition Coil	14
1.4 i Bivalent	54 kW	1.4 l	02/02→			
1.6 16V	80 kW	1.6 l	02/02→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
CITROËN - C3 II					11/09→	
1.4 VTi 95	70 kW	1.4 l	11/09→	⊗ 8FP (EP3); 4x	5DA 193 175-491 Ignition Coil	15
1.6 VTi 120	88 kW	1.6 l	11/09→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15
CITROËN - C3 Picasso					02/09→	
1.4 VTi 95	70 kW	1.4 l	02/09→	⊗ 8FP (EP3) / 8FS (EP3); 4x	5DA 193 175-491 Ignition Coil	15
1.4 VTi 95 LPG	70 kW	1.4 l	01/12→	⊗ 8FN (EP3); 4x	5DA 193 175-491 Ignition Coil	15
1.6 VTi 120	88 kW	1.6 l	02/09→	⊗ 5FS (EP6C) / 5FW (EP6); 4x	5DA 193 175-491 Ignition Coil	15
CITROËN - C3 Pluriel (HB_)					05/03→	
1.4	54 kW	1.4 l	05/03→	⊗ TU3JP	5DA 193 175-441 Ignition Coil	14
1.6	80 kW	1.6 l	05/03→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22

CITROËN - C4 I (LC_)							11/04→07/11
1.6 16V	80 kW	1.6 l	11/04→07/11	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
1.6 16V Bio-Flex	80 kW	1.6 l	09/07→07/08				
1.6 THP 140	103 kW	1.6 l	07/08→07/11	⊗ 5FT (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 THP 150	110 kW	1.6 l	07/08→07/11	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 VTi 120	88 kW	1.6 l	07/08→07/11	⊗ 5FW (EP6); 4x	5DA 193 175-491 Ignition Coil	15	
2.0 16V	103 kW	2 l	11/04→07/11	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40	
2.0 16V	130 kW	2 l	11/04→07/08	⊗ RFK (EW10J4S)	5DA 749 475-611 Ignition Coil	40	
CITROËN - C4 II (B7)							11/09→
1.6 THP 155	115 kW	1.6 l	11/09→	⊗ 5FV (EP6CDT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 VTi 120	88 kW	1.6 l	11/09→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 VTi 120 LPG	88 kW	1.6 l	09/11→				
CITROËN - C4 Coupe (LA_)							11/04→07/11
1.6 16V	80 kW	1.6 l	11/04→07/11	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
1.6 THP 150	110 kW	1.6 l	07/08→07/11	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 VTi 120	88 kW	1.6 l	07/08→07/11	⊗ 5FW (EP6); 4x	5DA 193 175-491 Ignition Coil	15	
2.0 16V	130 kW	2 l	11/04→12/10	⊗ RFK (EW10J4S)	5DA 749 475-611 Ignition Coil	40	
CITROËN - C4 Grand Picasso I (UA_)							10/06→
1.6 16V	103 kW	1.6 l	07/08→	⊗ 5FT (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V	110 kW	1.6 l	10/08→	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 THP 155	115 kW	1.6 l	09/10→	⊗ 5FV (EP6CDT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 VTi 120	88 kW	1.6 l	07/08→	⊗ 5FW (EP6); 4x	5DA 193 175-491 Ignition Coil	15	
1.8 i 16V	92 kW	1.8 l	10/06→	⊗ 6FY (EW7A)	5DA 749 475-601 Ignition Coil	40	
2.0 i 16V	103 kW	2 l	10/06→	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40	
CITROËN - C4 Picasso I (UD_)							02/07→08/13
1.6 16V	110 kW	1.6 l	07/08→08/13	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 THP 140	103 kW	1.6 l	07/08→08/13	⊗ 5FT (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 THP 155	115 kW	1.6 l	09/10→08/13	⊗ 5FV (EP6CDT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 VTi 120	88 kW	1.6 l	07/08→08/13	⊗ 5FW (EP6); 4x	5DA 193 175-491 Ignition Coil	15	
1.8 i 16V	92 kW	1.8 l	02/07→12/11	⊗ 6FY (EW7A)	5DA 749 475-601 Ignition Coil	40	
2.0 i 16V	103 kW	2 l	02/07→08/13	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40	
CITROËN - C4 Saloon							07/06→07/11
1.6 16V	80 kW	1.6 l	07/06→07/11	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
CITROËN - C5 II (RC_)							09/04→
2.0 16V (RCRFJB, RCRFJC)	103 kW	2 l	09/04→	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40	
CITROËN - C5 II Break (RE_)							09/04→
1.8 16V	92 kW	1.8 l	09/05→	⊗ 6FY (EW7A)	5DA 749 475-601 Ignition Coil	40	
2.0 16V (RERFJB, RERFJC)	103 kW	2 l	09/04→	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40	
CITROËN - C5 III Break (TD_)							02/08→
1.6 VTi 120	88 kW	1.6 l	07/10→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15	

										13	i	412	
CITROËN - C5 III Break (TD_)													02/08 →
1.8 16V	92 kW	1.8 l	02/08→	⊗ 6FY (EW7A)	5DA 749 475-601 Ignition Coil	40							
2.0 16V	103 kW	2 l	02/08→	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40							
CITROËN - C5 III Saloon (RD_)													02/08 →
1.6 VTi 120	88 kW	1.6 l	07/10→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15							
1.8 16V	92 kW	1.8 l	02/08→	⊗ 6FY (EW7A)	5DA 749 475-601 Ignition Coil	40							
2.0 16V	103 kW	2 l	02/08→	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40							
CITROËN - C8 (EA_, EB_)													07/02 →
2.0 16V	103 kW	2 l	09/05→	⊗ RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40							
2.2	116 kW	2.2 l	07/02→	⊗ 3FZ (EW12J4)	5DA 749 475-611 Ignition Coil	40							
CITROËN - C15 (VD_-)													05/87 → 12/96
1.4	49 kW	1.4 l	07/87→12/96	→09/87	5DA 006 623-001 Switch Unit, ignition system	4							
1.4 E	44 kW	1.4 l	05/87→12/96										
CITROËN - C25 Box (280_, 290_)													09/81 → 03/94
2.0	62 kW	2 l	02/91→03/94		5DA 006 623-001 Switch Unit, ignition system	4							
2.0 E	58 kW	2 l	09/81→03/94										
CITROËN - C25 Bus (280_, 290_)													09/81 → 02/94
1.8 E	51 kW	1.8 l	07/87→02/94		5DA 006 623-001 Switch Unit, ignition system	4							
2.0	62 kW	2 l	02/91→02/94										
2.0 E	58 kW	2 l	09/81→02/94										
CITROËN - C25 Platform/Chassis (280_, 290_)													01/87 → 03/94
2.0	62 kW	2 l	01/87→03/94		5DA 006 623-001 Switch Unit, ignition system	4							
CITROËN - CX I (MA)													06/79 → 08/85
2000	78 kW	2 l	06/79→08/85	→07/82	5DA 006 623-001 Switch Unit, ignition system	4							
CITROËN - CX II													08/85 → 12/92
20 RE	78 kW	2 l	08/85→12/92		5DA 006 623-001 Switch Unit, ignition system	4							
CITROËN - DISPATCH Box													01/07 →
2.0 i	103 kW	2 l	01/07→	⊗ EW10A	5DA 749 475-601 Ignition Coil	40							
CITROËN - DS3													01/10 →
1.4 VTi 95	70 kW	1.4 l	04/10→	⊗ 8FP (EP3); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 Racing	152 kW	1.6 l	02/11→	⊗ 5FD (EP6DTS); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 THP 150	110 kW	1.6 l	01/10→	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 THP 155	115 kW	1.6 l	04/10→	⊗ 5FR (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 VTi 120	88 kW	1.6 l	04/10→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15							
CITROËN - DS4													04/11 →
1.6 THP 155	115 kW	1.6 l	04/11→	⊗ 5FV (EP6CDT); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 THP 160	120 kW	1.6 l	04/12→	⊗ 5FM (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 THP 200	147 kW	1.6 l	04/11→	⊗ 5FU (EP6DTX); 4x	5DA 193 175-491 Ignition Coil	15							
1.6 VTi 120	88 kW	1.6 l	04/11→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15							
CITROËN - DS5													11/11 →
1.6 THP 155	115 kW	1.6 l	11/11→	⊗ 5FV (EP6CDT); 4x	5DA 193 175-491 Ignition Coil	15							

CITROËN - DS5							11/11→
1.6 THP 200	147 kW	1.6 l	11/11→	4x; 5FU (EP6DTX)	5DA 193 175-491 Ignition Coil	15	
CITROËN - EVASION (22, U6)							06/94→07/02
2.0	89 kW	2 l	06/94→07/02		5DA 193 175-421 Ignition Coil	13	
2.0 16V	97 kW	2 l	05/98→04/00	RFV (XU10J4R)	5DA 193 175-451 Ignition Coil	14	
2.0 Turbo C.T.	108 kW	2 l	06/94→07/02		5DA 006 623-601 Switch Unit, ignition system	8	
					5DA 193 175-421 Ignition Coil	13	
CITROËN - GS							09/79→07/86
A 1.3	48 kW	1.3 l	09/79→07/86		5DA 006 623-001 Switch Unit, ignition system	4	
CITROËN - JUMPER Box (244)							04/02→
2.0	81 kW	2 l	04/02→		5DA 193 175-421 Ignition Coil	13	
CITROËN - JUMPER Bus (244, Z_)							04/02→
2.0	81 kW	2 l	04/02→		5DA 193 175-421 Ignition Coil	13	
CITROËN - JUMPY							01/07→
2.0 i	103 kW	2 l	01/07→	EW10A	5DA 749 475-601 Ignition Coil	40	
CITROËN - JUMPY (U6U)							10/95→
1.6	58 kW	1.6 l	10/95→	220 A2.000	5DA 193 175-691 Ignition Coil	20	
				1580 SPI	5DA 193 175-691 Ignition Coil	20	
CITROËN - JUMPY Box (BS_, BT_, BY_, BZ_)							10/95→
1.6 i	58 kW	1.6 l	10/95→	220 A2.000	5DA 193 175-691 Ignition Coil	20	
				1580 SPI	5DA 193 175-691 Ignition Coil	20	
CITROËN - LNA							07/82→04/85
1.1	37 kW	1.1 l	07/82→04/85		5DA 006 623-001 Switch Unit, ignition system	4	
CITROËN - SAXO (S0, S1)							02/96→04/04
1.0 X	33 kW	1 l	05/96→11/98		5DA 193 175-421 Ignition Coil	13	
1.0 X	37 kW	1 l	05/98→06/03				
1.1 X,SX	40 kW	1.1 l	05/96→09/03				
1.1 X,SX	44 kW	1.1 l	05/96→09/03	HDZ	5DA 193 175-421 Ignition Coil	13	
				TU1JP	5DA 193 175-441 Ignition Coil	14	
1.4 VTS	55 kW	1.4 l	05/96→06/03	Manual Transmission; →Orga 07727 Automatic Transmission; L4	5DA 193 175-421 Ignition Coil	13	
				KFW (TU3JP) / KFX (TU3JP); Orga 07728→; Manual Transmission; L4	5DA 193 175-431 Ignition Coil	14	
				TU3JP	5DA 193 175-441 Ignition Coil	14	
1.6	88 kW	1.6 l	02/96→04/04	NFX (TU5JP4); CEE2000	5DA 193 175-461 Ignition Coil	14	
1.6 VTS	87 kW	1.6 l	06/96→09/03				
1.6 VTL,VTR	65 kW	1.6 l	05/96→06/03	Manual Transmission; →Orga 07874 Automatic Transmission	5DA 193 175-421 Ignition Coil	13	
				NFZ (TU5JP); Manual Transmission; L3	5DA 193 175-431 Ignition Coil	14	
CITROËN - VISA							03/82→03/91
11 E	37 kW	1.1 l	07/82→03/91		5DA 006 623-001 Switch Unit, ignition system	4	
14	44 kW	1.4 l	07/84→03/91				
16 GTI	76 kW	1.6 l	01/85→06/86				
16 GTI	83 kW	1.6 l	06/86→03/91				
14 GT	58 kW	1.4 l	03/82→03/91	07/82→	5DA 006 623-001 Switch Unit, ignition system	4	

				13	i	412	
CITROËN - XANTIA (X1)							03/93→01/98
1.6 i	65 kW	1.6 l	03/93→01/98			5DA 193 175-421 Ignition Coil	13
1.8 i	66 kW	1.8 l	04/97→01/98				
1.8 i	74 kW	1.8 l	03/93→01/98				
1.8 i 16V	81 kW	1.8 l	06/95→01/98	LFY (XU7JP4); Orga 07609→		5DA 193 175-451 Ignition Coil	14
			→09/97			5DA 358 000-301 Ignition Coil	35
2.0 i 16V	97 kW	2 l	06/95→01/98	RFV (XU10J4R); Orga 07609→		5DA 193 175-451 Ignition Coil	14
			→09/97			5DA 358 000-301 Ignition Coil	35
2.0 Turbo	108 kW	2 l	06/95→01/98			5DA 006 623-601 Switch Unit, ignition system	8
						5DA 193 175-421 Ignition Coil	13
CITROËN - XANTIA (X2)							01/98→04/03
1.8 i	66 kW	1.8 l	01/98→04/03			5DA 193 175-421 Ignition Coil	13
1.8 i 16V	81 kW	1.8 l	01/98→04/03	LFY (XU7JP4)		5DA 193 175-451 Ignition Coil	14
2.0 i 16V	97 kW	2 l	01/98→04/03	RFV (XU10J4R)		5DA 193 175-451 Ignition Coil	14
2.0 Turbo	108 kW	2 l	01/98→04/03			5DA 006 623-601 Switch Unit, ignition system	8
						5DA 193 175-421 Ignition Coil	13
CITROËN - XANTIA Break (X1)							06/95→01/98
1.8 i	66 kW	1.8 l	04/97→01/98			5DA 193 175-421 Ignition Coil	13
1.8 i	74 kW	1.8 l	06/95→01/98				
2.0 Turbo	108 kW	2 l	06/95→01/98				
1.8 i 16V	81 kW	1.8 l	06/95→01/98	LFY (XU7JP4); Orga 07609→		5DA 193 175-451 Ignition Coil	14
			→09/97			5DA 358 000-301 Ignition Coil	35
2.0 i 16V	97 kW	2 l	06/95→01/98	RFV (XU10J4R); Orga 07609→		5DA 193 175-451 Ignition Coil	14
			→09/97			5DA 358 000-301 Ignition Coil	35
CITROËN - XANTIA Break (X2)							01/98→04/03
1.8 i	66 kW	1.8 l	01/98→04/03			5DA 193 175-421 Ignition Coil	13
2.0 Turbo	108 kW	2 l	01/98→04/03				
1.8 i 16V	81 kW	1.8 l	01/98→04/03	LFY (XU7JP4)		5DA 193 175-451 Ignition Coil	14
2.0 i 16V	97 kW	2 l	01/98→04/03	RFV (XU10J4R)		5DA 193 175-451 Ignition Coil	14
CITROËN - XM (Y3)							05/89→06/94
2.0	94 kW	2 l	05/89→06/94	R6A; 05/90→; Manual Transmission; Orga ,04936→		5DA 193 175-421 Ignition Coil	13
2.0 i	79 kW	2 l	05/89→04/94	→05/90; with 3 way catalyst; + D / Austria / Denmark / FI / NL / + N / SV / + CH / BE / + UK / IT		5DA 006 623-001 Switch Unit, ignition system	4
2.0 i	89 kW	2 l	05/89→06/94	→05/90; with 3 way catalyst; + D / Austria / Scandinavia / + CH / NL / BE / + UK / IT		5DA 006 623-001 Switch Unit, ignition system	4
						5DA 006 623-041 Switch Unit, ignition system	4
						5DA 006 623-601 Switch Unit, ignition system	8
						5DA 193 175-421 Ignition Coil	13
2.0 i Turbo	104 kW	2 l	09/92→06/94			5DA 006 623-601 Switch Unit, ignition system	8
						5DA 193 175-421 Ignition Coil	13
CITROËN - XM (Y4)							05/94→10/00
2.0 i 16V	97 kW	2 l	05/94→10/00	RFV (XU10J4R); Orga 07609→		5DA 193 175-451 Ignition Coil	14
						5DA 358 000-301 Ignition Coil	35

CITROËN - XM (Y4)				05/94→10/00
2.0 Turbo	108 kW	2 l	05/94→10/00	04/95→ 5DA 006 623-601 Switch Unit, ignition system 8 5DA 193 175-421 Ignition Coil 13
3.0 V6	123 kW	3 l	05/94→10/00	5DA 006 623-191 Switch Unit, ignition system 5
3.0 V6 24V	147 kW	3 l	05/94→10/00	
CITROËN - XM Break (Y3)				05/89→06/94
2.0	94 kW	2 l	05/89→06/94	R6A; 05/90→; Manual Transmission; Orga 04936→ 5DA 193 175-421 Ignition Coil 13
2.0 i	89 kW	2 l	11/91→04/94	Orga 04937→; Manual Transmission 5DA 193 175-421 Ignition Coil 13
2.0 Turbo	104 kW	2 l	09/92→04/94	5DA 193 175-421 Ignition Coil 13
CITROËN - XM Break (Y4)				05/94→10/00
2.0 i 16V	97 kW	2 l	05/94→10/00	RFV (XU10J4R); Orga 07609→ 5DA 193 175-451 Ignition Coil 14 →09/97 5DA 358 000-301 Ignition Coil 35
2.0 Turbo	108 kW	2 l	05/94→10/00	5DA 193 175-421 Ignition Coil 13
CITROËN - XSARA (N1)				04/97→03/05
1.4 i	55 kW	1.4 l	04/97→03/05	→Orga 07874; CEE95 5DA 193 175-421 Ignition Coil 13 KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95 5DA 193 175-431 Ignition Coil 14 KFW (TU3JP) / KFX (TU3JP); CEE 2000 KFW (TU3JP) 5DA 193 175-441 Ignition Coil 14
1.6 16V	80 kW	1.6 l	09/00→03/05	NFU (TU5JP4); incl. spark plug connector 5DA 193 175-731 Ignition Coil 22
1.6 i	65 kW	1.6 l	04/97→09/00	→Orga 07874 5DA 193 175-421 Ignition Coil 13 NFZ (TU5JP); Orga 07875→ 5DA 193 175-431 Ignition Coil 14
1.8 i	66 kW	1.8 l	04/97→09/00	LFX (XU7JB) 5DA 193 175-421 Ignition Coil 13
1.8 i 16V	81 kW	1.8 l	04/97→09/00	LFY (XU7JP4); Orga 07665→ 5DA 193 175-451 Ignition Coil 14 →09/97 5DA 358 000-301 Ignition Coil 35
1.8 i Aut.	74 kW	1.8 l	04/97→09/00	5DA 193 175-421 Ignition Coil 13
2.0 16V	97 kW	2 l	07/98→09/00	RFV (XU10J4R) 5DA 193 175-451 Ignition Coil 14
CITROËN - XSARA Break (N2)				10/97→08/05
1.4 i	55 kW	1.4 l	10/97→08/05	→Orga 07874; CEE95 5DA 193 175-421 Ignition Coil 13 KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95 5DA 193 175-431 Ignition Coil 14 KFW (TU3JP) / KFX (TU3JP); CEE 2000 KFW (TU3JP) 5DA 193 175-441 Ignition Coil 14
1.6 16V	80 kW	1.6 l	09/00→08/05	NFU (TU5JP4); incl. spark plug connector 5DA 193 175-731 Ignition Coil 22
1.6 i	65 kW	1.6 l	10/97→09/00	→Orga 07874 5DA 193 175-421 Ignition Coil 13 NFZ (TU5JP); Orga 07875→ 5DA 193 175-431 Ignition Coil 14
1.8 i	66 kW	1.8 l	10/97→09/00	LFX (XU7JB) 5DA 193 175-421 Ignition Coil 13
1.8 i 16V	81 kW	1.8 l	10/97→09/00	LFY (XU7JP4); Orga 07665→ 5DA 193 175-451 Ignition Coil 14
1.8 i Aut.	74 kW	1.8 l	10/97→09/00	5DA 193 175-421 Ignition Coil 13
2.0 16V	97 kW	2 l	07/98→09/00	RFV (XU10J4R) 5DA 193 175-451 Ignition Coil 14

CITROËN - XSARA Coupe (N0)						02/98→03/05
1.4 i	55 kW	1.4 l	03/98→03/05	→Orga 07874; CEE95	5DA 193 175-421 Ignition Coil	13
				⊗ KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95	5DA 193 175-431 Ignition Coil	14
				⊗ KFW (TU3JP) / KFX (TU3JP); CEE 2000		
				⊗ KFW (TU3JP)	5DA 193 175-441 Ignition Coil	14
1.6 16V	80 kW	1.6 l	09/00→03/05	⊗ NFU (TU5JP4); incl. spark plug connector	5DA 193 175-731 Ignition Coil	22
1.8 i	66 kW	1.8 l	02/98→09/00	⊗ LFX (XU7JB)	5DA 193 175-421 Ignition Coil	13
1.8 i 16V	81 kW	1.8 l	02/98→09/00	⊗ LFY (XU7JP4); Orga 07665→	5DA 193 175-451 Ignition Coil	14
CITROËN - XSARA PICASSO (N68)						12/99→
1.6	65 kW	1.6 l	12/99→	⊗ NFZ (TU5JP); L3	5DA 193 175-431 Ignition Coil	14
1.6	70 kW	1.6 l	12/99→	⊗ NFV (TU5JP)	5DA 193 175-431 Ignition Coil	14
				⊗ TU5JP	5DA 193 175-441 Ignition Coil	14
1.6 16V	80 kW	1.6 l	09/05→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
CITROËN - ZX (N2)						03/91→06/97
1.1	44 kW	1.1 l	03/91→06/97	08/96→; Orga 07239→	5DA 193 175-421 Ignition Coil	13
				⊗ HDZ (TU1M); 04/94→	5DA 193 175-721 Ignition Coil	21
1.4	55 kW	1.4 l	03/91→06/97	⊗ KDZ (TU3M/Z)	5DA 193 175-721 Ignition Coil	21
1.4 i	55 kW	1.4 l	03/91→06/97	⊗ KFX	5DA 193 175-421 Ignition Coil	13
				⊗ KDZ (TU3M/Z) / KDX (TU3M/Z)	5DA 193 175-721 Ignition Coil	21
1.6 i	65 kW	1.6 l	03/91→06/97	⊗ BFZ	5DA 193 175-421 Ignition Coil	13
1.8 i	74 kW	1.8 l	07/92→06/97		5DA 193 175-421 Ignition Coil	13
1.9 i	88 kW	1.9 l	03/91→06/97			
1.8 i 16V	81 kW	1.8 l	01/96→06/97	→09/97	5DA 358 000-301 Ignition Coil	35
CITROËN - ZX Break (N2)						10/93→02/98
1.4 i	55 kW	1.4 l	10/93→10/97	⊗ KFX	5DA 193 175-421 Ignition Coil	13
				⊗ KDX (TU3M/Z)	5DA 193 175-721 Ignition Coil	21
1.6 i	65 kW	1.6 l	10/93→10/97	⊗ BFZ	5DA 193 175-421 Ignition Coil	13
1.8 i 16V	81 kW	1.8 l	01/96→02/98	→09/97	5DA 358 000-301 Ignition Coil	35

DACIA - LOGAN (LS_)											09/04 →		
1.2 16V	55 kW	1.2 l	02/06 →		D4F 732	5DA 193 175-831 Ignition Coil						25	
1.4 (LSOA, LSOC, LSOE, LSOG)	55 kW	1.4 l	09/04 →			5DA 193 175-391 Ignition Coil						12	
1.6 (LSOB, LSOD, LSOF, LSOH)	64 kW	1.6 l	09/04 →										
DACIA - LOGAN II											10/12 →		
1.2 LPG	55 kW	1.2 l	10/12 →		D4F 734	5DA 193 175-831 Ignition Coil						25	
DACIA - LOGAN MCV (KS_)											02/07 →		
1.4	55 kW	1.4 l	02/07 →		K7J 710; →engine 111130	5DA 193 175-391 Ignition Coil						12	
1.6	64 kW	1.6 l	02/07 →		K7M 710	5DA 193 175-391 Ignition Coil						12	
1.6 Bifuel	64 kW	1.6 l	11/08 →										
1.6 MPI 85	62 kW	1.6 l	05/10 →		K7M 800; →engine 111130	5DA 193 175-391 Ignition Coil						12	
DACIA - SANDERO											06/08 →		
1.2 16V	55 kW	1.2 l	11/08 →		D4F 732	5DA 193 175-831 Ignition Coil						25	
1.2 16V LPG	55 kW	1.2 l	11/08 →										
1.4	55 kW	1.4 l	06/08 →		K7J 710; →engine 111130	5DA 193 175-391 Ignition Coil						12	
1.6	64 kW	1.6 l	06/08 →		K7M 710; →engine 111130	5DA 193 175-391 Ignition Coil						12	
1.6 MPI 85	62 kW	1.6 l	05/10 →		K7M 800; →engine 111130	5DA 193 175-391 Ignition Coil						12	
DACIA - SANDERO II											10/12 →		
1.2	55 kW	1.2 l	10/12 →		D4F 732	5DA 193 175-831 Ignition Coil						25	

DAEWOO - KORANDO (KJ)							01/99 →
3.2 4x4	156 kW	3.2 l	01/99→	3x	5DA 193 175-361 Ignition Coil	11	
DAEWOO - LANOS (KLAT)							05/97 →
1.4	55 kW	1.4 l	05/97→	A14SMS	5DA 193 175-581 Ignition Coil	18	
1.5	63 kW	1.5 l	05/97→	A15SMS	5DA 193 175-581 Ignition Coil	18	
1.6 16V	78 kW	1.6 l	05/97→	A16DMS	5DA 193 175-581 Ignition Coil	18	
DAEWOO - LANOS Saloon (KLAT)							05/97 →
1.4	55 kW	1.4 l	05/97→	A14SMS	5DA 193 175-581 Ignition Coil	18	
1.5	63 kW	1.5 l	05/97→	A15SMS	5DA 193 175-581 Ignition Coil	18	
1.6 16V	78 kW	1.6 l	05/97→	A16DMS	5DA 193 175-581 Ignition Coil	18	
DAEWOO - LEGANZA Saloon (KLAJ)							06/97 → 12/02
2.0 16V	98 kW	2 l	06/97→12/02	X 20 SED	5DA 193 175-581 Ignition Coil	18	
DAEWOO - MUSSO (FJ)							01/99 →
2.3	103 kW	2.3 l	01/99→	2x	5DA 193 175-361 Ignition Coil	11	
3.2 4x4	162 kW	3.2 l	01/99→	3x	5DA 193 175-361 Ignition Coil	11	
DAEWOO - NUBIRA (KLAJ)							05/97 →
1.6 16V	78 kW	1.6 l	05/97→	A16DMS	5DA 193 175-581 Ignition Coil	18	
2.0 16V	98 kW	2 l	05/97→	X 20 SED	5DA 193 175-581 Ignition Coil	18	
DAEWOO - NUBIRA Saloon (KLAJ)							05/97 →
1.6 16V	78 kW	1.6 l	05/97→	A16DMS	5DA 193 175-581 Ignition Coil	18	
2.0 16V	98 kW	2 l	05/97→	X 20 SED	5DA 193 175-581 Ignition Coil	18	
DAEWOO - NUBIRA Wagon (KLAJ)							05/97 →
1.6 16V	78 kW	1.6 l	05/97→	A16DMS	5DA 193 175-581 Ignition Coil	18	
2.0 16V	98 kW	2 l	05/97→	X 20 SED	5DA 193 175-581 Ignition Coil	18	

FERRARI - 348 tb/GTB		02/90→04/94				
3.4	221 kW	3.4 l	02/90→04/94	5DA 006 623-601 Switch Unit, ignition system	8	
FERRARI - 348 ts/GTS		08/90→10/93				
3.4	221 kW	3.4 l	08/90→10/93	5DA 006 623-601 Switch Unit, ignition system	8	
FERRARI - DINO GT4 (208/308)		02/74→06/80				
208	125 kW	2 l	02/75→06/80	5DA 006 623-051 Switch Unit, ignition system	4	
308	188 kW	3 l	02/74→06/80			
FERRARI - MONDIAL		03/89→12/93				
3.4 T	221 kW	3.4 l	03/89→12/93	10/89→	5DA 006 623-601 Switch Unit, ignition system	8
FERRARI - MONDIAL Convertible		01/89→12/93				
3.4 T	221 kW	3.4 l	01/89→12/93	10/89→	5DA 006 623-601 Switch Unit, ignition system	8
FERRARI - TESTAROSSA		05/84→12/91				
5.0	272 kW	5 l	08/86→10/91	12/89→	5DA 006 623-431 Switch Unit, ignition system	6
5.0	287 kW	5 l	05/84→12/91			



										13		412		
FIAT - 132 Saloon										05/77→06/81				
2.0	82 kW	2 l	05/77→06/81			5DA 006 623-051 Switch Unit, ignition system				4				
FIAT - 500 (312)										10/07→				
1.4	74 kW	1.4 l	10/07→	169 A3.000; 4		5DA 193 175-761 Ignition Coil				23				
FIAT - 500 C (312)										09/09→				
1.4	74 kW	1.4 l	09/09→	169 A3.000; 4		5DA 193 175-761 Ignition Coil				23				
FIAT - 500L										09/12→				
1.4	70 kW	1.4 l	09/12→	843 A1.000; 4		5DA 193 175-761 Ignition Coil				23				
FIAT - ARGENTA Saloon (132A)										06/81→07/86				
2000 i.e.	90 kW	2 l	06/81→07/86	→05/83		5DA 006 623-051 Switch Unit, ignition system				4				
FIAT - BARCHETTA (183)										04/95→05/05				
1.8 16V	96 kW	1.8 l	04/95→05/05	183 A1.000; 05/98→; VET 0037640→; →Model 2004; 4x		5DA 193 175-741 Ignition Coil				22				
				188 A6.000; →Model 2004; 4x						39				
				183 A1.000; →05/98; →VET 0037640; engine 0283747→		5DA 749 475-511 Ignition Coil				39				
FIAT - BRAVA (182)										10/95→12/02				
1.2 16V 80	59 kW	1.2 l	10/00→10/01	188 A5.000		5DA 193 175-691 Ignition Coil				20				
1.2 16V 80	60 kW	1.2 l	12/98→12/02	182 B2.000		5DA 193 175-691 Ignition Coil				20				
1.4 (182.BG)	55 kW	1.4 l	10/95→10/01	182 A5.000		5DA 193 175-691 Ignition Coil				20				
1.4 12 V (182.BA)	59 kW	1.4 l	10/95→08/98	182 A3.000		5DA 193 175-691 Ignition Coil				20				
1.6 16V (182.BB)	76 kW	1.6 l	02/96→10/01			5DA 749 475-091 Ignition Coil				36				
1.6 16V (182.BH)	66 kW	1.6 l	10/95→10/01	182 A6.000		5DA 749 475-091 Ignition Coil				36				
1.8 GT 16V (182.BC)	83 kW	1.8 l	10/95→10/01	182 A2.000; 07/99→; VET 4873621→; 4x		5DA 193 175-741 Ignition Coil				22				
				182 A2.000; →07/99; →VET 4873621; engine 0283747→		5DA 749 475-511 Ignition Coil				39				
FIAT - BRAVO I (182)										10/95→10/01				
1.2 16V 80	59 kW	1.2 l	10/00→10/01	188 A5.000		5DA 193 175-691 Ignition Coil				20				
1.2 16V 80	60 kW	1.2 l	12/98→10/00	182 B2.000		5DA 193 175-691 Ignition Coil				20				
1.4 (182.AA)	59 kW	1.4 l	10/95→10/01	182 A3.000		5DA 193 175-691 Ignition Coil				20				
1.4 (182.AG)	55 kW	1.4 l	10/95→10/01	182 A5.000		5DA 193 175-691 Ignition Coil				20				
1.6 16V (182.AB)	76 kW	1.6 l	03/96→10/01			5DA 749 475-091 Ignition Coil				36				
1.6 16V (182.AH)	66 kW	1.6 l	10/95→10/01			5DA 749 475-091 Ignition Coil				36				
1.8 GT (182.AC)	83 kW	1.8 l	10/95→10/01	182 A2.000; 07/99→; VET 4873621→; 4x		5DA 193 175-741 Ignition Coil				22				
				182 A2.000; →07/99; →VET 4873621; engine 0283747→		5DA 749 475-511 Ignition Coil				39				
2.0 HGT 20V (182.AD)	108 kW	2 l	10/95→07/98	182 A1.000		5DA 193 175-061 Ignition Coil				10				
FIAT - CINQUECENTO (170)										07/91→07/99				
0.7 (170AA)	23 kW	0.7 l	12/91→01/96	1x		5DA 193 175-341 Ignition Coil				11				
0.7 i (170AD)	22 kW	0.7 l	07/94→01/98			5DA 193 175-341 Ignition Coil				11				
0.9 (170AB)	30 kW	0.9 l	07/91→12/93	2x		5DA 193 175-341 Ignition Coil				11				
0.9 i.e. (170AC)	30 kW	0.9 l	07/91→12/93			5DA 193 175-341 Ignition Coil				11				
0.9 i.e. S (170AF, 170CF)	29 kW	0.9 l	07/91→07/99			5DA 193 175-341 Ignition Coil				11				
1.1 Sporting (170AH)	40 kW	1.1 l	10/94→01/98			5DA 193 175-341 Ignition Coil				11				
FIAT - COUPE (FA/175)										11/93→08/00				
1.8 16V	96 kW	1.8 l	03/96→08/00	183 A1.000; 05/98→; engine 1070426→; 4x		5DA 193 175-741 Ignition Coil				22				
				183 A1.000; →05/98; engine 0283747→engine 1070426		5DA 749 475-511 Ignition Coil				39				

FIAT - COUPE (FA/175)							11/93→08/00
2.0 16V Turbo	140 kW	2 l	11/93→08/96	2x	5DA 193 175-341 Ignition Coil	11	
2.0 20V	108 kW	2 l	08/96→04/98	☉ 182 A1.000	5DA 193 175-061 Ignition Coil	10	
2.0 20V Turbo	162 kW	2 l	08/96→08/00	☉ 175 A3.000	5DA 193 175-061 Ignition Coil	10	
FIAT - CROMA (154)							12/85→08/96
2000 16V	101 kW	2 l	08/92→08/96	☉ 154 E1.000	5DA 193 175-691 Ignition Coil	20	
2000 CHT	74 kW	2 l	01/91→09/92		5DA 006 623-051 Switch Unit, ignition system	4	
2000 CHT (154.AC)	66 kW	2 l	12/85→02/89				
2000 i.e. Turbo	111 kW	2 l	11/86→11/88		5DA 006 623-431 Switch Unit, ignition system	6	
2000 i.e. Turbo (154.AM, 154.LM)	110 kW	2 l	06/87→08/96				
2000 i.e. Turbo (154.AM)	114 kW	2 l	12/85→06/90				
FIAT - DOBLO (119)							03/01→
1.2 (223AXA1A)	48 kW	1.2 l	03/01→	2x	5DA 193 175-341 Ignition Coil	11	
1.6 16V (223AXD1A)	76 kW	1.6 l	10/01→	☉ 182 B6.000	5DA 193 175-751 Ignition Coil	22	
					5DA 749 475-091 Ignition Coil	36	
FIAT - DOBLO Box Body / Estate (263)							02/10→
1.4	70 kW	1.4 l	02/10→	☉ 843 A1.000; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - DOBLO Cargo (223)							03/01→
1.2 (223ZX1A)	48 kW	1.2 l	03/01→	2x	5DA 193 175-341 Ignition Coil	11	
1.6 16V (223ZXD1A)	76 kW	1.6 l	10/01→	☉ 182 B6.000	5DA 193 175-751 Ignition Coil	22	
					5DA 749 475-091 Ignition Coil	36	
FIAT - DOBLO MPV (152, 263)							02/10→
1.4	70 kW	1.4 l	02/10→	☉ 843 A1.000; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - DOBLO Platform/Chassis (263)							04/10→
1.4	70 kW	1.4 l	04/10→	☉ 843 A1.000; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - DUCATO Box (230L)							03/94→04/02
2.0	80 kW	2 l	03/94→04/02		5DA 193 175-421 Ignition Coil	13	
FIAT - DUCATO Box (244)							04/02→
2.0	81 kW	2 l	04/02→		5DA 193 175-421 Ignition Coil	13	
FIAT - DUCATO Box (250)							04/09→
140 Natural Power	100 kW	3 l	04/09→	☉ F1CE0441A; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - DUCATO Bus (230)							03/94→04/02
2.0 Panorama/Combinato	80 kW	2 l	03/94→04/02		5DA 193 175-421 Ignition Coil	13	
FIAT - DUCATO Bus (244, Z_)							04/02→
2.0	81 kW	2 l	04/02→		5DA 193 175-421 Ignition Coil	13	
FIAT - DUCATO Bus (250)							04/09→
140 Natural Power	100 kW	3 l	04/09→	☉ F1CE0441A; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - DUCATO Platform/Chassis (230)							06/98→04/02
2.0	80 kW	2 l	06/98→04/02		5DA 193 175-421 Ignition Coil	13	
FIAT - DUNA (146 B)							01/87→12/91
60 1.1	43 kW	1.1 l	01/87→12/91		5DA 006 623-161 Switch Unit, ignition system	4	
70 1.3	49 kW	1.3 l	01/87→12/91				

FIAT - DUNA Weekend (146 B)						01/87→12/91
60 1.1	43 kW	1.1 l	01/87→12/91		5DA 006 623-161 Switch	4
70 1.3	49 kW	1.3 l	01/87→12/91		Unit, ignition system	
FIAT - FIORINO (147)						12/87→08/93
1.3	49 kW	1.3 l	12/87→08/93	01/89→	5DA 006 623-161 Switch	4
						Unit, ignition system
FIAT - FIORINO Box (146)						01/88→05/01
70 1.3	49 kW	1.3 l	01/88→12/94		5DA 006 623-161 Switch	4
						Unit, ignition system
70 i.e. 1.4	49 kW	1.4 l	05/94→05/01	146 D5.000	5DA 193 175-691 Ignition	20
						Coil
75 i.e. 1.6	55 kW	1.6 l	10/93→05/01	146 D6.000	5DA 193 175-691 Ignition	20
						Coil
FIAT - FIORINO Pick up (146)						01/94→05/01
1.4	49 kW	1.4 l	05/94→05/01	146 D5.000	5DA 193 175-691 Ignition	20
						Coil
1.6	55 kW	1.6 l	01/94→05/01	146 D6.000	5DA 193 175-691 Ignition	20
						Coil
FIAT - IDEA						12/03→
1.2 16V	59 kW	1.2 l	01/04→	188 A5.000; 4	5DA 193 175-761 Ignition	23
						Coil
1.4	66 kW	1.4 l	12/03→	192 B2.000; 4	5DA 193 175-761 Ignition	23
						Coil
1.4 16V	70 kW	1.4 l	01/04→	843 A1.000; 4	5DA 193 175-761 Ignition	23
						Coil
FIAT - MAREA (185)						09/96→05/02
1.2 16V	60 kW	1.2 l	10/98→05/02	182 B2.000	5DA 193 175-691 Ignition	20
						Coil
1.4 80 12V	59 kW	1.4 l	09/96→05/02	182 A3.000	5DA 193 175-691 Ignition	20
						Coil
1.6 100 16V	76 kW	1.6 l	09/96→05/02		5DA 749 475-091 Ignition	36
						Coil
1.6 100 16V Bipower	76 kW	1.6 l	04/99→05/02	185 A3.000; →Model 2002	5DA 749 475-091 Ignition	36
						Coil
1.8 115 16V	83 kW	1.8 l	09/96→05/02	182 A2.000; Model 1999→Model 2002; VET 0270957→ / VET 2018321→; 4x	5DA 193 175-741 Ignition	22
						Coil
				182 A2.000; engine 0283747→; →VET 0270957 / →VET 2018321	5DA 749 475-511 Ignition	39
						Coil
2.0 150 20V	108 kW	2 l	09/96→04/99	182 A1.000	5DA 193 175-061 Ignition	10
						Coil
FIAT - MAREA Weekend (185)						09/96→05/02
1.2 16V	60 kW	1.2 l	10/98→05/02	182 B2.000	5DA 193 175-691 Ignition	20
						Coil
1.4 80 12V	59 kW	1.4 l	09/96→05/02	182 A3.000	5DA 193 175-691 Ignition	20
						Coil
1.6 100 16V	76 kW	1.6 l	09/96→05/02		5DA 749 475-091 Ignition	36
						Coil
1.8 115 16V	83 kW	1.8 l	09/96→05/02	182 A2.000; Model 1999→Model 2002; VET 0270957→ / VET 2018321→; 4x	5DA 193 175-741 Ignition	22
						Coil
				182 A2.000; engine 0283747→; →VET 0270957 / →VET 2018321	5DA 749 475-511 Ignition	39
						Coil
2.0 150 20V	108 kW	2 l	09/96→04/99	182 A1.000	5DA 193 175-061 Ignition	10
						Coil
FIAT - MULTIPLA (186)						04/99→06/10
1.6	76 kW	1.6 l	09/00→06/10	182 B6.000	5DA 749 475-091 Ignition	36
						Coil
1.6 16V (186AGB1A)	70 kW	1.6 l	04/02→06/10			
1.6 16V Bipower (186AXC1A)	76 kW	1.6 l	10/01→06/10			
1.6 100 16V (186AXA1A)	76 kW	1.6 l	04/99→06/10		5DA 749 475-091 Ignition	36
						Coil
1.6 16V Bipower (186AMB1A)	76 kW	1.6 l	04/99→06/10			
1.6 16V Blupower (186AMA1A)	70 kW	1.6 l	04/99→06/10			
FIAT - PALIO Weekend (178DX)						04/96→02/01
1.2	59 kW	1.2 l	09/01→	188 A5.000	5DA 193 175-691 Ignition	20
						Coil
1.2 (178DX.G1A)	54 kW	1.2 l	04/96→02/01	2x	5DA 193 175-341 Ignition	11
						Coil
1.2 (178DYA1A)	44 kW	1.2 l	02/01→			
1.6 16V (178DX.D1A)	74 kW	1.6 l	04/96→02/01	178 B3.000	5DA 749 475-091 Ignition	36
						Coil

		13	i	412	
FIAT - PALIO Weekend (178DX)					04/96→02/01
1.6 16V (178DYC1A06)	76 kW	1.6 l	02/01→	182 B6.000; →Model 2004	5DA 749 475-091 Ignition Coil 36
FIAT - PANDA (141A_)					01/86→07/04
1000	32 kW	1 l	01/86→04/92		5DA 006 623-161 Switch Unit, ignition system 4
1000 4x4	32 kW	1 l	01/86→07/89		
1000 4x4	37 kW	1 l	01/86→12/92		
750 (141AA)	25 kW	0.8 l	01/86→01/95		
750 (141AM) CAT	25 kW	0.8 l	01/95→10/03		
1000 4x4	33 kW	1 l	05/86→12/94		5DA 006 623-161 Switch Unit, ignition system 4
1000 i.e. CAT	33 kW	1 l	10/87→08/98		
				2x	5DA 193 175-341 Ignition Coil 11
1100	37 kW	1.1 l	05/91→12/99	2x	5DA 193 175-341 Ignition Coil 11
1100	40 kW	1.1 l	02/95→09/03		
1100 4x4	40 kW	1.1 l	02/95→07/04		
1100 Trekking 4x4	37 kW	1.1 l	10/91→07/04		
900	29 kW	0.9 l	04/92→12/96		
FIAT - PANDA (169)					09/03→
1.1	40 kW	1.1 l	09/03→	2x	5DA 193 175-341 Ignition Coil 11
1.2	44 kW	1.2 l	09/03→		
1.2 4x4	44 kW	1.2 l	10/04→		
1.2 Natural Power	44 kW	1.2 l	01/07→11/09		
1.4	74 kW	1.4 l	10/06→	169 A3.000; 4	5DA 193 175-761 Ignition Coil 23
FIAT - PANDA (312)					02/12→
0.9	44 kW	0.9 l	12/13→	312 A4.000; Naturally Aspirated Engine; 2	5DA 193 175-761 Ignition Coil 23
0.9	48 kW	0.9 l	02/12→		
0.9	57 kW	0.9 l	02/12→	312 A2.000; Naturally Aspirated Engine; 2	5DA 193 175-761 Ignition Coil 23
0.9	63 kW	0.9 l	02/12→		
0.9 4x4	63 kW	0.9 l	09/12→		
0.9 Natural Power	63 kW	0.9 l	07/12→		
0.9	59 kW	0.9 l	12/13→	312 A5.000; Naturally Aspirated Engine; 2	5DA 193 175-761 Ignition Coil 23
FIAT - PANDA Van (141_)					01/86→02/04
1000	32 kW	1 l	01/86→02/92		5DA 006 623-161 Switch Unit, ignition system 4
750	25 kW	0.8 l	01/86→07/92		
1000 i.e	33 kW	1 l	08/92→02/04		5DA 006 623-161 Switch Unit, ignition system 4
				2x	5DA 193 175-341 Ignition Coil 11
FIAT - PANDA VAN (312)					02/12→
0.9	48 kW	0.9 l	02/12→	312 A4.000; Naturally Aspirated Engine; 2	5DA 193 175-761 Ignition Coil 23
0.9	63 kW	0.9 l	02/12→	312 A2.000; Naturally Aspirated Engine; 2	5DA 193 175-761 Ignition Coil 23
0.9 4x4	63 kW	0.9 l	09/12→		
FIAT - PUNTO (176)					09/93→09/99
1.2 16V	63 kW	1.2 l	04/97→09/99	2x	5DA 193 175-341 Ignition Coil 11
55 1.1	40 kW	1.1 l	09/93→09/99		
60 1.2	43 kW	1.2 l	01/94→09/99		
75 1.2	54 kW	1.2 l	10/93→09/99		
1.4 GT Turbo	96 kW	1.4 l	09/96→09/99	176 B6.000	5DA 193 175-691 Ignition Coil 20
1.4 GT Turbo	98 kW	1.4 l	01/94→09/96		5DA 006 623-601 Switch Unit, ignition system 8
				176 A4.000	5DA 193 175-691 Ignition Coil 20
60 1.2	44 kW	1.2 l	03/94→09/99	2x; 176 B4.000	5DA 193 175-341 Ignition Coil 11
FIAT - PUNTO (188)					09/99→
1.2 16V 80 (188.233, .235, .253, .255, .333, .353, .639...)	59 kW	1.2 l	09/99→	188 A5.000	5DA 193 175-691 Ignition Coil 20
1.2 60 (188.030, .050, .130, .150, .230, .250)	44 kW	1.2 l	09/99→	2x	5DA 193 175-341 Ignition Coil 11
1.2 Natural Power	44 kW	1.2 l	09/03→		
1.4	70 kW	1.4 l	09/03→	843 A1.000; 4	5DA 193 175-761 Ignition Coil 23
1.8 130 HGT (188.738, .718)	96 kW	1.8 l	09/99→	183 A1.000; →Model 2003; 4x 188 A6.000; 4x	5DA 193 175-741 Ignition Coil 22

FIAT - PUNTO (199)							10/05→
1.4 16V	70 kW	1.4 l	10/05→	☉ 199 A6.000; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - PUNTO Convertible (176C)							04/94→06/00
60 1.2	43 kW	1.2 l	04/94→06/00	2x	5DA 193 175-341 Ignition Coil	11	
85 16V 1.2	63 kW	1.2 l	04/97→06/00				
60 1.2	44 kW	1.2 l	05/95→06/00	2x; ☉ 176 B4.000	5DA 193 175-341 Ignition Coil	11	
FIAT - PUNTO Van (188AX)							02/00→10/09
1.2 60	44 kW	1.2 l	02/00→10/09	2x	5DA 193 175-341 Ignition Coil	11	
FIAT - REGATA Saloon (138)							09/83→07/89
85 1.5	58 kW	1.5 l	05/85→12/87		5DA 006 623-051 Switch Unit, ignition system	4	
85 Super 1.5	60 kW	1.5 l	09/83→04/85				
90 i.e. 1.6	66 kW	1.6 l	01/87→07/89				
FIAT - REGATA Weekend (138)							01/84→07/89
85 1.5	60 kW	1.5 l	01/84→04/89	→12/87	5DA 006 623-051 Switch Unit, ignition system	4	
90 i.e. 1.6	66 kW	1.6 l	01/87→07/89		5DA 006 623-051 Switch Unit, ignition system	4	
FIAT - RITMO III (198)							04/07→
1.4	66 kW	1.4 l	04/07→	☉ 192 B2.000; Naturally Aspirated Engine; 4	5DA 193 175-761 Ignition Coil	23	
1.4 16V	103 kW	1.4 l	03/08→	☉ 198 A7.000; 4; Naturally Aspirated Engine	5DA 193 175-761 Ignition Coil	23	
1.4 T-Jet	88 kW	1.4 l	09/07→	☉ 198 A4.000; 4; Naturally Aspirated Engine	5DA 193 175-761 Ignition Coil	23	
1.4 T-Jet	110 kW	1.4 l	09/07→	☉ 198 A1.000; Naturally Aspirated Engine; 4	5DA 193 175-761 Ignition Coil	23	
FIAT - SCUDO Box (220L)							02/96→12/06
1.6	58 kW	1.6 l	02/96→12/06	☉ 220 A 2.000	5DA 193 175-691 Ignition Coil	20	
FIAT - SCUDO Combinato (220P)							02/96→12/06
1.6	58 kW	1.6 l	02/96→12/06	☉ 220 A 2.000	5DA 193 175-691 Ignition Coil	20	
FIAT - SEICENTO (187)							01/98→01/10
0.9 (187AXA, 187AXA1A)	29 kW	0.9 l	01/98→01/10	2x	5DA 193 175-341 Ignition Coil	11	
1.1 (187AXB, 187AXB1A)	40 kW	1.1 l	01/98→01/10				
FIAT - STILO (192)							10/01→11/06
1.2 16V (192_XA1B)	59 kW	1.2 l	02/02→11/06	☉ 188 A5.000; 4	5DA 193 175-761 Ignition Coil	23	
1.4 16V	66 kW	1.4 l	03/05→11/06	☉ 192 B2.000; 4	5DA 193 175-761 Ignition Coil	23	
1.4 16V	70 kW	1.4 l	01/04→11/06	☉ 843 A1.000; 4	5DA 193 175-761 Ignition Coil	23	
1.6 16V (192_XB1A)	76 kW	1.6 l	10/01→11/06	☉ 182 B6.000	5DA 193 175-751 Ignition Coil	22	
1.8 16V (192_XC1A)	98 kW	1.8 l	10/01→11/06	☉ 192 A4.000; →Model 2003; 4x	5DA 193 175-741 Ignition Coil	22	
FIAT - STILO Multi Wagon (192)							01/03→08/08
1.4 16V	66 kW	1.4 l	03/05→08/08	☉ 192 B2.000; 4	5DA 193 175-761 Ignition Coil	23	
1.4 16V	70 kW	1.4 l	01/04→08/08	☉ 843 A1.000; 4	5DA 193 175-761 Ignition Coil	23	
1.6 16V	76 kW	1.6 l	01/03→08/08	☉ 182 B6.000	5DA 193 175-751 Ignition Coil	22	
1.8 16V	98 kW	1.8 l	01/03→08/08	☉ 192 A4.000; 4x	5DA 193 175-741 Ignition Coil	22	
FIAT - STRADA Pickup (178E)							06/99→
1.2	54 kW	1.2 l	06/99→	2x	5DA 193 175-341 Ignition Coil	11	

FIAT - SUPERBRAVO				06/78→12/81	
2.0 Racing	85 kW	2 l	06/78→12/81		5DA 006 623-051 Switch Unit, ignition system 4
FIAT - TEMPRA (159)				03/90→08/96	
1.4 i.e. (159.AC, 159.AX)	51 kW	1.4 l	03/92→08/96	836 A4.000	5DA 193 175-691 Ignition Coil 20
1.6	63 kW	1.6 l	03/90→04/93		5DA 006 623-161 Switch Unit, ignition system 4
1.6 i.e. (159.AS, 159.AT)	55 kW	1.6 l	06/92→08/96	835 C1.000	5DA 193 175-691 Ignition Coil 20
1.8 i.e. (159.AV)	76 kW	1.8 l	09/93→08/96	2x	5DA 193 175-341 Ignition Coil 11
1.8 i.e. (159.AZ)	66 kW	1.8 l	09/93→08/96		
1.8 i.e. (159.BY)	74 kW	1.8 l	10/94→08/96		
FIAT - TEMPRA S.W. (159)				10/90→08/96	
1.4 i.e. (159.AC, 159.AX)	51 kW	1.4 l	10/92→08/96	836 A4.000	5DA 193 175-691 Ignition Coil 20
1.6	63 kW	1.6 l	12/90→04/93		5DA 006 623-161 Switch Unit, ignition system 4
1.6 i.e. (159.AE)	57 kW	1.6 l	10/90→08/96	835 C1.000	5DA 193 175-691 Ignition Coil 20
1.6 i.e. (159.AS, 159.AT)	55 kW	1.6 l	10/92→08/96		
1.8 i.e. (159.AV)	76 kW	1.8 l	09/93→08/96	2x	5DA 193 175-341 Ignition Coil 11
1.8 i.e. (159.AZ)	66 kW	1.8 l	09/93→08/96		
1.8 i.e. (159.BY)	74 kW	1.8 l	10/94→08/96		
FIAT - TIPO (160)				05/89→04/95	
1.4 i.e. (160.AP, 160.AD, 160.EA)	51 kW	1.4 l	05/89→04/95	836 A4.000	5DA 193 175-691 Ignition Coil 20
1.6 i.e. (160.A1, 160.EC, 160.EB)	55 kW	1.6 l	10/92→04/95	835 C1.000	5DA 193 175-691 Ignition Coil 20
1.8 i.e.	71 kW	1.8 l	03/93→04/95	2x	5DA 193 175-341 Ignition Coil 11
1.8 i.e.	66 kW	1.8 l	09/93→04/95		
1.8 i.e. (160.ED)	76 kW	1.8 l	04/93→04/95		
1.8 i.e. 16V Sport	100 kW	1.8 l	11/89→06/92		5DA 006 623-431 Switch Unit, ignition system 6
FIAT - ULYSSE (220)				06/94→08/02	
1.8 (220.BB5)	73 kW	1.8 l	05/97→08/02		5DA 193 175-421 Ignition Coil 13
2.0 (220.AC5)	89 kW	2 l	06/94→08/02		
2.0 Turbo (220.AD5)	108 kW	2 l	06/94→08/02		
FIAT - UNO (146A/E)				04/85→12/92	
1.3 Turbo i.e.	74 kW	1.3 l	09/89→03/91		5DA 006 623-431 Switch Unit, ignition system 6
1.3 Turbo i.e.	77 kW	1.3 l	04/85→08/89		
60 1.1	42 kW	1.1 l	04/89→12/92		5DA 006 623-161 Switch Unit, ignition system 4
60 1.1 (146A.EG)	43 kW	1.1 l	05/85→08/89		

FORD - C-MAX (DM2)						02/07→09/10
1.6	74 kW	1.6 l	02/07→09/10	HWDA / HWDB	5DA 193 175-791 Ignition Coil	23
1.8	90 kW	1.8 l	02/07→09/10	QQDC; 4	5DA 193 175-781 Ignition Coil	23
1.8	92 kW	1.8 l	02/07→09/10	QQDB / QQDA; 4	5DA 193 175-781 Ignition Coil	23
1.8 Flexifuel	92 kW	1.8 l	02/07→09/10	Q7DA; 4	5DA 193 175-781 Ignition Coil	23
2.0	107 kW	2 l	02/07→09/10	AODB / SYDA / AODE / AODA; 4	5DA 193 175-781 Ignition Coil	23
2.0 CNG	107 kW	2 l	04/09→09/10	SYDA; 4	5DA 193 175-781 Ignition Coil	23
2.0 LPG	107 kW	2 l	06/08→09/10			
FORD - COUGAR (EC_)						08/98→12/01
2.0 16V	96 kW	2 l	08/98→12/01	EDBD / EDBC / EDBB / EDDBA	5DA 193 175-411 Ignition Coil	13
2.5 ST 200	151 kW	2.5 l	01/00→12/01	SGA; →09/00	5DA 358 000-011 Ignition Coil	31
2.5 V6 24V	125 kW	2.5 l	08/98→12/01	LCBA; →09/00	5DA 358 000-011 Ignition Coil	31
2.5 V6 24V	125 kW	2.5 l	06/00→12/01	LCBC / LCBE / LCBB; →09/00	5DA 358 000-011 Ignition Coil	31
FORD - ESCORT '81 Express (AVA)						03/81→02/86
1.3	51 kW	1.3 l	03/81→02/86	02/85→	5DA 006 623-041 Switch Unit, ignition system	4
FORD - ESCORT '86 Express (AVF)						02/86→07/90
1.1	37 kW	1.1 l	05/86→07/90		5DA 006 623-041 Switch Unit, ignition system	4
1.3	46 kW	1.3 l	07/88→07/90	for vehicles without distributor	5DA 193 175-401 Ignition Coil	13
1.4 i	54 kW	1.4 l	02/86→07/90	F6B, F6D; for vehicles without distributor	5DA 193 175-401 Ignition Coil	13
FORD - ESCORT '91 Express (AVL)						07/90→12/94
1.3	46 kW	1.3 l	07/90→12/94	for vehicles with distributor	5DA 006 623-041 Switch Unit, ignition system	4
				JBD; for vehicles without distributor	5DA 193 175-401 Ignition Coil	13
1.4	52 kW	1.4 l	07/90→12/94		5DA 193 175-401 Ignition Coil	13
FORD - ESCORT '95 Box (AVL)						01/95→
1.4	54 kW	1.4 l	01/95→		5DA 193 175-401 Ignition Coil	13
FORD - ESCORT III (GAA)						09/80→12/85
1.1	37 kW	1.1 l	08/83→12/85		5DA 006 623-041 Switch Unit, ignition system	4
1.1	40 kW	1.1 l	09/80→08/83			
1.1	43 kW	1.1 l	09/80→08/83			
1.3	51 kW	1.3 l	09/80→12/85			
1.6 i (GAA)	66 kW	1.6 l	07/85→12/85			
1.6 RS Turbo	97 kW	1.6 l	11/84→12/85			
1.6	58 kW	1.6 l	09/80→12/85	02/85→	5DA 006 623-041 Switch Unit, ignition system	4
1.6 XR3i	77 kW	1.6 l	10/82→12/85	03/85→	5DA 006 623-041 Switch Unit, ignition system	4
FORD - ESCORT III Convertible (ALD)						09/83→12/85
1.3	51 kW	1.3 l	09/83→12/85		5DA 006 623-041 Switch Unit, ignition system	4
1.6 i	77 kW	1.6 l	09/83→12/85			
FORD - ESCORT III Estate (AWA)						09/80→12/85
1.1	37 kW	1.1 l	08/83→12/85		5DA 006 623-041 Switch Unit, ignition system	4
1.1	40 kW	1.1 l	09/80→08/83			
1.3	51 kW	1.3 l	03/81→12/85			
1.6	58 kW	1.6 l	09/80→12/85			
FORD - ESCORT IV (GAF, AWF, ABFT)						12/85→10/90
1.1	37 kW	1.1 l	12/85→07/90		5DA 006 623-041 Switch Unit, ignition system	4
1.3 (GAF)	46 kW	1.3 l	07/88→10/90	for vehicles without distributor	5DA 193 175-401 Ignition Coil	13

				13	i	412		
FORD - ESCORT IV (GAF, AWF, ABFT)								12/85→10/90
1.4	54 kW	1.4 l	01/86→07/90				5DA 006 623-041 Switch Unit, ignition system	4
				⊗ F6B, F6D; for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.4	55 kW	1.4 l	01/86→07/90	for vehicles with distributor			5DA 006 623-041 Switch Unit, ignition system	4
1.6	65 kW	1.6 l	04/89→07/90					
1.6 Turbo RS	97 kW	1.6 l	01/86→07/90	for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.6 XR3i	77 kW	1.6 l	01/86→08/89					
1.6 i	66 kW	1.6 l	01/86→05/90	for vehicles with distributor			5DA 006 623-191 Switch Unit, ignition system	5
				for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.6 i	75 kW	1.6 l	08/89→07/90				5DA 006 623-191 Switch Unit, ignition system	5
FORD - ESCORT IV Convertible (ALF)								01/86→07/90
1.4	54 kW	1.4 l	02/87→07/90	for vehicles with distributor			5DA 006 623-041 Switch Unit, ignition system	4
				⊗ F6B, F6D; for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.4	55 kW	1.4 l	01/86→07/90	for vehicles with distributor			5DA 006 623-041 Switch Unit, ignition system	4
1.6 i	66 kW	1.6 l	01/86→07/90					
1.6 XR3i	77 kW	1.6 l	01/86→07/90	for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.6 i	75 kW	1.6 l	08/89→07/90				5DA 006 623-041 Switch Unit, ignition system	4
FORD - ESCORT IV Estate (AWF, AVF)								01/86→07/90
1.3	44 kW	1.3 l	01/86→07/90				5DA 006 623-041 Switch Unit, ignition system	4
1.4	54 kW	1.4 l	01/86→07/90	for vehicles with distributor			5DA 006 623-041 Switch Unit, ignition system	4
				⊗ F6B, F6D; for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.4	55 kW	1.4 l	01/86→07/90	for vehicles with distributor			5DA 006 623-041 Switch Unit, ignition system	4
				for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.6 i	66 kW	1.6 l	01/86→07/90	for vehicles with distributor			5DA 006 623-191 Switch Unit, ignition system	5
				for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
FORD - ESCORT V (GAL)								07/90→12/92
1.3	44 kW	1.3 l	07/90→09/92	for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.6	66 kW	1.6 l	07/90→08/92					
1.4	52 kW	1.4 l	07/90→09/92				5DA 193 175-401 Ignition Coil	13
1.6	77 kW	1.6 l	07/90→12/92					
RS 2000	110 kW	2 l	05/91→12/92	⊗ N7A; 10/91→			5DA 749 475-401 Ignition Coil	39
FORD - ESCORT V Convertible (ALL)								07/90→12/92
1.4	52 kW	1.4 l	07/90→12/92				5DA 193 175-401 Ignition Coil	13
1.6	77 kW	1.6 l	07/90→12/92					
FORD - ESCORT V Estate (GAL, AVL)								07/90→09/92
1.3	44 kW	1.3 l	09/91→09/92	⊗ J6A; for vehicles with distributor			5DA 006 623-041 Switch Unit, ignition system	4
				for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.4	52 kW	1.4 l	07/90→09/92				5DA 193 175-401 Ignition Coil	13
1.6	77 kW	1.6 l	07/90→09/92					
1.6	66 kW	1.6 l	07/90→08/92	for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
FORD - ESCORT VI (GAL)								09/92→01/95
1.3	44 kW	1.3 l	09/92→01/95	for vehicles without distributor			5DA 193 175-401 Ignition Coil	13
1.4	55 kW	1.4 l	01/94→01/95					
1.4	52 kW	1.4 l	09/92→01/95				5DA 193 175-401 Ignition Coil	13
1.8 XR3i 16V 4x4	96 kW	1.8 l	08/93→01/95					
1.6 i 16V	65 kW	1.6 l	01/94→01/95	⊗ L1H			5DA 193 175-401 Ignition Coil	13

FORD - ESCORT VI (GAL)		09/92→01/95				
1.6 i 16V	66 kW	1.6 l	09/92→01/95	03/93→	5DA 193 175-401 Ignition	13
1.8 16V XR3i	96 kW	1.8 l	09/92→01/95		Coil	
1.8 i 16V	77 kW	1.8 l	09/92→01/95			
RS 2000	110 kW	2 l	09/92→01/95	⊗ N7A	5DA 749 475-401 Ignition	39
RS 2000 4x4	110 kW	2 l	08/93→01/95		Coil	
FORD - ESCORT VI Convertible (ALL)		12/92→01/95				
1.4	52 kW	1.4 l	12/92→04/94		5DA 193 175-401 Ignition	13
					Coil	
1.4 i	55 kW	1.4 l	07/93→01/95	for vehicles without distributor	5DA 193 175-401 Ignition	13
					Coil	
1.6 16V XR3i	66 kW	1.6 l	12/92→01/95	03/93→	5DA 193 175-401 Ignition	13
1.8 16V XR3i	96 kW	1.8 l	12/92→01/95		Coil	
FORD - ESCORT VI Estate (GAL)		09/92→01/95				
1.3	44 kW	1.3 l	09/92→01/95	⊗ J6A; for vehicles with distributor	5DA 006 623-041 Switch Unit, ignition system	4
				for vehicles without distributor	5DA 193 175-401 Ignition	13
					Coil	
1.4	52 kW	1.4 l	09/92→01/95		5DA 193 175-401 Ignition	13
1.8 i 16V	77 kW	1.8 l	01/93→01/95		Coil	
1.8 i 16V	96 kW	1.8 l	02/93→01/95			
1.4	55 kW	1.4 l	01/94→01/95	for vehicles without distributor	5DA 193 175-401 Ignition	13
					Coil	
1.6 i 16V	66 kW	1.6 l	09/92→01/95	03/93→	5DA 193 175-401 Ignition	13
					Coil	
FORD - ESCORT VI Saloon (GAL)		08/93→01/95				
1.3	44 kW	1.3 l	08/93→01/95	for vehicles without distributor	5DA 193 175-401 Ignition	13
1.4	55 kW	1.4 l	08/93→01/95		Coil	
1.4	52 kW	1.4 l	08/93→04/94		5DA 193 175-401 Ignition	13
1.6 i 16V	66 kW	1.6 l	08/93→01/95		Coil	
1.8 i 16V	77 kW	1.8 l	08/93→01/95			
FORD - ESCORT VII (GAL, AAL, ABL)		01/95→10/98				
1.3	44 kW	1.3 l	01/95→10/98	⊗ J6A / J4B; →09/98	5DA 193 175-401 Ignition	13
					Coil	
				⊗ J4B; 10/98→	5DA 193 175-411 Ignition	13
					Coil	
1.4	55 kW	1.4 l	01/95→10/98		5DA 193 175-401 Ignition	13
1.6 16V	66 kW	1.6 l	01/95→10/98		Coil	
1.6 16V 4x4	66 kW	1.6 l	01/95→10/98			
1.8 16V	77 kW	1.8 l	01/95→08/95			
1.8 16V	85 kW	1.8 l	01/95→10/98			
1.6 i 16V	65 kW	1.6 l	01/95→08/95	⊗ L1H	5DA 193 175-401 Ignition	13
					Coil	
RS 2000	110 kW	2 l	02/95→02/98	⊗ N7A; →08/96	5DA 749 475-401 Ignition	39
RS 2000 4x4	110 kW	2 l	02/95→10/98		Coil	
FORD - ESCORT VII Convertible (ALL)		02/95→08/00				
1.4	55 kW	1.4 l	02/95→08/98		5DA 193 175-401 Ignition	13
1.6 16V XR3i	66 kW	1.6 l	02/95→09/99		Coil	
1.8 16V XR3i	85 kW	1.8 l	10/95→08/98			
1.8 16V XR3i	96 kW	1.8 l	02/95→08/00			
1.6 16V XR3i	65 kW	1.6 l	02/95→12/96	⊗ L1H	5DA 193 175-401 Ignition	13
					Coil	
FORD - ESCORT VII Estate (GAL, ANL)		01/95→02/99				
1.3	44 kW	1.3 l	01/95→01/99	for vehicles with distributor	5DA 006 623-041 Switch Unit, ignition system	4
				⊗ J6A / J4B; →09/98; for vehicles without distributor	5DA 193 175-401 Ignition	13
					Coil	
				⊗ J4B; 10/98→	5DA 193 175-411 Ignition	13
					Coil	
1.4	55 kW	1.4 l	01/95→02/99		5DA 193 175-401 Ignition	13
1.6 16V	66 kW	1.6 l	01/95→02/99		Coil	
1.8 16V	77 kW	1.8 l	01/95→08/95			
1.8 16V	85 kW	1.8 l	01/95→02/99			
1.6 i 16V	65 kW	1.6 l	01/95→08/95	⊗ L1H	5DA 193 175-401 Ignition	13
					Coil	

				13	i	412			
FORD - ESCORT VII Saloon (GAL, AFL)							01/95→02/99		
1.3	44 kW	1.3 l	01/95→02/99	⊗ J4B / J6A; →09/98; for vehicles without distributor	5DA 193 175-401	Ignition Coil	13		
				⊗ J4B; 10/98→	5DA 193 175-411	Ignition Coil	13		
1.4	55 kW	1.4 l	01/95→02/99		5DA 193 175-401	Ignition Coil	13		
1.8 16V	77 kW	1.8 l	01/95→08/95						
1.8 16V	85 kW	1.8 l	01/95→02/99						
1.6 i 16V	66 kW	1.6 l	01/95→02/99	⊗ L1E / L1K	5DA 193 175-401	Ignition Coil	13		
FORD - ESCORT CLASSIC (AAL, ABL)							10/98→07/00		
1.6 16V	66 kW	1.6 l	10/98→07/00		5DA 193 175-401	Ignition Coil	13		
FORD - ESCORT CLASSIC Turnier (ANL)							02/99→07/00		
1.6 16V	66 kW	1.6 l	02/99→07/00		5DA 193 175-401	Ignition Coil	13		
FORD - FIESTA II (FBD)							09/83→11/89		
1.0 (FBD)	33 kW	1 l	09/83→02/89	05/86→	5DA 006 623-041	Switch Unit, ignition system	4		
1.1 (FBD)	36 kW	1.1 l	05/86→02/89		5DA 006 623-041	Switch Unit, ignition system	4		
1.4 (FBD)	55 kW	1.4 l	10/85→11/89						
1.4 (FBD)	52 kW	1.4 l	10/86→02/89	for vehicles without distributor	5DA 193 175-401	Ignition Coil	13		
FORD - FIESTA III (GFJ)							01/89→01/97		
1.1	37 kW	1.1 l	03/89→12/95	for vehicles without distributor	5DA 193 175-401	Ignition Coil	13		
1.3	44 kW	1.3 l	03/89→12/92						
1.3 CAT	44 kW	1.3 l	05/91→01/97						
1.6	65 kW	1.6 l	01/89→01/94						
1.6 XR2i	76 kW	1.6 l	03/89→03/93						
1.1	40 kW	1.1 l	03/89→12/95	⊗ GUE; for vehicles without distributor	5DA 193 175-401	Ignition Coil	13		
1.4	52 kW	1.4 l	03/89→12/95	08/89→	5DA 193 175-401	Ignition Coil	13		
1.4 CAT	54 kW	1.4 l	03/89→12/95						
1.4	54 kW	1.4 l	03/89→12/95	⊗ FUJ; for vehicles without distributor	5DA 193 175-401	Ignition Coil	13		
1.6 i 16V	65 kW	1.6 l	01/94→12/95		5DA 193 175-401	Ignition Coil	13		
1.6 Turbo (FBJT)	96 kW	1.6 l	03/90→10/92						
1.8 16V	77 kW	1.8 l	02/92→12/95	03/93→; for vehicles without distributor	5DA 193 175-401	Ignition Coil	13		
1.8 XR2i 16V	96 kW	1.8 l	02/92→12/95						
FORD - FIESTA IV (JA_, JB_)							08/95→01/02		
1.25 i 16V	55 kW	1.25 l	08/95→01/02	⊗ DHD / DHC / DHB / DHA; →05/98	5DA 193 175-401	Ignition Coil	13		
				⊗ DHC / DHG / DHF / DHE / DHD / DHB / DHA; 06/98→	5DA 193 175-411	Ignition Coil	13		
1.3 i	37 kW	1.3 l	08/95→01/02	⊗ JJE / JJA / JJM / JJC / JJK / JJJ; →09/98	5DA 193 175-401	Ignition Coil	13		
				⊗ JJM / JJK / JJJ / JJE / JJC / JJA; Brazil / Argentina; 10/98→	5DA 193 175-411	Ignition Coil	13		
1.3 i	44 kW	1.3 l	08/95→01/02	⊗ J4L / J4J / J4C / J4T / J4R / J4Q; →09/98	5DA 193 175-401	Ignition Coil	13		
				⊗ J4J / J4C / J4T / J4R / J4Q / J4L; Argentina / Brazil; 10/98→	5DA 193 175-411	Ignition Coil	13		
1.4 i 16V	66 kW	1.4 l	04/96→01/02	⊗ FHE / FHA; →05/98	5DA 193 175-401	Ignition Coil	13		
				⊗ FHA / FHE; 06/98→	5DA 193 175-411	Ignition Coil	13		
1.6 16V Sport	76 kW	1.6 l	02/00→01/02	⊗ L1T / L1V	5DA 193 175-411	Ignition Coil	13		
FORD - FIESTA V (JH_, JD_)							11/01→06/08		
1.25 16V	51 kW	1.25 l	03/03→06/08	⊗ M7JB / M7JA; →02/05	5DA 193 175-411	Ignition Coil	13		
				⊗ M7JB / M7JA; 03/05→	5DA 193 175-791	Ignition Coil	23		
1.25 16V	55 kW	1.25 l	05/02→06/08	⊗ FUJB / FUJA; →02/05	5DA 193 175-411	Ignition Coil	13		
				⊗ FUJA / FUJB; 03/05→	5DA 193 175-791	Ignition Coil	23		
1.3	44 kW	1.3 l	11/01→06/08	⊗ BAJA	5DA 193 175-411	Ignition Coil	13		

FORD - FIESTA V (JH_, JD_)				11/01→06/08
1.3	51 kW	1.3 l	11/01→06/08	Ⓞ A9JA / A9JB 5DA 193 175-411 Ignition Coil 13
1.4 16V	59 kW	1.4 l	11/01→06/08	Ⓞ FXJB / FXJA; →02/05 5DA 193 175-411 Ignition Coil 13
				Ⓞ FXJA / FXJB; 03/05→ 5DA 193 175-791 Ignition Coil 23
1.6 16V	74 kW	1.6 l	11/01→06/08	Ⓞ FYJA / FYJB; →02/05 5DA 193 175-411 Ignition Coil 13
				Ⓞ FYJA / FYJB; 03/05→ 5DA 193 175-791 Ignition Coil 23
ST150	110 kW	2 l	03/05→06/08	Ⓞ N4JB 5DA 193 175-411 Ignition Coil 13
FORD - FIESTA V Van				10/03→07/05
1.3	51 kW	1.3 l	10/03→07/05	Ⓞ A9JB / A9JA 5DA 193 175-411 Ignition Coil 13
FORD - FIESTA VI				06/08→
1.25	44 kW	1.25 l	06/08→	Ⓞ STJA / STJB; 07/08→02/11 5DA 193 175-791 Ignition Coil 23
1.25	60 kW	1.25 l	06/08→	Ⓞ SNJA / SNJB; 07/08→02/11 5DA 193 175-791 Ignition Coil 23
1.4	71 kW	1.4 l	06/08→	Ⓞ SPJC / SPJA 5DA 193 175-791 Ignition Coil 23
1.6 Ti	88 kW	1.6 l	06/08→	Ⓞ HXJB / HXJA 5DA 193 175-791 Ignition Coil 23
FORD - FIESTA Box (F3L, F5L)				09/91→02/96
1.3	44 kW	1.3 l	09/91→02/96	for vehicles without distributor 5DA 193 175-401 Ignition Coil 13
FORD - FIESTA Box (J5_, J3_)				02/96→
1.3	44 kW	1.3 l	02/96→	Ⓞ J4C; →09/98 5DA 193 175-401 Ignition Coil 13
				Ⓞ J4C; Brazil / Argentina; 10/98→ 5DA 193 175-411 Ignition Coil 13
FORD - FOCUS (DAW, DBW)				10/98→11/04
1.4 16V	55 kW	1.4 l	10/98→11/04	Ⓞ FXDC / FXDA / FXDB / FXDD 5DA 193 175-411 Ignition Coil 13
1.6 16V	74 kW	1.6 l	10/98→11/04	Ⓞ FYDB / FYDD / FYDC / FYDA / FYDH 5DA 193 175-411 Ignition Coil 13
1.8 16V	85 kW	1.8 l	10/98→11/04	Ⓞ EYDJ / EYDL / EYDI / EYDG / EYDC / EYDB / EYDE / EYDD / EYDF 5DA 193 175-411 Ignition Coil 13
2.0 16V	96 kW	2 l	10/98→11/04	Ⓞ EDDB / EDDF / EDDD / EDDC 5DA 193 175-411 Ignition Coil 13
RS	158 kW	2 l	10/02→11/04	Ⓞ HMDA 5DA 193 175-411 Ignition Coil 13
ST170	127 kW	2 l	03/02→11/04	Ⓞ ALDA 5DA 193 175-411 Ignition Coil 13
FORD - FOCUS II (DA_)				11/04→09/12
1.4	59 kW	1.4 l	11/04→09/12	Ⓞ ASDA / ASDB; →02/05 5DA 193 175-411 Ignition Coil 13
				Ⓞ ASDA / ASDB; 03/05→01/08 5DA 193 175-791 Ignition Coil 23
1.6	74 kW	1.6 l	11/04→09/12	Ⓞ HWDA / HWDB / SHDA; →02/05 5DA 193 175-411 Ignition Coil 13
				Ⓞ HWDA / HWDB; 03/05→01/08 5DA 193 175-791 Ignition Coil 23
1.6 Ti	85 kW	1.6 l	11/04→09/12	Ⓞ HXDB / HXDA; →02/05 5DA 193 175-411 Ignition Coil 13
				Ⓞ HXDA; 03/05→01/08 5DA 193 175-791 Ignition Coil 23
1.8	92 kW	1.8 l	03/06→09/12	Ⓞ QQDB; 4 5DA 193 175-781 Ignition Coil 23
1.8 Flexifuel	92 kW	1.8 l	01/06→09/12	Ⓞ Q7DA; 4 5DA 193 175-781 Ignition Coil 23
2.0	107 kW	2 l	11/04→01/08	Ⓞ AODA; 4 5DA 193 175-781 Ignition Coil 23
				Ⓞ AODB; 4 5DA 193 175-781 Ignition Coil 23
2.0 CNG	107 kW	2 l	04/09→07/11	Ⓞ SYDA; 4 5DA 193 175-781 Ignition Coil 23
2.0 LPG	107 kW	2 l	06/08→07/11	Ⓞ SYDA; 4 5DA 193 175-781 Ignition Coil 23

FORD - FOCUS II (DA_)						11/04→09/12
2.5 RS	224 kW	2.5 l	01/09→07/11	⊗ JZDA; 5	5DA 193 175-801 Ignition Coil	24
2.5 ST	166 kW	2.5 l	10/05→09/12	⊗ HYDA; 5	5DA 193 175-801 Ignition Coil	24
FORD - FOCUS II Convertible						10/06→07/11
1.6	74 kW	1.6 l	10/06→07/11	⊗ HWDB / HWDA	5DA 193 175-411 Ignition Coil	13
				⊗ HWDA / HWDB	5DA 193 175-791 Ignition Coil	23
2.0	107 kW	2 l	10/06→07/11	⊗ AODB / AODA; 4	5DA 193 175-781 Ignition Coil	23
FORD - FOCUS II Estate (DA_)						11/04→09/12
1.4	59 kW	1.4 l	11/04→09/12	⊗ ASDB / ASDA; →02/05	5DA 193 175-411 Ignition Coil	13
				⊗ ASDB / ASDA; 03/05→01/08	5DA 193 175-791 Ignition Coil	23
1.6	74 kW	1.6 l	11/04→07/11	⊗ HWDA / HWDB / SHDA; →02/05	5DA 193 175-411 Ignition Coil	13
				⊗ HWDA / HWDB; 03/05→01/08	5DA 193 175-791 Ignition Coil	23
1.6 Ti	85 kW	1.6 l	11/04→01/08	⊗ HXDB / HXDA; →02/05	5DA 193 175-411 Ignition Coil	13
				⊗ HXDA; 03/05→01/08	5DA 193 175-791 Ignition Coil	23
1.8	92 kW	1.8 l	03/06→09/12	⊗ Q7DA / QQDB; 4	5DA 193 175-781 Ignition Coil	23
1.8 Flexifuel	92 kW	1.8 l	01/06→09/12	⊗ Q7DA; 4	5DA 193 175-781 Ignition Coil	23
2.0	107 kW	2 l	11/04→01/08	⊗ AODB / AODA; 4	5DA 193 175-781 Ignition Coil	23
2.0 LPG	107 kW	2 l	06/08→07/11	⊗ SYDA; 4	5DA 193 175-781 Ignition Coil	23
FORD - FOCUS II Saloon (DA_)						04/05→09/12
1.4	59 kW	1.4 l	04/05→09/12	⊗ ASDA / ASDB; →01/08	5DA 193 175-791 Ignition Coil	23
1.6	74 kW	1.6 l	04/05→01/08	⊗ HWDA / HWDB / SHDA	5DA 193 175-411 Ignition Coil	13
				⊗ HWDB / HWDA; →01/08	5DA 193 175-791 Ignition Coil	23
1.6 Ti	85 kW	1.6 l	04/05→01/08	⊗ HXDA; →01/08	5DA 193 175-791 Ignition Coil	23
1.8	92 kW	1.8 l	03/06→01/08	⊗ QQDB; 4	5DA 193 175-781 Ignition Coil	23
1.8 Flexifuel	92 kW	1.8 l	06/06→07/11	⊗ Q7DA; 4	5DA 193 175-781 Ignition Coil	23
2.0	107 kW	2 l	04/05→07/11	⊗ AODA; 4	5DA 193 175-781 Ignition Coil	23
				⊗ AODB; 4	5DA 193 175-781 Ignition Coil	23
FORD - FOCUS C-MAX						10/03→03/07
1.6	74 kW	1.6 l	10/03→03/07	⊗ HWDB / HWDA; →02/05	5DA 193 175-411 Ignition Coil	13
				⊗ HWDB / HWDA; 03/05→01/08	5DA 193 175-791 Ignition Coil	23
1.6 Ti	85 kW	1.6 l	08/04→03/07	⊗ SIDA / HXDA; →02/05	5DA 193 175-411 Ignition Coil	13
				⊗ HXDA; 03/05→	5DA 193 175-791 Ignition Coil	23
1.8	88 kW	1.8 l	10/03→03/07	⊗ CSDB / CSDA; 4	5DA 193 175-781 Ignition Coil	23
1.8	90 kW	1.8 l	09/05→03/07	⊗ QQDC; 4	5DA 193 175-781 Ignition Coil	23
1.8	92 kW	1.8 l	04/04→03/07	⊗ Q7DA / QQDB / QQDA; 4	5DA 193 175-781 Ignition Coil	23
1.8 Flexifuel	92 kW	1.8 l	01/06→03/07	⊗ Q7DA; 4	5DA 193 175-781 Ignition Coil	23
2.0	107 kW	2 l	03/04→03/07	⊗ AODA / AODB / SYDA; 4	5DA 193 175-781 Ignition Coil	23

FORD - FOCUS Estate (DNW)										02/99→11/04			
1.4 16V	55 kW	1.4 l	02/99→11/04	FXDC / FXDA / FXDD / FXDB	5DA 193 175-411	Ignition Coil	13						
1.6 16V	74 kW	1.6 l	02/99→11/04	FYDB / FYDD / FYDC / FYDA / FYDH	5DA 193 175-411	Ignition Coil	13						
1.8 16V	85 kW	1.8 l	02/99→11/04	EYDJ / EYDL / EYDI / EYDG / EYDC / EYDB / EYDE / EYDD / EYDF	5DA 193 175-411	Ignition Coil	13						
2.0 16V	96 kW	2 l	02/99→11/04	EDDB / EDDF / EDDD / EDDC	5DA 193 175-411	Ignition Coil	13						
ST170	127 kW	2 l	08/02→11/04	ALDA	5DA 193 175-411	Ignition Coil	13						
FORD - FOCUS Saloon (DFW)										02/99→11/04			
1.4 16V	55 kW	1.4 l	02/99→11/04	FXDD / FXDB / FXDA / FXDC	5DA 193 175-411	Ignition Coil	13						
1.6 16V	74 kW	1.6 l	02/99→11/04	FYDA / FYDC / FYDB / FYDD / FYDH	5DA 193 175-411	Ignition Coil	13						
1.8 16V	85 kW	1.8 l	02/99→11/04	EYDJ / EYDL / EYDG / EYDI / EYDB / EYDD / EYDE / EYDF / EYDC	5DA 193 175-411	Ignition Coil	13						
2.0 16V	96 kW	2 l	02/99→11/04	EDDC / EDDD / EDDF / EDDB	5DA 193 175-411	Ignition Coil	13						
FORD - FUSION (JU_)										08/02→12/12			
1.25	55 kW	1.25 l	08/04→12/12	FUJA / FUJB; →02/05	5DA 193 175-411	Ignition Coil	13						
1.4	59 kW	1.4 l	08/02→12/12	FXJC / FXJB / FXJA; →02/05	5DA 193 175-411	Ignition Coil	13						
1.6	74 kW	1.6 l	08/02→11/08	FYJA / FYJB; →02/05	5DA 193 175-411	Ignition Coil	13						
FORD - GALAXY (WA6)										05/06→06/15			
2.0	107 kW	2 l	05/06→06/15	AOWA / AOWB; 4	5DA 193 175-781	Ignition Coil	23						
2.0 Flexifuel	107 kW	2 l	05/06→12/12	TBWB / TBWA; 4	5DA 193 175-781	Ignition Coil	23						
2.3	118 kW	2.3 l	07/07→	SEWA; 4x	5DA 193 175-811	Ignition Coil	24						
FORD - GALAXY (WGR)										11/95→05/06			
2.0 i	85 kW	2 l	11/95→05/06	ZVSA	5DA 193 175-411	Ignition Coil	13						
2.3 16V	103 kW	2.3 l	09/01→05/06	E5SB	5DA 193 175-411	Ignition Coil	13						
2.3 16V	107 kW	2.3 l	01/97→05/06	E5SA	5DA 193 175-411	Ignition Coil	13						
				Y5B; →02/00	5DA 749 475-401	Ignition Coil	39						
2.8 V6	150 kW	2.8 l	04/00→05/06	AYL; 6	5DA 358 000-001	Ignition Coil	30						
FORD - GRANADA (GU)										08/77→08/85			
2.8 i	108 kW	2.8 l	08/77→08/85	01/85→ 10/82→08/85	5DA 006 623-331	Switch Unit, ignition system	6						
2.8 i	110 kW	2.8 l	10/82→08/85										
FORD - GRANADA Estate (GNU)										08/77→08/85			
2.8 i	108 kW	2.8 l	08/77→08/85	01/85→ 10/82→08/85	5DA 006 623-331	Switch Unit, ignition system	6						
2.8 i	110 kW	2.8 l	10/82→08/85										
FORD - KA (RB_)										09/96→11/08			
1.3 i	36 kW	1.3 l	06/98→11/08	JJD / JJL / JJH / JJG / JJF	5DA 193 175-411	Ignition Coil	13						
1.3 i	37 kW	1.3 l	09/96→10/02	JJB	5DA 193 175-411	Ignition Coil	13						
1.3 i	44 kW	1.3 l	09/96→11/08	J4D / J4K / J4M / J4N / J4P / J4S / BAA; 09/98→	5DA 193 175-411	Ignition Coil	13						
1.3 i	51 kW	1.3 l	08/02→11/08	A9A / A9B	5DA 193 175-411	Ignition Coil	13						
1.6 i	70 kW	1.6 l	07/03→11/08	CDB / CDC	5DA 193 175-411	Ignition Coil	13						
FORD - KUGA I										03/09→			
2.5	147 kW	2.5 l	03/09→	HYDB; 5	5DA 193 175-801	Ignition Coil	24						
2.5 4x4	147 kW	2.5 l	03/09→										

FORD - MAVERICK							02/01 →
2.0 16V	91 kW	2 l	02/01 →	☉ YF	5DA 193 175-411 Ignition Coil	13	
2.3 16V	110 kW	2.3 l	03/04 →	☉ GZ; 4	5DA 193 175-781 Ignition Coil	23	
FORD - MONDEO I (GBP)							02/93 → 08/96
1.6 i 16V	65 kW	1.6 l	07/94 → 08/96		5DA 193 175-401 Ignition Coil	13	
1.6 i 16V	66 kW	1.6 l	02/93 → 08/96				
1.8 i 16V	82 kW	1.8 l	07/94 → 08/96				
1.8 i 16V	85 kW	1.8 l	02/93 → 08/96				
1.8 i 16V 4x4	85 kW	1.8 l	02/93 → 08/96				
2.0 i 16V	100 kW	2 l	02/93 → 08/96				
2.0 i 16V 4x4	97 kW	2 l	12/94 → 08/96				
2.5 i 24V	125 kW	2.5 l	07/94 → 08/96	☉ SEA	5DA 358 000-011 Ignition Coil	31	
FORD - MONDEO I Estate (BNP)							04/93 → 08/96
1.6 i 16V	65 kW	1.6 l	07/94 → 08/96		5DA 193 175-401 Ignition Coil	13	
1.6 i 16V	66 kW	1.6 l	04/93 → 08/96				
1.8 i 16V	82 kW	1.8 l	07/94 → 08/96				
1.8 i 16V	85 kW	1.8 l	04/93 → 08/96				
1.8 i 16V 4x4	85 kW	1.8 l	04/93 → 08/96				
2.0 i 16V	100 kW	2 l	04/93 → 08/96				
2.0 i 16V 4x4	100 kW	2 l	04/93 → 08/96				
2.5 i 24V	125 kW	2.5 l	07/94 → 08/96	☉ SEA	5DA 358 000-011 Ignition Coil	31	
FORD - MONDEO I Saloon (GBP)							02/93 → 08/96
1.6 i 16V	65 kW	1.6 l	07/94 → 08/96		5DA 193 175-401 Ignition Coil	13	
1.6 i 16V	66 kW	1.6 l	02/93 → 08/96				
1.8 i 16V	82 kW	1.8 l	01/94 → 08/96				
1.8 i 16V	85 kW	1.8 l	02/93 → 08/96				
2.0 i 16V	100 kW	2 l	02/93 → 08/96				
2.0 i 16V 4x4	97 kW	2 l	12/94 → 08/96				
2.5 i 24V	125 kW	2.5 l	07/94 → 08/96	☉ SEA	5DA 358 000-011 Ignition Coil	31	
FORD - MONDEO II (BAP)							08/96 → 09/00
1.6 i	66 kW	1.6 l	08/96 → 09/00	☉ L1J; →05/98	5DA 193 175-401 Ignition Coil	13	
				☉ L1J; 05/98 →	5DA 193 175-411 Ignition Coil	13	
1.6 i 16V	70 kW	1.6 l	05/98 → 09/00	☉ L1L / L1Q / L1N	5DA 193 175-411 Ignition Coil	13	
1.8 i	85 kW	1.8 l	08/96 → 09/00	☉ RKK / RKB / RKH / RKJ / RKF; →05/98	5DA 193 175-401 Ignition Coil	13	
				☉ RKJ / RKB / RKF / RKK / RKH; 05/98 →	5DA 193 175-411 Ignition Coil	13	
2.0 i	96 kW	2 l	08/96 → 09/00	☉ NGA / NGD / NGC / NGB; →05/98	5DA 193 175-401 Ignition Coil	13	
				☉ NGC / NGD / NGB / NGA; 05/98 →	5DA 193 175-411 Ignition Coil	13	
2.5 24V	125 kW	2.5 l	08/96 → 09/00	☉ SEA	5DA 358 000-011 Ignition Coil	31	
2.5 24V	125 kW	2.5 l	06/00 → 09/00	☉ SEB / SEC	5DA 358 000-011 Ignition Coil	31	
2.5 ST 200	151 kW	2.5 l	05/99 → 09/00	☉ SGA	5DA 358 000-011 Ignition Coil	31	
FORD - MONDEO II Estate (BNP)							08/96 → 09/00
1.6 i	66 kW	1.6 l	08/96 → 09/00	☉ L1J; →05/98	5DA 193 175-401 Ignition Coil	13	
				☉ L1J; 05/98 →	5DA 193 175-411 Ignition Coil	13	
1.6 i 16V	70 kW	1.6 l	05/98 → 09/00	☉ L1L / L1Q / L1N	5DA 193 175-411 Ignition Coil	13	
1.8 i	85 kW	1.8 l	08/96 → 09/00	☉ RKH / RKB / RKF / RKJ / RKK; →05/98	5DA 193 175-401 Ignition Coil	13	
				☉ RKJ / RKB / RKF / RKK / RKH; 05/98 →	5DA 193 175-411 Ignition Coil	13	
2.0 i	96 kW	2 l	08/96 → 09/00	☉ NGD / NGB / NGA / NGC; →05/98	5DA 193 175-401 Ignition Coil	13	
				☉ NGC / NGD / NGB / NGA; 05/98 →	5DA 193 175-411 Ignition Coil	13	

FORD - MONDEO II Estate (BNP)						08/96→09/00
2.5 24V	125 kW	2.5 l	08/96→09/00	⊗ SEA	5DA 358 000-011 Ignition Coil	31
2.5 24V	125 kW	2.5 l	10/99→09/00	⊗ SEB / SEC	5DA 358 000-011 Ignition Coil	31
2.5 ST 200	151 kW	2.5 l	05/99→09/00	⊗ SGA	5DA 358 000-011 Ignition Coil	31
FORD - MONDEO II Saloon (BFP)						08/96→09/00
1.6 i	66 kW	1.6 l	08/96→09/00	⊗ L1J; →05/98	5DA 193 175-401 Ignition Coil	13
				⊗ L1J; 05/98→	5DA 193 175-411 Ignition Coil	13
1.6 i 16V	70 kW	1.6 l	05/98→09/00	⊗ L1N / L1Q / L1L	5DA 193 175-411 Ignition Coil	13
1.8 i	85 kW	1.8 l	08/96→09/00	⊗ RKH / RKJ / RKF / RKK / RKB; →05/98	5DA 193 175-401 Ignition Coil	13
				⊗ RKJ / RKB / RKF / RKK / RKH; 05/98→	5DA 193 175-411 Ignition Coil	13
2.0 i	96 kW	2 l	08/96→09/00	⊗ NGC / NGA / NGB / NGD; →05/98	5DA 193 175-401 Ignition Coil	13
				⊗ NGC / NGD / NGB / NGA; 05/98→	5DA 193 175-411 Ignition Coil	13
2.5 24V	125 kW	2.5 l	08/96→09/00	⊗ SEA	5DA 358 000-011 Ignition Coil	31
2.5 24V	125 kW	2.5 l	06/00→09/00	⊗ SEB / SEC	5DA 358 000-011 Ignition Coil	31
2.5 ST 200	151 kW	2.5 l	05/99→09/00	⊗ SGA	5DA 358 000-011 Ignition Coil	31
FORD - MONDEO III (B5Y)						10/00→03/07
1.8 16V	81 kW	1.8 l	10/00→03/07	⊗ CGBB / CGBA; →02/05	5DA 193 175-411 Ignition Coil	13
1.8 16V	92 kW	1.8 l	10/00→03/07	⊗ CHBB / CHBA; →02/05	5DA 193 175-411 Ignition Coil	13
2.0 16V	107 kW	2 l	10/00→03/07	⊗ CJBB / CJBA; →02/05	5DA 193 175-411 Ignition Coil	13
2.5 V6 24V	125 kW	2.5 l	10/00→03/07	→09/02	5DA 193 175-551 Ignition Coil	17
FORD - MONDEO III Estate (BWY)						10/00→03/07
1.8 16V	81 kW	1.8 l	10/00→03/07	⊗ CGBA / CGBB; →02/05	5DA 193 175-411 Ignition Coil	13
1.8 16V	92 kW	1.8 l	10/00→03/07	⊗ CHBA / CHBB; →02/05	5DA 193 175-411 Ignition Coil	13
2.0 16V	107 kW	2 l	10/00→03/07	⊗ CJBA / CJBB; →02/05	5DA 193 175-411 Ignition Coil	13
FORD - MONDEO III Saloon (B4Y)						10/00→03/07
1.8 16V	81 kW	1.8 l	10/00→03/07	⊗ CGBA / CGBB; →02/05	5DA 193 175-411 Ignition Coil	13
1.8 16V	92 kW	1.8 l	10/00→03/07	⊗ CHBA / CHBB; →02/05	5DA 193 175-411 Ignition Coil	13
2.0 16V	107 kW	2 l	10/00→03/07	⊗ CJBA / CJBB; →02/05	5DA 193 175-411 Ignition Coil	13
FORD - MONDEO IV (BA7)						03/07→09/14
1.6 Ti	81 kW	1.6 l	03/07→09/14		5DA 193 175-791 Ignition Coil	23
1.6 Ti	92 kW	1.6 l	03/07→09/14		5DA 193 175-781 Ignition Coil	23
2.0	107 kW	2 l	03/07→09/14	⊗ AOBA / AOBC / TBBA; 4	5DA 193 175-781 Ignition Coil	23
2.0 Flexifuel	107 kW	2 l	03/09→09/14	⊗ TBBA / TBBB; 4	5DA 193 175-781 Ignition Coil	23
2.0 LPG	107 kW	2 l	07/09→09/14	⊗ TBBA; 4	5DA 193 175-781 Ignition Coil	23
2.3	118 kW	2.3 l	07/07→09/14	⊗ SEBA; 4x	5DA 193 175-811 Ignition Coil	24
2.5	162 kW	2.5 l	03/07→09/14	⊗ HUBA; 5	5DA 193 175-801 Ignition Coil	24
FORD - MONDEO IV Saloon (BA7)						03/07→09/14
2.0	107 kW	2 l	03/07→09/14	⊗ TBBA / AOBA / AOBC; 4	5DA 193 175-781 Ignition Coil	23
2.0 Flexifuel	107 kW	2 l	03/09→09/14	⊗ TBBA / TBBB; 4	5DA 193 175-781 Ignition Coil	23

FORD - MONDEO IV Saloon (BA7)										03/07→09/14			
2.0 LPG	107 kW	2 l	07/09→09/14	⊗ TBBA; 4	5DA 193 175-781 Ignition Coil							23	
2.3	118 kW	2.3 l	07/07→09/14	⊗ SEBA; 4x	5DA 193 175-811 Ignition Coil							24	
2.5	162 kW	2.5 l	03/07→09/14	⊗ HUBA; 5	5DA 193 175-801 Ignition Coil							24	
FORD - MONDEO IV Turnier (BA7)										03/07→09/14			
1.6 Ti	81 kW	1.6 l	03/07→12/12		5DA 193 175-791 Ignition Coil							23	
1.6 Ti	92 kW	1.6 l	03/07→12/10										
1.6 Ti	88 kW	1.6 l	07/10→09/14	02/07→02/11	5DA 193 175-791 Ignition Coil							23	
2.0	107 kW	2 l	03/07→09/14	⊗ TBBA / AOBA / AOBC; 4	5DA 193 175-781 Ignition Coil							23	
2.0 Flexifuel	107 kW	2 l	03/09→09/14	⊗ TBBB / TBBA; 4	5DA 193 175-781 Ignition Coil							23	
2.0 LPG	107 kW	2 l	07/09→09/14	⊗ TBBA; 4	5DA 193 175-781 Ignition Coil							23	
2.3	118 kW	2.3 l	07/07→09/14	⊗ SEBA; 4x	5DA 193 175-811 Ignition Coil							24	
2.5	162 kW	2.5 l	03/07→12/12	⊗ HUBA; 5	5DA 193 175-801 Ignition Coil							24	
FORD - ORION I (AFD)										07/83→03/86			
1.3	51 kW	1.3 l	07/83→03/86	02/85→	5DA 006 623-041 Switch Unit, ignition system							4	
1.6	58 kW	1.6 l	07/83→03/86										
1.6 i	77 kW	1.6 l	07/83→03/86										
FORD - ORION II (AFF)										12/85→07/90			
1.3	44 kW	1.3 l	12/85→07/90		5DA 006 623-041 Switch Unit, ignition system							4	
1.4	52 kW	1.4 l	03/86→07/90										
1.4 CAT	54 kW	1.4 l	02/87→07/90										
1.6	66 kW	1.6 l	12/85→07/90										
1.6 i	77 kW	1.6 l	03/86→07/90										
1.6 i CAT	66 kW	1.6 l	03/86→07/90										
1.4	54 kW	1.4 l	01/86→07/90	04/86→	5DA 006 623-041 Switch Unit, ignition system							4	
1.4	55 kW	1.4 l	12/85→07/90	03/86→; for vehicles with distributor	5DA 006 623-041 Switch Unit, ignition system							4	
				for vehicles without distributor	5DA 193 175-401 Ignition Coil							13	
FORD - ORION III (GAL)										07/90→12/93			
1.3	44 kW	1.3 l	07/90→12/93	for vehicles without distributor	5DA 193 175-401 Ignition Coil							13	
1.4	54 kW	1.4 l	07/90→12/93										
1.6	66 kW	1.6 l	07/90→12/92										
1.4	52 kW	1.4 l	07/90→12/93		5DA 193 175-401 Ignition Coil							13	
1.6 i	77 kW	1.6 l	07/90→09/92										
1.6 i 16V	66 kW	1.6 l	07/92→12/93	03/93→	5DA 193 175-401 Ignition Coil							13	
1.8 i 16V	77 kW	1.8 l	02/92→12/93										
1.8 i 16V	96 kW	1.8 l	01/92→12/93										
FORD - PUMA (EC_)										03/97→06/02			
1.4 16V	66 kW	1.4 l	11/97→10/00	⊗ FHD / FHF; 01/98→05/98	5DA 193 175-401 Ignition Coil							13	
				⊗ FHD / FHF; 05/98→	5DA 193 175-411 Ignition Coil							13	
1.6 16V	76 kW	1.6 l	08/00→06/02	⊗ L1W	5DA 193 175-411 Ignition Coil							13	
1.7 16V	92 kW	1.7 l	03/97→06/02	⊗ MHA / MHB; 06/97→05/00	5DA 193 175-401 Ignition Coil							13	
				⊗ MHB / MHA; 05/98→	5DA 193 175-411 Ignition Coil							13	
FORD - SCORPIO I (GAE, GGE)										04/91→09/94			
2.9 i 24V	143 kW	2.9 l	04/91→09/94	⊗ BOA	5DA 358 000-011 Ignition Coil							31	
FORD - SCORPIO I Estate (GGE)										08/93→09/94			
2.9 24V	143 kW	2.9 l	08/93→09/94	⊗ BOA	5DA 358 000-011 Ignition Coil							31	









										13		412	
FORD - SCORPIO I Saloon (GGE)											04/91→09/94		
2.9 i 24V	143 kW	2.9 l	04/91→09/94	BOA	5DA 358 000-011	Ignition	31						
FORD - SCORPIO II (GFR, GGR)											10/94→08/98		
2.0 i 16V	100 kW	2 l	10/94→08/98	N3A; 11/94→05/96	5DA 749 475-401	Ignition	39						
2.3 i 16V	108 kW	2.3 l	06/96→08/98	Y5A; →07/98	5DA 749 475-401	Ignition	39						
2.9 i 24V	152 kW	2.9 l	10/94→08/98	BOB	5DA 358 000-011	Ignition	31						
FORD - SCORPIO II Estate (GNR, GGR)											10/94→08/98		
2.0 i 16V	100 kW	2 l	10/94→08/98	N3A; 11/94→05/96	5DA 749 475-401	Ignition	39						
2.3 i 16V	108 kW	2.3 l	06/96→08/98	Y5A; →07/98	5DA 749 475-401	Ignition	39						
2.9 i 24V	152 kW	2.9 l	10/94→08/98	BOB	5DA 358 000-011	Ignition	31						
FORD - SIERRA (GBG, GB4)											05/88→02/93		
1.6 i	59 kW	1.6 l	10/89→02/93		5DA 193 175-401	Ignition	13						
1.8	64 kW	1.8 l	05/88→02/93	R6A; for vehicles without distributor	5DA 193 175-401	Ignition	13						
FORD - SIERRA Estate (BNG)											05/88→02/93		
1.6 i	59 kW	1.6 l	10/89→02/93		5DA 193 175-401	Ignition	13						
1.8	64 kW	1.8 l	05/88→02/93	R6A; for vehicles without distributor	5DA 193 175-401	Ignition	13						
FORD - SIERRA Hatchback (GBC, GBG)											05/88→02/93		
1.6 i	59 kW	1.6 l	10/89→02/93		5DA 193 175-401	Ignition	13						
1.8	64 kW	1.8 l	05/88→02/93	R6A; for vehicles without distributor	5DA 193 175-401	Ignition	13						
FORD - S-MAX (WA6)											05/06→		
2.0	107 kW	2 l	05/06→	AOWB / AOWA; 4	5DA 193 175-781	Ignition	23						
2.0 Flexifuel	107 kW	2 l	05/06→	TBWB / TBWA; 4	5DA 193 175-781	Ignition	23						
2.3	118 kW	2.3 l	07/07→	SEWA; 4x	5DA 193 175-811	Ignition	24						
2.5 ST	162 kW	2.5 l	05/06→	HUWA; 5	5DA 193 175-801	Ignition	24						
FORD - STREET KA (RL2)											05/03→07/05		
1.6	70 kW	1.6 l	05/03→07/05	CDRB / CDRA	5DA 193 175-411	Ignition	13						
FORD - TOURNEO CONNECT											06/02→12/13		
1.8 16V	85 kW	1.8 l	06/02→12/13	EYPA / EYPC / EYPD	5DA 193 175-411	Ignition	13						
FORD - TRANSIT Box											04/06→08/14		
2.3 16V [RWD]	107 kW	2.3 l	04/06→08/14	GZFA / GZFC / GZFB; 4	5DA 193 175-781	Ignition	23						
2.3 16V CNG [RWD]	100 kW	2.3 l	04/06→08/14	GZFA; 4	5DA 193 175-781	Ignition	23						
2.3 16V LPG [RWD]	107 kW	2.3 l	04/06→08/14		5DA 193 175-781	Ignition	23						
FORD - TRANSIT Box (FA__)											04/01→05/06		
2.3 16V [RWD] (FAA_, FAB_, FAC_)	107 kW	2.3 l	04/01→05/06	E5FA / E5FC; →Model 2006	5DA 749 475-401	Ignition	39						
FORD - TRANSIT Bus (FD__, FB__, FS__, FZ__, FC__)											08/00→05/06		
2.3 16V [RWD] (F_B_, F_C_, F_A_)	107 kW	2.3 l	08/00→05/06	E5FA / E5FC; 01/01→; →Model 2006	5DA 749 475-401	Ignition	39						
FORD - TRANSIT CONNECT (P65_, P70_, P80_)											06/02→12/13		
1.8 16V	85 kW	1.8 l	06/02→12/13	EYPD / EYPC / EYPA	5DA 193 175-411	Ignition	13						

FORD - TRANSIT Platform/Chassis						04/06→08/14
2.3 16V [RWD]	107 kW	2.3 l	04/06→08/14	GZFC / GZFA / GZFB; 4	5DA 193 175-781 Ignition Coil	23
2.3 16V CNG [RWD]	100 kW	2.3 l	04/06→08/14	GZFA; 4	5DA 193 175-781 Ignition	23
2.3 16V LPG [RWD]	107 kW	2.3 l	04/06→08/14		Coil	
FORD - TRANSIT Platform/Chassis (FM_-, FN_-)						04/01→05/06
2.3 16V (F_A_, F_B_, F_C_, F_D_)	107 kW	2.3 l	04/01→05/06	E5FA / E5FC; →Model 2006	5DA 749 475-401 Ignition Coil	39



FORD USA - EXPLORER (U2)							01/93→12/01
4.0	150 kW	4 l	10/99→12/01	→09/00		5DA 749 475-371 Ignition	39
4.0	152 kW	4 l	09/96→12/01			Coil	
4.0 V6 All-wheel Drive	150 kW	4 l	10/98→12/01				
4.0 V6 All-wheel Drive	152 kW	4 l	10/96→12/01				
4.0 V6 All-wheel Drive	115 kW	4 l	03/95→12/01	→08/96		5DA 749 475-371 Ignition	39
4.0 V6 All-wheel Drive	121 kW	4 l	01/93→			Coil	
FORD USA - WINDSTAR (A3)							03/95→02/99
3.0 V6	108 kW	3 l	02/99→	→12/00		5DA 358 000-011 Ignition	31
						Coil	
3.0 V6	109 kW	3 l	03/95→02/99			5DA 358 000-011 Ignition	31
						Coil	



 				 13		 412	
FSO - 125P							10/67→08/92
1.5 1500	55 kW	1.5 l	10/67→08/92			5DA 006 623-051 Switch Unit, ignition system	4
FSO - POLONEZ I							10/77→08/88
1.5	55 kW	1.5 l	10/77→08/88	01/83→12/86		5DA 006 623-051 Switch Unit, ignition system	4
1.5	60 kW	1.5 l	01/78→08/88				











HONDA - ACCORD VI Hatchback (CH)													12/99→12/02		
1.6	85 kW	1.6 l	12/99→12/02	D16B6; →12/99		5DA 193 175-691 Ignition Coil								20	
HONDA - ACCORD VII Saloon (CG, CK)													10/98→12/02		
1.6 i	85 kW	1.6 l	10/98→12/02	D16B6; →12/99		5DA 193 175-691 Ignition Coil								20	
1.6 LS	79 kW	1.6 l	10/98→12/02	D16B7; →12/99		5DA 193 175-691 Ignition Coil								20	
HONDA - CIVIC II Shuttle (EE)													01/88→02/95		
1.5 i 16V (EE2)	69 kW	1.5 l	01/88→11/91	→12/90		5DA 006 623-401 Switch Unit, ignition system								6	
1.6 i 16V 4WD (EE4)	80 kW	1.6 l	01/88→12/89			5DA 006 623-401 Switch Unit, ignition system								6	
1.6 i 16V 4WD (EE4)	81 kW	1.6 l	01/88→02/95	→12/92		5DA 006 623-401 Switch Unit, ignition system								6	
HONDA - CIVIC IV Hatchback (EC, ED, EE)													10/88→09/91		
1.5 i 16V (ED6)	69 kW	1.5 l	10/88→09/91			5DA 006 623-401 Switch Unit, ignition system								6	
HONDA - CIVIC IV Hatchback (EG)													10/91→11/95		
1.3 16V (EG3)	55 kW	1.3 l	10/91→11/95	01/93→		5DA 006 623-471 Switch Unit, ignition system								7	
1.6 16V Vtec (EG5)	92 kW	1.6 l	10/91→11/95												
1.6 VTi 16V (EG6)	118 kW	1.6 l	10/91→11/95												
1.5 i 16V (EG4)	69 kW	1.5 l	10/91→11/95	→12/92		5DA 006 623-401 Switch Unit, ignition system								6	
				01/93→		5DA 006 623-471 Switch Unit, ignition system								7	
HONDA - CIVIC IV Saloon (ED)													10/87→09/91		
1.5 i 16V (ED3)	69 kW	1.5 l	10/87→09/91	01/88→		5DA 006 623-401 Switch Unit, ignition system								6	
HONDA - CIVIC V Saloon (EG, EH)													10/91→11/95		
1.5 i 16V (EG8)	69 kW	1.5 l	10/91→11/95	→12/92		5DA 006 623-401 Switch Unit, ignition system								6	
HONDA - CONCERTO (HW)													08/89→03/95		
1.5 i 16V	66 kW	1.5 l	08/89→03/95	01/90→12/92		5DA 006 623-401 Switch Unit, ignition system								6	
1.6 i 16V	82 kW	1.6 l	08/89→03/95												
1.6 i 16V	90 kW	1.6 l	08/89→03/95												
HONDA - CRX I (AF, AS)													03/86→10/87		
1.6 i 16V (AS)	92 kW	1.6 l	03/86→10/87			5DA 006 623-581 Switch Unit, ignition system								7	
HONDA - CRX II (ED, EE)													10/87→02/92		
1.6 i 16V (ED9)	91 kW	1.6 l	10/87→02/92	→12/91		5DA 006 623-401 Switch Unit, ignition system								6	
1.6 i 16V Vtec (EE8)	110 kW	1.6 l	10/89→02/92												
1.6 i 16V (ED9)	96 kW	1.6 l	10/87→12/89			5DA 006 623-401 Switch Unit, ignition system								6	

HYUNDAI - ACCENT IV (MC)				11/05→11/10	
1.4 GL	71 kW	1.4 l	11/05→11/10	5DA 193 175-381 Ignition	12
1.6 GLS	82 kW	1.6 l	11/05→11/10	Coil	
HYUNDAI - ACCENT IV Saloon (MC)				11/05→11/10	
1.4 GL	71 kW	1.4 l	11/05→11/10	5DA 193 175-381 Ignition	12
1.6 GLS	82 kW	1.6 l	11/05→11/10	Coil	
HYUNDAI - COUPE (RD)				08/96→04/02	
1.6 16V	85 kW	1.6 l	03/98→04/02	5DA 193 175-521 Ignition	16
1.6 i 16V	84 kW	1.6 l	12/96→04/02	Coil	
2.0 16V	102 kW	2 l	08/96→04/02		
HYUNDAI - GETZ (TB)				08/05→06/09	
1.4 i	71 kW	1.4 l	08/05→06/09	5DA 193 175-381 Ignition	12
				Coil	
HYUNDAI - i10 (IA)				12/13→	
1.0 LPG	51 kW	1 l	02/14→	B3LA	5DA 193 175-971 Ignition
					29
1.0	49 kW	1 l	12/13→	G3LA	5DA 193 175-971 Ignition
					29
				Coil	
HYUNDAI - i10 (PA)				11/08→	
1.0	51 kW	1 l	01/11→	G3LA	5DA 193 175-971 Ignition
					29
				Coil	
1.2	57 kW	1.2 l	11/08→	G4LA	5DA 193 175-961 Ignition
					29
				Coil	
HYUNDAI - i20 (PB, PBT)				09/08→	
1.2	57 kW	1.2 l	09/08→	G4LA	5DA 193 175-961 Ignition
					29
1.2	63 kW	1.2 l	03/12→		
				Coil	
HYUNDAI - i30 (FD)				10/07→11/11	
1.4	77 kW	1.4 l	10/07→11/11	5DA 193 175-511 Ignition	16
1.4	80 kW	1.4 l	10/07→11/11	Coil	
1.6	85 kW	1.6 l	10/07→11/11	5DA 193 175-481 Ignition	15
1.6	90 kW	1.6 l	10/07→11/11	Coil	
1.6	93 kW	1.6 l	02/08→11/11		
HYUNDAI - i30 CW (FD)				02/08→06/12	
1.6	85 kW	1.6 l	02/08→06/12	5DA 193 175-481 Ignition	15
1.6	90 kW	1.6 l	02/08→06/12	Coil	
1.6	93 kW	1.6 l	02/08→06/12		
				Coil	
HYUNDAI - LANTRA II Saloon (J-2)				11/95→09/00	
1.6 16V	84 kW	1.6 l	11/95→09/00	5DA 193 175-521 Ignition	16
1.6 i	66 kW	1.6 l	11/95→09/00	Coil	
1.8 16V	94 kW	1.8 l	11/95→09/00		
2.0 16V	102 kW	2 l	08/96→09/00		
HYUNDAI - LANTRA II Wagon (J-2)				02/96→10/00	
1.6 16V	84 kW	1.6 l	02/96→10/00	5DA 193 175-521 Ignition	16
1.6 i	66 kW	1.6 l	02/96→10/00	Coil	
1.8 16V	94 kW	1.8 l	02/96→10/00		
2.0 16V	102 kW	2 l	12/96→10/00		
HYUNDAI - SANTA FÉ I (SM)				02/01→03/06	
2.0	99 kW	2 l	08/01→03/06	5DA 193 175-531 Ignition	17
2.4 16V	100 kW	2.4 l	02/01→03/06	Coil	
2.4 16V	107 kW	2.4 l	02/01→03/06		
2.4 16V 4x4	100 kW	2.4 l	02/01→03/06		
2.4 16V 4x4	107 kW	2.4 l	02/01→03/06		
HYUNDAI - S COUPE (SLC)				02/90→05/96	
1.5 i	62 kW	1.5 l	02/90→05/96	01/93→12/94; G4DJ	5DA 006 623-511 Switch
					7
				Unit, ignition system	
1.5 i Turbo	85 kW	1.5 l	04/91→05/96	07/92→04/95	5DA 006 623-601 Switch
					8
				Unit, ignition system	
HYUNDAI - SONATA IV Saloon (EF)				06/98→11/04	
2.0 16V	96 kW	2 l	10/01→11/04	5DA 193 175-531 Ignition	17
2.0 16V	100 kW	2 l	06/98→10/01	Coil	

HYUNDAI - TRAJET (FO)							03/00→07/08
2.0	100 kW	2 l	03/00→07/08			5DA 193 175-531 Ignition	17
2.0	103 kW	2 l	01/04→07/08			Coil	



				 13		412	
INFINITI - FX							01/03→12/08
35 All-wheel Drive	206 kW	3.5 l	01/03→12/08	 VQ35DE; 07/06→	5DA 749 475-971 Ignition Coil	41	



KIA - CEE'D Hatchback (ED)						12/06→
1.4	80 kW	1.4 l	12/06→		5DA 193 175-511 Ignition	16
1.6	90 kW	1.6 l	12/06→		Coil	
KIA - CERATO (LD)						07/04→
1.6	77 kW	1.6 l	07/04→		5DA 193 175-381 Ignition	12
					Coil	
KIA - CERATO Saloon (LD)						04/04→
1.6	77 kW	1.6 l	04/04→		5DA 193 175-381 Ignition	12
					Coil	
1.6	90 kW	1.6 l	05/06→		5DA 193 175-481 Ignition	15
					Coil	
KIA - PICANTO (TA)						05/11→
1.0	51 kW	1 l	05/11→	G3LA	5DA 193 175-971 Ignition	29
					Coil	
1.0 Bi-Fuel	60 kW	1 l	05/11→	B3LA	5DA 193 175-971 Ignition	29
					Coil	
1.2	63 kW	1.2 l	09/11→	G4LA	5DA 193 175-961 Ignition	29
					Coil	
KIA - PRO CEE'D (ED)						02/08→
1.4	80 kW	1.4 l	02/08→		5DA 193 175-511 Ignition	16
					Coil	
KIA - RIO II (JB)						03/05→
1.4 16V	71 kW	1.4 l	03/05→		5DA 193 175-381 Ignition	12
1.6 CVVT	82 kW	1.6 l	03/05→		Coil	
KIA - RIO II Saloon (JB)						03/05→
1.4 16V	71 kW	1.4 l	03/05→		5DA 193 175-381 Ignition	12
1.6 16V	82 kW	1.6 l	03/05→		Coil	
KIA - RIO III (UB)						09/11→
1.25 CVVT	63 kW	1.25 l	09/11→	G4LA	5DA 193 175-961 Ignition	29
					Coil	
1.25 LPG	63 kW	1.25 l	09/11→		5DA 193 175-961 Ignition	29
					Coil	
KIA - RIO III Saloon (UB)						10/11→
1.25 CVVT	63 kW	1.25 l	10/11→	G4LA	5DA 193 175-961 Ignition	29
					Coil	
KIA - RONDO III (UN)						08/09→
1.6 CVVT	93 kW	1.6 l	10/10→		5DA 193 175-481 Ignition	15
1.6 CVVT	97 kW	1.6 l	08/09→		Coil	
KIA - SOUL (AM)						02/09→
1.6 CVVT	93 kW	1.6 l	02/09→		5DA 193 175-481 Ignition	15
					Coil	
KIA - SPORTAGE (K00)						04/94→08/99
2.0 i4WD	70 kW	2 l	04/94→08/99	FE (8V)	5DA 193 175-691 Ignition	20
					Coil	

				13	i	412		
LADA - CEVARO (2108, 2109, 2115)								01/86 →
1100	39 kW	1.1 l	02/88→12/94				5DA 006 623-931 Switch Unit, ignition system	8
1300	45 kW	1.3 l	09/91→					
1300	46 kW	1.3 l	01/88→					
1300	48 kW	1.3 l	01/86→12/94					
1500	53 kW	1.5 l	01/88→					
1500	50 kW	1.5 l	09/91→	→02/95			5DA 006 623-931 Switch Unit, ignition system	8
1500	52 kW	1.5 l	02/95→	→01/04			5DA 006 623-931 Switch Unit, ignition system	8
LADA - SABLE Saloon (21099)								05/89 →
1300	48 kW	1.3 l	05/89→07/97				5DA 006 623-931 Switch Unit, ignition system	8
1500	53 kW	1.5 l	09/91→					



LANCIA - A 112																03/78→12/86		
1.0 Abarth (A112B2/5)	51 kW	1 l	03/78→02/84											5DA 006 623-051	Switch	4		
1.0 LX	35 kW	1 l	03/84→12/86											Unit, ignition system				
LANCIA - DEDRA (835)																04/93→07/99		
1.6 16V (835EI)	76 kW	1.6 l	01/96→07/99											5DA 749 475-091	Ignition	36		
														Coil				
1.6 i.e. (835AN)	55 kW	1.6 l	04/93→07/99											835 C1.000	5DA 193 175-691	Ignition	20	
														Coil				
1.8 16V LE (835FG)	83 kW	1.8 l	03/96→07/99											182 A2.000; engine 0283747→	5DA 749 475-511	Ignition	39	
														Coil				
1.8 GT 16V (835EH)	96 kW	1.8 l	03/96→07/99											183 A1.000; engine 0283747→	5DA 749 475-511	Ignition	39	
														Coil				
1.8 i.e. (835FA)	74 kW	1.8 l	07/94→07/99											2x	5DA 193 175-341	Ignition	11	
														Coil				
LANCIA - DEDRA SW (835)																07/94→07/99		
1.6 16V (835EI)	76 kW	1.6 l	01/96→07/99											5DA 749 475-091	Ignition	36		
														Coil				
1.8 16V LE (835FG)	83 kW	1.8 l	03/96→07/99											182 A2.000; engine 0283747→	5DA 749 475-511	Ignition	39	
														Coil				
1.8 GT 16V (835EH)	96 kW	1.8 l	03/96→07/99											183 A1.000; engine 0283747→	5DA 749 475-511	Ignition	39	
														Coil				
1.8 i.e. (835FA)	74 kW	1.8 l	07/94→07/99											2x	5DA 193 175-341	Ignition	11	
														Coil				
LANCIA - DELTA I (831AB0)																09/79→01/94		
1.3 (831AB.011)	55 kW	1.3 l	09/79→08/92											5DA 006 623-161	Switch	4		
														Unit, ignition system				
1.5 (831AB.025)	63 kW	1.5 l	09/79→12/92											→04/86	5DA 006 623-051	Switch	4	
														Unit, ignition system				
1.6 HF Turbo	96 kW	1.6 l	10/83→12/86											05/86→	5DA 006 623-431	Switch	6	
														Unit, ignition system				
1.6 HF Turbo (831AB.020)	103 kW	1.6 l	08/86→08/88												5DA 006 623-431	Switch	6	
2.0 HF Integrale (831AB.019)	122 kW	2 l	11/86→08/88												Unit, ignition system			
2.0 16V HF Evo Integrale (831AB.027)	155 kW	2 l	06/93→01/94												831 E5.046; 2x	5DA 193 175-341	Ignition	11
														Coil				
LANCIA - DELTA II (836)																06/93→08/99		
1.4 i.e. (836AF, 836AH)	51 kW	1.4 l	10/94→08/99												836 A4.000	5DA 193 175-691	Ignition	20
														Coil				
1.6 i.e. (836AD)	55 kW	1.6 l	06/93→08/99												835 C1.000	5DA 193 175-691	Ignition	20
														Coil				
1.6 i.e. (836AP)	66 kW	1.6 l	03/96→08/99												5DA 749 475-091	Ignition	36	
1.6 i.e. 16V (836AO)	76 kW	1.6 l	01/96→08/99												Coil			
1.8 i.e. (836AE)	76 kW	1.8 l	06/93→08/99												2x	5DA 193 175-341	Ignition	11
2.0 16V Turbo (836AB)	137 kW	2 l	06/93→08/99												Coil			
2.0 16V Turbo (836AS)	142 kW	2 l	07/96→08/99															
1.8 i.e. (836AG, 836AL)	66 kW	1.8 l	07/94→08/99												835 C4.000 / 836 A6.000; 2x	5DA 193 175-341	Ignition	11
														Coil				
1.8 i.e. 16V (836AQ)	83 kW	1.8 l	03/96→08/99												182 A2.000; engine 0283747→	5DA 749 475-511	Ignition	39
														Coil				
1.8 i.e. 16V GT (836AR)	96 kW	1.8 l	03/96→08/99												183 A1.000; 04/98→; 4x	5DA 193 175-741	Ignition	22
														Coil				
															183 A1.000; →04/98; engine 0283747→	5DA 749 475-511	Ignition	39
														Coil				
LANCIA - KAPPA (838A)																08/94→10/01		
2.0 16V Turbo (838AB1AA)	151 kW	2 l	02/95→10/01												Multipoint Injection	5DA 006 623-601	Switch	8
															Unit, ignition system			
															838 A4.000	5DA 193 175-691	Ignition	20
															Coil			
2.0 20V (838AA1AA)	107 kW	2 l	10/94→10/01												838 A1.000	5DA 193 175-061	Ignition	10
															Coil			
2.0 20V (838AG1AA, 838AG11A)	114 kW	2 l	07/96→10/01												838 A6.000	5DA 193 175-061	Ignition	10
															Coil			
2.0 20V Turbo (838AM1AA)	162 kW	2 l	06/98→10/01												175 A3.000	5DA 193 175-061	Ignition	10
															Coil			
2.4 20V (838AC1AA, 838AC11A)	129 kW	2.4 l	08/94→10/01												838 A2.000 / 838 A2.027	5DA 193 175-061	Ignition	10
															Coil			
3.0 24V (838AD1AA, 838AD11A, 838XD1AA, 838ZD1AA)	150 kW	3 l	08/94→10/01												838 B.000	5DA 193 175-671	Ignition	20
															Coil			

										13			412	
LANCIA - KAPPA Coupe (838)										11/96→03/01				
2.0 16V Turbo (838CB)	151 kW	2 l	11/96→03/01	Multipoint Injection	5DA 006 623-601	Switch Unit, ignition system					8			
2.0 20V Turbo (838CM)	162 kW	2 l	06/98→03/01	☉ 175 A3.000	5DA 193 175-061	Ignition Coil					10			
2.4 20V (838CC)	129 kW	2.4 l	11/96→03/01	☉ 838 A2.000	5DA 193 175-061	Ignition Coil					10			
3.0 24V (838CD, 838CD11A)	150 kW	3 l	11/96→03/01	☉ 838 B.000; Automatic Transmission	5DA 193 175-671	Ignition Coil					20			
LANCIA - KAPPA SW (838B)										07/96→10/01				
2.0 16V Turbo (838BB1AA)	151 kW	2 l	07/96→10/01	Multipoint Injection	5DA 006 623-601	Switch Unit, ignition system					8			
				☉ 838 A4.000	5DA 193 175-691	Ignition Coil					20			
2.0 20V (838BG1AA)	114 kW	2 l	07/96→10/01	☉ 838 A6.000	5DA 193 175-061	Ignition Coil					10			
2.0 20V Turbo (838BM1AA)	162 kW	2 l	06/98→10/01	☉ 175 A3.000	5DA 193 175-061	Ignition Coil					10			
2.4 20V (838BC1AA, 838BC11A)	129 kW	2.4 l	07/96→10/01	☉ 838 A2.000	5DA 193 175-061	Ignition Coil					10			
3.0 24V (838BD11A)	150 kW	3 l	07/96→10/01	☉ 838 B.000	5DA 193 175-671	Ignition Coil					20			
LANCIA - LYBRA (839AX)										07/99→10/05				
1.6 16V (839AXA1A)	76 kW	1.6 l	07/99→10/05		5DA 749 475-091	Ignition Coil					36			
1.8 16V (839AXB1A, 839AXG1A)	96 kW	1.8 l	07/99→10/05	☉ 839 A4.000 / 839 A7.000 / 839 A9.000; →Model 2005; 4x	5DA 193 175-741	Ignition Coil					22			
LANCIA - LYBRA SW (839BX)										07/99→10/05				
1.6 16V (839BXA1A)	76 kW	1.6 l	07/99→10/05		5DA 749 475-091	Ignition Coil					36			
1.8 16V (839BXB1A, 839BXG1A)	96 kW	1.8 l	07/99→10/05	☉ 839 A4.000 / 839 A7.000; →Model 2005; 4x	5DA 193 175-741	Ignition Coil					22			
LANCIA - MUSA (350)										10/04→				
1.4	66 kW	1.4 l	10/07→	☉ 192 B2.000; 4	5DA 193 175-761	Ignition Coil					23			
1.4	70 kW	1.4 l	10/04→	☉ 843 A 1.000; 4	5DA 193 175-761	Ignition Coil					23			
LANCIA - PRISMA (831AB0)										01/83→12/89				
1.5	63 kW	1.5 l	01/83→04/86		5DA 006 623-051	Switch Unit, ignition system					4			
1.6 i.e.	80 kW	1.6 l	05/86→12/89		5DA 006 623-431	Switch Unit, ignition system					6			
1.6 i.e. Super	66 kW	1.6 l	05/87→12/89											
LANCIA - THEMA (834)										11/84→07/94				
2000 16V (834FA)	112 kW	2 l	08/92→12/93	☉ 834 F1.000	5DA 193 175-691	Ignition Coil					20			
2000 16V Turbo (834AC)	133 kW	2 l	12/88→06/90	2x	5DA 193 175-341	Ignition Coil					11			
2000 i.e. (834BV)	85 kW	2 l	09/87→05/92											
2000 i.e. 16V (834AA)	108 kW	2 l	05/88→08/92											
2000 i.e. 16V (834AI)	104 kW	2 l	02/89→05/92											
2000 i.e. 16V Turbo (834AL)	130 kW	2 l	04/89→05/92											
2000 i.e (834AB)	86 kW	2 l	09/88→05/92											
2000 16V Turbo (834GC, 834FC)	148 kW	2 l	10/92→07/94		5DA 006 623-601	Switch Unit, ignition system					8			
				☉ 834 F2.000	5DA 193 175-691	Ignition Coil					20			
2000 i.e. Turbo (834C)	122 kW	2 l	11/84→12/87	07/86→	5DA 006 623-431	Switch Unit, ignition system					6			
2000 i.e. Turbo (834CV)	110 kW	2 l	07/86→05/90		5DA 006 623-431	Switch Unit, ignition system					6			
				2x	5DA 193 175-341	Ignition Coil					11			
LANCIA - THEMA SW (834)										12/88→07/94				
2000 16V (834FA)	112 kW	2 l	05/92→07/94	☉ 834 F1.000	5DA 193 175-691	Ignition Coil					20			
2000 i.e. 16V (834AA)	108 kW	2 l	05/89→08/92	2x	5DA 193 175-341	Ignition Coil					11			
2000 i.e. 16V Turbo (834AC)	133 kW	2 l	12/88→06/90											
2000 i.e. 16V Turbo (834AL)	130 kW	2 l	04/89→03/93											
2000 Turbo	110 kW	2 l	01/89→03/92											










								13	i	412	
LANCIA - THEMA SW (834)										12/88→07/94	
2000 i.e. 16V (834AI)	104 kW	2 l	02/89→05/92	→05/90		5DA 006 623-431	Switch Unit, ignition system			6	
				2x		5DA 193 175-341	Ignition Coil			11	
2000 Turbo 16V (834GC, 834FC)	148 kW	2 l	11/92→07/94			5DA 006 623-601	Switch Unit, ignition system			8	
					834 F2.000	5DA 193 175-691	Ignition Coil			20	
LANCIA - THESIS (841AX)										07/02→07/09	
3.0 V6 (841AXC1101)	158 kW	3 l	07/02→07/09		841 A.000; →Model 2007	5DA 193 175-671	Ignition Coil			20	
3.2 V6	169 kW	3.2 l	05/03→07/09		→Model 2007	5DA 193 175-671	Ignition Coil			20	
LANCIA - Y (840A)										11/95→09/03	
1.1 (840AE)	40 kW	1.1 l	11/95→09/03	2x		5DA 193 175-341	Ignition Coil			11	
1.2 (840AA, 840AF1A)	44 kW	1.2 l	03/96→09/03								
1.2 16V (840AD)	63 kW	1.2 l	04/97→09/03								
1.2 16V (840AG1A)	59 kW	1.2 l	10/00→09/03		188 A5.000	5DA 193 175-691	Ignition Coil			20	
1.4 12V (840AB)	59 kW	1.4 l	10/96→09/03		840 A2.000	5DA 193 175-691	Ignition Coil			20	
1.4 12V (840AC)	55 kW	1.4 l	03/96→09/03		840 A4.000	5DA 193 175-691	Ignition Coil			20	
LANCIA - Y10 (156)										03/85→12/95	
1.0 Fire (156AE) CAT	33 kW	1 l	10/87→02/92			5DA 006 623-161	Switch Unit, ignition system			4	
1.0 Fire (156B, 156AD)	32 kW	1 l	06/85→06/91								
1.0 Fire (156C)	41 kW	1 l	03/85→07/89								
1.0 Fire All-wheel Drive	32 kW	1 l	12/86→02/89								
1.0 Turbo (156D)	62 kW	1 l	03/85→02/89								
1.1 i.e. Fire (156AG)	37 kW	1.1 l	07/89→09/95								
1.3 i.e. Fire (156AF)	53 kW	1.3 l	02/89→12/95								
1.1 Avenue (156AG)	40 kW	1.1 l	01/95→12/95			5DA 006 623-161	Switch Unit, ignition system			4	
1.1 Avenue All-wheel Drive (156AG)	40 kW	1.1 l	01/95→12/95								
					176 B2.000	5DA 193 175-691	Ignition Coil			20	
1.1 i.e. Fire All-wheel Drive (156AG)	37 kW	1.1 l	09/92→12/95			5DA 006 623-161	Switch Unit, ignition system			4	
					156 C.046	5DA 193 175-691	Ignition Coil			20	
LANCIA - YPSILON (843)										10/03→12/11	
1.2	44 kW	1.2 l	10/03→12/11	2x		5DA 193 175-341	Ignition Coil			11	
1.2	59 kW	1.2 l	10/03→12/11		188 A5.000; 4	5DA 193 175-761	Ignition Coil			23	
1.4 16V	70 kW	1.4 l	10/03→12/11		843 A 1.000; 4	5DA 193 175-761	Ignition Coil			23	
LANCIA - ZETA (220)										05/95→09/02	
2.0 Turbo (220AD5, 220CD5)	108 kW	2 l	05/95→09/02			5DA 006 623-601	Switch Unit, ignition system			8	
						5DA 193 175-421	Ignition Coil			13	

				13	i	412	
LAND ROVER - DISCOVERY II (LJ, LT)							11/98→06/04
4.0 V8 4x4	136 kW	4 l	11/98→06/04	56 D; 2	5DA 193 175-691 Ignition Coil		20
LAND ROVER - FREELANDER (LN)							02/98→10/06
1.8 16V 4x4	86 kW	1.8 l	11/00→10/06	18 K4F	5DA 193 175-891 Ignition Coil		27
1.8 i 16V 4x4	88 kW	1.8 l	02/98→11/00				
LAND ROVER - FREELANDER Soft Top							02/98→10/06
1.8 i 16V 4x4	88 kW	1.8 l	02/98→10/06	18 K4F	5DA 193 175-891 Ignition Coil		27
LAND ROVER - RANGE ROVER II (LP)							07/94→03/02
3.9 4x4	140 kW	3.9 l	07/94→03/02	42 D; XA410482→; 2	5DA 193 175-691 Ignition Coil		20
4.0 4x4	136 kW	4 l	06/98→03/02				
4.6 4x4	165 kW	4.6 l	07/94→03/02	46 D; XA410482→; 2	5DA 193 175-691 Ignition Coil		20
LAND ROVER - RANGE ROVER III (LM)							03/02→08/12
4.4 4x4	210 kW	4.4 l	03/02→08/12		5DA 193 175-551 Ignition Coil		17











LEXUS - IS II Saloon (GSE2_, ALE2_, USE2_)							11/07 →
IS F (USE20)	311 kW	5 l	11/07 →	2UR-GSE; 8x	5DA 193 175-941 Ignition Coil	28	



 				 13		412	
LOTUS - ELISE							08/95→11/00
1.8	88 kW	1.8 l	08/95→11/00	 18 K4F	5DA 193 175-891 Ignition Coil	27	
111 S	107 kW	1.8 l	03/99→11/00	 18 K4K	5DA 193 175-371 Ignition Coil	12	



										13		412	
MAZDA - 2 (DY)												04/03→	
1.25	55 kW	1.25 l	04/03→		FUJA; →02/05	5DA 193 175-411 Ignition Coil						13	
1.4	59 kW	1.4 l	04/03→		FXJA; →02/05	5DA 193 175-411 Ignition Coil						13	
1.6	74 kW	1.6 l	04/03→		FYJA; →02/05	5DA 193 175-411 Ignition Coil						13	
MAZDA - 3 (BK)												10/03→06/09	
2.0	110 kW	2 l	10/03→06/09		LF17; 4	5DA 193 175-781 Ignition Coil						23	
MAZDA - 3 Saloon (BK)												02/04→	
2.0	110 kW	2 l	02/04→		LF17; 4	5DA 193 175-781 Ignition Coil						23	
MAZDA - 121 III (JASM, JBSM)												03/96→04/03	
1.25	55 kW	1.25 l	03/96→04/03		DHG / DHF	5DA 193 175-401 Ignition Coil						13	
1.3	37 kW	1.3 l	03/96→04/03		JJK / JJM	5DA 193 175-411 Ignition Coil						13	
1.3	44 kW	1.3 l	03/96→04/03		J4R / J4T	5DA 193 175-411 Ignition Coil						13	
MAZDA - 323 ASTINA V (BA)												08/94→09/98	
1.5 16V	65 kW	1.5 l	08/94→09/98			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 323 ASTINA V (BA)												07/94→09/98	
1.5 16V	65 kW	1.5 l	07/94→09/98			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 323 ASTINA VI (BJ)												09/98→01/01	
1.5 16V	65 kW	1.5 l	09/98→01/01			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 323 P V (BA)												10/96→	
1.5 16V	65 kW	1.5 l	10/96→			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 323 PROTEGÉ V Saloon (BA)												08/94→09/98	
1.5 16V	65 kW	1.5 l	08/94→09/98			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 323 PROTEGÉ VI (BJ)												09/98→01/01	
1.5 16V	65 kW	1.5 l	09/98→01/01			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 626 III Hatchback (GD)												11/87→05/92	
1.8	65 kW	1.8 l	11/87→05/92		10/89→	5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 626 III Saloon (GD)												11/87→05/92	
1.8	65 kW	1.8 l	11/87→05/92		10/89→	5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 626 IV Hatchback (GE)												08/91→04/97	
1.8	66 kW	1.8 l	08/94→04/97			5DA 006 623-421 Switch Unit, ignition system						6	
1.8	77 kW	1.8 l	08/91→04/97			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 626 IV Saloon (GE)												01/92→04/97	
1.8 i	66 kW	1.8 l	08/94→04/97			5DA 006 623-421 Switch Unit, ignition system						6	
1.8 i	77 kW	1.8 l	01/92→04/97			5DA 006 623-421 Switch Unit, ignition system						6	
MAZDA - 626 V Hatchback (GF)												05/97→10/02	
2.0	85 kW	2 l	05/97→10/02		FS	5DA 193 175-401 Ignition Coil						13	
MAZDA - 626 V Station Wagon (GW)												02/98→10/02	
2.0	85 kW	2 l	02/98→10/02		FS	5DA 193 175-401 Ignition Coil						13	
MAZDA - E-SERIE Box (SR2)												05/85→05/03	
E2000	60 kW	2 l	03/91→05/94			5DA 006 623-421 Switch Unit, ignition system						6	
E2000	70 kW	2 l	06/94→05/03			5DA 006 623-421 Switch Unit, ignition system						6	

 				 13		412	
MAZDA - E-SERIE Box (SR2)							05/85→05/03
E2000	63 kW	2 l	05/85→04/89	12/87→	5DA 006 623-421 Switch Unit, ignition system		6
MAZDA - E-SERIE Bus (SR1)							11/84→09/89
E2000	63 kW	2 l	11/84→02/88	12/87→	5DA 006 623-421 Switch Unit, ignition system		6
E2000 4WD	60 kW	2 l	10/88→09/89		5DA 006 623-421 Switch Unit, ignition system		6
MAZDA - TRIBUTE Closed (EP)							12/03→10/04
2.3 GX	110 kW	2.3 l	12/03→10/04	 L3-VE; 4	5DA 193 175-781 Ignition Coil		23



				412		
MERCEDES-BENZ - 190 Saloon (W201)						10/82→06/93
2.0 (201.022)	66 kW	2 l	10/82→10/84		5DA 006 623-181 Switch Unit, ignition system	4
2.0 (201.023)	75 kW	2 l	01/86→05/90	→08/86	5DA 006 623-181 Switch Unit, ignition system	4
2.0 (201.023)	77 kW	2 l	09/84→05/90			
E 2.0 (201.024)	90 kW	2 l	10/82→06/93			
MERCEDES-BENZ - A-CLASS (W168)						07/97→08/04
A 140 (168.031, 168.131)	60 kW	1.4 l	07/97→08/04		5DA 358 000-191 Ignition Coil	33
A 140 (168.031, 168.131)	60 kW	1.6 l	01/01→08/04			
A 160 (168.033, 168.133)	75 kW	1.6 l	07/97→08/04			
A 190 (168.032, 168.132)	92 kW	1.9 l	03/99→08/04			
A 210 (168.035, 168.135)	103 kW	2.1 l	03/02→08/04			
MERCEDES-BENZ - A-CLASS (W169)						09/04→06/12
A 150 (169.031, 169.331)	70 kW	1.5 l	09/04→06/12	⊕ M 266.920; 2x	5DA 193 175-991 Ignition Coil	30
A 170 (169.032, 169.332)	85 kW	1.7 l	09/04→06/12	⊕ M 266.940; 2x	5DA 193 175-991 Ignition Coil	30
A 200 (169.033, 169.333)	100 kW	2 l	09/04→06/12	⊕ M 266.960; 2x	5DA 193 175-991 Ignition Coil	30
A 200 TURBO (169.034, 169.334)	142 kW	2 l	09/05→06/12	⊕ M 266.980; 2x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - B-CLASS (W245)						03/05→11/11
B 150 (245.231)	70 kW	1.5 l	03/05→11/11	⊕ M 266.920; 2x	5DA 193 175-991 Ignition Coil	30
B 170 (245.232)	85 kW	1.7 l	03/05→11/11	⊕ M 266.940; 2x	5DA 193 175-991 Ignition Coil	30
B 200 (245.233)	100 kW	2 l	03/05→11/11	⊕ M 266.960; 2x	5DA 193 175-991 Ignition Coil	30
B 200 TURBO (245.234)	142 kW	2 l	03/05→11/11	⊕ M 266.980; 2x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - C-CLASS Coupe (CL203)						05/02→05/08
C 160 Kompressor (203.730)	90 kW	1.8 l	05/02→05/08	→engine 30099998; →08/07; 30405223	5DA 358 000-111 Ignition Coil	32
C 180 Kompressor (203.746)	105 kW	1.8 l	05/02→05/08			
C 200 CGI Kompressor (203.743)	125 kW	1.8 l	03/03→05/08			
C 200 Kompressor (203.742)	120 kW	1.8 l	05/02→05/08			
C 230 Kompressor (203.740)	141 kW	1.8 l	05/02→05/08			
C 320 (203.764)	160 kW	3.2 l	09/02→05/08	⊕ M 112.946; 6x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - C-CLASS Estate (S202)						06/96→03/01
C 180 T (202.078)	90 kW	1.8 l	06/96→09/00	⊕ M 111.921; 2x	5DA 193 175-361 Ignition Coil	11
					5DA 358 000-021 Ignition Coil	31
C 200 T (202.080)	100 kW	2 l	06/96→03/01	⊕ M 111.945; 2x	5DA 193 175-361 Ignition Coil	11
					5DA 358 000-021 Ignition Coil	31
C 200 T Kompressor (202.082)	141 kW	2 l	11/96→03/01	2x	5DA 193 175-361 Ignition Coil	11
C 230 T (202.083)	110 kW	2.3 l	06/96→06/98			
C 230 T Kompressor (202.085)	142 kW	2.3 l	06/97→09/00			
C 240 T (202.086)	125 kW	2.4 l	06/97→09/00	⊕ M 112.910; 6x	5DA 193 175-991 Ignition Coil	30
C 240 T (202.088)	125 kW	2.6 l	09/00→03/01	⊕ M 112.915; 6x	5DA 193 175-991 Ignition Coil	30
C 280 T (202.089)	145 kW	2.8 l	06/97→03/01	⊕ M 112.920; 6x	5DA 193 175-991 Ignition Coil	30
C 43 AMG (202.093)	225 kW	4.3 l	08/97→03/01	⊕ M 113.944; 8x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - C-CLASS Saloon (W202)						03/93→05/00
C 180 (202.018)	89 kW	1.8 l	11/94→05/00	2x	5DA 193 175-361 Ignition Coil	11
C 200 Kompressor (202.025)	132 kW	2 l	10/95→05/00			
C 200 Kompressor (202.025)	141 kW	2 l	11/96→05/00			
C 230 (202.023)	110 kW	2.3 l	06/96→06/97			
C 230 Kompressor (202.024)	142 kW	2.3 l	10/95→05/00			
C 180 (202.018)	90 kW	1.8 l	03/93→05/00	⊕ M 111.921; 2x	5DA 193 175-361 Ignition Coil	11
					5DA 358 000-021 Ignition Coil	31

				13	i	412	
MERCEDES-BENZ - C-CLASS Saloon (W202)							03/93→05/00
C 200 (202.020)	100 kW	2 l	01/94→05/00	☉ M 111.945; 2x		5DA 193 175-361 Ignition Coil	11
						5DA 358 000-021 Ignition Coil	31
C 220 (202.022)	110 kW	2.2 l	03/93→05/00			5DA 358 000-021 Ignition Coil	31
C 240 (202.026)	125 kW	2.4 l	06/97→05/00	☉ M 112.910; 6x		5DA 193 175-991 Ignition Coil	30
C 280 (202.028)	142 kW	2.8 l	05/93→05/00	3x		5DA 193 175-361 Ignition Coil	11
C 280 (202.029)	145 kW	2.8 l	06/97→05/00	☉ M 112.920; 6x		5DA 193 175-991 Ignition Coil	30
C 43 AMG (202.033)	225 kW	4.3 l	08/97→05/00	☉ M 113.944; 8x		5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - C-CLASS Saloon (W203)							05/00→02/07
C 180 Kompressor (203.046)	105 kW	1.8 l	05/02→02/07	→engine 30099998; →08/07; 30405223		5DA 358 000-111 Ignition Coil	32
C 200 CGI Kompressor (203.043)	125 kW	1.8 l	07/03→02/07				
C 200 Kompressor (203.042)	120 kW	1.8 l	05/02→02/07				
C 230 Kompressor (203.040)	141 kW	1.8 l	02/04→02/07				
C 240 (203.061)	125 kW	2.6 l	05/00→02/07	☉ M 112.912; 6x		5DA 193 175-991 Ignition Coil	30
C 240 4-matic (203.081)	125 kW	2.6 l	07/02→02/07	☉ M 112.916; 6x		5DA 193 175-991 Ignition Coil	30
C 320 (203.064)	160 kW	3.2 l	05/00→02/07	☉ M 112.946; 6x		5DA 193 175-991 Ignition Coil	30
C 320 4-matic (203.084)	160 kW	3.2 l	07/02→02/07	☉ M 112.953; 6x		5DA 193 175-991 Ignition Coil	30
C 32 AMG Kompressor (203.065)	260 kW	3.2 l	02/01→02/07	☉ M 112.961; 6x		5DA 193 175-991 Ignition Coil	30
C 55 AMG (203.076)	270 kW	5.4 l	02/04→02/07	☉ M 113.988; 8x		5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - C-CLASS Saloon (W204)							01/07→
C 180 Kompressor (204.046)	115 kW	1.8 l	01/07→	→engine 30099998; →08/07; 30405223		5DA 358 000-111 Ignition Coil	32
C 200 Kompressor (204.041)	135 kW	1.8 l	01/07→				
MERCEDES-BENZ - C-CLASS T-Model (S203)							03/01→08/07
C 180 Kompressor (203.246)	105 kW	1.8 l	05/02→08/07	→engine 30099998; →08/07; 30405223		5DA 358 000-111 Ignition Coil	32
C 200 CGI Kompressor (203.243)	125 kW	1.8 l	07/03→08/07				
C 200 Kompressor (203.242)	120 kW	1.8 l	05/02→08/07				
C 230 Kompressor (203.240)	141 kW	1.8 l	02/04→08/07				
C 240 (203.261)	125 kW	2.6 l	03/01→08/07	☉ M 112.912; 6x		5DA 193 175-991 Ignition Coil	30
C 240 4-matic (203.281)	125 kW	2.6 l	07/02→08/07	☉ M 112.916; 6x		5DA 193 175-991 Ignition Coil	30
C 320 (203.264, 203.764)	160 kW	3.2 l	03/01→08/07	☉ M 112.946; 6x		5DA 193 175-991 Ignition Coil	30
C 320 4-matic (203.284)	160 kW	3.2 l	07/02→08/07	☉ M 112.953; 6x		5DA 193 175-991 Ignition Coil	30
C 32 AMG Kompressor (203.265)	260 kW	3.2 l	03/01→08/07	☉ M 112.961; 6x		5DA 193 175-991 Ignition Coil	30
C 55 AMG (203.276)	270 kW	5.4 l	02/04→08/07	☉ M 113.988; 8x		5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - C-CLASS T-Model (S204)							08/07→
C 180 Kompressor (204.246)	115 kW	1.8 l	08/07→	→engine 30099998; →08/07; 30405223		5DA 358 000-111 Ignition Coil	32
C 200 Kompressor (204.241)	135 kW	1.8 l	08/07→				
MERCEDES-BENZ - CLK (C208)							06/97→06/02
200 (208.335)	100 kW	2 l	06/97→06/02	☉ M 111.945; 2x		5DA 193 175-361 Ignition Coil	11
						5DA 358 000-021 Ignition Coil	31
200 Kompressor (208.345)	141 kW	2 l	06/97→06/00	2x		5DA 193 175-361 Ignition Coil	11
230 Kompressor (208.347)	142 kW	2.3 l	06/97→06/00				
320 (208.365)	160 kW	3.2 l	06/97→06/02	☉ M 112.940; 6x		5DA 193 175-991 Ignition Coil	30
430 (208.370)	205 kW	4.3 l	07/98→06/02	☉ M 113.943; 8x		5DA 193 175-991 Ignition Coil	30
55 AMG (208.374)	255 kW	5.4 l	08/99→06/02	☉ M 113.981 / M 113.984; 8x		5DA 193 175-991 Ignition Coil	30

MERCEDES-BENZ - CLK (C209)							06/02→05/09
200 CGI (209.343)	125 kW	1.8 l	07/03→05/09	→engine 30099998; →08/07; 30405223	5DA 358 000-111	Ignition	32
200 Kompressor (209.341)	135 kW	1.8 l	10/06→05/09		Coil		
200 Kompressor (209.342)	120 kW	1.8 l	09/02→05/09				
240 (209.361)	125 kW	2.6 l	06/02→05/09	⊗ M 112.912; 6x	5DA 193 175-991	Ignition	30
					Coil		
320 (209.365)	160 kW	3.2 l	06/02→05/09	⊗ M 112.955; 6x	5DA 193 175-991	Ignition	30
					Coil		
500 (209.375)	225 kW	5 l	06/02→05/09	⊗ M 113.968; 8x	5DA 193 175-991	Ignition	30
					Coil		
55 AMG (209.376)	270 kW	5.4 l	09/02→05/09	⊗ M 113.987; 8x	5DA 193 175-991	Ignition	30
					Coil		
MERCEDES-BENZ - CLK Convertible (A208)							03/98→03/02
200 (208.435)	100 kW	2 l	03/98→03/02	⊗ M 111.945; 2x	5DA 193 175-361	Ignition	11
					Coil		
					5DA 358 000-021	Ignition	31
					Coil		
200 Kompressor (208.445)	141 kW	2 l	03/98→06/00	2x	5DA 193 175-361	Ignition	11
230 Kompressor (208.447)	142 kW	2.3 l	03/98→06/00		Coil		
320 (208.465)	160 kW	3.2 l	03/98→03/02	⊗ M 112.940; 6x	5DA 193 175-991	Ignition	30
					Coil		
430 (208.470)	205 kW	4.3 l	09/98→03/02	⊗ M 113.943; 8x	5DA 193 175-991	Ignition	30
					Coil		
55 AMG (208.474)	255 kW	5.4 l	01/00→03/02	⊗ M 113.981 / M 113.984; 8x	5DA 193 175-991	Ignition	30
					Coil		
MERCEDES-BENZ - CLK Convertible (A209)							02/03→03/10
CLK 200 CGI (209.443)	125 kW	1.8 l	07/03→03/10	→engine 30099998; →08/07; 30405223	5DA 358 000-111	Ignition	32
CLK 200 Kompressor (209.441)	135 kW	1.8 l	10/06→03/10		Coil		
CLK 200 Kompressor (209.442)	120 kW	1.8 l	02/03→03/10				
CLK 240 (209.461)	125 kW	2.6 l	02/03→03/10	⊗ M 112.912; 6x	5DA 193 175-991	Ignition	30
					Coil		
CLK 320 (209.465)	160 kW	3.2 l	02/03→03/10	⊗ M 112.955; 6x	5DA 193 175-991	Ignition	30
					Coil		
CLK 500 (209.475)	225 kW	5 l	02/03→03/10	⊗ M 113.968; 8x	5DA 193 175-991	Ignition	30
					Coil		
CLK 55 AMG (209.476)	270 kW	5.5 l	02/03→03/10	⊗ M 113.987; 8x	5DA 193 175-991	Ignition	30
					Coil		
MERCEDES-BENZ - CLS (C219)							10/04→12/10
CLS 500 (219.375)	225 kW	5 l	10/04→12/10	⊗ M 113.967; 8x	5DA 193 175-991	Ignition	30
					Coil		
CLS 55 AMG (219.376)	350 kW	5.4 l	01/05→12/10	⊗ M 113.990; 8x	5DA 193 175-991	Ignition	30
					Coil		
MERCEDES-BENZ - COUPE (C123)							03/77→12/85
230 CE (123.243)	100 kW	2.3 l	04/80→12/85		5DA 006 623-181	Switch	4
280 CE	130 kW	2.7 l	09/77→08/79		Unit, ignition system		
280 CE	136 kW	2.7 l	03/77→11/85				
MERCEDES-BENZ - COUPE (C124)							10/92→05/93
220 CE (124.042)	110 kW	2.2 l	10/92→05/93		5DA 358 000-021	Ignition	31
					Coil		
320 CE (124.052)	162 kW	3.2 l	10/92→05/93	3x	5DA 193 175-361	Ignition	11
					Coil		
MERCEDES-BENZ - E-CLASS Convertible (A124)							06/93→03/98
E 200 (124.060)	100 kW	2 l	06/93→03/98		5DA 358 000-021	Ignition	31
E 220 (124.062)	110 kW	2.2 l	06/93→03/98		Coil		
E 320 (124.066)	162 kW	3.2 l	06/93→03/98	3x	5DA 193 175-361	Ignition	11
					Coil		
MERCEDES-BENZ - E-CLASS Coupe (C124)							06/93→06/97
E 200 (124.040)	100 kW	2 l	06/93→06/97		5DA 358 000-021	Ignition	31
E 220 (124.042)	110 kW	2.2 l	06/93→06/97		Coil		
E 320 (124.052)	162 kW	3.2 l	06/93→06/97	3x	5DA 193 175-361	Ignition	11
					Coil		
MERCEDES-BENZ - E-CLASS Estate (S124)							06/93→06/96
E 200 T (124.079)	100 kW	2 l	06/93→06/96		5DA 358 000-021	Ignition	31
E 220 T (124.082)	110 kW	2.2 l	06/93→06/96		Coil		
E 280 T (124.088)	145 kW	2.8 l	06/93→06/96	3x	5DA 193 175-361	Ignition	11
E 280 T (124.088)	142 kW	2.8 l	06/93→06/96		Coil		
E 320 T (124.092)	162 kW	3.2 l	06/93→06/96				

MERCEDES-BENZ - E-CLASS Estate (S210)										06/96→03/03			
E 200 T (210.235)	100 kW	2 l	06/96→08/00	2x		5DA 193 175-361	Ignition	11					
E 200 T Kompressor (210.245)	137 kW	2 l	06/97→03/03			Coil							
E 230 T (210.237)	110 kW	2.3 l	06/96→06/97										
E 240 T (210.261)	125 kW	2.4 l	06/97→03/03		M 112.911; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 240 T (210.262)	125 kW	2.6 l	08/00→03/03		M 112.914; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 280 T (210.263)	150 kW	2.8 l	12/96→03/03		M 112.921; 6x	5DA 193 175-991	Ignition	30					
E 280 T 4-matic (210.281)	150 kW	2.8 l	12/96→03/03			Coil							
E 320 T (210.265)	165 kW	3.2 l	12/96→03/03		M 112.941; 6x	5DA 193 175-991	Ignition	30					
E 320 T 4-matic (210.282)	165 kW	3.2 l	12/96→03/03			Coil							
E 430 T (210.270)	205 kW	4.3 l	06/97→03/03		M 113.940; 8x	5DA 193 175-991	Ignition	30					
E 430 T 4-matic (210.283)	205 kW	4.3 l	05/99→03/03			Coil							
E 55 T AMG (210.274)	260 kW	5.4 l	08/97→03/03		M 113.980; 8x	5DA 193 175-991	Ignition	30					
E 55 T AMG 4-matic (210.283)	260 kW	5.4 l	03/01→03/03			Coil							
MERCEDES-BENZ - E-CLASS Saloon (W124)										06/93→06/95			
E 200 (124.019)	100 kW	2 l	06/93→06/95			5DA 358 000-021	Ignition	31					
E 220 (124.022)	110 kW	2.2 l	06/93→06/95			Coil							
E 280 (124.028)	145 kW	2.8 l	06/93→06/95	3x		5DA 193 175-361	Ignition	11					
E 280 (124.029)	142 kW	2.8 l	06/93→06/95			Coil							
E 320 (124.032)	162 kW	3.2 l	06/93→06/95										
MERCEDES-BENZ - E-CLASS Saloon (W210)										06/95→03/02			
E 200 (210.035)	100 kW	2 l	06/95→08/00	2x		5DA 193 175-361	Ignition	11					
E 200 Kompressor (210.045)	137 kW	2 l	06/97→03/02			Coil							
E 230 (210.037)	110 kW	2.3 l	06/95→06/97										
E 240 (210.061)	125 kW	2.4 l	06/97→08/00		M 112.911; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 240 (210.062)	125 kW	2.6 l	08/00→03/02		M 112.914; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 280 (210.053)	142 kW	2.8 l	01/96→06/97	3x		5DA 193 175-361	Ignition	11					
E 320 (210.055)	162 kW	3.2 l	06/95→06/97			Coil							
E 280 (210.063)	150 kW	2.8 l	12/96→03/02		M 112.921; 6x	5DA 193 175-991	Ignition	30					
E 280 4-matic (210.081)	150 kW	2.8 l	12/96→03/02			Coil							
E 320 (210.065)	165 kW	3.2 l	06/97→03/02		M 112.941; 6x	5DA 193 175-991	Ignition	30					
E 320 4-matic (210.082)	165 kW	3.2 l	06/97→03/02			Coil							
E 430 (210.070)	205 kW	4.3 l	06/97→03/02		M 113.940; 8x	5DA 193 175-991	Ignition	30					
E 430 4-matic (210.083)	205 kW	4.3 l	05/99→03/02			Coil							
E 55 AMG (210.074)	260 kW	5.4 l	08/97→03/02		M 113.980; 8x	5DA 193 175-991	Ignition	30					
E 55 AMG 4-matic (210.074)	260 kW	5.4 l	03/01→03/02			Coil							
MERCEDES-BENZ - E-CLASS Saloon (W211)										03/02→12/08			
E 200 Kompressor (211.041)	135 kW	1.8 l	04/06→12/08	→engine 30099998; →08/07; 30405223		5DA 358 000-111	Ignition	32					
E 200 Kompressor (211.042)	120 kW	1.8 l	11/02→12/08			Coil							
E 200 NGT (211.041)	120 kW	1.8 l	03/04→12/08										
E 240 (211.061)	130 kW	2.6 l	03/02→12/08		M 112.917 / M 112.913; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 240 4-matic (211.080)	130 kW	2.6 l	03/03→12/08		M 112.917; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 320 (211.065)	165 kW	3.2 l	03/02→12/08		M 112.949; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 320 4-matic (211.082)	165 kW	3.2 l	03/03→12/08		M 112.954; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 500 (211.070)	225 kW	5 l	03/02→12/08		M 113.967; 8x	5DA 193 175-991	Ignition	30					
						Coil							
E 500 4-matic (211.083)	225 kW	5 l	10/03→12/08		M 113.969; 8x	5DA 193 175-991	Ignition	30					
						Coil							
E 55 AMG Kompressor (211.076)	350 kW	5.5 l	10/02→12/08		M 113.990; 8x	5DA 193 175-991	Ignition	30					
						Coil							
MERCEDES-BENZ - E-CLASS T-Model (S211)										03/03→07/09			
E 200 Kompressor (211.241)	135 kW	1.8 l	04/06→07/09	→engine 30099998; →08/07; 30405223		5DA 358 000-111	Ignition	32					
E 200 T Kompressor (211.242)	120 kW	1.8 l	03/03→07/09			Coil							
E 240 T (211.261)	130 kW	2.6 l	03/03→07/09		M 112.913; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 240 T 4-matic (211.280)	130 kW	2.6 l	07/03→07/09		M 112.917; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 320 T (211.265)	165 kW	3.2 l	03/03→07/09		M 112.949; 6x	5DA 193 175-991	Ignition	30					
						Coil							
E 320 T 4-matic (211.282)	165 kW	3.2 l	07/03→07/09		M 112.954; 6x	5DA 193 175-991	Ignition	30					
						Coil							

MERCEDES-BENZ - E-CLASS T-Model (S211)						03/03→07/09
E 500 T (211.270)	225 kW	5 l	10/03→07/09	☉ M 113.967; 8x	5DA 193 175-991 Ignition Coil	30
E 500 T 4-matic (211.283)	225 kW	5 l	10/03→07/09	☉ M 113.969; 6x	5DA 193 175-991 Ignition Coil	30
E 55 T AMG Kompressor (211.276)	350 kW	5.4 l	07/03→07/09	☉ M 113.990; 8x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - G-CLASS (W460)						11/79→08/92
230 GE (460,2)	90 kW	2.3 l	05/87→08/92	→08/89; ☉ M102.987	5DA 006 623-181 Switch Unit, ignition system	4
230 GE (460,2)	92 kW	2.3 l	04/82→08/92	☉ M102.981 / M102.987	5DA 006 623-181 Switch Unit, ignition system	4
280 GE (460,2)	110 kW	2.7 l	08/84→08/89		5DA 006 623-181 Switch Unit, ignition system	4
280 GE (460,2)	115 kW	2.7 l	11/79→08/89		5DA 006 623-181 Switch Unit, ignition system	4
MERCEDES-BENZ - G-CLASS (W463)						09/94→12/97
G 320 (463.230, 463.231)	155 kW	3.2 l	09/94→12/97	3x	5DA 193 175-361 Ignition Coil	11
G 320 (463.232, 463.233, 463.244, 463.245)	158 kW	3.2 l	07/97→	☉ M 112.945; 6x	5DA 193 175-991 Ignition Coil	30
G 500 (463.247, 463.248, 463.249, 463.240, 463.421)	218 kW	5 l	04/98→	☉ M 113.962; 8x	5DA 193 175-991 Ignition Coil	30
G 55 AMG (463.243, 463.246)	260 kW	5.5 l	04/99→	☉ M 113.982; 8x	5DA 193 175-991 Ignition Coil	30
G 55 AMG (463.270, 463.271)	350 kW	5.4 l	06/04→	☉ M 113.993; 8x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - G-CLASS Cabrio (W463)						09/94→11/97
320 GE (463.208)	155 kW	3.2 l	09/94→11/97	3x	5DA 193 175-361 Ignition Coil	11
G 320 (463.209)	158 kW	3.2 l	11/97→	☉ M 112.945; 6x	5DA 193 175-991 Ignition Coil	30
G 500 (463)	218 kW	5 l	04/98→	☉ M 113.962; 8x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - KOMBI Estate (S123)						09/77→11/85
200 T	80 kW	2 l	11/80→11/85	→07/84	5DA 006 623-181 Switch Unit, ignition system	4
200 T (123.280)	74 kW	2 l	11/80→11/85		5DA 006 623-181 Switch Unit, ignition system	4
230 TE (123.283)	100 kW	2.3 l	04/80→11/85		5DA 006 623-181 Switch Unit, ignition system	4
250 T (123.086)	95 kW	2.5 l	05/78→10/79		5DA 006 623-181 Switch Unit, ignition system	4
250 T (123.086)	103 kW	2.5 l	05/78→08/82		5DA 006 623-181 Switch Unit, ignition system	4
280 TE (123.093)	136 kW	2.7 l	09/77→11/85		5DA 006 623-181 Switch Unit, ignition system	4
MERCEDES-BENZ - KOMBI Estate (S124)						09/85→06/93
200 T (124.080)	77 kW	2 l	01/86→05/90	→08/86	5DA 006 623-181 Switch Unit, ignition system	4
200 T (124.080)	80 kW	2 l	09/85→08/89		5DA 006 623-181 Switch Unit, ignition system	4
230 TE (124.083)	97 kW	2.3 l	09/85→08/92		5DA 006 623-181 Switch Unit, ignition system	4
230 TE (124.083)	100 kW	2.3 l	09/85→08/92		5DA 006 623-181 Switch Unit, ignition system	4
200 TE (124.079)	100 kW	2 l	05/86→06/93		5DA 358 000-021 Ignition Coil	31
220 TE (124.082)	110 kW	2.2 l	10/92→05/93		5DA 358 000-021 Ignition Coil	31
280 TE (124.088)	145 kW	2.8 l	10/92→06/93	3x	5DA 193 175-361 Ignition Coil	11
320 TE (124.092)	162 kW	3.2 l	10/92→06/93		5DA 193 175-361 Ignition Coil	11
MERCEDES-BENZ - M-CLASS (W163)						02/98→06/05
ML 230 (163.136)	110 kW	2.3 l	02/98→06/05	2x	5DA 193 175-361 Ignition Coil	11
ML 320 (163.154)	160 kW	3.2 l	02/98→08/02	☉ M 112.942; 6x	5DA 193 175-991 Ignition Coil	30
ML 350 (163.157)	180 kW	3.7 l	08/02→06/05	☉ M 112.970; 6x	5DA 193 175-991 Ignition Coil	30
ML 350 4-matic	173 kW	3.7 l	02/03→06/05		5DA 193 175-991 Ignition Coil	30
ML 430 (163.172)	200 kW	4.3 l	02/98→06/05	☉ M 113.942; 8x	5DA 193 175-991 Ignition Coil	30
ML 500 (163.175)	215 kW	5 l	09/01→06/05	☉ M 113.964 / M 113.965; 8x	5DA 193 175-991 Ignition Coil	30
ML 55 AMG (163.174)	255 kW	5.4 l	02/00→06/05	☉ M 113.981; 8x	5DA 193 175-991 Ignition Coil	30
MERCEDES-BENZ - M-CLASS (W164)						07/05→
ML 500 4-matic (164.175)	225 kW	5 l	07/05→	☉ M 113.964; 8x	5DA 193 175-991 Ignition Coil	30

				13	i	412			
MERCEDES-BENZ - Saloon (W123)							02/76→12/85		
200	74 kW	2 l	06/80→11/85				5DA 006 623-181	Switch	4
230 E (123.223)	100 kW	2.3 l	04/80→12/85				Unit, ignition system		
280 E	130 kW	2.7 l	08/76→08/81						
280 E (123.033)	136 kW	2.7 l	02/76→11/85						
MERCEDES-BENZ - Saloon (W124)							12/84→06/93		
200	77 kW	2 l	01/86→05/90	→08/86			5DA 006 623-181	Switch	4
200 (124.020)	75 kW	2 l	01/86→05/90				Unit, ignition system		
200 (124.020)	80 kW	2 l	12/85→05/90						
230 E (124.023)	97 kW	2.3 l	12/84→03/92						
230 E (124.023)	100 kW	2.3 l	01/85→06/93						
200 E (124.019)	100 kW	2 l	10/92→06/93				5DA 358 000-021	Ignition	31
220 E (124.022)	110 kW	2.2 l	10/92→06/93				Coil		
200 E (124.021)	87 kW	2 l	09/88→08/92				5DA 006 623-181	Switch	4
							Unit, ignition system		
280 E (124.028)	145 kW	2.8 l	10/92→06/93	3x			5DA 193 175-361	Ignition	11
320 E (124.032)	162 kW	3.2 l	10/92→06/93				Coil		
MERCEDES-BENZ - S-CLASS Coupe (C126)							10/81→08/85		
380 SEC (126.043)	150 kW	3.8 l	10/81→07/85				5DA 006 623-181	Switch	4
500 SEC (126.044)	170 kW	4.9 l	10/81→08/85				Unit, ignition system		
MERCEDES-BENZ - S-CLASS Coupe (C215)							03/99→03/06		
CL 500 (215.375)	225 kW	5 l	03/99→03/06		M 113.960; 8x		5DA 193 175-991	Ignition	30
							Coil		
CL 55 AMG (215.373)	265 kW	5.4 l	10/99→03/06		M 113.986; 8x		5DA 193 175-991	Ignition	30
							Coil		
CL 55 AMG Kompressor (215.374)	368 kW	5.5 l	06/02→03/06		M 113.991; 8x		5DA 193 175-991	Ignition	30
							Coil		
MERCEDES-BENZ - S-CLASS Saloon (W126)							10/79→08/85		
280 S (126.021)	115 kW	2.7 l	12/79→07/85				5DA 006 623-181	Switch	4
280 SE,SEL (126.022, 126.023)	136 kW	2.7 l	10/79→07/85				Unit, ignition system		
380 SE,SEL (126.032)	150 kW	3.8 l	12/79→08/85						
500 SE,SEL (126.036)	170 kW	4.9 l	12/79→08/85						
500 SE,SEL (126.036)	177 kW	4.9 l	12/79→08/85						
MERCEDES-BENZ - S-CLASS Saloon (W140)							03/91→10/98		
300 SE,SEL/S320 (140.032, 140.033)	170 kW	3.2 l	03/91→10/98		M 104.994; Automatic Transmission; 3x		5DA 193 175-361	Ignition	11
							Coil		
300 SE 2.8 (140.028)	145 kW	2.8 l	01/93→10/98	3x			5DA 193 175-361	Ignition	11
S 280 (140.028)	142 kW	2.8 l	02/93→10/98				Coil		
MERCEDES-BENZ - S-CLASS Saloon (W220)							10/98→08/05		
S 280 (220.063, 220.163)	150 kW	2.8 l	10/98→08/05		M 112.922; 6x		5DA 193 175-991	Ignition	30
							Coil		
S 320 (220.065, 220.165)	165 kW	3.2 l	10/98→08/05		M 112.944; 6x		5DA 193 175-991	Ignition	30
							Coil		
S 350 (220.067, 220.167)	180 kW	3.7 l	09/02→08/05		M 112.972; 6x		5DA 193 175-991	Ignition	30
							Coil		
S 350 4-matic (220.087, 220.187)	180 kW	3.7 l	06/03→08/05		M 112.975; 6x		5DA 193 175-991	Ignition	30
							Coil		
S 430 (220.070, 220.170)	205 kW	4.3 l	10/98→08/05		M 113.941; 8x		5DA 193 175-991	Ignition	30
							Coil		
S 430 4-matic (220.083, 220.183)	205 kW	4.3 l	09/02→08/05		M 113.948; 8x		5DA 193 175-991	Ignition	30
							Coil		
S 500 (220.075, 220.175, 220.875)	225 kW	5 l	10/98→08/05		M 113.960; 8x		5DA 193 175-991	Ignition	30
							Coil		
S 500 4-matic (220.084, 220.184)	225 kW	5 l	09/02→08/05		M 113.966; 8x		5DA 193 175-991	Ignition	30
							Coil		
S 55 AMG (220.073, 220.173)	265 kW	5.5 l	04/99→08/05		M 113.986; 8x		5DA 193 175-991	Ignition	30
							Coil		
S 55 AMG Kompressor (220.074, 220.174)	368 kW	5.5 l	06/02→08/05		M 113.991; 8x		5DA 193 175-991	Ignition	30
							Coil		
MERCEDES-BENZ - SL (R107)							08/74→12/85		
280 SL (107.042)	130 kW	2.7 l	06/76→09/81				5DA 006 623-181	Switch	4
380 SL (107.045)	150 kW	3.8 l	09/80→08/85				Unit, ignition system		
380 SL (107.045)	160 kW	3.8 l	09/80→08/81						
500 SL (107.046)	170 kW	4.9 l	05/80→12/85						
500 SL (107.046)	177 kW	4.9 l	05/80→12/81						
280 SL (107.042)	136 kW	2.7 l	08/74→07/85	06/76→			5DA 006 623-181	Switch	4
							Unit, ignition system		

MERCEDES-BENZ - SL (R129)													08/93→10/01		
280 (129.058)	142 kW	2.8 l	08/93→10/01	3x		5DA 193 175-361	Ignition	11							
320 (129.063)	170 kW	3.2 l	09/93→10/01	Automatic Transmission; 3x		5DA 193 175-361	Ignition	11							
320 (129.064)	165 kW	3.2 l	05/98→10/01	M 112.943; 6x		5DA 193 175-991	Ignition	30							
500 (129.068)	225 kW	5 l	05/98→10/01	M 113.961; 8x		5DA 193 175-991	Ignition	30							
MERCEDES-BENZ - SL (R230)													10/01→01/12		
350 (230.467)	180 kW	3.7 l	03/03→01/12	M 112.973; 6x		5DA 193 175-991	Ignition	30							
500 (230.475)	225 kW	5 l	10/01→01/12	M 113.963; 8x		5DA 193 175-991	Ignition	30							
55 AMG (230.474)	350 kW	5.4 l	10/01→06/02	M 113.992; 8x		5DA 193 175-991	Ignition	30							
55 AMG Kompressor (230.474)	368 kW	5.5 l	06/02→01/12			5DA 193 175-991	Ignition	30							
MERCEDES-BENZ - SL Coupe (C107)													08/74→09/81		
280 SLC (107.022)	130 kW	2.7 l	06/76→09/81			5DA 006 623-181	Switch	4							
280 SLC (107.022)	136 kW	2.7 l	08/74→09/81	06/76→		5DA 006 623-181	Switch	4							
MERCEDES-BENZ - SLK (R170)													09/96→04/04		
200 (170.435)	100 kW	2 l	09/96→03/00	2x		5DA 193 175-361	Ignition	11							
200 Kompressor (170.445)	141 kW	2 l	10/96→03/00			5DA 193 175-361	Ignition	11							
230 Kompressor (170.447)	142 kW	2.3 l	09/96→03/00			5DA 193 175-361	Ignition	11							
320 (170.465)	160 kW	3.2 l	03/00→04/04	M 112.947; 6x		5DA 193 175-991	Ignition	30							
32 AMG Kompressor (170.466)	260 kW	3.2 l	03/01→04/04	M 112.960; 6x		5DA 193 175-991	Ignition	30							
MERCEDES-BENZ - SLK (R171)													03/04→02/11		
200 Kompressor (171.442)	120 kW	1.8 l	03/04→02/11	→engine 30099998; →08/07; 30405223		5DA 358 000-111	Ignition	32							
55 AMG (171.473)	265 kW	5.5 l	06/04→02/11	M 113.989; 8x		5DA 193 175-991	Ignition	30							
MERCEDES-BENZ - SLR (R199)													04/04→		
5.4 (199.376)	460 kW	5.4 l	04/04→	M 155.980; 8x		5DA 193 175-991	Ignition	30							
MERCEDES-BENZ - SPRINTER 2-t Box (901, 902)													02/95→05/06		
214	105 kW	2.3 l	02/95→05/06	2x		5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 2-t Bus (901, 902)													02/95→05/06		
214	105 kW	2.3 l	02/95→05/06	2x		5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 2-t Platform/Chassis (901, 902)													02/95→05/06		
214	105 kW	2.3 l	02/95→05/06	2x		5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 3-t Box (903)													02/95→05/06		
314	105 kW	2.3 l	02/95→05/06	2x		5DA 193 175-361	Ignition	11							
314 4x4	105 kW	2.3 l	08/02→05/06			5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 3-t Bus (903)													02/95→05/06		
314	105 kW	2.3 l	02/95→05/06	2x		5DA 193 175-361	Ignition	11							
314 4x4	105 kW	2.3 l	08/02→05/06			5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 3-t Platform/Chassis (903)													02/95→05/06		
314	105 kW	2.3 l	02/95→05/06	2x		5DA 193 175-361	Ignition	11							
314 4x4	105 kW	2.3 l	08/02→05/06			5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 4-t Box (904)													02/96→05/06		
414	105 kW	2.3 l	02/96→05/06	2x		5DA 193 175-361	Ignition	11							
414 4x4	105 kW	2.3 l	05/97→05/06			5DA 193 175-361	Ignition	11							
MERCEDES-BENZ - SPRINTER 4-t Bus (904)													02/96→05/06		
414	105 kW	2.3 l	02/96→05/06	2x		5DA 193 175-361	Ignition	11							

MERCEDES-BENZ - SPRINTER 4-t Platform/Chassis (904)										02/96→05/06			
414	105 kW	2.3 l	02/96→05/06	2x		5DA 193 175-361 Ignition						11	
414 4x4	105 kW	2.3 l	05/97→05/06			Coil							
MERCEDES-BENZ - T1 Box (601)										07/82→02/96			
210 2.3	70 kW	2.3 l	07/82→02/96		M 102.946	5DA 006 623-181 Switch						4	
						Unit, ignition system							
210 2.3	77 kW	2.3 l	05/89→02/96		→06/95	5DA 006 623-181 Switch						4	
						Unit, ignition system							
MERCEDES-BENZ - T1 Bus (601)										07/82→02/96			
210 2.3	70 kW	2.3 l	07/82→01/90			5DA 006 623-181 Switch						4	
						Unit, ignition system							
210 2.3	77 kW	2.3 l	05/89→02/96		→06/95	5DA 006 623-181 Switch						4	
						Unit, ignition system							
MERCEDES-BENZ - T1 Platform/Chassis (601)										04/77→10/89			
210 2.3	70 kW	2.3 l	04/77→10/89		08/82→	5DA 006 623-181 Switch						4	
						Unit, ignition system							
MERCEDES-BENZ - T2/LN1 Box Body / Estate										04/86→12/94			
510 (667.061, 667.062)	70 kW	2.3 l	04/86→12/94		M 102.946	5DA 006 623-181 Switch						4	
						Unit, ignition system							
510 (667.061, 667.062)	77 kW	2.3 l	04/86→12/94										
MERCEDES-BENZ - T2/LN1 Platform/Chassis										04/86→12/94			
510 (667.001, 667.002)	70 kW	2.3 l	04/86→12/94		M 102.946	5DA 006 623-181 Switch						4	
						Unit, ignition system							
510 (667.001, 667.002)	77 kW	2.3 l	04/86→12/94										
MERCEDES-BENZ - Vaneo (414)										02/02→07/05			
1.6 (414.700)	60 kW	1.6 l	02/02→07/05			5DA 358 000-191 Ignition						33	
						Coil							
1.6 (414.700)	75 kW	1.6 l	02/02→07/05										
1.9 (414.700)	92 kW	1.9 l	02/02→07/05										
MERCEDES-BENZ - V-CLASS (638/2)										10/96→07/03			
V 200 (638.214, 638.294)	95 kW	2 l	02/97→07/03	2x		5DA 193 175-361 Ignition						11	
						Coil							
V 230 (638.234, 638.294)	105 kW	2.3 l	10/96→07/03										
MERCEDES-BENZ - VIANO (W639)										09/03→			
3.0	140 kW	3.2 l	09/03→		M 112.951; 6x	5DA 193 175-991 Ignition						30	
						Coil							
3.2	160 kW	3.2 l	09/03→										
3.7	170 kW	3.7 l	06/04→		M 112.976; 6x	5DA 193 175-991 Ignition						30	
						Coil							
MERCEDES-BENZ - VITO / MIXTO Box (W639)										09/03→			
119	140 kW	3.2 l	09/03→		M 112.951; 6x	5DA 193 175-991 Ignition						30	
						Coil							
122	160 kW	3.2 l	09/03→										
MERCEDES-BENZ - VITO Box (638)										03/97→07/03			
113 2.0 (638.014, 638.094)	95 kW	2 l	03/97→07/03	2x		5DA 193 175-361 Ignition						11	
						Coil							
114 2.3 (638.034, 638.094)	105 kW	2.3 l	03/97→07/03										
MERCEDES-BENZ - VITO Bus (638)										02/96→07/03			
113 2.0 (638.114, 638.194)	95 kW	2 l	02/96→07/03	2x		5DA 193 175-361 Ignition						11	
						Coil							
114 2.3 (638.134, 638.194)	105 kW	2.3 l	12/96→07/03										
MERCEDES-BENZ - VITO Bus (W639)										09/03→			
119	140 kW	3 l	09/03→		M 112.951; 6x	5DA 193 175-991 Ignition						30	
						Coil							
122	160 kW	3.2 l	09/03→										
123	170 kW	3.7 l	06/04→		M 112.976; 6x	5DA 193 175-991 Ignition						30	
						Coil							

MG - MGF (RD)						03/95→03/02
1.6	82 kW	1.6 l	02/00→03/02	16 K4F	5DA 193 175-891 Ignition Coil	27
1.8 i 16V	88 kW	1.8 l	03/95→03/02	18 K4F; 522573→; Model 2000→	5DA 193 175-891 Ignition Coil	27
1.8 i VVC	107 kW	1.8 l	03/95→03/02	18 K4K	5DA 193 175-371 Ignition Coil	12
MG - MG TF						03/02→12/09
115	85 kW	1.6 l	03/02→12/09	16 K4F	5DA 193 175-891 Ignition Coil	27
120 135	88 kW 100 kW	1.8 l 1.8 l	03/02→12/09 03/02→12/09	18 K4F; 522573→	5DA 193 175-891 Ignition Coil	27
MG - MG ZR						06/01→04/05
105	76 kW	1.4 l	06/01→04/05	14 K4F; 471656→	5DA 193 175-891 Ignition Coil	27
120	86 kW	1.8 l	06/01→04/05	18 K4F; 471064→	5DA 193 175-891 Ignition Coil	27
MG - MG ZS Hatchback						07/01→10/05
120	86 kW	1.8 l	07/01→10/05	18 K4F	5DA 193 175-721 Ignition Coil	21
				18 K4F; 471064→	5DA 193 175-891 Ignition Coil	27
MG - MG ZS Saloon						07/01→04/05
120	86 kW	1.8 l	07/01→04/05	18 K4F	5DA 193 175-721 Ignition Coil	21
				18 K4F; 471064→	5DA 193 175-891 Ignition Coil	27
180	130 kW	2.5 l	07/01→04/05	Bremi	5DA 193 175-551 Ignition Coil	17
MG - MG ZT Saloon						01/03→07/05
1.8 16V	88 kW	1.8 l	01/03→07/05	18 K4F	5DA 193 175-891 Ignition Coil	27
MG - MG ZT- T						01/03→07/05
1.8 16V	88 kW	1.8 l	01/03→07/05	18 K4F	5DA 193 175-891 Ignition Coil	27

MINI - MINI (R56)						10/06→11/13
Cooper	85 kW	1.6 l	03/10→11/13	⊗ N16 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper	90 kW	1.6 l	09/09→11/13		Coil	
One	55 kW	1.6 l	03/10→11/13			
One	72 kW	1.6 l	03/10→11/13			
Cooper	88 kW	1.6 l	10/06→02/12	⊗ N12 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
Cooper S	120 kW	1.6 l	03/10→11/13	⊗ N18 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	135 kW	1.6 l	03/10→11/13		Coil	
Cooper S	147 kW	1.6 l	01/12→11/13			
Cooper S	128 kW	1.6 l	10/06→01/11	⊗ N14 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
John Cooper Works	155 kW	1.6 l	03/08→11/13	⊗ N14 B16 C; 4x	5DA 193 175-491 Ignition	15
					Coil	
John Cooper Works GP	160 kW	1.6 l	09/12→11/13	⊗ N18 B16 B; 4x	5DA 193 175-491 Ignition	15
					Coil	
One	55 kW	1.4 l	03/09→03/10	⊗ N12 B14 A; 4x	5DA 193 175-491 Ignition	15
One	70 kW	1.4 l	11/06→03/10		Coil	
MINI - MINI CLUBMAN Estate (R55)						10/07→12/13
Cooper	85 kW	1.6 l	03/10→	⊗ N16 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper	90 kW	1.6 l	03/10→		Coil	
Cooper	88 kW	1.6 l	10/07→12/13	⊗ N12 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
Cooper S	120 kW	1.6 l	10/07→02/10	⊗ N14 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	128 kW	1.6 l	10/07→02/10		Coil	
Cooper S	135 kW	1.6 l	03/10→	⊗ N18 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	147 kW	1.6 l	03/10→		Coil	
John Cooper Works	155 kW	1.6 l	03/08→08/12	⊗ N14 B16 C; 4x	5DA 193 175-491 Ignition	15
					Coil	
One	70 kW	1.4 l	03/09→02/10	⊗ N12 B14 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
One	72 kW	1.6 l	03/10→	4x	5DA 193 175-491 Ignition	15
					Coil	
MINI - MINI Convertible (R57)						03/08→
Cooper	85 kW	1.6 l	03/09→	⊗ N16 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper	90 kW	1.6 l	03/10→		Coil	
One	72 kW	1.6 l	03/10→			
Cooper	88 kW	1.6 l	03/09→	⊗ N12 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
Cooper S	128 kW	1.6 l	03/09→	⊗ N14 B16 A; 4x	5DA 193 175-491 Ignition	15
					Coil	
Cooper S	135 kW	1.6 l	03/10→	⊗ N18 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	147 kW	1.6 l	03/10→		Coil	
John Cooper Works	155 kW	1.6 l	03/08→	⊗ N14 B16 C; 4x	5DA 193 175-491 Ignition	15
					Coil	
MINI - MINI COUNTRYMAN (R60)						06/10→
Cooper	85 kW	1.6 l	06/10→	⊗ N16 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper	90 kW	1.6 l	06/10→		Coil	
Cooper S	135 kW	1.6 l	06/10→	⊗ N18 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	147 kW	1.6 l	02/12→		Coil	
Cooper S ALL4	120 kW	1.6 l	06/10→			
Cooper S ALL4	135 kW	1.6 l	06/10→			
Cooper S JCW	160 kW	1.6 l	09/12→			
One	72 kW	1.6 l	06/10→	4x	5DA 193 175-491 Ignition	15
					Coil	
MINI - MINI Coupe (R58)						09/11→
Cooper	85 kW	1.6 l	09/11→	⊗ N16 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper	90 kW	1.6 l	09/11→		Coil	
Cooper S	120 kW	1.6 l	09/11→	⊗ N18 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	135 kW	1.6 l	09/11→		Coil	
Cooper S	147 kW	1.6 l	09/11→			
John Cooper Works	155 kW	1.6 l	09/11→	⊗ N14 B16 C; 4x	5DA 193 175-491 Ignition	15
					Coil	
MINI - MINI Roadster (R59)						02/12→
Cooper	85 kW	1.6 l	02/12→	⊗ N16 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper	90 kW	1.6 l	02/12→		Coil	
Cooper S	120 kW	1.6 l	02/12→	⊗ N18 B16 A; 4x	5DA 193 175-491 Ignition	15
Cooper S	135 kW	1.6 l	02/12→		Coil	
Cooper S	147 kW	1.6 l	02/12→			

MINI - MINI Roadster (R59)							02/12 →
John Cooper Works	155 kW	1.6 l	02/12 →	N14 B16 C; 4x	5DA 193 175-491 Ignition Coil	15	



				13	i	412		
MITSUBISHI - COLT III (C5_A)								04/88→05/92
1.3 (C51A)	51 kW	1.3 l	04/88→05/92	01/89→			5DA 006 623-511 Switch	7
1.3 GL (C61A)	44 kW	1.3 l	04/88→12/90				Unit, ignition system	
1.5 GLXi (C52A)	62 kW	1.5 l	04/88→05/92					
1.6 GTi 16V (C53A)	91 kW	1.6 l	04/88→05/90					
1.3 12V (C51A)	55 kW	1.3 l	04/88→05/92				5DA 006 623-511 Switch	7
1.5 (C52A) CAT	66 kW	1.5 l	07/90→05/92				Unit, ignition system	
1.8 GTi 16V (C58A) CAT	100 kW	1.8 l	06/90→05/92					
MITSUBISHI - COLT IV (CA_A)								04/92→04/96
1.3 GLi 12V (CA1A)	55 kW	1.3 l	04/92→04/96				5DA 006 623-511 Switch	7
1.6 (CA4A)	66 kW	1.6 l	02/94→04/96				Unit, ignition system	
1.6 GLXi 16V (CA4A)	83 kW	1.6 l	04/92→04/96					
1.8 GTi 16V (CA5A)	103 kW	1.8 l	04/92→04/96					
MITSUBISHI - GALANT IV (E3_A)								11/88→12/92
1.8 (E32A)	66 kW	1.8 l	11/88→10/92	01/89→			5DA 006 623-511 Switch	7
2.0 GTi 16V (E39A, E38A, E33A)	106 kW	2 l	11/88→10/92				Unit, ignition system	
2.0 GTi 16V (E39A, E38A, E33A)	107 kW	2 l	11/88→10/92					
2.0 (E39A, E38A, E33A)	80 kW	2 l	04/89→10/92				5DA 006 623-511 Switch	7
2.0 4WD (E33A, E38A, E39A)	80 kW	2 l	04/89→10/92				Unit, ignition system	
2.0 GTi 16V 4x4 (E38A, E39A, E33A)	106 kW	2 l	07/89→12/92					
MITSUBISHI - GALANT IV Saloon (E3_A)								11/87→10/92
1.8 (E32A)	63 kW	1.8 l	11/87→08/90	01/89→			5DA 006 623-511 Switch	7
1.8 (E32A)	66 kW	1.8 l	11/87→10/92				Unit, ignition system	
2.0 (E39A, E38A, E33A)	80 kW	2 l	11/87→10/92					
2.0 4WD (E39A, E38A, E33A)	80 kW	2 l	12/88→10/92					
2.0 GTi 16V (E39A, E38A, E33A)	106 kW	2 l	11/87→10/92					
2.0 GTi 16V 4WD (E39A, E38A, E33A)	106 kW	2 l	06/88→10/92					
2.0 GTi 16V 4WD (E38A, E39A, E33A) CAT	110 kW	2 l	09/91→10/92				5DA 006 623-511 Switch	7
MITSUBISHI - GALANT V (E5_A, E7_A, E8_A)								11/92→08/96
1.8 (E52A)	85 kW	1.8 l	02/94→08/96				5DA 006 623-511 Switch	7
1.8 GLSi (E52A)	93 kW	1.8 l	11/92→08/96				Unit, ignition system	
2.0 GLSi (E55A)	101 kW	2 l	11/92→08/96					
2.0 GLSi 4WD (E75A)	101 kW	2 l	11/92→08/96					
2.0 V6-24 (E64A, E54A)	110 kW	2 l	11/92→08/96					
2.5 V6-24 4WD (E88A)	125 kW	2.5 l	11/92→08/96					
MITSUBISHI - GALANT V Saloon (E5_A, E7_A, E8_A)								11/92→08/96
1.8 (E52A)	85 kW	1.8 l	02/94→08/96				5DA 006 623-511 Switch	7
1.8 GLSi (E52A)	93 kW	1.8 l	11/92→08/96				Unit, ignition system	
2.0 GLSi (E55A)	101 kW	2 l	11/92→08/96					
2.0 GLSi 4WD (E75A)	101 kW	2 l	11/92→08/96					
2.0 V6-24 (E64A, E54A)	110 kW	2 l	11/92→08/96					
2.5 V6-24 4WD (E88A)	125 kW	2.5 l	11/92→08/96					
MITSUBISHI - GALANT VI Estate (EA_)								09/96→10/03
2.0 (EA2W)	100 kW	2 l	09/96→09/00				5DA 006 623-511 Switch	7
2.4 GDI (EA3W)	110 kW	2.4 l	02/99→10/03				Unit, ignition system	
2.5 V6 24V (EA5W)	120 kW	2.5 l	09/96→09/00					
MITSUBISHI - GALANT VI Saloon (EA_)								09/96→09/00
2.0 (EA2A)	100 kW	2 l	09/96→09/00				5DA 006 623-511 Switch	7
2.4 GDI (EA3A)	110 kW	2.4 l	02/99→09/00				Unit, ignition system	
2.5 V6 24V (EA5A)	120 kW	2.5 l	09/96→09/00					
MITSUBISHI - LANCER III Station Wagon (C1_V, C3_V)								09/85→06/92
1.5 (C12V)	51 kW	1.5 l	09/85→08/89	01/89→			5DA 006 623-511 Switch	7
1.5 (C12V)	61 kW	1.5 l	09/88→12/90				Unit, ignition system	
1.8 4WD (C37V)	61 kW	1.8 l	01/87→08/89					
1.5 12V (C12V)	66 kW	1.5 l	09/90→12/91				5DA 006 623-511 Switch	7
1.8 4WD (C37V)	63 kW	1.8 l	03/89→12/90				Unit, ignition system	
1.8 4WD (C37V)	69 kW	1.8 l	08/90→06/92					
MITSUBISHI - LANCER IV (C6_A, C7_A)								05/89→05/94
1.3 12V (C61A)	55 kW	1.3 l	06/92→05/94				5DA 006 623-511 Switch	7
1.5 12V (C62A)	66 kW	1.5 l	05/89→05/92				Unit, ignition system	
1.6 16V (C76A, C66A)	83 kW	1.6 l	06/92→05/94					
1.8 4WD (C77A)	71 kW	1.8 l	09/89→06/92					
1.8 GTi 16V (C68A)	100 kW	1.8 l	11/89→05/92					
1.8 GTi 16V (C69A)	103 kW	1.8 l	06/92→12/93					

				13	i	412	
MITSUBISHI - LANCER IV Saloon (C6_A)							04/88→06/92
1.3 (C61A)	44 kW	1.3 l	04/88→05/92	01/89→		5DA 006 623-511 Switch	7
1.3 (C61A)	51 kW	1.3 l	08/88→05/92			Unit, ignition system	
1.5 (C62A)	62 kW	1.5 l	04/88→05/92				
1.3 12V (C61A)	55 kW	1.3 l	07/90→06/92			5DA 006 623-511 Switch	7
						Unit, ignition system	
MITSUBISHI - LANCER V Saloon (CB/D_A, CC)							06/92→12/96
1.3 (CB1A)	55 kW	1.3 l	06/92→12/96			5DA 006 623-511 Switch	7
1.6 (CB4A)	66 kW	1.6 l	02/94→12/96			Unit, ignition system	
1.6 16V (CB4A)	83 kW	1.6 l	06/92→12/96				
1.6 16V 4WD (CD4A)	83 kW	1.6 l	06/92→12/96				
MITSUBISHI - LANCER VI Saloon (CJ-CP_)							12/95→08/03
1.3 12V (CK1A)	55 kW	1.3 l	12/95→08/03			5DA 006 623-511 Switch	7
1.5 16V (CK2A)	69 kW	1.5 l	12/95→08/03			Unit, ignition system	
1.6 16V (CK4A)	66 kW	1.6 l	12/95→08/03				
2.0 16V EVO	206 kW	2 l	08/98→08/01				
MITSUBISHI - LIBERO V Estate (CB_W, CD_W, CC, CE)							12/92→10/03
1.6 16V (CB4W)	83 kW	1.6 l	12/92→10/03			5DA 006 623-511 Switch	7
1.6 16V 4WD (CD4W)	83 kW	1.6 l	12/92→10/03			Unit, ignition system	
MITSUBISHI - MIRAGE V (CJ_, CP_)							11/95→09/03
1300 GL,GLX (CJ1A)	55 kW	1.3 l	05/96→09/00			5DA 006 623-511 Switch	7
1500 (CJ2A)	69 kW	1.5 l	11/95→09/03			Unit, ignition system	
1600 GLX (CJ4A)	66 kW	1.6 l	05/96→09/00				

										13		412	
NISSAN - 350 Z (Z33)													09/02 →
3.5		206 kW	3.5 l	10/03→			VQ35DE; →01/07		5DA 749 475-971	Ignition	41		
3.5		221 kW	3.5 l	09/02→						Coil			
NISSAN - 350 Z Roadster (Z33)													03/05 →
3.5		206 kW	3.5 l	03/05→			VQ35DE; →01/07		5DA 749 475-971	Ignition	41		
3.5		221 kW	3.5 l	04/06→						Coil			
NISSAN - ALMERA TINO (V10)													08/00 →
1.8		84 kW	1.8 l	08/00→			QG18DE; 07/02→		5DA 193 175-681	Ignition	20		
							QG18DE; →11/00		5DA 193 175-841	Ignition	25		
										Coil			
1.8		85 kW	1.8 l	12/02→			QG18DE		5DA 193 175-681	Ignition	20		
										Coil			
NISSAN - CUBE (Z12)													03/10 →
1.6 16V		81 kW	1.6 l	03/10→			HR16DE; 4		5DA 193 175-851	Ignition	25		
										Coil			
NISSAN - DUALIS (J10, JJ10)													02/07 →
1.6		84 kW	1.6 l	02/07→			HR16DE; Euro 5; 4		5DA 193 175-851	Ignition	25		
1.6		86 kW	1.6 l	11/10→						Coil			
2.0		104 kW	2 l	02/07→			MR20DE; 4		5DA 193 175-851	Ignition	25		
2.0 All-wheel Drive		104 kW	2 l	02/07→						Coil			
NISSAN - JUKE (F15)													06/10 →
1.6		69 kW	1.6 l	01/13→			HR16DE; 4		5DA 193 175-851	Ignition	25		
1.6		86 kW	1.6 l	06/10→						Coil			
NISSAN - KUBISTAR (X76)													08/03 → 10/09
1.2		44 kW	1.2 l	08/03→10/09			D7F 726/744/764		5DA 193 175-391	Ignition	12		
										Coil			
NISSAN - KUBISTAR Box (X80)													04/06 →
1.2 16V		55 kW	1.2 l	04/06→			D4F 712		5DA 193 175-831	Ignition	25		
										Coil			
NISSAN - MICRA IV (K13)													05/10 →
1.2		59 kW	1.2 l	05/10→			HR12DE; 3		5DA 193 175-851	Ignition	25		
										Coil			
NISSAN - MURANO (Z50)													08/03 →
3.5 4x4		172 kW	3.5 l	08/03→			VQ35DE		5DA 749 475-961	Ignition	40		
										Coil			
NISSAN - NOTE (E11)													03/06 →
1.6		81 kW	1.6 l	03/06→			HR16DE; Euro 5; 4		5DA 193 175-851	Ignition	25		
										Coil			
NISSAN - NOTE (E12)													06/13 →
1.2		59 kW	1.2 l	06/13→			HR12DE; 3		5DA 193 175-851	Ignition	25		
										Coil			
NISSAN - NV200 Box													02/10 →
1.6 16V (M20, M20M)		81 kW	1.6 l	02/10→			HR16DE; 4		5DA 193 175-851	Ignition	25		
										Coil			
NISSAN - NV200 EVALIA													07/10 →
1.6 16V (M20, M20M)		81 kW	1.6 l	07/10→			HR16DE; 4		5DA 193 175-851	Ignition	25		
										Coil			
NISSAN - PATHFINDER (R50)													11/00 → 12/04
3.5 V6 4WD		162 kW	3.5 l	11/00→12/04			VQ35		5DA 749 475-961	Ignition	40		
										Coil			
NISSAN - PATHFINDER (R51)													09/05 →
4.0 4WD		198 kW	4 l	09/05→			VQ40DE		5DA 749 475-961	Ignition	40		
										Coil			
NISSAN - PRIMERA (P11)													08/99 → 12/01
1.8 16V		84 kW	1.8 l	08/99→12/01			QG18DE; →09/00		5DA 193 175-841	Ignition	25		
										Coil			

NISSAN - PRIMERA (P12)							01/02→
1.6	78 kW	1.6 l	03/02→	QG16DE; 07/02→	5DA 193 175-681 Ignition Coil	20	
1.6	80 kW	1.6 l	01/02→				
1.8	85 kW	1.8 l	03/02→	QG18DE; 07/02→	5DA 193 175-681 Ignition Coil	20	
2.0	103 kW	2 l	03/02→	QR20DE	5DA 749 475-951 Ignition Coil	40	
NISSAN - PRIMERA Estate (WP12)							03/02→
2.0	103 kW	2 l	03/02→	QR20DE	5DA 749 475-951 Ignition Coil	40	
NISSAN - PRIMERA Hatchback (P11)							08/99→07/02
1.8 16V	84 kW	1.8 l	08/99→07/02	QG18DE; →09/00	5DA 193 175-841 Ignition Coil	25	
NISSAN - PRIMERA Hatchback (P12)							07/02→
1.6	78 kW	1.6 l	07/02→	QG16DE	5DA 193 175-681 Ignition Coil	20	
1.6	80 kW	1.6 l	07/02→				
1.8	85 kW	1.8 l	07/02→	QG18DE	5DA 193 175-681 Ignition Coil	20	
2.0	103 kW	2 l	07/02→	QR20DE	5DA 749 475-951 Ignition Coil	40	
NISSAN - PRIMERA Traveller (WP11)							08/99→12/01
1.8 16V	84 kW	1.8 l	08/99→12/01	QG18DE; →09/00	5DA 193 175-841 Ignition Coil	25	
NISSAN - PULSAR VII Hatchback (N16)							01/00→
1.5	66 kW	1.5 l	03/00→	QG15DE; 07/02→	5DA 193 175-681 Ignition Coil	20	
				QG15DE; 04/00→03/01; Japan-made	5DA 193 175-841 Ignition Coil	25	
				QG15DE; →10/00; UK-made			
1.5	72 kW	1.5 l	10/02→	QG15DE	5DA 193 175-681 Ignition Coil	20	
1.8	84 kW	1.8 l	01/00→	QG18DE; 07/02→	5DA 193 175-681 Ignition Coil	20	
				QG18DE; 04/00→03/01; Japan-made	5DA 193 175-841 Ignition Coil	25	
				QG18DE; →10/00; UK-made			
1.8	85 kW	1.8 l	10/02→	QG18DE	5DA 193 175-681 Ignition Coil	20	
NISSAN - PULSAR VII Saloon (N16)							07/00→
1.5	66 kW	1.5 l	07/00→	QG15DE; 07/02→	5DA 193 175-681 Ignition Coil	20	
				QG15DE; →03/01; Japan-made	5DA 193 175-841 Ignition Coil	25	
				QG15DE; →10/00; UK-made			
1.5	72 kW	1.5 l	10/02→	QG15DE	5DA 193 175-681 Ignition Coil	20	
1.8	84 kW	1.8 l	07/00→	QG18DE; 07/02→	5DA 193 175-681 Ignition Coil	20	
				QG18DE; →03/01; Japan-made	5DA 193 175-841 Ignition Coil	25	
				QG18DE; →10/00; UK-made			
1.8	85 kW	1.8 l	10/02→	QG18DE	5DA 193 175-681 Ignition Coil	20	
NISSAN - TIIDA Hatchback (C11X)							09/07→
1.6	81 kW	1.6 l	09/07→	HR16DE; 4; 03/10→	5DA 193 175-851 Ignition Coil	25	
NISSAN - TIIDA Saloon (SC11X)							09/07→
1.6	81 kW	1.6 l	09/07→	HR16DE; 03/10→; 4	5DA 193 175-851 Ignition Coil	25	
NISSAN - X-TRAIL (T30)							07/01→
2.0	103 kW	2 l	07/01→	QR20DE; 12/01→	5DA 749 475-951 Ignition Coil	40	
2.0 4x4	103 kW	2 l	07/01→				
2.5 4x4	121 kW	2.5 l	09/02→	QR25DE	5DA 749 475-951 Ignition Coil	40	
NISSAN - X-TRAIL (T31)							06/07→
2.5 4x4	124 kW	2.5 l	06/07→	QR25DE; 4	5DA 193 175-851 Ignition Coil	25	

OPEL - ADAM				10/12→
1.2	51 kW	1.2 l	10/12→	5DA 358 000-341 Ignition Coil 35
1.4	64 kW	1.4 l	10/12→	
1.4	74 kW	1.4 l	10/12→	
1.4 LPG	64 kW	1.4 l	07/13→	
OPEL - AGILA (A) (H00)				09/00→12/07
1.0	44 kW	1 l	08/03→12/07	5DA 358 000-351 Ignition Coil 36
1.0 12V	43 kW	1 l	09/00→12/07	Z 10 XE 5DA 193 175-471 Ignition Coil 15
1.2 16V	55 kW	1.2 l	09/00→12/07	5DA 358 000-201 Ignition Coil 33
1.2 16V Twinport	59 kW	1.2 l	07/04→12/07	Z 12 XEP; Bosch 5DA 193 175-861 Ignition Coil 26
OPEL - AMPERA				11/11→
EV 150	111 kW		11/11→	5DA 358 000-341 Ignition Coil 35
OPEL - ANTARA				12/10→
2.4	123 kW	2.4 l	12/10→	5DA 358 000-121 Ignition Coil 33
2.4 4x4	123 kW	2.4 l	12/10→	
OPEL - ASCONA C (81_, 86_, 87_, 88_)				09/81→08/88
1.6	55 kW	1.6 l	09/81→09/87	5DA 006 623-931 Switch Unit, ignition system 8
1.6 S	66 kW	1.6 l	09/81→08/86	
1.6 i	55 kW	1.6 l	09/87→08/88	5DA 006 623-581 Switch Unit, ignition system 7
1.6 i CAT	55 kW	1.6 l	09/86→08/88	
OPEL - ASCONA C Hatchback (84_, 89_)				09/81→08/88
1.6	55 kW	1.6 l	09/81→08/88	5DA 006 623-931 Switch Unit, ignition system 8
1.6 S	66 kW	1.6 l	09/81→08/86	
1.6 i	55 kW	1.6 l	09/87→08/88	5DA 006 623-581 Switch Unit, ignition system 7
1.6 i CAT	55 kW	1.6 l	09/86→08/88	
OPEL - ASTRA F (56_, 57_)				09/91→09/98
1.4 i	44 kW	1.4 l	09/91→09/98	+ servo 5DA 006 623-251 Switch Unit, ignition system 5
				C 14 NZ 5DA 193 175-651 Ignition Coil 19
1.4 i 16V	66 kW	1.4 l	02/96→09/98	X 14 XE 5DA 193 175-651 Ignition Coil 19
1.4 Si	60 kW	1.4 l	03/92→09/98	→engine 02T14052; + servo 5DA 006 623-251 Switch Unit, ignition system 5
				C 14 SE; engine 02T14053→ 5DA 193 175-651 Ignition Coil 19
1.6 i	52 kW	1.6 l	05/93→07/96	X 16 SZ 5DA 193 175-651 Ignition Coil 19
1.6 i	55 kW	1.6 l	03/92→09/98	5DA 006 623-581 Switch Unit, ignition system 7
				C 16 NZ 5DA 193 175-651 Ignition Coil 19
1.6 i 16V	74 kW	1.6 l	08/94→09/98	5DA 193 175-651 Ignition Coil 19
1.6 Si	74 kW	1.6 l	05/92→12/94	C 16 SE 5DA 193 175-651 Ignition Coil 19
1.8 i	66 kW	1.8 l	03/92→09/98	+ servo 5DA 006 623-251 Switch Unit, ignition system 5
1.8 i 16V	85 kW	1.8 l	11/94→09/98	5DA 358 000-291 Ignition Coil 35
1.8 i 16V	85 kW	1.8 l	09/95→08/97	
2.0 i 16V	100 kW	2 l	02/95→09/98	
OPEL - ASTRA F Convertible (53_B)				03/93→03/01
1.4 i 16V	66 kW	1.4 l	01/96→03/01	X 14 XE 5DA 193 175-651 Ignition Coil 19
1.4 Si	60 kW	1.4 l	05/93→03/01	→engine 02T14052; + servo 5DA 006 623-251 Switch Unit, ignition system 5
				C 14 SE; engine 02T14053→ 5DA 193 175-651 Ignition Coil 19
1.6 i	52 kW	1.6 l	03/93→08/96	X 16 SZ 5DA 193 175-651 Ignition Coil 19
1.6 i	55 kW	1.6 l	01/96→03/01	X 16 SZR 5DA 193 175-651 Ignition Coil 19

OPEL - ASTRA F Convertible (53_B)						03/93→03/01
1.8 i 16V	85 kW	1.8 l	11/94→03/01		5DA 358 000-291 Ignition Coil	35
OPEL - ASTRA F Estate (51_, 52_)						09/91→01/98
1.4 i	44 kW	1.4 l	09/91→01/98	+ servo	5DA 006 623-251 Switch Unit, ignition system	5
				C 14 NZ	5DA 193 175-651 Ignition Coil	19
1.4 i 16V	66 kW	1.4 l	02/96→01/98	X 14 XE	5DA 193 175-651 Ignition Coil	19
1.4 Si	60 kW	1.4 l	03/92→01/98	→engine 02T14052; + servo	5DA 006 623-251 Switch Unit, ignition system	5
				C 14 SE; engine 02T14053→	5DA 193 175-651 Ignition Coil	19
1.6 i	52 kW	1.6 l	05/93→07/96	X 16 SZ	5DA 193 175-651 Ignition Coil	19
1.6 i	55 kW	1.6 l	09/91→01/98		5DA 006 623-581 Switch Unit, ignition system	7
				C 16 NZ / X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6 i 16V	74 kW	1.6 l	08/94→01/98	X 16 XEL	5DA 193 175-651 Ignition Coil	19
1.6 Si	74 kW	1.6 l	03/92→12/94	C 16 SE	5DA 193 175-651 Ignition Coil	19
1.8 i	66 kW	1.8 l	09/91→01/98	+ servo	5DA 006 623-251 Switch Unit, ignition system	5
1.8 i 16V	85 kW	1.8 l	07/94→01/98		5DA 358 000-291 Ignition Coil	35
2.0 i 16V	100 kW	2 l	02/95→01/98			
2.0 i 16V	110 kW	2 l	03/93→01/98		5DA 006 623-601 Switch Unit, ignition system	8
				C 20 XE; engine 14137013→	5DA 193 175-351 Ignition Coil	11
OPEL - ASTRA F Hatchback (53_, 54_, 58_, 59_)						09/91→01/98
1.4 i	44 kW	1.4 l	03/92→01/98	+ servo	5DA 006 623-251 Switch Unit, ignition system	5
				C 14 NZ	5DA 193 175-651 Ignition Coil	19
1.4 i 16V	66 kW	1.4 l	01/96→01/98	X 14 XE	5DA 193 175-651 Ignition Coil	19
1.4 Si	60 kW	1.4 l	03/92→01/98	→engine 02T14052; + servo	5DA 006 623-251 Switch Unit, ignition system	5
				C 14 SE; engine 02T14053→	5DA 193 175-651 Ignition Coil	19
1.6 i	52 kW	1.6 l	05/93→07/96	X 16 SZ	5DA 193 175-651 Ignition Coil	19
1.6 i	55 kW	1.6 l	09/91→01/98		5DA 006 623-581 Switch Unit, ignition system	7
				C 16 NZ / X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6 i 16V	74 kW	1.6 l	08/94→01/98	X 16 XEL	5DA 193 175-651 Ignition Coil	19
1.6 Si	74 kW	1.6 l	03/92→12/94	C 16 SE	5DA 193 175-651 Ignition Coil	19
1.8 i	66 kW	1.8 l	09/91→01/98	+ servo	5DA 006 623-251 Switch Unit, ignition system	5
1.8 i 16V	85 kW	1.8 l	09/94→01/98		5DA 358 000-291 Ignition Coil	35
2.0 i 16V	100 kW	2 l	02/95→01/98			
2.0 GSI 16V	110 kW	2 l	09/91→01/98	C 20 XE; engine 14137013→	5DA 193 175-351 Ignition Coil	11
OPEL - ASTRA F Van (55_)						10/91→01/99
1.4 i	44 kW	1.4 l	10/91→01/99	+ servo	5DA 006 623-251 Switch Unit, ignition system	5
				C 14 NZ	5DA 193 175-651 Ignition Coil	19
1.6 i	52 kW	1.6 l	02/93→07/96	X 16 SZ	5DA 193 175-651 Ignition Coil	19
1.6 i	55 kW	1.6 l	10/91→04/93		5DA 006 623-581 Switch Unit, ignition system	7
				C 16 NZ	5DA 193 175-651 Ignition Coil	19

OPEL - ASTRA G Box (F70)						01/99→04/05
1.6	55 kW	1.6 l	01/99→09/00	X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6	62 kW	1.6 l	09/00→04/05	Z 16 SE	5DA 193 175-561 Ignition Coil	18
OPEL - ASTRA G Convertible (F67)						03/01→10/05
1.6	76 kW	1.6 l	01/03→10/05	Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	92 kW	1.8 l	03/01→10/05	Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 16V Turbo	147 kW	2 l	11/02→10/05		5DA 358 000-331 Ignition	35
2.0 OPC	141 kW	2 l	03/02→10/05		Coil	
OPEL - ASTRA G Coupe (F07_)						03/00→05/05
1.6 16V	76 kW	1.6 l	03/00→05/05	Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	85 kW	1.8 l	03/00→10/00	X 18 XE1	5DA 358 000-041 Ignition Coil	31
1.8 16V	92 kW	1.8 l	09/00→05/05	Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 16V Turbo	140 kW	2 l	09/00→08/01		5DA 358 000-331 Ignition	35
2.0 16V Turbo	141 kW	2 l	08/01→05/05		Coil	
2.0 16V Turbo	147 kW	2 l	11/02→05/05			
OPEL - ASTRA G Estate (F35_)						02/98→12/09
1.2 16V	48 kW	1.2 l	02/98→09/00		5DA 358 000-201 Ignition Coil	33
1.2 16V	55 kW	1.2 l	09/00→07/04	Z 12 XE; 42000001→ / 45000001→ / 46000001→ / 48000001→	5DA 193 175-861 Ignition Coil	26
				→32999999 / →35999999 / →36999999 / →38999999 / →3H / →3G	5DA 358 000-201 Ignition Coil	33
1.4	66 kW	1.4 l	09/07→12/09	Z 14 XEP	5DA 193 175-861 Ignition Coil	26
1.6	55 kW	1.6 l	02/98→09/00	X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6	62 kW	1.6 l	09/00→07/04	Z 16 SE	5DA 193 175-561 Ignition Coil	18
1.6	76 kW	1.6 l	12/02→07/09	Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	85 kW	1.8 l	02/98→09/00	X 18 XE1	5DA 358 000-041 Ignition Coil	31
1.8 16V	92 kW	1.8 l	09/00→07/04	Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 16V	100 kW	2 l	02/98→07/04		5DA 358 000-291 Ignition Coil	35
2.0 OPC	141 kW	2 l	09/02→07/04		5DA 358 000-331 Ignition	35
2.0 OPC	147 kW	2 l	11/02→07/04		Coil	
OPEL - ASTRA G Hatchback (F48_, F08_)						02/98→12/09
1.2 16V	48 kW	1.2 l	02/98→09/00		5DA 358 000-201 Ignition Coil	33
1.2 16V	55 kW	1.2 l	09/00→01/05	Z 12 XE; 42000001→ / 45000001→ / 46000001→ / 48000001→	5DA 193 175-861 Ignition Coil	26
				→32999999 / →35999999 / →36999999 / →38999999 / →3H / →3G	5DA 358 000-201 Ignition Coil	33
1.4	66 kW	1.4 l	09/07→12/09	Z 14 XEP	5DA 193 175-861 Ignition Coil	26
1.6	55 kW	1.6 l	02/98→09/00	X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6	62 kW	1.6 l	09/00→01/05	Z 16 SE	5DA 193 175-561 Ignition Coil	18
1.6	76 kW	1.6 l	12/02→12/09	Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	85 kW	1.8 l	02/98→09/00	X 18 XE1	5DA 358 000-041 Ignition Coil	31
1.8 16V	92 kW	1.8 l	09/00→01/05	Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 16V	100 kW	2 l	02/98→01/05	X 20 XEV	5DA 358 000-291 Ignition Coil	35
2.0 16V OPC	118 kW	2 l	11/99→09/02		5DA 358 000-291 Ignition Coil	35
2.0 OPC	141 kW	2 l	09/02→01/05		5DA 358 000-331 Ignition	35
2.0 OPC	147 kW	2 l	11/02→01/05		Coil	

OPEL - ASTRA G Saloon (F69_)						09/98→12/09
1.2 16V	48 kW	1.2 l	09/98→09/00		5DA 358 000-201 Ignition Coil	33
1.2 16V	55 kW	1.2 l	09/00→01/05	⊗ Z 12 XE; 42000001→ / 45000001→ / 46000001→ / 48000001→	5DA 193 175-861 Ignition Coil	26
				→32999999 / →35999999 / →36999999 / →38999999 / →3H / →3G	5DA 358 000-201 Ignition Coil	33
1.4	66 kW	1.4 l	09/07→12/09	⊗ Z 14 XEP	5DA 193 175-861 Ignition Coil	26
1.6	55 kW	1.6 l	09/98→09/00	⊗ X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6	62 kW	1.6 l	09/00→01/05	⊗ Z 16 SE	5DA 193 175-561 Ignition Coil	18
1.6	76 kW	1.6 l	12/02→12/09	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	85 kW	1.8 l	09/98→09/00	⊗ X 18 XE1	5DA 358 000-041 Ignition Coil	31
1.8 16V	92 kW	1.8 l	06/00→01/05	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 16V	100 kW	2 l	09/98→01/05		5DA 358 000-291 Ignition Coil	35
OPEL - ASTRA GTC J						10/11→
1.6	132 kW	1.6 l	10/11→		5DA 358 000-231 Ignition Coil	34
1.8	103 kW	1.8 l	10/11→			
2.0	206 kW	2 l	04/12→		5DA 358 000-121 Ignition Coil	33
OPEL - ASTRA H (L48)						03/04→
1.2	59 kW	1.2 l	08/05→	⊗ Z 12 XEP	5DA 193 175-861 Ignition Coil	26
1.4	66 kW	1.4 l	03/04→	⊗ Z 14 XEP	5DA 193 175-861 Ignition Coil	26
1.6	77 kW	1.6 l	03/04→	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.6	85 kW	1.6 l	12/06→	⊗ A 16 XER / Z 16 XER; 1x	5DA 193 175-331 Ignition Coil	10
1.6 Turbo	132 kW	1.6 l	02/07→	⊗ Z 16 LET; 1x	5DA 193 175-331 Ignition Coil	10
1.8	92 kW	1.8 l	03/04→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
1.8	103 kW	1.8 l	01/06→	⊗ Z 18 XER / A 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
2.0 Turbo	125 kW	2 l	03/04→		5DA 358 000-331 Ignition Coil	35
2.0 Turbo	147 kW	2 l	09/04→			
2.0 Turbo	177 kW	2 l	03/05→			
OPEL - ASTRA H Estate (L35)						08/04→
1.4	66 kW	1.4 l	08/04→	⊗ Z 14 XEP	5DA 193 175-861 Ignition Coil	26
1.4 LPG	66 kW	1.4 l	08/09→			
1.6	77 kW	1.6 l	08/04→	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.6	85 kW	1.6 l	12/06→	⊗ A 16 XER / Z 16 XER; 1x	5DA 193 175-331 Ignition Coil	10
1.6 LPG	85 kW	1.6 l	08/09→	⊗ Z 16 XER; 1x	5DA 193 175-331 Ignition Coil	10
1.6 Turbo	132 kW	1.6 l	02/07→	⊗ Z 16 LET; 1x	5DA 193 175-331 Ignition Coil	10
1.8	92 kW	1.8 l	08/04→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
1.8	103 kW	1.8 l	08/05→	⊗ A 18 XER / Z 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
2.0 Turbo	125 kW	2 l	08/04→		5DA 358 000-331 Ignition Coil	35
2.0 Turbo	147 kW	2 l	09/04→			
OPEL - ASTRA H GTC (L08)						03/05→
1.2	59 kW	1.2 l	08/05→	⊗ Z 12 XEP	5DA 193 175-861 Ignition Coil	26
1.4	66 kW	1.4 l	03/05→	⊗ Z 14 XEP	5DA 193 175-861 Ignition Coil	26
1.6	77 kW	1.6 l	03/05→	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.6	85 kW	1.6 l	12/06→	⊗ Z 16 XER; 1x	5DA 193 175-331 Ignition Coil	10

										13		412	
OPEL - ASTRA H GTC (L08)													03/05 →
1.6 Turbo	132 kW	1.6 l	02/07→	⊗ Z 16 LET; 1x	5DA 193 175-331 Ignition Coil	10							
1.8	92 kW	1.8 l	03/05→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31							
1.8	103 kW	1.8 l	01/06→	⊗ Z 18 XER; 1x	5DA 193 175-331 Ignition Coil	10							
2.0 Turbo	125 kW	2 l	03/05→			5DA 358 000-331 Ignition Coil	35						
2.0 Turbo	147 kW	2 l	03/05→										
2.0 Turbo	177 kW	2 l	08/05→										
OPEL - ASTRA H Saloon (L69)													02/07 →
1.6	85 kW	1.6 l	02/07→	⊗ Z 16 XER; 1x	5DA 193 175-331 Ignition Coil	10							
1.8	103 kW	1.8 l	02/07→	⊗ Z 18 XER / A 18 XER; 1x	5DA 193 175-331 Ignition Coil	10							
OPEL - ASTRA H TwinTop (L67)													09/05 →
1.6	77 kW	1.6 l	09/05→	⊗ Z 16 XEP / Z 16 XE1; 1x	5DA 193 175-331 Ignition Coil	10							
1.6	85 kW	1.6 l	12/06→	⊗ Z 16 XER; 1x	5DA 193 175-331 Ignition Coil	10							
1.6 Turbo	132 kW	1.6 l	02/07→	⊗ Z 16 LET; 1x	5DA 193 175-331 Ignition Coil	10							
1.8	92 kW	1.8 l	09/05→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31							
1.8	103 kW	1.8 l	09/05→	⊗ Z 18 XER / A 18 XER; 1x	5DA 193 175-331 Ignition Coil	10							
2.0 Turbo	125 kW	2 l	09/05→			5DA 358 000-331 Ignition Coil	35						
2.0 Turbo	147 kW	2 l	09/05→										
OPEL - ASTRA J													12/09 →
1.4	64 kW	1.4 l	12/09→	⊗ 19SP3409; engine 19VD6142→	5DA 358 000-341 Ignition Coil	35							
1.4	74 kW	1.4 l	12/09→										
1.4 LPG	103 kW	1.4 l	01/12→										
1.4 Turbo	88 kW	1.4 l	10/10→										
1.4 Turbo	103 kW	1.4 l	12/09→										
1.6	85 kW	1.6 l	12/09→			5DA 358 000-241 Ignition Coil	34						
1.6 Turbo	132 kW	1.6 l	12/09→			5DA 358 000-231 Ignition Coil	34						
OPEL - ASTRA J Saloon													06/12 →
1.4	74 kW	1.4 l	06/12→	⊗ 19SP3409; engine 19VD6142→	5DA 358 000-341 Ignition Coil	35							
1.4 LPG	103 kW	1.4 l	07/14→										
1.4 Turbo	88 kW	1.4 l	06/12→										
1.4 Turbo	103 kW	1.4 l	06/12→										
1.6	85 kW	1.6 l	06/12→			5DA 358 000-241 Ignition Coil	34						
1.6 Turbo	132 kW	1.6 l	06/12→			5DA 358 000-231 Ignition Coil	34						
OPEL - ASTRA J Sports Tourer													10/10 →
1.4	74 kW	1.4 l	10/10→	⊗ 19SP3409; engine 19VD6142→	5DA 358 000-341 Ignition Coil	35							
1.4 LPG	103 kW	1.4 l	01/12→										
1.4 Turbo	88 kW	1.4 l	10/10→										
1.4 Turbo	103 kW	1.4 l	10/10→										
1.6	85 kW	1.6 l	10/10→			5DA 358 000-241 Ignition Coil	34						
1.6 LPG	84 kW	1.6 l	10/12→										
1.6 Turbo	132 kW	1.6 l	10/10→			5DA 358 000-231 Ignition Coil	34						
OPEL - CALIBRA A (85_)													06/90 → 07/97
2.0 i 16V	100 kW	2 l	02/94→07/97			5DA 006 623-601 Switch Unit, ignition system	8						
2.0 i 16V 4x4	100 kW	2 l	02/94→07/97			5DA 358 000-291 Ignition Coil	35						
2.0 i 16V	110 kW	2 l	06/90→02/94	⊗ C 20 XE; Model 1993→	5DA 193 175-351 Ignition Coil	11							
2.0 i 16V 4x4	110 kW	2 l	06/90→02/94										
2.0 i 4x4	85 kW	2 l	06/90→07/97			5DA 006 623-601 Switch Unit, ignition system	8						
OPEL - CASCADA (W13)													03/13 →
1.4	88 kW	1.4 l	03/13→			5DA 358 000-341 Ignition Coil	35						
1.4 Turbo	103 kW	1.4 l	03/13→										

				13	i	412	
OPEL - COMBO (71_)							07/94→10/01
1.2	33 kW	1.2 l	07/94→10/01	⊗ C 12 NZ; for vehicles without air conditioning	5DA 006 623-251	Switch Unit, ignition system	5
				⊗ X 12 SZ	5DA 193 175-651	Ignition Coil	19
1.4	44 kW	1.4 l	07/94→10/01	⊗ C 14 NZ; for vehicles without air conditioning	5DA 006 623-251	Switch Unit, ignition system	5
				⊗ X 14 SZ	5DA 193 175-651	Ignition Coil	19
1.4	60 kW	1.4 l	07/94→10/01	⊗ C 14 SE	5DA 193 175-651	Ignition Coil	19
OPEL - COMBO Box Body / Estate							10/01→
1.4 16V	66 kW	1.4 l	08/05→	⊗ Z 14 XEP; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861	Ignition Coil	26
1.6	64 kW	1.6 l	10/01→	⊗ Z 16 SE	5DA 193 175-561	Ignition Coil	18
OPEL - COMBO Tour							10/01→
1.4	66 kW	1.4 l	10/04→	⊗ Z 14 XEP; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861	Ignition Coil	26
1.6	64 kW	1.6 l	10/01→	⊗ Z 16 SE	5DA 193 175-561	Ignition Coil	18
OPEL - CORSA A Box							02/86→04/89
1.2	33 kW	1.2 l	02/86→04/89		5DA 006 623-001	Switch Unit, ignition system	4
OPEL - CORSA A Hatchback (93_, 94_, 98_, 99_)							09/82→03/93
1.2	33 kW	1.2 l	09/82→08/90		5DA 006 623-001	Switch Unit, ignition system	4
1.4 S	53 kW	1.4 l	01/90→03/93				
1.2 i	33 kW	1.2 l	09/89→03/93		5DA 006 623-251	Switch Unit, ignition system	5
1.4 i	44 kW	1.4 l	01/90→03/93				
1.3 i	44 kW	1.3 l	09/86→09/90		5DA 006 623-581	Switch Unit, ignition system	7
1.6 GSI	72 kW	1.6 l	09/89→03/93				
1.4 Si	60 kW	1.4 l	09/91→03/93		5DA 006 623-251	Switch Unit, ignition system	5
				⊗ C 14 SE; engine 2T14053→	5DA 193 175-651	Ignition Coil	19
1.6 GSI	74 kW	1.6 l	05/88→03/92		5DA 006 623-251	Switch Unit, ignition system	5
			04/89→		5DA 006 623-581	Switch Unit, ignition system	7
				⊗ E 16 SE; ⚡ L4000001→	5DA 193 175-651	Ignition Coil	19
1.6 GSI CAT	74 kW	1.6 l	02/92→03/93	⊗ C 16 SE; ⚡ L4000001→	5DA 193 175-651	Ignition Coil	19
OPEL - CORSA A TR (91_, 92_, 96_, 97_)							01/85→10/87
1.2 N	33 kW	1.2 l	01/85→10/87		5DA 006 623-001	Switch Unit, ignition system	4
OPEL - CORSA B (73_, 78_, 79_)							03/93→09/00
1.0 i 12V	40 kW	1 l	11/96→09/00	⊗ X 10 XE	5DA 193 175-471	Ignition Coil	15
1.2 i	33 kW	1.2 l	03/93→09/00	⊗ C 12 NZ; for vehicles without air conditioning	5DA 006 623-251	Switch Unit, ignition system	5
				⊗ X 12 SZ	5DA 193 175-651	Ignition Coil	19
1.2 i 16V	48 kW	1.2 l	03/98→09/00		5DA 358 000-201	Ignition Coil	33
1.4 i	44 kW	1.4 l	03/93→09/00	⊗ C 14 NZ; for vehicles without air conditioning	5DA 006 623-251	Switch Unit, ignition system	5
				⊗ X 14 SZ	5DA 193 175-651	Ignition Coil	19
1.4 i 16V	66 kW	1.4 l	09/94→09/00	⊗ X 14 XE	5DA 193 175-651	Ignition Coil	19
1.4 Si	60 kW	1.4 l	03/93→09/00	⊗ C 14 SE	5DA 193 175-651	Ignition Coil	19
1.6 GSI 16V	80 kW	1.6 l	03/93→09/00	⊗ C 16 XE	5DA 193 175-651	Ignition Coil	19
1.6 i 16V	78 kW	1.6 l	09/94→09/00	⊗ X 16 XE	5DA 193 175-651	Ignition Coil	19

OPEL - CORSA B Box (73_)							08/99→09/00
1.4 i	44 kW	1.4 l	08/99→09/00	⊗ X 14 SZ	5DA 193 175-651 Ignition Coil	19	
OPEL - CORSA B Estate (F35)							01/99→
1.4 i 16V	66 kW	1.4 l	01/99→	⊗ X 14 XE	5DA 193 175-651 Ignition Coil	19	
OPEL - CORSA C (F08, F68)							09/00→12/09
1.0	43 kW	1 l	09/00→06/03	⊗ Z 10 XE	5DA 193 175-471 Ignition Coil	15	
1.0	44 kW	1 l	06/03→12/09		5DA 358 000-351 Ignition Coil	36	
1.2	55 kW	1.2 l	09/00→12/09	⊗ Z 12 XE; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861 Ignition Coil	26	
				⚡ →33999999 / →34999999 / →36999999	5DA 358 000-201 Ignition Coil	33	
1.2 Twinport	59 kW	1.2 l	07/04→12/09	⊗ Z 12 XEP; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861 Ignition Coil	26	
1.4 Twinport	66 kW	1.4 l	06/03→12/09	⊗ Z 14 XEP; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861 Ignition Coil	26	
1.8	92 kW	1.8 l	09/00→12/09	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31	
OPEL - CORSA C Box (F08, W5L)							09/00→
1.2	59 kW	1.2 l	07/05→	⊗ Z 12 XEP; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861 Ignition Coil	26	
1.2 16V	55 kW	1.2 l	09/00→	⊗ Z 12 XE; ⚡ 43000001→ / 44000001→ / 46000001→	5DA 193 175-861 Ignition Coil	26	
				⚡ →33999999 / →34999999 / →36999999	5DA 358 000-201 Ignition Coil	33	
OPEL - CORSA D							07/06→
1.0	44 kW	1 l	07/06→		5DA 358 000-351 Ignition Coil	36	
1.2	59 kW	1.2 l	07/06→	⊗ Z 12 XEP	5DA 193 175-861 Ignition Coil	26	
1.4	66 kW	1.4 l	07/06→	⊗ Z 14 XEP	5DA 193 175-861 Ignition Coil	26	
1.4 LPG	66 kW	1.4 l	07/06→				
1.4	88 kW	1.4 l	07/12→		5DA 358 000-341 Ignition Coil	35	
1.6 Turbo	110 kW	1.6 l	02/07→	⊗ Z 16 LEL / A 16 LEL; 1x	5DA 193 175-331 Ignition Coil	10	
1.6 Turbo	141 kW	1.6 l	02/07→	⊗ A 16 LER / Z 16 LER; 1x	5DA 193 175-331 Ignition Coil	10	
1.6 Turbo	155 kW	1.6 l	06/11→	1x	5DA 193 175-331 Ignition Coil	10	
OPEL - CORSA E							09/14→
1.2	51 kW	1.2 l	09/14→		5DA 358 000-341 Ignition Coil	35	
1.4	55 kW	1.4 l	09/14→				
1.4	66 kW	1.4 l	09/14→				
1.4 LPG	66 kW	1.4 l	03/15→				
1.4 Turbo	74 kW	1.4 l	09/14→				
1.4 Turbo	110 kW	1.4 l	03/15→				
OPEL - CORSA E Van							09/14→
1.2	51 kW	1.2 l	01/15→		5DA 358 000-341 Ignition Coil	35	
1.4	55 kW	1.4 l	09/14→				
1.4	66 kW	1.4 l	09/14→				
OPEL - FRONTERA A (5_MWL4)							03/95→10/98
2.2 i (54MWL4)	100 kW	2.2 l	03/95→10/98	⊗ X 22 XE; Model 1995→	5DA 193 175-351 Ignition Coil	11	
OPEL - FRONTERA A Sport (5_SUD2)							03/92→10/98
2.0 i (52SUD2, 55SUD2)	85 kW	2 l	03/92→10/98	⊗ X 20 SE; Model 1995→	5DA 193 175-351 Ignition Coil	11	
OPEL - FRONTERA B (6B_)							10/98→
2.2 i (6B_ZC, 6B_VF, 6B_66, 6B_76)	100 kW	2.2 l	10/98→	⊗ Y 22 SE / X 22 SE; + ABS; →Model 2004	5DA 193 175-581 Ignition Coil	18	

OPEL - GT Convertible						06/07→
2.0	194 kW	2 l	06/07→	8Y000001→	5DA 358 000-121 Ignition Coil	33
OPEL - INSIGNIA						07/08→
1.4	103 kW	1.4 l	04/11→		5DA 358 000-341 Ignition Coil	35
1.4 LPG	103 kW	1.4 l	07/12→			
1.6	85 kW	1.6 l	07/08→	A 16 XER; 1x	5DA 193 175-331 Ignition Coil	10
					5DA 358 000-231 Ignition Coil	34
1.6 Turbo	132 kW	1.6 l	07/08→	A 16 LET; 1x; →B1999999	5DA 193 175-331 Ignition Coil	10
1.8	103 kW	1.8 l	07/08→	A 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
					5DA 358 000-231 Ignition Coil	34
2.0 E85 Turbo	162 kW	2 l	09/10→	C1000001→	5DA 358 000-121 Ignition Coil	33
2.0 Turbo	162 kW	2 l	07/08→			
2.0 Turbo	184 kW	2 l	04/14→			
2.0 Turbo 4x4	162 kW	2 l	07/08→			
2.0 Turbo 4x4	184 kW	2 l	09/11→			
OPEL - INSIGNIA Estate						07/08→
1.4	103 kW	1.4 l	09/11→		5DA 358 000-341 Ignition Coil	35
1.4 LPG	103 kW	1.4 l	07/12→			
1.6	85 kW	1.6 l	07/08→	A 16 XER; 1x	5DA 193 175-331 Ignition Coil	10
					5DA 358 000-231 Ignition Coil	34
1.6 Turbo	132 kW	1.6 l	01/09→	A 16 LET; 1x; →B1999999	5DA 193 175-331 Ignition Coil	10
1.8	103 kW	1.8 l	07/08→	A 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
					5DA 358 000-231 Ignition Coil	34
2.0 E85 Turbo	162 kW	2 l	09/10→	C1000001→	5DA 358 000-121 Ignition Coil	33
2.0 Turbo	162 kW	2 l	07/08→			
2.0 Turbo	184 kW	2 l	04/14→			
2.0 Turbo 4x4	162 kW	2 l	07/08→			
2.0 Turbo 4x4	184 kW	2 l	09/11→			
OPEL - INSIGNIA Saloon						07/08→
1.4	103 kW	1.4 l	04/11→		5DA 358 000-341 Ignition Coil	35
1.4 LPG	103 kW	1.4 l	07/12→			
1.6	85 kW	1.6 l	07/08→	A 16 XER; 1x	5DA 193 175-331 Ignition Coil	10
					5DA 358 000-231 Ignition Coil	34
1.6 Turbo	132 kW	1.6 l	01/09→	A 16 LET; 1x; →B1999999	5DA 193 175-331 Ignition Coil	10
1.8	103 kW	1.8 l	07/08→	A 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
					5DA 358 000-231 Ignition Coil	34
2.0 Turbo	162 kW	2 l	07/08→	C1000001→	5DA 358 000-121 Ignition Coil	33
2.0 Turbo	184 kW	2 l	04/14→			
2.0 Turbo 4x4	162 kW	2 l	07/08→			
2.0 Turbo 4x4	184 kW	2 l	09/11→			
2.0 Turbo E85	162 kW	2 l	07/08→			
OPEL - KADETT E (39_, 49_)						09/84→08/91
1.4 i	44 kW	1.4 l	01/90→08/91	SV / + CH	5DA 006 623-251 Switch Unit, ignition system	5
1.6 S	60 kW	1.6 l	09/86→08/91			
1.4 S	55 kW	1.4 l	01/90→08/91		5DA 006 623-001 Switch Unit, ignition system	4
1.6 i	55 kW	1.6 l	09/86→08/91		5DA 006 623-251 Switch Unit, ignition system	5
				09/87→	5DA 006 623-581 Switch Unit, ignition system	7
1.6 S	66 kW	1.6 l	09/84→08/86		5DA 006 623-931 Switch Unit, ignition system	8
1.8	84 kW	1.8 l	09/87→08/90			
1.8 i	66 kW	1.8 l	09/90→08/91	C 18 NZ; SV / + CH	5DA 006 623-251 Switch Unit, ignition system	5

										13		412	
OPEL - KADETT E (39_, 49_)										09/84→08/91			
1.8 i	85 kW	1.8 l	09/84→08/86		18 E	5DA 006 623-931 Switch Unit, ignition system						8	
OPEL - KADETT E Box (37_, 47_)										08/89→09/93			
1.4 i	44 kW	1.4 l	01/90→08/91	SV / + CH		5DA 006 623-251 Switch Unit, ignition system						5	
1.6 i	55 kW	1.6 l	08/89→09/93			5DA 006 623-251 Switch Unit, ignition system						5	
				→10/91		5DA 006 623-581 Switch Unit, ignition system						7	
OPEL - KADETT E Combo (38_, 48_)										09/86→07/94			
1.4 i	44 kW	1.4 l	08/91→07/94	SV / + CH		5DA 006 623-251 Switch Unit, ignition system						5	
1.6	60 kW	1.6 l	09/86→12/91			5DA 006 623-001 Switch Unit, ignition system						4	
1.4 S	55 kW	1.4 l	07/89→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
1.6 i	55 kW	1.6 l	08/91→07/94			5DA 006 623-251 Switch Unit, ignition system						5	
				→10/91		5DA 006 623-581 Switch Unit, ignition system						7	
OPEL - KADETT E Convertible (43B_)										10/86→02/93			
1.4 i	44 kW	1.4 l	01/90→08/91	SV / + CH		5DA 006 623-251 Switch Unit, ignition system						5	
1.4 S	55 kW	1.4 l	08/90→02/93			5DA 006 623-001 Switch Unit, ignition system						4	
1.6 i	55 kW	1.6 l	10/86→02/93			5DA 006 623-251 Switch Unit, ignition system						5	
				09/87→10/91		5DA 006 623-581 Switch Unit, ignition system						7	
1.6 i	60 kW	1.6 l	07/89→02/93	SV / + CH		5DA 006 623-251 Switch Unit, ignition system						5	
				→10/91		5DA 006 623-581 Switch Unit, ignition system						7	
OPEL - KADETT E Estate (35_, 36_, 45_, 46_)										09/84→08/91			
1.3 i CAT	44 kW	1.3 l	09/85→08/91	01/89→		5DA 006 623-251 Switch Unit, ignition system						5	
1.3 N	44 kW	1.3 l	09/84→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
1.6 i CAT	55 kW	1.6 l	09/86→08/91			5DA 006 623-001 Switch Unit, ignition system						4	
1.8 S	62 kW	1.8 l	09/87→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
2.0 i	85 kW	2 l	09/87→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
2.0 i CAT	85 kW	2 l	09/87→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
1.4 i	44 kW	1.4 l	01/90→08/91	SV / + CH		5DA 006 623-251 Switch Unit, ignition system						5	
1.6	60 kW	1.6 l	09/86→08/91			5DA 006 623-001 Switch Unit, ignition system						4	
1.4 S	55 kW	1.4 l	01/90→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
1.6 i	55 kW	1.6 l	09/86→08/91	01/89→		5DA 006 623-251 Switch Unit, ignition system						5	
				09/87→		5DA 006 623-581 Switch Unit, ignition system						7	
1.6 S	66 kW	1.6 l	09/84→08/86			5DA 006 623-931 Switch Unit, ignition system						8	
1.8	82 kW	1.8 l	12/88→08/91			5DA 006 623-931 Switch Unit, ignition system						8	
1.8 i	85 kW	1.8 l	09/84→08/86			5DA 006 623-251 Switch Unit, ignition system						5	
1.8 i	66 kW	1.8 l	06/85→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
OPEL - KADETT E Hatchback (33_, 34_, 43_, 44_)										09/84→08/91			
1.4 i	44 kW	1.4 l	01/90→08/91	SV / + CH		5DA 006 623-251 Switch Unit, ignition system						5	
1.6 S	60 kW	1.6 l	09/86→08/91			5DA 006 623-001 Switch Unit, ignition system						4	
1.4 S	55 kW	1.4 l	01/90→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
1.6 i	55 kW	1.6 l	09/86→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
				09/87→		5DA 006 623-581 Switch Unit, ignition system						7	
1.6 S	66 kW	1.6 l	09/84→08/86			5DA 006 623-931 Switch Unit, ignition system						8	
1.8 GSI	85 kW	1.8 l	09/84→08/86			5DA 006 623-251 Switch Unit, ignition system						5	
1.8 i	66 kW	1.8 l	06/85→08/91			5DA 006 623-251 Switch Unit, ignition system						5	
OPEL - MERIVA										05/03→05/10			
1.4 16V Twinport	66 kW	1.4 l	07/04→05/10			5DA 193 175-861 Ignition Coil						26	

OPEL - MERIVA						05/03→05/10
1.6	64 kW	1.6 l	05/03→05/10	⊗ Z 16 SE	5DA 193 175-561 Ignition Coil	18
1.6	77 kW	1.6 l	01/06→05/10	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.6 Turbo	132 kW	1.6 l	09/05→05/10	⊗ Z 16 LET; 1x	5DA 193 175-331 Ignition Coil	10
1.8	92 kW	1.8 l	05/03→05/10	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
OPEL - MERIVA B						06/10→
1.4	74 kW	1.4 l	06/10→		5DA 358 000-341 Ignition Coil	35
1.4	88 kW	1.4 l	06/10→			
1.4	103 kW	1.4 l	06/10→			
1.4 LPG	88 kW	1.4 l	06/11→			
OPEL - MOKKA						06/12→
1.4	103 kW	1.4 l	04/13→		5DA 358 000-341 Ignition Coil	35
1.4 4x4	103 kW	1.4 l	06/12→			
1.4 LPG	103 kW	1.4 l	04/13→			
1.6	85 kW	1.6 l	06/12→		5DA 358 000-241 Ignition Coil	34
OPEL - OMEGA A (16_, 17_, 19_)						09/86→03/94
1.8 S	66 kW	1.8 l	09/86→03/94	⊗ L1019855→; Manual Transmission	5DA 006 623-251 Switch Unit, ignition system	5
OPEL - OMEGA A Estate (66_, 67_)						09/86→03/94
1.8 S	66 kW	1.8 l	09/86→03/94	⊗ L1019855→; Manual Transmission	5DA 006 623-251 Switch Unit, ignition system	5
3.0	130 kW	3 l	03/87→09/90	→12/89	5DA 006 623-001 Switch Unit, ignition system	4
OPEL - OMEGA B (25_, 26_, 27_)						03/94→07/03
2.0	85 kW	2 l	03/94→09/99	⊗ X 20 SE	5DA 193 175-351 Ignition Coil	11
2.0 16V	100 kW	2 l	03/94→09/99		5DA 358 000-291 Ignition Coil	35
2.5 V6	125 kW	2.5 l	03/94→09/00	⊗ X 25 XE	5DA 358 000-031 Ignition Coil	31
2.6 V6	132 kW	2.6 l	09/00→07/03		5DA 358 000-281 Ignition Coil	34
3.2 V6	160 kW	3.2 l	02/01→07/03			
3.0 V6	155 kW	3 l	04/94→02/01	⊗ X 30 XE	5DA 358 000-031 Ignition Coil	31
OPEL - OMEGA B Estate (21_, 22_, 23_)						03/94→07/03
2.0	85 kW	2 l	03/94→09/99	⊗ X 20 SE	5DA 193 175-351 Ignition Coil	11
2.0 16V	100 kW	2 l	03/94→09/99		5DA 358 000-291 Ignition Coil	35
2.5 V6	125 kW	2.5 l	03/94→09/00	⊗ X 25 XE	5DA 358 000-031 Ignition Coil	31
2.6 V6	132 kW	2.6 l	09/00→07/03		5DA 358 000-281 Ignition Coil	34
3.2 V6	160 kW	3.2 l	02/01→07/03			
3.0 V6	155 kW	3 l	04/94→02/01	⊗ X 30 XE	5DA 358 000-031 Ignition Coil	31
OPEL - SIGNUM						05/03→
1.8	90 kW	1.8 l	05/03→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
1.8	103 kW	1.8 l	09/05→	⊗ Z 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
3.2 V6	155 kW	3.2 l	05/03→		5DA 358 000-281 Ignition Coil	34
OPEL - SPEEDSTER						04/03→
2.0 Turbo	147 kW	2 l	04/03→		5DA 358 000-331 Ignition Coil	35
OPEL - TIGRA (95_)						07/94→12/00
1.4 16V	66 kW	1.4 l	07/94→12/00	⊗ X 14 XE	5DA 193 175-651 Ignition Coil	19
1.6 16V	78 kW	1.6 l	07/94→08/98	⊗ X 16 XE	5DA 193 175-651 Ignition Coil	19

OPEL - TIGRA TwinTop										06/04→	
1.4	66 kW	1.4 l	06/04→		Z 14 XEP; Bosch 0221503473	5DA 193 175-861	Ignition Coil			26	
1.8	92 kW	1.8 l	06/04→		Z 18 XE	5DA 358 000-041	Ignition Coil			31	
OPEL - VECTRA A (86_, 87_)										09/88→11/95	
1.6	60 kW	1.6 l	09/88→05/93	→12/92		5DA 006 623-251	Switch Unit, ignition system			5	
1.6 i	52 kW	1.6 l	09/93→11/95		X 16 SZ	5DA 193 175-651	Ignition Coil			19	
1.6 i	55 kW	1.6 l	09/88→11/95			5DA 006 623-251	Switch Unit, ignition system			5	
						5DA 006 623-581	Switch Unit, ignition system			7	
1.8 i CAT	66 kW	1.8 l	03/90→11/95	120		5DA 006 623-251	Switch Unit, ignition system			5	
1.8 S	66 kW	1.8 l	09/89→10/90								
2.0 i 16V	100 kW	2 l	06/94→11/95			5DA 006 623-601	Switch Unit, ignition system			8	
2.0 i 16V 4x4	100 kW	2 l	06/94→11/95			5DA 358 000-291	Ignition Coil			35	
2000/GT 16V	110 kW	2 l	01/89→06/94	09/92→		5DA 006 623-601	Switch Unit, ignition system			8	
2000/GT 16V 4x4 CAT	110 kW	2 l	02/90→11/95		C 20 XE; Model 1993→	5DA 193 175-351	Ignition Coil			11	
2000/GT 16V CAT	110 kW	2 l	02/90→11/95								
OPEL - VECTRA A Hatchback (88_, 89_)										09/88→11/95	
1.6 i	52 kW	1.6 l	09/93→11/95		X 16 SZ	5DA 193 175-651	Ignition Coil			19	
1.6 i CAT	55 kW	1.6 l	09/88→11/95			C 16 NZ2; 120	5DA 006 623-251	Switch Unit, ignition system		5	
							5DA 006 623-581	Switch Unit, ignition system		7	
1.6 S	60 kW	1.6 l	09/88→05/93	→12/92		5DA 006 623-251	Switch Unit, ignition system			5	
1.8 i	66 kW	1.8 l	09/88→10/90	120		5DA 006 623-251	Switch Unit, ignition system			5	
1.8 i CAT	66 kW	1.8 l	03/90→11/95								
2.0 i 16V	100 kW	2 l	06/94→11/95			5DA 006 623-601	Switch Unit, ignition system			8	
2.0 i 16V CAT	110 kW	2 l	02/90→11/95			5DA 358 000-291	Ignition Coil			35	
						5DA 193 175-351	Ignition Coil			11	
OPEL - VECTRA B (36_)										10/95→04/02	
1.6 i	55 kW	1.6 l	10/95→04/02		X 16 SZR	5DA 193 175-651	Ignition Coil			19	
1.6 i 16V	74 kW	1.6 l	10/95→04/02		Z 16 XE / Y 16 XE / X 16 XEL; →W1285446 / →W5276825 / →W7154258	5DA 193 175-651	Ignition Coil			19	
1.8 i 16V	85 kW	1.8 l	10/95→09/00			X 18 XE1	5DA 358 000-041	Ignition Coil		31	
							5DA 358 000-291	Ignition Coil		35	
1.8 i 16V	92 kW	1.8 l	09/00→04/02		Z 18 XE	5DA 358 000-041	Ignition Coil			31	
2.0 i 16V	100 kW	2 l	10/95→09/00			5DA 006 623-601	Switch Unit, ignition system			8	
						5DA 358 000-291	Ignition Coil			35	
2.5 i V6	125 kW	2.5 l	10/95→09/00		X 25 XE	5DA 358 000-031	Ignition Coil			31	
i 500 2.5	143 kW	2.5 l	05/98→09/00								
2.6 i V6	125 kW	2.6 l	09/00→04/02			5DA 358 000-281	Ignition Coil			34	
OPEL - VECTRA B Estate (31_)										11/96→07/03	
1.6 i	55 kW	1.6 l	11/96→06/00		X 16 SZR	5DA 193 175-651	Ignition Coil			19	
1.6 i 16V	74 kW	1.6 l	11/96→07/02			Z 16 XE / Y 16 XE / X 16 XEL; →W1285446 / →W5276825 / →W7154258	5DA 193 175-651	Ignition Coil		19	
1.8 i 16V	85 kW	1.8 l	11/96→09/00			X 18 XE1	5DA 358 000-041	Ignition Coil		31	
							5DA 358 000-291	Ignition Coil		35	

OPEL - VECTRA B Estate (31_)						11/96→07/03
1.8 i 16V	92 kW	1.8 l	09/00→07/03		5DA 358 000-041 Ignition Coil	31
2.0 i 16V	100 kW	2 l	11/96→09/00		5DA 006 623-601 Switch Unit, ignition system	8
					5DA 358 000-291 Ignition Coil	35
2.5 i V6	125 kW	2.5 l	11/96→09/00	⊗ X 25 XE	5DA 358 000-031 Ignition Coil	31
i 500 2.5	143 kW	2.5 l	05/98→09/00			
2.6 i V6	125 kW	2.6 l	09/00→07/03		5DA 358 000-281 Ignition Coil	34
OPEL - VECTRA B Hatchback (38_)						10/95→07/03
1.6 i	55 kW	1.6 l	10/95→07/03	⊗ X 16 SZR	5DA 193 175-651 Ignition Coil	19
1.6 i 16V	74 kW	1.6 l	10/95→07/02	⊗ Z 16 XE / Y 16 XE / X 16 XEL; ⊗ →W1285446 / →W5276825 / →W7154258	5DA 193 175-651 Ignition Coil	19
1.8 i 16V	85 kW	1.8 l	10/95→09/00	⊗ X 18 XE1	5DA 358 000-041 Ignition Coil	31
					5DA 358 000-291 Ignition Coil	35
1.8 i 16V	92 kW	1.8 l	09/00→07/03	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 i 16V	100 kW	2 l	10/95→09/00		5DA 006 623-601 Switch Unit, ignition system	8
					5DA 358 000-291 Ignition Coil	35
2.5 i V6	125 kW	2.5 l	10/95→09/00	⊗ X 25 XE	5DA 358 000-031 Ignition Coil	31
2.6 i V6	125 kW	2.6 l	09/00→07/03		5DA 358 000-281 Ignition Coil	34
OPEL - VECTRA C						04/02→
1.6	77 kW	1.6 l	01/06→	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8	81 kW	1.8 l	04/02→	⊗ Z 18 XEL	5DA 358 000-041 Ignition Coil	31
1.8	103 kW	1.8 l	01/06→	⊗ Z 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	90 kW	1.8 l	04/02→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
3.2 V6	155 kW	3.2 l	08/02→		5DA 358 000-281 Ignition Coil	34
OPEL - VECTRA C Estate						10/03→
1.6	77 kW	1.6 l	01/06→	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8	90 kW	1.8 l	10/03→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
1.8	103 kW	1.8 l	01/06→	⊗ Z 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
3.2 V6	155 kW	3.2 l	10/03→		5DA 358 000-281 Ignition Coil	34
OPEL - VECTRA C GTS						08/02→
1.6	77 kW	1.6 l	01/06→	⊗ Z 16 XEP; 1x	5DA 193 175-331 Ignition Coil	10
1.8	103 kW	1.8 l	01/06→	⊗ Z 18 XER; 1x	5DA 193 175-331 Ignition Coil	10
1.8 16V	90 kW	1.8 l	08/02→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
3.2 V6	155 kW	3.2 l	08/02→		5DA 358 000-281 Ignition Coil	34
OPEL - ZAFIRA A (F75_)						04/99→06/05
1.8 16V	85 kW	1.8 l	04/99→09/00	⊗ X 18 XE1	5DA 358 000-041 Ignition Coil	31
1.8 16V	92 kW	1.8 l	09/00→06/05	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31
2.0 OPC	141 kW	2 l	09/01→06/05		5DA 358 000-331 Ignition Coil	35
2.0 OPC	147 kW	2 l	11/02→06/05		5DA 358 000-331 Ignition Coil	35

				13	i	412	
OPEL - ZAFIRA B (A05)							07/05→
1.6	77 kW	1.6 l	07/05→	Z 16 XEP / Z 16 XE1; 1x	5DA 193 175-331 Ignition Coil		10
1.6	85 kW	1.6 l	01/08→	Z 16 XER / A 16 XER; 1x	5DA 193 175-331 Ignition Coil		10
1.6 CNG Turbo	110 kW	1.6 l	02/09→	Z 16 XNT / A 16 XNT; 1x	5DA 193 175-331 Ignition Coil		10
1.8	103 kW	1.8 l	07/05→	Z 18 XER / A 18 XER; 1x	5DA 193 175-331 Ignition Coil		10
2.0	147 kW	2 l	07/05→		5DA 358 000-331 Ignition Coil		35
2.0	177 kW	2 l	01/06→		5DA 358 000-331 Ignition Coil		
OPEL - ZAFIRA B Van							07/05→
1.6 CNG Turbo	110 kW	1.6 l	02/09→	Z 16 XNT / A 16 XNT; 1x	5DA 193 175-331 Ignition Coil		10
1.8	103 kW	1.8 l	07/05→	A 18 XER / Z 18 XER; 1x	5DA 193 175-331 Ignition Coil		10
OPEL - ZAFIRA C (P12)							10/11→
1.4	88 kW	1.4 l	10/11→		5DA 358 000-341 Ignition Coil		35
1.4	103 kW	1.4 l	10/11→		5DA 358 000-341 Ignition Coil		
1.4 LPG	103 kW	1.4 l	10/11→		5DA 358 000-341 Ignition Coil		
1.8	85 kW	1.8 l	10/11→		5DA 358 000-231 Ignition Coil		34
1.8	88 kW	1.8 l	10/11→		5DA 358 000-231 Ignition Coil		
1.8	103 kW	1.8 l	10/11→		5DA 358 000-231 Ignition Coil		
1.8 LPG	101 kW	1.8 l	10/11→		5DA 358 000-231 Ignition Coil		



										13		412	
PEUGEOT - 104										08/79→06/88			
1.1	37 kW	1.1 l	08/80→06/88							5DA 006 623-001	Switch Unit, ignition system	4	
1.2	42 kW	1.2 l	08/79→06/83	05/80→						5DA 006 623-001	Switch Unit, ignition system	4	
1.4	53 kW	1.4 l	08/79→06/83										
PEUGEOT - 104 Coupe										08/79→06/88			
1.1	37 kW	1.1 l	08/79→06/88							5DA 006 623-001	Switch Unit, ignition system	4	
1.4	53 kW	1.4 l	08/79→06/84	05/80→						5DA 006 623-001	Switch Unit, ignition system	4	
PEUGEOT - 106 I (1A, 1C)										09/91→04/96			
1.0	33 kW	1 l	09/91→04/96	CDY (TU9M)						5DA 193 175-721	Ignition Coil	21	
1.1	44 kW	1.1 l	09/91→04/96							5DA 006 623-041	Switch Unit, ignition system	4	
				HDZ (TU1M); 07/92→						5DA 193 175-721	Ignition Coil	21	
1.3	72 kW	1.3 l	10/93→04/96	TU2J2						5DA 193 175-721	Ignition Coil	21	
1.4	55 kW	1.4 l	09/91→04/96	KDX (TU3MC)						5DA 193 175-721	Ignition Coil	21	
1.4	69 kW	1.4 l	09/91→04/96	KFZ (TU3J2/Z)						5DA 193 175-721	Ignition Coil	21	
1.6	65 kW	1.6 l	06/93→04/96	NFZ (TU5JP)						5DA 193 175-721	Ignition Coil	21	
1.6	76 kW	1.6 l	01/94→04/96	NFY (TU5J2)						5DA 193 175-721	Ignition Coil	21	
PEUGEOT - 106 II (1)										05/96→			
1.0 i	33 kW	1 l	05/96→							5DA 193 175-421	Ignition Coil	13	
1.0 i	37 kW	1 l	01/97→										
1.1 i	40 kW	1.1 l	01/97→										
1.6 i	65 kW	1.6 l	05/96→										
1.1 i	44 kW	1.1 l	05/96→	HDZ						5DA 193 175-421	Ignition Coil	13	
				HFX (TU1JP)						5DA 193 175-441	Ignition Coil	14	
1.4 i	55 kW	1.4 l	05/96→	Manual Transmission; →Orga 07727 Automatic Transmission						5DA 193 175-421	Ignition Coil	13	
				KFW (TU3JP) / KFX (TU3JP); Orga 07728→; Manual Transmission; L4						5DA 193 175-431	Ignition Coil	14	
				01/98→; TU3JP						5DA 193 175-441	Ignition Coil	14	
1.6 i	74 kW	1.6 l	05/96→	NFY (TU5J2) / NFW (TU5J2)						5DA 193 175-721	Ignition Coil	21	
1.6 S16	87 kW	1.6 l	05/96→	NFX (TU5J4); L3						5DA 193 175-461	Ignition Coil	14	
PEUGEOT - 205 I (741A/C)										02/83→10/87			
1.0	33 kW	1 l	02/83→10/87	Carburettor						5DA 006 623-001	Switch Unit, ignition system	4	
1.1	37 kW	1.1 l	02/83→10/87										
1.4	44 kW	1.4 l	02/83→10/87										
1.4	58 kW	1.4 l	10/85→10/87										
1.4	59 kW	1.4 l	02/83→10/87										
1.1	36 kW	1.1 l	02/83→10/87	Carburettor						5DA 006 623-001	Switch Unit, ignition system	4	
										5DA 006 623-041	Switch Unit, ignition system	4	
1.6	53 kW	1.6 l	03/87→10/87							5DA 006 623-001	Switch Unit, ignition system	4	
1.6	55 kW	1.6 l	08/86→10/87										
1.6 GTI	76 kW	1.6 l	12/84→10/87							5DA 006 623-041	Switch Unit, ignition system	4	
1.9 GTI	94 kW	1.9 l	10/86→10/87							5DA 006 623-041	Switch Unit, ignition system	4	
PEUGEOT - 205 I Convertible (741B, 20D)										04/86→12/94			
1.1 CJ	44 kW	1.1 l	10/89→12/94							5DA 006 623-041	Switch Unit, ignition system	4	
				24902801→; Magneti Marelli						5DA 193 175-421	Ignition Coil	13	

				13	i	412			
PEUGEOT - 205 I Convertible (741B, 20D)								04/86→12/94	
1.4 CJ	44 kW	1.4 l	03/88→05/89	Carburettor		5DA 006 623-001 Switch Unit, ignition system	4		
						5DA 006 623-041 Switch Unit, ignition system	4		
1.4 CJ	49 kW	1.4 l	03/89→12/94			5DA 006 623-041 Switch Unit, ignition system	4		
1.4 CJ	55 kW	1.4 l	05/91→12/94						
1.4 CT	58 kW	1.4 l	04/86→12/88	Carburettor		5DA 006 623-001 Switch Unit, ignition system	4		
				→10/87		5DA 006 623-041 Switch Unit, ignition system	4		
1.6 CJ	65 kW	1.6 l	08/92→12/94			5DA 006 623-041 Switch Unit, ignition system	4		
						5DA 193 175-421 Ignition Coil	13		
1.6 CTI	76 kW	1.6 l	04/86→10/90			5DA 006 623-001 Switch Unit, ignition system	4		
						5DA 006 623-041 Switch Unit, ignition system	4		
1.9 CTI	75 kW	1.9 l	10/87→12/94	08/91→		5DA 006 623-001 Switch Unit, ignition system	4		
						5DA 006 623-041 Switch Unit, ignition system	4		
PEUGEOT - 205 II (20A/C)								06/87→09/98	
1.0	33 kW	1 l	10/87→09/98			5DA 006 623-041 Switch Unit, ignition system	4		
1.1	40 kW	1.1 l	10/87→10/90						
1.4	49 kW	1.4 l	10/87→10/90						
1.4	55 kW	1.4 l	07/88→09/98						
1.4	62 kW	1.4 l	06/87→12/89						
1.9 GTI	75 kW	1.9 l	10/87→05/89						
1.9 GTI	88 kW	1.9 l	10/87→10/94						
1.1	36 kW	1.1 l	10/87→10/90	Carburettor		5DA 006 623-001 Switch Unit, ignition system	4		
						5DA 006 623-041 Switch Unit, ignition system	4		
1.1	44 kW	1.1 l	07/89→09/98			5DA 006 623-041 Switch Unit, ignition system	4		
				24902801→; Magneti Marelli		5DA 193 175-421 Ignition Coil	13		
				HDZ (TU1M); 2490281→		5DA 193 175-721 Ignition Coil	21		
1.4	44 kW	1.4 l	10/87→05/89			5DA 006 623-001 Switch Unit, ignition system	4		
1.4	55 kW	1.4 l	08/90→07/98	KDX (TU3MC)		5DA 193 175-721 Ignition Coil	21		
1.4	58 kW	1.4 l	07/88→05/89	Carburettor		5DA 006 623-001 Switch Unit, ignition system	4		
1.6	53 kW	1.6 l	10/87→09/98						
1.6	55 kW	1.6 l	10/87→09/98						
1.6 Aut.	65 kW	1.6 l	05/90→09/98	→07/91		5DA 006 623-001 Switch Unit, ignition system	4		
						5DA 006 623-041 Switch Unit, ignition system	4		
						5DA 193 175-421 Ignition Coil	13		
1.6 GTI	76 kW	1.6 l	10/87→12/89	→12/89		5DA 006 623-001 Switch Unit, ignition system	4		
				10/88→		5DA 006 623-041 Switch Unit, ignition system	4		
1.9 GTI	94 kW	1.9 l	10/87→09/98	12/89→		5DA 006 623-001 Switch Unit, ignition system	4		
						5DA 006 623-041 Switch Unit, ignition system	4		
1.9 GTI CAT	75 kW	1.9 l	10/87→07/94	08/91→		5DA 006 623-001 Switch Unit, ignition system	4		
PEUGEOT - 206 CC (2D)								09/00→	
1.6 16V	80 kW	1.6 l	09/00→	NFU (TU5JP4)		5DA 193 175-731 Ignition Coil	22		
PEUGEOT - 206 Hatchback (2A/C)								09/98→12/00	
1.1 i	44 kW	1.1 l	09/98→	HFZ (TU1JP) / HFX (TU1JP); L4		5DA 193 175-431 Ignition Coil	14		
				HFX (TU1JP)		5DA 193 175-441 Ignition Coil	14		

				13	i	412	
PEUGEOT - 206 Hatchback (2A/C)							09/98→12/00
1.4 i	55 kW	1.4 l	09/98→	⊗ KFW (TU3JP) / KFX (TU3JP); L4	5DA 193 175-431 Ignition Coil	14	
				⊗ KFW (TU3JP)	5DA 193 175-441 Ignition Coil	14	
1.6 16V	80 kW	1.6 l	12/00→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
1.6 i	65 kW	1.6 l	09/98→12/00	⊗ NFZ (TU5JP)	5DA 193 175-431 Ignition Coil	14	
2.0 RC	130 kW	2 l	07/03→	⊗ RFK (EW10J4S); 3	5DA 749 475-611 Ignition Coil	40	
PEUGEOT - 206 Saloon							03/07→
1.6 16V	80 kW	1.6 l	03/07→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
PEUGEOT - 206 SW (2E/K)							07/02→
1.1	44 kW	1.1 l	07/02→	⊗ HFX (TU1JP); L4	5DA 193 175-431 Ignition Coil	14	
				⊗ HFX (TU1JP)	5DA 193 175-441 Ignition Coil	14	
1.4	55 kW	1.4 l	07/02→	⊗ KFW (TU3JP); L4	5DA 193 175-431 Ignition Coil	14	
				⊗ KFW (TU3JP)	5DA 193 175-441 Ignition Coil	14	
1.6 16V	80 kW	1.6 l	07/02→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
PEUGEOT - 206+ (T3E)							07/10→
1.6 16V	80 kW	1.6 l	07/10→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
PEUGEOT - 207 (WA_, WC_)							02/06→
1.4 16V	70 kW	1.4 l	06/07→	⊗ EP3 / EP3C; 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V	80 kW	1.6 l	02/06→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22	
1.6 16V RC	128 kW	1.6 l	02/07→	⊗ 5FY (EP6DTS); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V Turbo	110 kW	1.6 l	02/06→	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V Turbo	115 kW	1.6 l	10/09→	⊗ 5FR (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V VTi	88 kW	1.6 l	02/07→	⊗ 5FS (EP6C) / EP6; 4x	5DA 193 175-491 Ignition Coil	15	
PEUGEOT - 207 CC (WD_)							02/07→
1.6 16V	88 kW	1.6 l	02/07→	⊗ EP6; 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V Turbo	110 kW	1.6 l	02/07→	⊗ 5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V Turbo	115 kW	1.6 l	10/09→	⊗ 5FR (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15	
PEUGEOT - 207 SW Estate (WK_)							02/07→
1.4 16V	70 kW	1.4 l	06/07→	⊗ EP3 / EP3C; 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V	88 kW	1.6 l	06/07→	⊗ EP6; 4x	5DA 193 175-491 Ignition Coil	15	
1.6 16V RC	128 kW	1.6 l	02/07→	⊗ 5FY (EP6DTS); 4x	5DA 193 175-491 Ignition Coil	15	
PEUGEOT - 208							03/12→
1.4	70 kW	1.4 l	03/12→	⊗ EP3C; 4x	5DA 193 175-491 Ignition Coil	15	
1.6	115 kW	1.6 l	03/12→	⊗ EP6CDT; 4x	5DA 193 175-491 Ignition Coil	15	
PEUGEOT - 305 I (581A)							11/77→09/82
1.3	44 kW	1.3 l	11/77→09/82		5DA 006 623-001 Switch Unit, ignition system	4	
1.5	54 kW	1.5 l	11/79→09/82				
1.5	65 kW	1.5 l	05/80→09/82				

PEUGEOT - 305 I Break (581D)										08/80→09/82			
1.3	44 kW	1.3 l	08/80→09/82					5DA 006 623-001 Switch		4			
1.5	54 kW	1.5 l	08/80→09/82					Unit, ignition system					
PEUGEOT - 305 II (581M)										10/82→07/90			
1.3	44 kW	1.3 l	10/82→08/85					5DA 006 623-001 Switch		4			
1.5	50 kW	1.5 l	09/85→07/90					Unit, ignition system					
1.5	54 kW	1.5 l	10/82→08/85										
1.6	55 kW	1.6 l	10/82→07/88										
1.6	66 kW	1.6 l	07/84→08/87										
1.6	71 kW	1.6 l	10/82→06/84										
1.9	75 kW	1.9 l	10/82→08/85										
PEUGEOT - 305 II Break (581E)										10/82→12/88			
1.3	44 kW	1.3 l	10/82→08/86					5DA 006 623-001 Switch		4			
1.5	50 kW	1.5 l	09/85→10/86					Unit, ignition system					
1.5	54 kW	1.5 l	10/82→08/86										
1.6	54 kW	1.6 l	11/86→12/88										
1.6	55 kW	1.6 l	02/86→12/88										
1.6	66 kW	1.6 l	07/84→12/87										
1.6	71 kW	1.6 l	09/83→06/84										
1.9	75 kW	1.9 l	09/84→10/87										
PEUGEOT - 306 Break (7E, N3, N5)										03/97→04/02			
1.4	55 kW	1.4 l	03/97→04/02	→Orga 07874; CEE95		5DA 193 175-421 Ignition		13					
				⊗ KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95, 15-04		5DA 193 175-431 Ignition		14					
				⊗ KFW (TU3JP) / KFX (TU3JP); CEE 2000; L4									
				06/98→; ⊗ TU3JP		5DA 193 175-441 Ignition		14					
1.6	65 kW	1.6 l	03/97→10/00	→Orga 07874		5DA 193 175-421 Ignition		13					
				⊗ NFZ (TU5JP); Orga 07875→; L3		5DA 193 175-431 Ignition		14					
				⊗ NFZ (TU5JP); →04/97		5DA 193 175-721 Ignition		21					
1.8	74 kW	1.8 l	03/97→04/02			5DA 193 175-421 Ignition		13					
1.8 16V	81 kW	1.8 l	03/97→04/02	⊗ LFY (XU7JP4); Orga 07609→		5DA 193 175-451 Ignition		14					
				→09/97		5DA 358 000-301 Ignition		35					
2.0	97 kW	2 l	03/97→04/02	⊗ RFV (XU10J4R); Orga 07609→		5DA 193 175-451 Ignition		14					
				→09/97		5DA 358 000-301 Ignition		35					
PEUGEOT - 306 Convertible (7D, N3, N5)										03/94→04/02			
1.6	65 kW	1.6 l	04/96→10/00	→Orga 07874		5DA 193 175-421 Ignition		13					
				⊗ NFZ (TU5JP); Orga 07875→; L3		5DA 193 175-431 Ignition		14					
				⊗ NFZ (TU5JP); →04/97		5DA 193 175-721 Ignition		21					
1.8	74 kW	1.8 l	03/94→04/02			5DA 193 175-421 Ignition		13					
2.0	89 kW	2 l	03/94→04/02			Coil							
1.8 16V	81 kW	1.8 l	07/00→04/02	⊗ LFY (XU7JP4); Orga 07609→		5DA 193 175-451 Ignition		14					
2.0 16V	97 kW	2 l	03/97→04/02	⊗ RFV (XU10J4R); Orga 07609→		5DA 193 175-451 Ignition		14					
				→09/97		5DA 358 000-301 Ignition		35					
PEUGEOT - 306 Hatchback (7A, 7C, N3, N5)										05/93→05/01			
1.1	44 kW	1.1 l	05/93→05/01			5DA 193 175-421 Ignition		13					
				⊗ HDZ (TU1M)		5DA 193 175-721 Ignition		21					

				13	i	412			
PEUGEOT - 306 Hatchback (7A, 7C, N3, N5)							05/93→05/01		
1.4	55 kW	1.4 l	05/93→05/01	⊗ KFX, KFW; →Orga 07874; CEE95	5DA 193 175-421	Ignition	13	Coil	
				⊗ KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95, 15-04	5DA 193 175-431	Ignition	14	Coil	
				⊗ KFW (TU3JP) / KFX (TU3JP); CEE 2000; L4					
				06/98→; ⊗ TU3JP	5DA 193 175-441	Ignition	14	Coil	
				⊗ KDX (TU3MC)	5DA 193 175-721	Ignition	21	Coil	
1.6	65 kW	1.6 l	05/93→10/00	→Orga 07874	5DA 193 175-421	Ignition	13	Coil	
				⊗ NFZ (TU5JP); Orga 07875→; L3	5DA 193 175-431	Ignition	14	Coil	
				⊗ NFZ (TU5JP); →04/97	5DA 193 175-721	Ignition	21	Coil	
1.8	74 kW	1.8 l	05/93→05/01		5DA 193 175-421	Ignition	13	Coil	
2.0 XSi	89 kW	2 l	05/93→05/01						
1.8 16V	81 kW	1.8 l	03/97→05/01	⊗ LFY (XU7JP4); Orga 07609→	5DA 193 175-451	Ignition	14	Coil	
				→09/97	5DA 358 000-301	Ignition	35	Coil	
2.0 16V	97 kW	2 l	03/97→05/01	⊗ RFV (XU10J4R); Orga 07609→	5DA 193 175-451	Ignition	14	Coil	
				→09/97	5DA 358 000-301	Ignition	35	Coil	
PEUGEOT - 306 Saloon (7B, N3, N5)							06/94→05/01		
1.1	44 kW	1.1 l	06/94→05/01	⊗ HDZ (TU1M)	5DA 193 175-721	Ignition	21	Coil	
1.4 SL	55 kW	1.4 l	06/94→05/01	⊗ KFX, KFW; →Orga 07874; CEE95	5DA 193 175-421	Ignition	13	Coil	
				⊗ KFW (TU3JP) / KFX (TU3JP); Orga 07875→; CEE 95, 15-04	5DA 193 175-431	Ignition	14	Coil	
				⊗ KFW (TU3JP) / KFX (TU3JP); CEE 2000; L4					
				⊗ TU3JP; 06/98→	5DA 193 175-441	Ignition	14	Coil	
				⊗ KDX (TU3MC)	5DA 193 175-721	Ignition	21	Coil	
1.6 SR	65 kW	1.6 l	06/94→10/00	→Orga 07874	5DA 193 175-421	Ignition	13	Coil	
				⊗ NFZ (TU5JP); L3	5DA 193 175-431	Ignition	14	Coil	
				⊗ NFZ (TU5JP); →04/97	5DA 193 175-721	Ignition	21	Coil	
1.8 16V	81 kW	1.8 l	03/97→05/01	⊗ LFY (XU7JP4); Orga 07609→	5DA 193 175-451	Ignition	14	Coil	
				→09/97	5DA 358 000-301	Ignition	35	Coil	
1.8 ST	74 kW	1.8 l	06/94→05/01		5DA 193 175-421	Ignition	13	Coil	
2.0 ST	89 kW	2 l	07/94→05/01						
2.0	97 kW	2 l	03/97→05/01	⊗ RFV (XU10J4R); Orga 07609→	5DA 193 175-451	Ignition	14	Coil	
				→09/97	5DA 358 000-301	Ignition	35	Coil	
PEUGEOT - 307 (3A/C)							08/00→		
1.4	55 kW	1.4 l	08/00→	⊗ KFW (TU3JP)	5DA 193 175-441	Ignition	14	Coil	
1.6 16V	80 kW	1.6 l	08/00→	⊗ NFU (TU5JP4)	5DA 193 175-731	Ignition	22	Coil	
2.0 16V	103 kW	2 l	03/05→	⊗ RFJ (EW10A)	5DA 749 475-601	Ignition	40	Coil	
2.0 16V	130 kW	2 l	06/05→	⊗ RFK (EW10J4S)	5DA 749 475-611	Ignition	40	Coil	
PEUGEOT - 307 Break (3E)							03/02→09/03		
1.4	55 kW	1.4 l	04/02→09/03	⊗ KFW (TU3JP)	5DA 193 175-441	Ignition	14	Coil	
1.6 16V	80 kW	1.6 l	03/02→	⊗ NFU (TU5JP4)	5DA 193 175-731	Ignition	22	Coil	
2.0 16V	103 kW	2 l	03/05→	⊗ RFJ (EW10A)	5DA 749 475-601	Ignition	40	Coil	

PEUGEOT - 307 Break (3E)						03/02→09/03
2.0 16V	130 kW	2 l	06/05→	RFK (EW10J4S)	5DA 749 475-611 Ignition Coil	40
PEUGEOT - 307 CC (3B)						10/03→
1.6 16V	80 kW	1.6 l	02/05→	NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
2.0 16V	103 kW	2 l	03/05→	RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40
2.0 16V	130 kW	2 l	10/03→	RFK (EW10J4S)	5DA 749 475-611 Ignition Coil	40
PEUGEOT - 307 SW (3H)						03/02→09/03
1.4	55 kW	1.4 l	04/02→09/03	KFW (TU3JP)	5DA 193 175-441 Ignition Coil	14
1.6 16V	80 kW	1.6 l	03/02→	NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
2.0 16V	103 kW	2 l	03/05→	RFJ (EW10A)	5DA 749 475-601 Ignition Coil	40
PEUGEOT - 308 (4A_, 4C_)						09/07→
1.4 16V	70 kW	1.4 l	09/07→	EP3; 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	88 kW	1.6 l	09/07→	EP6; 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	103 kW	1.6 l	09/07→	5FT (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	110 kW	1.6 l	09/07→	5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	115 kW	1.6 l	10/09→	EP6CDT; 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	128 kW	1.6 l	03/08→	5FY (EP6DTS); 4x	5DA 193 175-491 Ignition Coil	15
1.6 BioFlex	80 kW	1.6 l	04/08→	NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
1.6 GTi	147 kW	1.6 l	07/10→	EP6CDTX; 4x	5DA 193 175-491 Ignition Coil	15
PEUGEOT - 308 CC						06/09→
1.6 16V	88 kW	1.6 l	06/09→	EP6; 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	103 kW	1.6 l	06/09→	5FT (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	110 kW	1.6 l	06/09→	5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	115 kW	1.6 l	06/09→	EP6CDT; 4x	5DA 193 175-491 Ignition Coil	15
1.6 THP	147 kW	1.6 l	10/10→	EP6CDTX; 4x	5DA 193 175-491 Ignition Coil	15
PEUGEOT - 308 SW Estate						09/07→
1.4 16V	70 kW	1.4 l	09/07→	8FS (EP3); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	88 kW	1.6 l	09/07→	EP6; 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	103 kW	1.6 l	09/07→	5FT (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	110 kW	1.6 l	09/07→	5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	115 kW	1.6 l	10/09→	EP6CDT; 4x	5DA 193 175-491 Ignition Coil	15
1.6 16V	128 kW	1.6 l	03/08→	5FY (EP6DTS); 4x	5DA 193 175-491 Ignition Coil	15
1.6 Bioflex	82 kW	1.6 l	03/09→	NFU (TU5JP4)	5DA 193 175-731 Ignition Coil	22
PEUGEOT - 309 I (10C, 10A)						10/85→07/89
1.1	40 kW	1.1 l	10/85→07/89	Carburettor	5DA 006 623-001 Switch Unit, ignition system	4
1.3	47 kW	1.3 l	10/85→07/89			
1.4	49 kW	1.4 l	03/89→07/89		5DA 006 623-041 Switch Unit, ignition system	4
1.4	62 kW	1.4 l	03/89→07/89			
1.6	53 kW	1.6 l	08/87→07/89		5DA 006 623-001 Switch Unit, ignition system	4
1.6	76 kW	1.6 l	11/85→09/88			
1.9	72 kW	1.9 l	03/86→07/89			
1.9 GTI	94 kW	1.9 l	10/86→07/89			

				13	i	412		
PEUGEOT - 309 I (10C, 10A)								10/85→07/89
1.6	55 kW	1.6 l	10/85→07/89				5DA 006 623-001 Switch Unit, ignition system	4
							5DA 006 623-041 Switch Unit, ignition system	4
1.9	75 kW	1.9 l	10/85→07/89	XU92C			5DA 006 623-001 Switch Unit, ignition system	4
PEUGEOT - 309 II (3C, 3A)								07/89→12/93
1.1	44 kW	1.1 l	08/90→12/93	10/90→			5DA 006 623-041 Switch Unit, ignition system	4
1.4	55 kW	1.4 l	07/89→12/93				5DA 006 623-041 Switch Unit, ignition system	4
1.6	68 kW	1.6 l	07/89→12/93				5DA 006 623-041 Switch Unit, ignition system	4
1.6	65 kW	1.6 l	07/89→12/93	BDY; 01/91→			5DA 193 175-421 Ignition Coil	13
1.9	72 kW	1.9 l	08/89→12/93				5DA 006 623-001 Switch Unit, ignition system	4
1.9 GTI	88 kW	1.9 l	07/89→12/93				5DA 006 623-001 Switch Unit, ignition system	4
1.9 GTI 16V	116 kW	1.9 l	08/89→07/90				5DA 006 623-001 Switch Unit, ignition system	4
PEUGEOT - 405 I Break (15E)								10/88→08/92
1.6	53 kW	1.6 l	10/88→08/92				5DA 006 623-001 Switch Unit, ignition system	4
							5DA 006 623-041 Switch Unit, ignition system	4
1.6	55 kW	1.6 l	10/88→08/92				5DA 006 623-041 Switch Unit, ignition system	4
1.6	66 kW	1.6 l	10/88→08/92				5DA 006 623-041 Switch Unit, ignition system	4
1.9	80 kW	1.9 l	10/88→08/92				5DA 006 623-041 Switch Unit, ignition system	4
1.6	65 kW	1.6 l	10/88→08/92				5DA 006 623-041 Switch Unit, ignition system	4
				BDY; 70119981→			5DA 193 175-421 Ignition Coil	13
1.9	70 kW	1.9 l	10/88→08/92				5DA 006 623-001 Switch Unit, ignition system	4
1.9	77 kW	1.9 l	10/88→08/92				5DA 006 623-041 Switch Unit, ignition system	4
				Automatic Transmission			5DA 006 623-041 Switch Unit, ignition system	4
1.9	88 kW	1.9 l	10/88→08/92	Automatic Transmission			5DA 006 623-041 Switch Unit, ignition system	4
PEUGEOT - 405 I Saloon (15B)								07/87→12/92
1.6	53 kW	1.6 l	07/87→12/92				5DA 006 623-001 Switch Unit, ignition system	4
1.6	55 kW	1.6 l	07/87→06/88	Carburettor			5DA 006 623-001 Switch Unit, ignition system	4
							5DA 006 623-041 Switch Unit, ignition system	4
1.6	65 kW	1.6 l	07/87→12/92				5DA 006 623-041 Switch Unit, ignition system	4
				BDY; 70119981→			5DA 193 175-421 Ignition Coil	13
1.6	66 kW	1.6 l	10/89→12/92				5DA 006 623-041 Switch Unit, ignition system	4
1.9 4x4	80 kW	1.9 l	07/88→12/92				5DA 006 623-041 Switch Unit, ignition system	4
1.9 Sport MI-16	108 kW	1.9 l	04/88→12/92				5DA 006 623-041 Switch Unit, ignition system	4
1.9 SPort MI-16 4x4	108 kW	1.9 l	04/88→12/92				5DA 006 623-041 Switch Unit, ignition system	4
1.9	70 kW	1.9 l	07/87→12/92				5DA 006 623-001 Switch Unit, ignition system	4
1.9 Injection	77 kW	1.9 l	07/87→12/92				5DA 006 623-041 Switch Unit, ignition system	4
1.9 Sport MI-16	116 kW	1.9 l	07/87→11/91				5DA 006 623-041 Switch Unit, ignition system	4
1.9	80 kW	1.9 l	07/88→12/92	→09/92			5DA 006 623-041 Switch Unit, ignition system	4
1.9	88 kW	1.9 l	07/88→12/92	Automatic Transmission			5DA 006 623-041 Switch Unit, ignition system	4
PEUGEOT - 405 II Break (4E)								08/92→10/96
1.4	55 kW	1.4 l	08/92→10/96				5DA 006 623-041 Switch Unit, ignition system	4
2.0	89 kW	2 l	08/92→10/96				5DA 006 623-041 Switch Unit, ignition system	4
1.6	65 kW	1.6 l	08/92→10/96				5DA 006 623-041 Switch Unit, ignition system	4
1.8	74 kW	1.8 l	08/92→10/96				5DA 006 623-041 Switch Unit, ignition system	4
2.0 4x4	89 kW	2 l	08/92→10/96				5DA 193 175-421 Ignition Coil	13
PEUGEOT - 405 II Saloon (4B)								08/92→10/95
1.4	55 kW	1.4 l	08/92→10/95				5DA 006 623-041 Switch Unit, ignition system	4
2.0 T 16 X4	144 kW	2 l	08/92→10/95				5DA 006 623-041 Switch Unit, ignition system	4

				13	i	412			
PEUGEOT - 405 II Saloon (4B)								08/92→10/95	
1.6	65 kW	1.6 l	08/92→10/95				5DA 006 623-041 Switch Unit, ignition system	4	
1.8	74 kW	1.8 l	08/92→10/95						
2.0	89 kW	2 l	08/92→10/95				5DA 193 175-421 Ignition Coil	13	
2.0 X4	89 kW	2 l	08/92→10/95						
2.0 MI-16	112 kW	2 l	08/92→10/95	01/93→			5DA 006 623-601 Switch Unit, ignition system	8	
PEUGEOT - 406 Break (8E/F)								10/96→10/04	
1.8	66 kW	1.8 l	05/97→10/04				5DA 193 175-421 Ignition Coil	13	
1.8 16V	81 kW	1.8 l	10/96→10/00	LFY (XU7JP4); Orga 07609→			5DA 193 175-451 Ignition Coil	14	
				→09/97			5DA 358 000-301 Ignition Coil	35	
2.0 16V	97 kW	2 l	10/96→10/04	RFV (XU10J4R); Orga 07637→			5DA 193 175-451 Ignition Coil	14	
				→09/97			5DA 358 000-301 Ignition Coil	35	
2.0 Turbo	108 kW	2 l	10/96→10/04				5DA 006 623-601 Switch Unit, ignition system	8	
							5DA 193 175-421 Ignition Coil	13	
2.2	116 kW	2.2 l	07/00→10/04	3FZ (EW12J4)			5DA 749 475-611 Ignition Coil	40	
PEUGEOT - 406 Coupe (8C)								03/97→12/04	
2.0 16V	97 kW	2 l	03/97→12/04	RFV (XU10J4R); Orga 07637→			5DA 193 175-451 Ignition Coil	14	
				→09/97			5DA 358 000-301 Ignition Coil	35	
2.2	116 kW	2.2 l	03/02→12/04	3FZ (EW12J4)			5DA 749 475-611 Ignition Coil	40	
PEUGEOT - 406 Saloon (8B)								11/95→05/04	
1.6	65 kW	1.6 l	11/95→05/04				5DA 193 175-421 Ignition Coil	13	
1.8	66 kW	1.8 l	05/97→05/04						
2.0 Turbo	108 kW	2 l	04/96→05/04						
1.8 16V	81 kW	1.8 l	11/95→10/00	LFY (XU7JP4); Orga 07609→			5DA 193 175-451 Ignition Coil	14	
				→09/97			5DA 358 000-301 Ignition Coil	35	
2.0 16V	97 kW	2 l	11/95→05/04	RFV (XU10J4R); Orga 07637→			5DA 193 175-451 Ignition Coil	14	
				→09/97			5DA 358 000-301 Ignition Coil	35	
2.2	116 kW	2.2 l	07/00→05/04	3FZ (EW12J4)			5DA 749 475-611 Ignition Coil	40	
PEUGEOT - 407 Coupe (6C_)								10/05→	
2.2 16V	120 kW	2.2 l	10/05→	3FY (EW12J4); CEE 2000			5DA 749 475-611 Ignition Coil	40	
PEUGEOT - 407 Saloon (6D_)								05/04→	
1.8 16V	92 kW	1.8 l	09/05→	6FY (EW7A)			5DA 749 475-601 Ignition Coil	40	
2.0 16V	103 kW	2 l	09/05→	RFJ (EW10A)			5DA 749 475-601 Ignition Coil	40	
2.2	116 kW	2.2 l	05/04→	3FZ (EW12J4); CEE 2000			5DA 749 475-611 Ignition Coil	40	
2.2 16V	120 kW	2.2 l	09/05→	CEE 2000; 3FY (EW12J4)			5DA 749 475-611 Ignition Coil	40	
PEUGEOT - 407 SW (6E_)								05/04→	
1.8 16V	92 kW	1.8 l	09/05→	6FY (EW7A)			5DA 749 475-601 Ignition Coil	40	
2.0 16V	103 kW	2 l	09/05→	RFJ (EW10A)			5DA 749 475-601 Ignition Coil	40	
2.2	116 kW	2.2 l	05/04→	3FZ (EW12J4); CEE 2000			5DA 749 475-611 Ignition Coil	40	
2.2 16V	120 kW	2.2 l	09/05→	3FY (EW12J4); CEE 2000			5DA 749 475-611 Ignition Coil	40	

PEUGEOT - 504 Break (D_, F_)						04/71→07/86
2.0 (D11, F11)	68 kW	2 l	04/71→07/86		5DA 006 623-001 Switch Unit, ignition system	4
PEUGEOT - 504 Saloon (A_, M_)						03/71→06/86
2.0 (A1, A13, MY1, MY3)	71 kW	2 l	03/71→06/86		5DA 006 623-001 Switch Unit, ignition system	4
PEUGEOT - 505 (551A)						08/79→09/95
1.8	55 kW	1.8 l	06/81→10/85		5DA 006 623-001 Switch Unit, ignition system	4
1.8	60 kW	1.8 l	01/82→10/85			
2.0	71 kW	2 l	11/80→12/85			
2.0	72 kW	2 l	09/85→09/95			
2.0 TI,STI	81 kW	2 l	08/79→10/86			
2.2	85 kW	2.2 l	05/81→10/84			
2.2 Turbo Injection	114 kW	2.2 l	03/84→10/88			
1.8	62 kW	1.8 l	09/85→10/86	XM7A	5DA 006 623-001 Switch Unit, ignition system	4
2.2 Turbo Injection	128 kW	2.2 l	06/87→12/88	→10/88	5DA 006 623-001 Switch Unit, ignition system	4
PEUGEOT - 505 Break (551D)						08/83→11/87
2.0	69 kW	2 l	08/83→12/85		5DA 006 623-001 Switch Unit, ignition system	4
2.0	72 kW	2 l	09/85→11/87			
PEUGEOT - 508						11/10→
1.6 THP	115 kW	1.6 l	11/10→	EP6CDT; 4x	5DA 193 175-491 Ignition Coil	15
1.6 VTi	88 kW	1.6 l	11/10→	5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15
PEUGEOT - 508 SW						11/10→
1.6 THP	115 kW	1.6 l	11/10→	EP6CDT; 4x	5DA 193 175-491 Ignition Coil	15
1.6 VTi	88 kW	1.6 l	11/10→	5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil	15
PEUGEOT - 605 Saloon (6B)						06/89→09/99
2.0	89 kW	2 l	06/89→09/99	→07/91	5DA 006 623-001 Switch Unit, ignition system	4
				Manual Transmission	5DA 193 175-421 Ignition Coil	13
2.0 16V	97 kW	2 l	07/94→09/99		5DA 193 175-421 Ignition Coil	13
				RFV (XU10J4R); Orga 07609→	5DA 193 175-451 Ignition Coil	14
				→09/97	5DA 358 000-301 Ignition Coil	35
2.0 Turbo	104 kW	2 l	07/92→09/99		5DA 006 623-601 Switch Unit, ignition system	8
					5DA 193 175-421 Ignition Coil	13
2.0 Turbo	108 kW	2 l	07/91→09/99	07/94→	5DA 006 623-601 Switch Unit, ignition system	8
					5DA 193 175-421 Ignition Coil	13
3.0	123 kW	3 l	10/89→09/99	07/93→	5DA 006 623-191 Switch Unit, ignition system	5
3.0 SV 24	147 kW	3 l	08/89→09/99			
PEUGEOT - 607 Saloon (9D, 9U)						02/00→
2.2 16V	116 kW	2.2 l	02/00→	3FZ (EW12J4); L5	5DA 749 475-611 Ignition Coil	40
PEUGEOT - 806 (221)						06/94→08/02
1.8	73 kW	1.8 l	07/95→08/02		5DA 193 175-421 Ignition Coil	13
2.0	89 kW	2 l	06/94→08/02			
2.0 16V	97 kW	2 l	05/98→09/00	RFV (XU10J4R)	5DA 193 175-451 Ignition Coil	14
2.0 Turbo	108 kW	2 l	06/94→08/02		5DA 006 623-601 Switch Unit, ignition system	8
					5DA 193 175-421 Ignition Coil	13

										13		412	
PEUGEOT - 807 (E)													06/02 →
2.0 16V	103 kW	2 l	09/05→		RFJ (EW10A)	5DA 749 475-601 Ignition Coil						40	
2.2	116 kW	2.2 l	06/02→		3FZ (EW12J4)	5DA 749 475-611 Ignition Coil						40	
PEUGEOT - 1007 (KM_)													04/05 →
1.4	54 kW	1.4 l	04/05→		KFV (TU3JP)	5DA 193 175-441 Ignition Coil						14	
1.6 16V	80 kW	1.6 l	04/05→		NFU (TU5JP4)	5DA 193 175-731 Ignition Coil						22	
PEUGEOT - 3008													06/09 →
1.6 THP	110 kW	1.6 l	06/09→		5FX (EP6DT); 4x	5DA 193 175-491 Ignition Coil						15	
1.6 THP	115 kW	1.6 l	06/09→		5FV (EP6DT); 4x	5DA 193 175-491 Ignition Coil						15	
1.6 VTi	88 kW	1.6 l	06/09→		EP6 / 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil						15	
PEUGEOT - 5008													09/09 →
1.6 16V	88 kW	1.6 l	09/09→		EP6 / 5FS (EP6C); 4x	5DA 193 175-491 Ignition Coil						15	
1.6 16V	115 kW	1.6 l	09/09→		EP6CDT; 4x	5DA 193 175-491 Ignition Coil						15	
PEUGEOT - BOXER Box (230L)													06/94 → 04/02
2.0 i	80 kW	2 l	06/94→04/02			5DA 193 175-421 Ignition Coil						13	
PEUGEOT - BOXER Box (244)													04/02 →
2.0	81 kW	2 l	04/02→		RFL (XU10J2U)	5DA 193 175-421 Ignition Coil						13	
PEUGEOT - BOXER Bus (230P)													03/94 → 04/02
2.0 i	80 kW	2 l	03/94→04/02			5DA 193 175-421 Ignition Coil						13	
2.0 i 4x4	80 kW	2 l	08/96→04/02										
PEUGEOT - BOXER Platform/Chassis (ZCT_)													06/94 → 04/02
2.0 i	80 kW	2 l	06/94→04/02			5DA 193 175-421 Ignition Coil						13	
PEUGEOT - EXPERT (224)													02/96 →
1.6	58 kW	1.6 l	02/96→		222A2 (1580 SPI)	5DA 193 175-691 Ignition Coil						20	
PEUGEOT - EXPERT Box (222)													02/96 →
1.6	58 kW	1.6 l	02/96→		222A2 (1580 SPI)	5DA 193 175-691 Ignition Coil						20	
PEUGEOT - EXPERT Box (VF3A_, VF3U_, VF3X_)													01/07 →
2.0 16V	103 kW	2 l	01/07→		RFJ (EW10A)	5DA 749 475-601 Ignition Coil						40	
PEUGEOT - EXPERT Platform/Chassis (223)													02/96 →
1.6	58 kW	1.6 l	02/96→		222A2 (1580 SPI)	5DA 193 175-691 Ignition Coil						20	
PEUGEOT - EXPERT Tepee (VF3V_)													01/07 →
2.0 16V	103 kW	2 l	01/07→		RFJ (EW10A)	5DA 749 475-601 Ignition Coil						40	
PEUGEOT - J5 Box (280L)													01/83 → 11/88
1.8	51 kW	1.8 l	01/83→11/88			5DA 006 623-001 Switch Unit, ignition system						4	
PEUGEOT - J5 Bus (280P)													09/81 → 09/90
2.0	55 kW	2 l	09/81→09/90			5DA 006 623-001 Switch Unit, ignition system						4	
2.0	58 kW	2 l	01/83→09/90										
PEUGEOT - J5 Bus (290P)													10/90 → 02/94
2.0	62 kW	2 l	10/90→02/94	→12/93			5DA 006 623-001 Switch Unit, ignition system				4		

PEUGEOT - J5 Platform/Chassis (280L)						01/83→11/88
2.0	55 kW	2 l	01/86→11/88		5DA 006 623-001 Switch	4
2.0	58 kW	2 l	01/83→11/88		Unit, ignition system	
PEUGEOT - J5 Platform/Chassis (290L)						10/90→02/94
2.0	62 kW	2 l	10/90→02/94	→12/93	5DA 006 623-001 Switch	4
						Unit, ignition system
PEUGEOT - J9 Box						03/80→06/87
1.6	44 kW	1.6 l	03/80→06/87	10/80→	5DA 006 623-001 Switch	4
2.0	57 kW	2 l	03/80→06/87		Unit, ignition system	
PEUGEOT - J9 Bus						03/80→06/87
2.0	57 kW	2 l	03/80→06/87	10/80→	5DA 006 623-001 Switch	4
						Unit, ignition system
PEUGEOT - J9 Platform/Chassis						03/80→06/87
2.0	57 kW	2 l	03/80→06/87	10/80→	5DA 006 623-001 Switch	4
						Unit, ignition system
PEUGEOT - PARTNER Box						04/08→
1.6	66 kW	1.6 l	04/08→	⊗ NFR (TU5JP4B)	5DA 193 175-731 Ignition	22
						Coil
1.6	80 kW	1.6 l	04/08→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition	22
						Coil
PEUGEOT - PARTNER Box (5)						06/96→
1.1	44 kW	1.1 l	06/96→		5DA 193 175-421 Ignition	13
						Coil
1.4	55 kW	1.4 l	06/96→	→Orga 07874; CEE95, CEE W2	5DA 193 175-421 Ignition	13
						Coil
						⊗ KFX (TU3JP); CEE 95, 15-04
						5DA 193 175-431 Ignition
						Coil
						⊗ KFX (TU3JP); CEE 2000 / L4, W4
						5DA 193 175-441 Ignition
						Coil
1.4 BiFuel	55 kW	1.4 l	04/03→	⊗ KFW (TU3JP)	5DA 193 175-441 Ignition	14
						Coil
PEUGEOT - PARTNER Combispacer (5F)						06/96→
1.1	44 kW	1.1 l	06/96→	⊗ HDZ	5DA 193 175-421 Ignition	13
						Coil
						⊗ HFX (TU1JP)
						5DA 193 175-441 Ignition
						Coil
1.4	55 kW	1.4 l	06/96→	→Orga 07874; CEE95, CEE W2	5DA 193 175-421 Ignition	13
						Coil
						⊗ KFW (TU3JP) / KFX (TU3JP); Orga
						07875→; CEE 95, 15-04
						5DA 193 175-431 Ignition
						Coil
						⊗ KFW (TU3JP) / KFX (TU3JP); CEE 2000;
						L4, W4
						5DA 193 175-441 Ignition
						Coil
1.6 16V	80 kW	1.6 l	07/01→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition	22
						Coil
1.8	66 kW	1.8 l	05/97→		5DA 193 175-421 Ignition	13
						Coil
PEUGEOT - PARTNER Tepee						04/08→
1.6	66 kW	1.6 l	04/08→	⊗ NFR (TU5JP4B)	5DA 193 175-731 Ignition	22
						Coil
1.6	80 kW	1.6 l	04/08→	⊗ NFU (TU5JP4)	5DA 193 175-731 Ignition	22
						Coil
1.6	88 kW	1.6 l	04/10→	⊗ 5FS (EP6C); 4x	5DA 193 175-491 Ignition	15
						Coil
PEUGEOT - RCZ						03/10→
1.6 16V	115 kW	1.6 l	03/10→	⊗ EP6CDT; 4x	5DA 193 175-491 Ignition	15
						Coil
1.6 16V	147 kW	1.6 l	06/10→	⊗ EP6CDTX; 4x	5DA 193 175-491 Ignition	15
						Coil

PORSCHE - 911 (964)				12/88→09/93		
3.6 Carrera	184 kW	3.6 l	07/89→09/93	08/89→	5DA 006 623-191 Switch Unit, ignition system	5
3.6 Carrera 4	184 kW	3.6 l	12/88→09/93		5DA 006 623-191 Switch Unit, ignition system	5
PORSCHE - 911 (993)				10/93→09/97		
3.6 Carrera	200 kW	3.6 l	10/93→08/95		5DA 006 623-601 Switch Unit, ignition system	8
3.8 Carrera 4	221 kW	3.8 l	08/95→09/97			
3.6 Carrera 4	200 kW	3.6 l	07/94→08/95	09/94→; M64.05	5DA 006 623-601 Switch Unit, ignition system	8
3.6 Carrera 4	210 kW	3.6 l	08/95→09/97	M64.21	5DA 006 623-601 Switch Unit, ignition system	8
3.8 Carrera RS	221 kW	3.8 l	06/95→09/97	M64.20	5DA 006 623-601 Switch Unit, ignition system	8
PORSCHE - 911 Convertible (964)				05/89→05/94		
3.6 Carrera 4	184 kW	3.6 l	05/89→05/94		5DA 006 623-191 Switch Unit, ignition system	5
PORSCHE - 911 Convertible (993)				07/94→09/97		
3.6 Carrera 4	200 kW	3.6 l	07/94→08/95	M64.05	5DA 006 623-601 Switch Unit, ignition system	8
3.6 Carrera 4	210 kW	3.6 l	08/95→09/97	M64.21	5DA 006 623-601 Switch Unit, ignition system	8
PORSCHE - 911 Targa (993)				08/95→09/97		
3.6 Carrera	210 kW	3.6 l	08/95→09/97		5DA 006 623-601 Switch Unit, ignition system	8
PORSCHE - 928				09/85→11/95		
5.0 S	212 kW	5 l	09/85→12/86	→07/86	5DA 006 623-191 Switch Unit, ignition system	5
5.4 GTS	257 kW	5.4 l	08/91→11/95		5DA 006 623-191 Switch Unit, ignition system	5
PORSCHE - 944				08/86→07/91		
2.5 S	140 kW	2.5 l	08/86→07/88		5DA 006 623-191 Switch Unit, ignition system	5
2.7	121 kW	2.7 l	11/88→08/89			
3.0 S2	155 kW	3 l	12/88→07/91			
PORSCHE - 944 Convertible				12/88→07/91		
3.0 S2	155 kW	3 l	12/88→07/91		5DA 006 623-191 Switch Unit, ignition system	5

				13		412	
PUCH - G-MODELL (W 463)							09/94→12/97
G 320	155 kW	3.2 l	09/94→12/97	3x	5DA 193 175-361 Ignition Coil	11	
G 500	218 kW	5 l	04/98→	M 113.962; 8x	5DA 193 175-991 Ignition Coil	30	



RENAULT - 11 (B/C37_)				04/84→12/88		
1.4 Turbo (B/C375)	77 kW	1.4 l	04/84→12/86		5DA 006 623-051 Switch	4
1.4 Turbo (B/C375)	85 kW	1.4 l	10/86→12/88		Unit, ignition system	
RENAULT - 18 Saloon (134_)				10/82→07/86		
1.6 Turbo (1345)	92 kW	1.6 l	10/82→07/86	01/83→	5DA 006 623-051 Switch	4
					Unit, ignition system	
RENAULT - 18 Variable (135_)				10/82→07/86		
1.6 Turbo	92 kW	1.6 l	10/82→07/86	01/83→	5DA 006 623-051 Switch	4
					Unit, ignition system	
RENAULT - 19 I (B/C53_)				09/88→04/92		
1.4 (B/C532) CAT	43 kW	1.4 l	01/89→04/92		5DA 006 623-671 Ignition	9
1.4 (B/C53P)	43 kW	1.4 l	01/89→12/89		Coil	
1.7 (B/C53B)	54 kW	1.7 l	09/88→04/92			
1.7 (B/C53C)	66 kW	1.7 l	09/88→04/92			
RENAULT - 19 II (B/C53_)				01/92→12/95		
1.4 (B/C532)	43 kW	1.4 l	04/92→12/95		5DA 006 623-671 Ignition	9
1.4 (B/C535)	55 kW	1.4 l	01/92→12/95		Coil	
1.7 (B/C53B)	54 kW	1.7 l	04/92→12/95			
1.8 (5/353F, B/C538)	79 kW	1.8 l	05/94→12/95			
1.8 16V (B/C53D)	99 kW	1.8 l	04/92→12/95			
1.8 (5/353A)	66 kW	1.8 l	04/92→12/95		5DA 006 623-231 Switch	5
					Unit, ignition system	
					5DA 006 623-671 Ignition	9
					Coil	
				F3P 760	5DA 358 000-061 Ignition	32
					Coil	
1.8 (B/C538)	81 kW	1.8 l	04/92→05/94		5DA 006 623-231 Switch	5
					Unit, ignition system	
					5DA 006 623-671 Ignition	9
					Coil	
1.8 (B/C53Y)	65 kW	1.8 l	04/92→12/95		5DA 006 623-231 Switch	5
					Unit, ignition system	
					5DA 006 623-671 Ignition	9
					Coil	
				F3P 708 / F3P 760	5DA 358 000-061 Ignition	32
					Coil	
RENAULT - 19 II Cabriolet (D53_, 853_)				04/92→06/96		
1.8 (853A)	66 kW	1.8 l	09/93→06/96		5DA 006 623-231 Switch	5
1.8 (D53Y)	65 kW	1.8 l	04/92→06/96		Unit, ignition system	
					5DA 006 623-671 Ignition	9
					Coil	
RENAULT - 19 II Chamade (L53_)				04/92→12/95		
1.8 (453A/F)	66 kW	1.8 l	04/92→12/95		5DA 006 623-231 Switch	5
1.8 (L538)	81 kW	1.8 l	04/92→05/94		Unit, ignition system	
1.8 (L53Y)	65 kW	1.8 l	04/92→12/95		5DA 006 623-671 Ignition	9
					Coil	
RENAULT - 21 (B48_)				09/89→06/94		
1.7 (B48E)	66 kW	1.7 l	09/89→06/94	04/92→	5DA 006 623-231 Switch	5
2.0 (B48R/Y)	99 kW	2 l	02/90→10/92		Unit, ignition system	
2.0 4x4 (B48R/Y)	99 kW	2 l	09/90→10/92			
RENAULT - 21 Estate (K48_)				06/86→02/94		
1.7 (K48E)	66 kW	1.7 l	10/89→12/93	04/92→	5DA 006 623-231 Switch	5
2.0 (K48R)	99 kW	2 l	06/90→02/94		Unit, ignition system	
2.0 (K483)	85 kW	2 l	06/86→12/88	07/86→	5DA 006 623-231 Switch	5
					Unit, ignition system	
RENAULT - 21 Saloon (L48_)				03/86→06/94		
1.7 (L48E)	66 kW	1.7 l	09/89→02/94	04/92→	5DA 006 623-231 Switch	5
2.0 (L48R)	99 kW	2 l	02/90→06/94		Unit, ignition system	
2.0 4x4 (L48R)	99 kW	2 l	12/89→02/94			
1.7 (L48E)	69 kW	1.7 l	03/86→02/94	08/86→	5DA 006 623-671 Ignition	9
					Coil	
2.0 (L483)	85 kW	2 l	03/86→12/88	07/86→	5DA 006 623-231 Switch	5
					Unit, ignition system	
				07/86→	5DA 006 623-671 Ignition	9
					Coil	
2.0 Turbo (L485)	129 kW	2 l	04/87→03/90	06/87→06/88	5DA 006 623-671 Ignition	9
					Coil	

				13	i	412			
RENAULT - 21 Saloon (L48_)							03/86→06/94		
2.0 Turbo (L48L)	119 kW	2 l	02/90→10/92	04/92→	5DA 006 623-231 Switch Unit, ignition system		5		
2.0 Turbo 4x4 (L48L)	119 kW	2 l	02/90→10/92	⊗ J7R 756; 07/91→	5DA 193 175-881 Ignition Coil		26		
RENAULT - 25 (B29_)							04/84→05/90		
2.2 (B29E)	89 kW	2.2 l	04/84→12/89	01/85→; Automatic Transmission	5DA 006 623-671 Ignition Coil		9		
2.2 (B29E)	91 kW	2.2 l	04/84→12/89						
2.4 V6 Turbo (B295)	133 kW	2.4 l	10/84→05/90	01/85→	5DA 006 623-231 Switch Unit, ignition system		5		
				01/85→	5DA 006 623-671 Ignition Coil		9		
2.8 V6 Injection (B29A)	100 kW	2.8 l	06/86→02/88		5DA 006 623-231 Switch Unit, ignition system		5		
				06/87→	5DA 006 623-671 Ignition Coil		9		
RENAULT - CLIO I (B/C57_, 5/357_)							05/90→09/98		
1.2 (5/357Y, 5/357K)	40 kW	1.2 l	01/96→09/98		5DA 358 000-251 Ignition Coil		34		
1.2 (5/357Y, 5/357K)	43 kW	1.2 l	01/96→09/98						
1.2 (B/C/S577)	40 kW	1.2 l	01/96→12/96		5DA 358 000-061 Ignition Coil		32		
1.2 (B/C/S57A, B/C57S, 5/357F, 5/357J, 5/357L, 5/357R)	43 kW	1.2 l	05/90→09/98	07/93→; ⊗ E7F700 / E7F708	5DA 006 623-231 Switch Unit, ignition system		5		
1.2 (B/C57R)	40 kW	1.2 l	01/91→06/96	07/93→	5DA 006 623-231 Switch Unit, ignition system		5		
1.4 (B/C57T, B/C57Y)	58 kW	1.4 l	01/91→09/98						
1.8 Rsi (B/C579)	80 kW	1.8 l	01/93→08/95						
1.8 (B/C578)	66 kW	1.8 l	08/94→09/98	⊗ F3P755	5DA 006 623-231 Switch Unit, ignition system		5		
1.8 (B/C57C, B/C57U)	65 kW	1.8 l	01/91→09/98	07/93→; ⊗ F3P710	5DA 006 623-231 Switch Unit, ignition system		5		
1.8 16V (C57D)	99 kW	1.8 l	01/91→03/96	07/93→	5DA 006 623-231 Switch Unit, ignition system		5		
				07/93→;	5DA 006 623-671 Ignition Coil		9		
1.8 Rsi (B/C57H)	79 kW	1.8 l	08/95→09/98		5DA 006 623-231 Switch Unit, ignition system		5		
Williams (B/C57M)	108 kW	2 l	01/94→09/98						
RENAULT - CLIO II (BB0/1/2_, CB0/1/2_)							09/98→05/05		
1.2	55 kW	1.2 l	06/01→10/03	⊗ D4D 700 / D4F 706	5DA 193 175-821 Ignition Coil		24		
1.2 (BB0A, BB0F, BB10, BB1K, BB28, BB2D, BB2H, CB0A...)	43 kW	1.2 l	09/98→	⊗ D7F 720/726; 11/98→	5DA 193 175-391 Ignition Coil		12		
				⊗ D7F 720 / D7F 726; →engine 981021	5DA 358 000-251 Ignition Coil		34		
1.2 (BB0A, CB0A)	44 kW	1.2 l	03/99→05/01	→engine 981021	5DA 358 000-251 Ignition Coil		34		
1.2 16V (BB05, BB0W, BB11, BB27, BB2T, BB2U, BB2V, CB05...)	55 kW	1.2 l	06/01→	⊗ D4F 712	5DA 193 175-821 Ignition Coil		24		
				⊗ D4F 728	5DA 193 175-831 Ignition Coil		25		
				⊗ D4F 722	5DA 193 175-831 Ignition Coil		25		
1.4 (B/CB0C)	55 kW	1.4 l	09/98→05/05	⊗ E7J 780	5DA 749 475-111 Ignition Coil		37		
				⊗ E7J 780	5DA 749 475-211 Ignition Coil		38		
1.6 (B/CB0D)	66 kW	1.6 l	09/98→05/05	⊗ K7M 745 / K7M 744	5DA 749 475-111 Ignition Coil		37		
				⊗ K7M 744 / K7M 745	5DA 749 475-211 Ignition Coil		38		
2.0 16V Sport	132 kW	2 l	01/04→		5DA 358 000-251 Ignition Coil		34		
2.0 16V Sport (CB0M)	124 kW	2 l	02/00→						
RENAULT - CLIO III (BR0/1, CR0/1)							06/05→		
1.2 16V	58 kW	1.2 l	06/05→	⊗ D4F 764	5DA 193 175-831 Ignition Coil		25		
1.2 16V (BR02, BR0J, BR11, CR02, CR0J, CR11)	55 kW	1.2 l	06/05→	⊗ D4F 740	5DA 193 175-831 Ignition Coil		25		
1.2 16V (BR0R, BR1D, BR1L, CR0R)	48 kW	1.2 l	06/05→						
1.2 16V (BR0P, CR0P)	74 kW	1.2 l	05/07→	⊗ D4F 784	5DA 193 175-391 Ignition Coil		12		

				13	i	412	
RENAULT - CLIO III (BR0/1, CR0/1)							06/05→
1.2 16V Hi-Flex (BR1U, CR1U)	55 kW	1.2 l	07/08→		D4F 740 / D4F 742	5DA 193 175-831 Ignition Coil	25
RENAULT - CLIO IV							11/12→
1.2 16V	54 kW	1.2 l	11/12→		D4F 740	5DA 193 175-831 Ignition Coil	25
RENAULT - CLIO Grandtour (KR0/1_)							02/08→
1.2 16V (KR02, KR0J)	55 kW	1.2 l	02/08→		D4F 740	5DA 193 175-831 Ignition Coil	25
1.2 16V Hi-Flex (KR0S)	55 kW	1.2 l	07/08→				
1.2 16V (KR0E)	58 kW	1.2 l	02/08→		D4F 764	5DA 193 175-831 Ignition Coil	25
RENAULT - CLIO Grandtour IV							01/13→
1.2 16V	54 kW	1.2 l	01/13→		D4F 740	5DA 193 175-831 Ignition Coil	25
RENAULT - ESPACE I (J11_)							07/86→12/92
2.0 i (J116)	87 kW	2 l	01/89→12/90			5DA 006 623-231 Switch Unit, ignition system	5
2.0 i Quadra (J116)	87 kW	2 l	03/88→12/92			5DA 006 623-671 Ignition Coil	9
2.2 (J117)	79 kW	2.2 l	07/86→12/90			5DA 006 623-231 Switch Unit, ignition system	5
2.2 Quadra (J117)	79 kW	2.2 l	01/88→12/90				
RENAULT - ESPACE II (J/S63_)							01/91→12/96
2.0 (J636)	76 kW	2 l	01/91→10/96	07/91→		5DA 006 623-231 Switch Unit, ignition system	5
				07/91→;		5DA 006 623-671 Ignition Coil	9
2.2 4x4 (J/S637, J63G)	79 kW	2.2 l	03/91→12/96	07/91→;	J7T 772	5DA 006 623-231 Switch Unit, ignition system	5
2.8 V6 (J638, J63J)	110 kW	2.8 l	01/91→10/96	07/91→;	J7W 712	5DA 006 623-231 Switch Unit, ignition system	5
RENAULT - ESPACE III (JE0_)							11/96→10/00
2.0 (JE0A)	84 kW	2 l	11/96→10/00		F3R 768 / F3R 742 / F3R 728 / F3R 729 / F3R 769; 04/97→; 2	5DA 193 175-871 Ignition Coil	26
					F3R 768 / F3R 742 / F3R 728 / F3R 729 / F3R 769; →04/97; 2	5DA 193 175-881 Ignition Coil	26
3.0 (JE0D)	123 kW	3 l	11/96→10/98		Z7X 775	5DA 193 175-881 Ignition Coil	26
RENAULT - FUEGO (136_)							08/83→10/85
1.6 Turbo (1365)	97 kW	1.6 l	08/83→10/85			5DA 006 623-051 Switch Unit, ignition system	4
RENAULT - KANGOO (KC0/1_)							08/97→
1.2 (KC0A, KC0K, KC0F, KC01)	43 kW	1.2 l	08/97→		D7F 722/726/744/746; 11/98→	5DA 193 175-391 Ignition Coil	12
					D7F 710	5DA 358 000-251 Ignition Coil	34
					D7F 722 / D7F 726 / D7F 720; →engine 981021		
1.2 16V (KC05, KC06, KC03, KC0T, KC0W, KC1D)	55 kW	1.2 l	06/01→		D4F 712	5DA 193 175-821 Ignition Coil	24
1.4 (KC0C, KC0H, KC0B, KC0M)	55 kW	1.4 l	08/97→		E7J 634/635 / K7J 700/701	5DA 193 175-391 Ignition Coil	12
					E7J 780	5DA 749 475-111 Ignition Coil	37
					E7J 780	5DA 749 475-211 Ignition Coil	38
RENAULT - KANGOO Express (FC0/1_)							08/97→07/01
1.2 (FC01, FC0A, FC0F)	43 kW	1.2 l	08/97→		D7F 722/726/744/746; 11/98→	5DA 193 175-391 Ignition Coil	12
					D7F 720 / D7F 726 / D7F 722	5DA 358 000-251 Ignition Coil	34
					D7F 710		
1.2 (FC1A)	44 kW	1.2 l	07/98→07/01		D7F 764; 11/98→	5DA 193 175-391 Ignition Coil	12
1.2 16V (FC05)	55 kW	1.2 l	10/01→		D4F 712	5DA 193 175-821 Ignition Coil	24








				13	i	412	
RENAULT - KANGOO Express (FC0/1_)							08/97→07/01
1.4 (FC0C, FC0B, FC0H, FC0M)	55 kW	1.4 l	08/97→	⊗ E7J 634/635 / K7J 701	5DA 193 175-391	Ignition Coil	12
				⊗ E7J 780	5DA 749 475-111	Ignition Coil	37
				⊗ E7J 780	5DA 749 475-211	Ignition Coil	38
RENAULT - KOLEOS (HY_)							09/08→
2.5 (HY0C, HY0N)	126 kW	2.5 l	09/08→	⊗ 2TR 702 / 2TR 700 / 2TR 703; 4	5DA 193 175-851	Ignition Coil	25
2.5 4x4 (HY0C, HY0N)	126 kW	2.5 l	09/08→	⊗ 2TR 703 / 2TR 700 / 2TR 702; 4	5DA 193 175-851	Ignition Coil	25
RENAULT - LAGUNA I I (B56_, 556_)							11/93→03/01
1.8	69 kW	1.8 l	06/95→02/01	⊗ F3P 674; 04/97→; 2	5DA 193 175-871	Ignition Coil	26
				⊗ F3P 674; →04/97; 2	5DA 193 175-881	Ignition Coil	26
1.8	70 kW	1.8 l	06/95→06/98	⊗ F3P 676; 04/97→; 2	5DA 193 175-871	Ignition Coil	26
				⊗ F3P 676; →04/97; 2	5DA 193 175-881	Ignition Coil	26
1.8 (B56A/B)	66 kW	1.8 l	11/93→03/01	01/94→	5DA 006 623-231	Switch Unit, ignition system	5
2.0 (B56C/H/N)	83 kW	2 l	11/93→03/01				
1.8 (B56S/T/0)	66 kW	1.8 l	08/95→03/01	⊗ F3P 670; 04/97→; 2	5DA 193 175-871	Ignition Coil	26
				⊗ F3P 670; →04/97; 2	5DA 193 175-881	Ignition Coil	26
1.8 (B56Z)	69 kW	1.8 l	08/95→03/01		5DA 006 623-231	Switch Unit, ignition system	5
2.0	80 kW	2 l	03/99→03/01		5DA 006 623-231	Switch Unit, ignition system	5
				⊗ F3R 611; 2; →engine 970402	5DA 193 175-871	Ignition Coil	26
				⊗ F3R 611; 2; engine 970402→	5DA 193 175-881	Ignition Coil	26
2.0	84 kW	2 l	06/95→02/01	⊗ F3R 768; 04/97→; 2	5DA 193 175-871	Ignition Coil	26
				⊗ F3R 768; →04/97; 2	5DA 193 175-881	Ignition Coil	26
2.0 16V (B56D/M)	102 kW	2 l	06/95→03/01		5DA 749 475-101	Ignition Coil	36
				⊗ N7Q 700 / N7Q 704	5DA 749 475-201	Ignition Coil	37
3.0 (B56E/R, B565)	123 kW	3 l	11/93→03/01	⊗ Z7X 765 / Z7X 760	5DA 193 175-881	Ignition Coil	26
RENAULT - LAGUNA I Grandtour (K56_)							09/95→03/01
1.8 (K56S/T/0)	66 kW	1.8 l	09/95→03/01	⊗ F3P 670; 04/97→; 2	5DA 193 175-871	Ignition Coil	26
				⊗ F3P 670; →04/97; 2	5DA 193 175-881	Ignition Coil	26
1.8 (K56Z)	69 kW	1.8 l	09/95→03/01		5DA 006 623-231	Switch Unit, ignition system	5
2.0 (K56C/H)	83 kW	2 l	09/95→03/01				
2.0	84 kW	2 l	10/98→01/01	⊗ F3R 768; 2	5DA 193 175-871	Ignition Coil	26
2.0 16V (K56D/M)	102 kW	2 l	09/95→03/01		5DA 749 475-101	Ignition Coil	36
				⊗ N7Q 700 / N7Q 704	5DA 749 475-201	Ignition Coil	37
3.0 (K56R, K565)	123 kW	3 l	02/96→03/01	⊗ Z7X 765	5DA 193 175-881	Ignition Coil	26
RENAULT - LAGUNA II (BG0/1_)							04/01→
2.0 16V IDE (BG0N)	103 kW	2 l	04/01→	⊗ F5R 700	5DA 358 000-251	Ignition Coil	34
RENAULT - LAGUNA II Grandtour (KG0/1_)							04/01→
2.0 16V IDE (KG0N)	103 kW	2 l	04/01→	⊗ F5R 700	5DA 358 000-251	Ignition Coil	34
RENAULT - MEGANE I (BA0/1_)							01/96→08/03
1.4 e (BA0E, BA0V)	55 kW	1.4 l	01/96→08/03	⊗ E7J 626	5DA 193 175-391	Ignition Coil	12

				13	i	412		
RENAULT - MEGANE I (BA0/1_)								01/96→08/03
1.6 e (BA0F, BA0S)	66 kW	1.6 l	01/96→03/99	⊗ K7M 702/703; 07/98→	5DA 193 175-391 Ignition	12	Coil	
				⊗ K7M 702/703; →03/97	5DA 749 475-101 Ignition	36	Coil	
				⊗ K7M 790	5DA 749 475-111 Ignition	37	Coil	
				⊗ K7M 703 / K7M 702; 03/97→07/98	5DA 749 475-201 Ignition	37	Coil	
				⊗ K7M 702 / K7M 703; →03/97	5DA 749 475-211 Ignition	38	Coil	
				⊗ K7M 702 / K7M 703; 03/97→07/98	5DA 193 175-391 Ignition	12	Coil	
1.6 i (BA0L)	55 kW	1.6 l	01/96→03/99	07/98→	5DA 749 475-101 Ignition	36	Coil	
				→03/97	5DA 749 475-111 Ignition	37	Coil	
				⊗ K7M 720; 03/97→07/98	5DA 749 475-201 Ignition	37	Coil	
				⊗ K7M 720; →03/97	5DA 749 475-211 Ignition	38	Coil	
				⊗ K7M 720; 03/97→07/98	5DA 193 175-871 Ignition	26	Coil	
2.0 i	80 kW	2 l	03/99→08/03	⊗ F3R 751 / F3R 750; 2; →engine 970402	5DA 193 175-881 Ignition	26	Coil	
				⊗ F3R 751 / F3R 750; 2; engine 970402→	5DA 193 175-871 Ignition	26	Coil	
2.0 i (BA0G)	84 kW	2 l	01/96→08/03	⊗ F3R 751 / F3R 750; 04/97→; 2	5DA 193 175-881 Ignition	26	Coil	
				⊗ F3R 750 / F3R 751; →04/97; 2	5DA 193 175-871 Ignition	26	Coil	
RENAULT - MEGANE I Cabriolet (EA0/1_)								10/96→08/03
1.6 e (EA0F)	66 kW	1.6 l	10/96→03/99	07/98→	5DA 193 175-391 Ignition	12	Coil	
				→03/97	5DA 749 475-101 Ignition	36	Coil	
				⊗ K7M 702 / K7M 703; 03/97→07/98	5DA 749 475-111 Ignition	37	Coil	
				⊗ K7M 702 / K7M 703; →03/97	5DA 749 475-201 Ignition	37	Coil	
				⊗ K7M 702 / K7M 703; 03/97→07/98	5DA 749 475-211 Ignition	38	Coil	
2.0 (EA0G)	84 kW	2 l	04/97→08/03	⊗ F3R 750; 2	5DA 193 175-871 Ignition	26	Coil	
				⊗ F3R 750; →04/97; 2	5DA 193 175-881 Ignition	26	Coil	
2.0 16V IDE (EA03, EA0P, EA14)	103 kW	2 l	11/99→08/03	→01/00	5DA 193 175-391 Ignition	12	Coil	
				engine 001009→	5DA 358 000-251 Ignition	34	Coil	
2.0 i (EA0G)	80 kW	2 l	03/99→08/03	⊗ F3R 796 / F3R 791; 2	5DA 193 175-871 Ignition	26	Coil	
RENAULT - MEGANE I Classic (LA0/1_)								09/96→08/03
1.4 (LA0E, LA0V)	55 kW	1.4 l	09/96→08/03	⊗ E7J 626	5DA 193 175-391 Ignition	12	Coil	
1.6 e (LA0F, LA0S)	66 kW	1.6 l	09/96→03/99	⊗ K7M 702/703; 07/98→	5DA 193 175-391 Ignition	12	Coil	
				⊗ K7M 702/703; →03/97	5DA 749 475-101 Ignition	36	Coil	
				⊗ K7M 790	5DA 749 475-111 Ignition	37	Coil	
				⊗ K7M 703 / K7M 702; 03/97→07/98	5DA 749 475-201 Ignition	37	Coil	
				⊗ K7M 702 / K7M 703; →03/97	5DA 749 475-211 Ignition	38	Coil	
				⊗ K7M 702 / K7M 703; 03/97→07/98	5DA 193 175-391 Ignition	12	Coil	
1.6 i (LA0L)	55 kW	1.6 l	09/96→03/99	07/98→	5DA 749 475-101 Ignition	36	Coil	
				→03/97	5DA 749 475-111 Ignition	37	Coil	
				⊗ K7M 720; 03/97→07/98	5DA 749 475-201 Ignition	37	Coil	
				⊗ K7M 720; →03/97	5DA 749 475-211 Ignition	38	Coil	
				⊗ K7M 720; 03/97→07/98	5DA 193 175-391 Ignition	12	Coil	

RENAULT - MEGANE I Classic (LA0/1_)				09/96→08/03	
2.0 i (LA07, LA0G)	84 kW	2 l	09/96→08/03	F3R 798 / F3R 751 / F3R 750 / F3R 797 / F3R 791 / F3R 796 / F3R 752; 04/97→; 2	5DA 193 175-871 Ignition Coil 26
				F3R 798 / F3R 751 / F3R 750 / F3R 797 / F3R 791 / F3R 796 / F3R 752; →04/97; 2	5DA 193 175-881 Ignition Coil 26
2.0 i (LA0G)	80 kW	2 l	03/99→08/03	F3R 797 / F3R 750 / F3R 798 / F3R 751 / F3R 752 / F3R 791 / F3R 796; 2	5DA 193 175-871 Ignition Coil 26
				F3R 791 / F3R 750 / F3R 797 / F3R 798 / F3R 752 / F3R 796; 2	5DA 193 175-881 Ignition Coil 26
RENAULT - MEGANE I Coach (DA0/1_)				03/96→08/03	
1.6 e (DA0F)	66 kW	1.6 l	03/96→03/99	07/98→	5DA 193 175-391 Ignition Coil 12
				→03/97	5DA 749 475-101 Ignition Coil 36
				K7M 703 / K7M 702; 03/97→07/98	5DA 749 475-111 Ignition Coil 37
				K7M 702 / K7M 703; →03/97	5DA 749 475-201 Ignition Coil 37
				K7M 702 / K7M 703; 03/97→07/98	5DA 749 475-211 Ignition Coil 38
2.0 16V IDE (DA03, DA0P, DA14)	103 kW	2 l	11/99→08/03	→01/00	5DA 193 175-391 Ignition Coil 12
				engine 001009→	5DA 358 000-251 Ignition Coil 34
2.0 i (DA0G)	84 kW	2 l	03/96→08/03	F3R 750 / F3R 751; 04/97→; 2	5DA 193 175-871 Ignition Coil 26
				F3R 750 / F3R 751; →04/97; 2	5DA 193 175-881 Ignition Coil 26
RENAULT - MEGANE I Grandtour (KA0/1_)				03/99→08/03	
1.4 e (KA0V)	55 kW	1.4 l	03/99→08/03		5DA 193 175-391 Ignition Coil 12
1.6 e (KA0F)	66 kW	1.6 l	03/99→08/03		Coil
RENAULT - MEGANE Scenic (JA0/1_)				10/96→10/99	
1.6 e (JA0F)	66 kW	1.6 l	10/96→10/99	07/98→	5DA 193 175-391 Ignition Coil 12
				→03/97	5DA 749 475-101 Ignition Coil 36
				K7M 702 / K7M 703; 03/97→07/98	5DA 749 475-111 Ignition Coil 37
				K7M 702 / K7M 703; →03/97	5DA 749 475-201 Ignition Coil 37
				K7M 702 / K7M 703; 03/97→07/98	5DA 749 475-211 Ignition Coil 38
1.6 i (JA0L)	55 kW	1.6 l	01/97→09/99	07/98→	5DA 193 175-391 Ignition Coil 12
				→03/97	5DA 749 475-101 Ignition Coil 36
				K7M 720; 03/97→07/98	5DA 749 475-111 Ignition Coil 37
				K7M 720; →03/97	5DA 749 475-201 Ignition Coil 37
				K7M 720; 03/97→07/98	5DA 749 475-211 Ignition Coil 38
2.0 i (JA0G)	80 kW	2 l	01/99→09/99	F3R 796; 2	5DA 193 175-871 Ignition Coil 26
2.0 i (JA0G)	84 kW	2 l	01/97→09/99	F3R 750 / F3R 751; 04/97→; 2	5DA 193 175-871 Ignition Coil 26
				F3R 751 / F3R 750; →04/97; 2	5DA 193 175-881 Ignition Coil 26
RENAULT - MODUS / GRAND MODUS (F/JP0_)				12/04→	
1.2 (FP0C, FP0K, FP0P)	48 kW	1.2 l	05/05→	D4F 740	5DA 193 175-831 Ignition Coil 25
1.2 (JP0C, JP0K, FP0C, FP0K, FP0P, JP0P, JP0T)	55 kW	1.2 l	12/04→		
1.2 16V Hi-Flex	55 kW	1.2 l	10/08→		
1.2 (JP0S)	58 kW	1.2 l	12/04→	D4F 764	5DA 193 175-831 Ignition Coil 25
1.2 16V (JP0W)	74 kW	1.2 l	05/07→	D4F 784	5DA 193 175-391 Ignition Coil 12
RENAULT - RAPID Box (F40_, G40_)				09/91→03/98	
1.2 (F406, G40A)	40 kW	1.2 l	09/91→03/98		5DA 358 000-061 Ignition Coil 32

RENAULT - SAFRANE I (B54_)										04/92→07/96	
2.0 12V (B542, B54E)	97 kW	2 l	04/92→07/96		J7R 734	5DA 006 623-231	Switch Unit, ignition system			5	
2.2 (B541)	79 kW	2.2 l	04/92→07/96		J7T 762	5DA 006 623-231	Switch Unit, ignition system			5	
					J7T763	5DA 006 623-671	Ignition Coil			9	
2.2 (B543)	101 kW	2.2 l	04/92→07/96		J7T 760	5DA 006 623-231	Switch Unit, ignition system			5	
3.0 V6 (B54B, B544)	123 kW	3 l	12/92→07/96		Z7X 722 / Z7X 723	5DA 006 623-231	Switch Unit, ignition system			5	
3.0 V6 4x4 (B54B, B544)	123 kW	3 l	12/92→07/96		Z7X722 / Z7X723	5DA 006 623-671	Ignition Coil			9	
RENAULT - SAFRANE II (B54_)										07/96→12/00	
2.0 16V (B54L)	100 kW	2 l	07/96→12/00		D4F 712	5DA 749 475-101	Ignition Coil			36	
					N7Q 710 / N7Q 711	5DA 749 475-201	Ignition Coil			37	
2.5 20V (B54F)	121 kW	2.5 l	07/96→12/00			5DA 358 000-101	Ignition Coil			32	
3.0 V6 (B54M)	123 kW	3 l	07/96→12/00		Z7X 722 / Z7X 723	5DA 006 623-231	Switch Unit, ignition system			5	
RENAULT - SUPER 5 (B/C40_)										10/86→03/95	
1.7 (B/C408)	54 kW	1.7 l	10/86→03/95			5DA 006 623-231	Switch Unit, ignition system			5	
1.7 (B/C40K, B/C40G)	64 kW	1.7 l	06/87→03/95								
1.7 i (C409)	69 kW	1.7 l	10/86→08/91								
RENAULT - THALIA I (LB0/1/2_)										04/02→	
1.2 16V	55 kW	1.2 l	04/02→		D4F 712	5DA 193 175-821	Ignition Coil			24	
RENAULT - TRAFIC Box (TXX)										05/89→10/97	
2.2	70 kW	2.2 l	05/89→06/94			5DA 006 623-231	Switch Unit, ignition system			5	
2.2	74 kW	2.2 l	06/94→10/97								
2.2 4x4	70 kW	2.2 l	05/89→06/94								
2.2 4x4	74 kW	2.2 l	06/94→10/97								
RENAULT - TRAFIC Bus (TXW)										05/89→10/97	
2.2	70 kW	2.2 l	05/89→06/94			5DA 006 623-231	Switch Unit, ignition system			5	
2.2	74 kW	2.2 l	06/94→10/97								
RENAULT - TWINGO I (C06_)										03/93→06/07	
1.2 (C063, C064)	40 kW	1.2 l	03/93→10/96			5DA 358 000-061	Ignition Coil			32	
1.2 (C066, C068)	43 kW	1.2 l	05/96→		11/98→	5DA 193 175-391	Ignition Coil			12	
					D7F 700 / D7F 701 / D7F 702; →engine 981021	5DA 358 000-251	Ignition Coil			34	
1.2 (C067)	40 kW	1.2 l	05/96→		11/98→	5DA 193 175-391	Ignition Coil			12	
					→engine 981021	5DA 358 000-251	Ignition Coil			34	
1.2 16V (C060)	44 kW	1.2 l	08/04→06/07		D4F 708	5DA 193 175-831	Ignition Coil			25	
1.2 16V (C06C, C06D, C06K)	55 kW	1.2 l	01/01→		D4F 702	5DA 193 175-821	Ignition Coil			24	
1.2 LPG	44 kW	1.2 l	10/03→		D7F 702; →engine 981021	5DA 358 000-251	Ignition Coil			34	
RENAULT - TWINGO II (CN0_)										03/07→	
1.2 (CN0D)	43 kW	1.2 l	03/07→		D7F 800	5DA 193 175-391	Ignition Coil			12	
1.2 16V (CN04, CN0A, CN0B)	55 kW	1.2 l	03/07→		D4F 770	5DA 193 175-831	Ignition Coil			25	
					D4F 772	5DA 193 175-831	Ignition Coil			25	
1.2 16V (CN0K, CN0V)	56 kW	1.2 l	03/07→		D4F 772	5DA 193 175-831	Ignition Coil			25	
1.2 Turbo (CN0C, CN0F)	74 kW	1.2 l	03/07→		D4F 782	5DA 193 175-391	Ignition Coil			12	



 	 	 13		412	
ROLLS-ROYCE - SILVER SERAPH Saloon					03/98→09/02
5.4	240 kW	5.4 l	03/98→09/02	5DA 193 175-551 Ignition Coil	17



										13			412	
ROVER - 25 (RF)										10/99→05/05				
1.4 16V	62 kW	1.4 l	10/99→05/05		14 K4M;	471656→; Model 2000→	5DA 193 175-891 Ignition Coil				27			
1.4 16V	76 kW	1.4 l	10/99→05/05		14 K4F;	471656→; Model 2000→	5DA 193 175-891 Ignition Coil				27			
1.6 16V	80 kW	1.6 l	10/99→05/05		16 K4F;	471656→; Model 2000→	5DA 193 175-891 Ignition Coil				27			
1.8 16V	85 kW	1.8 l	10/99→05/05		18 K4F;	471656→; Model 2000→	5DA 193 175-891 Ignition Coil				27			
1.8 16V	107 kW	1.8 l	02/00→05/05		18 K4K		5DA 193 175-371 Ignition Coil				12			
ROVER - 45 (RT)										02/00→05/05				
1.4	76 kW	1.4 l	02/00→05/05		14 K4F;	471064→	5DA 193 175-891 Ignition Coil				27			
1.6	80 kW	1.6 l	02/00→05/05		16 K4F;	471064→	5DA 193 175-891 Ignition Coil				27			
1.8	86 kW	1.8 l	02/00→05/05		18 K4F		5DA 193 175-721 Ignition Coil				21			
							18 K4F;	471064→	5DA 193 175-891 Ignition Coil				27	
ROVER - 45 Saloon (RT)										02/00→05/05				
1.4	76 kW	1.4 l	02/00→05/05		14 K4F;	471064→	5DA 193 175-891 Ignition Coil				27			
1.6	80 kW	1.6 l	02/00→05/05		16 K4F;	471064→	5DA 193 175-891 Ignition Coil				27			
1.8	86 kW	1.8 l	02/00→05/05		18 K4F		5DA 193 175-721 Ignition Coil				21			
							18 K4F;	471064→	5DA 193 175-891 Ignition Coil				27	
ROVER - 75 Saloon (RJ)										02/99→05/05				
1.8	88 kW	1.8 l	02/99→05/05		K 1.8		5DA 193 175-891 Ignition Coil				27			
ROVER - 75 Tourer (RJ)										08/01→05/05				
1.8	88 kW	1.8 l	08/01→05/05		K 1.8		5DA 193 175-891 Ignition Coil				27			
ROVER - 200 (RF)										11/95→03/00				
214 Si	76 kW	1.4 l	11/95→03/00		14 K4F;	471656→; Model 2000→	5DA 193 175-891 Ignition Coil				27			
216 Si	82 kW	1.6 l	11/95→03/00		16 K4F;	471656→; Model 2000→	5DA 193 175-891 Ignition Coil				27			
218 K Vi	107 kW	1.8 l	11/95→03/00		18 K4K		5DA 193 175-371 Ignition Coil				12			
ROVER - 400 (RT)										05/95→03/00				
414 Si	76 kW	1.4 l	05/95→03/00		14 K4F;	471064→; Model 2000→; for vehicles with manual transmission	5DA 193 175-891 Ignition Coil				27			
416 Si	82 kW	1.6 l	05/95→03/00		16 K4F;	471064→; Model 2000→; for vehicles with manual transmission	5DA 193 175-891 Ignition Coil				27			
420 Si Lux	100 kW	2 l	12/95→03/00		20 T4H		5DA 193 175-721 Ignition Coil				21			
ROVER - 400 Hatchback (RT)										05/95→03/00				
414 Si	76 kW	1.4 l	05/95→03/00		14 K4F;	471064→; Model 2000→; for vehicles with manual transmission	5DA 193 175-891 Ignition Coil				27			
420 Si Lux	100 kW	2 l	12/95→03/00		20 T4H		5DA 193 175-721 Ignition Coil				21			
ROVER - 400 Tourer (XW)										05/94→11/98				
1.8 i	107 kW	1.8 l	06/96→11/98		18 K4K		5DA 193 175-371 Ignition Coil				12			
2.0 i	100 kW	2 l	05/94→11/98		20 T4H		5DA 193 175-721 Ignition Coil				21			
ROVER - 600 (RH)										07/94→02/99				
620 Ti Vitesse	147 kW	2 l	07/94→02/99		20 T4G;	BM246797→	5DA 193 175-721 Ignition Coil				21			
ROVER - 800 (XS)										01/92→02/99				
820 I/SI (RS)	100 kW	2 l	01/92→02/99		20 T4H;	230967→	5DA 193 175-721 Ignition Coil				21			

		13	i	412	
ROVER - 800 Hatchback (XS)					01/93→02/99
820 I/SI (XS)	100 kW	2 l	01/93→02/99	20 T4H; 230967→	5DA 193 175-721 Ignition Coil 21
ROVER - MINI					01/91→11/00
1300	37 kW	1.3 l	10/92→11/00	12 A2B; BD134455→	5DA 193 175-721 Ignition Coil 21
1300	39 kW	1.3 l	01/92→04/95	12 A2D; BD134455→	5DA 193 175-721 Ignition Coil 21
1300	45 kW	1.3 l	01/91→12/91	12 A2A; BD134455→	5DA 193 175-721 Ignition Coil 21
1300	46 kW	1.3 l	01/92→11/00	12 A2L / 12 A2E; BD134455→	5DA 193 175-721 Ignition Coil 21
ROVER - MINI Convertible (XN)					09/92→04/95
1300	46 kW	1.3 l	09/92→04/95	12 A2E; BD134455→	5DA 193 175-721 Ignition Coil 21
ROVER - STREETWISE					08/03→05/05
1.4	62 kW	1.4 l	08/03→05/05	14 K4M; 471656→	5DA 193 175-891 Ignition Coil 27
1.4	76 kW	1.4 l	08/03→05/05	14 K4F; 471656→	5DA 193 175-891 Ignition Coil 27

SAAB - 9-3 Estate (YS3F)							03/05→
1.8 i	90 kW	1.8 l	03/05→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31	
SAAB - 9-3 Saloon (YS3F)							01/04→
1.8 i	90 kW	1.8 l	01/04→	⊗ Z 18 XE	5DA 358 000-041 Ignition Coil	31	
SAAB - 90 Saloon							08/84→08/87
2.0	74 kW	2 l	08/84→08/87	05/85→	5DA 006 623-931 Switch Unit, ignition system	8	
SAAB - 900 I (AC4, AM4)							11/80→12/93
2.0 c	74 kW	2 l	07/82→12/88	⊗ B201XC; 08/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 i	81 kW	2 l	09/85→08/90	→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 Turbo	103 kW	2 l	10/86→12/91				
2.0 Turbo	110 kW	2 l	01/86→12/88				
2.0 Turbo-16	118 kW	2 l	11/85→12/93				
2.0 i	85 kW	2 l	11/80→08/90	⊗ B201XI; 08/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 Turbo-16 S	129 kW	2 l	01/84→12/88	08/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 Turbo-16 S CAT	129 kW	2 l	01/89→12/93	→08/93	5DA 006 623-941 Switch Unit, ignition system	9	
2.1 -16	100 kW	2.1 l	08/90→12/93	→08/93; with 3 way catalyst	5DA 006 623-191 Switch Unit, ignition system	5	
SAAB - 900 I Combi Coupe							09/79→06/94
2.0 c	74 kW	2 l	09/79→12/88	⊗ B201XC; 08/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 i	81 kW	2 l	09/85→08/90	→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 Turbo	103 kW	2 l	10/86→12/91				
2.0 Turbo	110 kW	2 l	01/86→12/88				
2.0 Turbo-16	118 kW	2 l	11/85→06/94				
2.0 i	85 kW	2 l	11/80→12/88	⊗ B201XI; 08/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 Turbo-16 S	129 kW	2 l	02/84→12/88	08/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 Turbo-16 S CAT	125 kW	2 l	01/89→12/93	→08/93	5DA 006 623-941 Switch Unit, ignition system	9	
2.1 -16	100 kW	2.1 l	09/90→07/93	with 3 way catalyst	5DA 006 623-191 Switch Unit, ignition system	5	
SAAB - 900 I Convertible							11/86→06/94
2.0 -16	93 kW	2 l	01/90→06/94	→08/93; with 3 way catalyst	5DA 006 623-191 Switch Unit, ignition system	5	
2.0 Turbo-16	118 kW	2 l	11/86→06/94	09/90→08/93; with 3 way catalyst	5DA 006 623-941 Switch Unit, ignition system	9	
2.0 Turbo-16 S	129 kW	2 l	11/86→06/94	→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.1 -16	100 kW	2.1 l	08/90→06/94	09/91→08/93; with 3 way catalyst	5DA 006 623-191 Switch Unit, ignition system	5	
SAAB - 9000							04/85→09/93
2.0 -16 Turbo	118 kW	2 l	05/88→08/93	01/90→	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 -16 Turbo CD	120 kW	2 l	09/88→08/93				
2.0 -16 Turbo	127 kW	2 l	03/90→09/93	→08/90	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 -16 Turbo	129 kW	2 l	04/85→12/91	09/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
SAAB - 9000 Hatchback							09/84→12/98
2.0 -16	92 kW	2 l	12/85→12/88	→08/86	5DA 006 623-191 Switch Unit, ignition system	5	
2.0 -16 Turbo	118 kW	2 l	09/84→08/93	09/85→08/90	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 -16 Turbo	120 kW	2 l	05/88→08/93	01/90→	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 -16 Turbo	127 kW	2 l	06/89→12/92	⊗ B202; 01/90→08/90	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 -16 Turbo	129 kW	2 l	09/84→12/91	09/85→08/88	5DA 006 623-931 Switch Unit, ignition system	8	
2.0 -16 Turbo CS	136 kW	2 l	09/88→12/98	→08/89	5DA 006 623-931 Switch Unit, ignition system	8	

SEAT - ALHAMBRA (7V8, 7V9)				04/96→03/10	
1.8 T 20V	110 kW	1.8 l	10/97→03/10	AJH; →Model 2000 AWC; Model 2001→Model 2010; 4x AJH	5DA 006 623-771 Switch Unit, ignition system 8 5DA 193 175-981 Ignition Coil 30 5DA 358 000-051 Ignition Coil 32
2.0 i	85 kW	2 l	04/96→03/10	ADY; →06/00	5DA 006 623-951 Ignition Coil 9 5DA 358 000-171 Ignition Coil 33
2.8 V6	150 kW	2.8 l	06/00→03/10	AYL; 6	5DA 358 000-001 Ignition Coil 30
2.8 V6 4motion	150 kW	2.8 l	06/00→03/10		
SEAT - ALHAMBRA (710, 711)				11/10→	
1.8 TFSI	118 kW	1.8 l	11/12→	CDAA; 4	5DA 193 175-921 Ignition Coil 28
2.0 TSI	147 kW	2 l	11/10→	CCZA; 4	5DA 193 175-921 Ignition Coil 28
SEAT - ALTEA (5P1)				03/04→05/09	
1.2 TSI	77 kW	1.2 l	04/10→		5DA 358 000-171 Ignition Coil 33
1.6	75 kW	1.6 l	03/04→		
1.6 LPG	75 kW	1.6 l	09/09→		
1.4 16V	63 kW	1.4 l	05/06→	BXW; →Model 2010; 4x	5DA 193 175-501 Ignition Coil 16
1.4 TSI	92 kW	1.4 l	11/07→	CAXC; 4x	5DA 193 175-501 Ignition Coil 16
1.8 TFSI	118 kW	1.8 l	01/07→	BZB / CDAA / BYT; 4	5DA 193 175-921 Ignition Coil 28
2.0 FSI	110 kW	2 l	05/04→03/09	BVY / BLR / BVZ / BLY; 4	5DA 193 175-921 Ignition Coil 28
2.0 TFSI	147 kW	2 l	04/06→05/09	BWA; 4	5DA 193 175-921 Ignition Coil 28
SEAT - ALTEA XL (5P5, 5P8)				10/06→05/09	
1.2 TSI	77 kW	1.2 l	04/10→		5DA 358 000-171 Ignition Coil 33
1.6	75 kW	1.6 l	10/06→		
1.6 LPG	75 kW	1.6 l	09/09→		
1.6 Multifuel	75 kW	1.6 l	10/06→		
1.4 16V	63 kW	1.4 l	10/06→	BXW; →Model 2010; 4x	5DA 193 175-501 Ignition Coil 16
1.4 TSI	92 kW	1.4 l	11/07→	CAXC; 4x	5DA 193 175-501 Ignition Coil 16
1.8 TFSI	118 kW	1.8 l	01/07→	BZB / CDAA / BYT; 4	5DA 193 175-921 Ignition Coil 28
2.0 FSI	110 kW	2 l	10/06→03/09	BVZ / BVY; 4	5DA 193 175-921 Ignition Coil 28
2.0 TFSI	147 kW	2 l	10/06→05/09	BWA; 4	5DA 193 175-921 Ignition Coil 28
2.0 TFSI 4x4	147 kW	2 l	06/07→05/09		
2.0 TFSI 4x4	155 kW	2 l	05/09→	CCZB; 4	5DA 193 175-921 Ignition Coil 28 5DA 358 000-171 Ignition Coil 33
SEAT - AROSA (6H)				05/97→06/04	
1.0	37 kW	1 l	05/97→06/04	AER / ALL; →06/03	5DA 006 623-951 Ignition Coil 9
				AUC / ALD / ANV	5DA 358 000-171 Ignition Coil 33
1.0	37 kW	1 l	10/98→01/01	AHT	5DA 193 175-081 Ignition Coil 10
1.4	44 kW	1.4 l	05/97→06/04	AEX / AKV / APQ; →06/03	5DA 006 623-951 Ignition Coil 9
				AKK / AUD / ANW	5DA 358 000-171 Ignition Coil 33
1.4 16V	74 kW	1.4 l	01/00→06/04	AFK / AUB	5DA 358 000-171 Ignition Coil 33
SEAT - CORDOBA (6K2)				06/99→10/02	
1.0	37 kW	1 l	06/99→10/02		5DA 358 000-171 Ignition Coil 33
1.4	44 kW	1.4 l	06/99→10/02		
1.4 16V	55 kW	1.4 l	05/00→10/02		
1.4 16V	74 kW	1.4 l	02/00→10/02		
1.6	74 kW	1.6 l	06/99→10/02		

				13	i	412			
SEAT - CORDOBA (6K2)							06/99→10/02		
1.6	55 kW	1.6 l	06/99→10/02	ALM; 6K-X-400000→6K-X-499999	5DA 006 623-951	Ignition	9		
					Coil				
1.8 T 20V Cupra	115 kW	1.8 l	07/00→10/02	AYP; 6K-1-134297→; 4x	5DA 193 175-911	Ignition	27		
					Coil				
				AQX; 6K-X-400000→6K-1-134296; 4x	5DA 193 175-981	Ignition	30		
					Coil				
SEAT - CORDOBA Saloon (6K1, 6K2)							02/93→10/99		
1.0 i	37 kW	1 l	09/96→06/99	AER	5DA 006 623-951	Ignition	9		
					Coil				
1.4 i	44 kW	1.4 l	06/94→06/99	AEX	5DA 006 623-951	Ignition	9		
				ABD; →06/96	Coil				
				AKV / APQ; 07/96→					
1.4 i 16V	74 kW	1.4 l	09/96→06/99	AFH	5DA 006 623-951	Ignition	9		
					Coil				
1.6 i	55 kW	1.6 l	02/93→06/99	ABU; →06/96	5DA 006 623-951	Ignition	9		
				AEE / ALM; 07/96→	Coil				
1.6 i	55 kW	1.6 l	05/94→06/99	1F	5DA 006 623-951	Ignition	9		
					Coil				
1.6 i	74 kW	1.6 l	07/96→10/99	AFT	5DA 006 623-951	Ignition	9		
					Coil				
				AKL	5DA 358 000-171	Ignition	33		
					Coil				
1.8 i	66 kW	1.8 l	02/93→06/99	ADZ	5DA 006 623-951	Ignition	9		
				ABS; →06/96	Coil				
1.8 i 16V	95 kW	1.8 l	10/93→08/96	ADL	5DA 006 623-951	Ignition	9		
					Coil				
2.0 i	85 kW	2 l	02/93→06/99	2E; →06/96	5DA 006 623-951	Ignition	9		
				AGG; 07/96→	Coil				
2.0 i 16V	110 kW	2 l	08/96→06/99	ABF	5DA 006 623-951	Ignition	9		
					Coil				
SEAT - CORDOBA Saloon (6L2)							09/02→11/09		
1.2	47 kW	1.2 l	10/02→06/06	AZQ / BME; 3x	5DA 193 175-501	Ignition	16		
					Coil				
1.2 12V	51 kW	1.2 l	05/06→11/09	BXV; 3x	5DA 193 175-501	Ignition	16		
					Coil				
1.4 16V	55 kW	1.4 l	09/02→12/07	BBY / BKY; 4x	5DA 193 175-501	Ignition	16		
					Coil				
1.4 16V	63 kW	1.4 l	05/06→11/09	BXW; 4x	5DA 193 175-501	Ignition	16		
					Coil				
1.4 16V	74 kW	1.4 l	10/02→11/09	BBZ; 4x	5DA 193 175-501	Ignition	16		
					Coil				
				AUB	5DA 358 000-171	Ignition	33		
					Coil				
1.6	74 kW	1.6 l	04/03→11/09		5DA 358 000-171	Ignition	33		
					Coil				
2.0	85 kW	2 l	09/02→11/09						
1.6 16V	77 kW	1.6 l	11/06→11/09	BTS; 4x	5DA 193 175-501	Ignition	16		
					Coil				
SEAT - CORDOBA Vario (6K5)							06/99→12/02		
1.4	44 kW	1.4 l	06/99→12/02		5DA 358 000-171	Ignition	33		
					Coil				
1.4 16V	55 kW	1.4 l	06/99→12/02						
1.6	74 kW	1.6 l	06/99→12/02						
1.6	55 kW	1.6 l	06/99→12/02	ALM; 6K-X-400000→6K-X-499999	5DA 006 623-951	Ignition	9		
					Coil				
SEAT - CORDOBA Vario (6K5)							09/96→06/99		
1.4 i	44 kW	1.4 l	09/96→06/99	AEX / APQ / AKV	5DA 006 623-951	Ignition	9		
					Coil				
1.6 i	55 kW	1.6 l	09/96→06/99	AEE / ALM	5DA 006 623-951	Ignition	9		
					Coil				
1.6 i	55 kW	1.6 l	05/97→06/99	1F	5DA 006 623-951	Ignition	9		
					Coil				
1.6 i	74 kW	1.6 l	09/96→06/99	AFT	5DA 006 623-951	Ignition	9		
					Coil				
SEAT - EXEO (3R2)							03/09→09/10		
1.6	75 kW	1.6 l	03/09→09/10		5DA 358 000-171	Ignition	33		
					Coil				
1.8 TSI	88 kW	1.8 l	09/10→	CDHA; 4	5DA 193 175-921	Ignition	28		
					Coil				
1.8 TSI	118 kW	1.8 l	05/10→	CDHB; 4	5DA 193 175-921	Ignition	28		
					Coil				

				13	i	412	
SEAT - EXEO (3R2)							03/09→09/10
2.0 TFSI	147 kW	2 l	03/09→	⊗ BWE; 4	5DA 193 175-921 Ignition Coil		28
2.0 TFSI	155 kW	2 l	05/10→	⊗ CDND; 4	5DA 193 175-921 Ignition Coil		28
SEAT - EXEO ST (3R5)							06/09→09/10
1.6	75 kW	1.6 l	06/09→09/10		5DA 358 000-171 Ignition Coil		33
1.8 TSI	88 kW	1.8 l	09/10→	⊗ CDHA; 4	5DA 193 175-921 Ignition Coil		28
1.8 TSI	118 kW	1.8 l	05/10→	⊗ CDHB; 4	5DA 193 175-921 Ignition Coil		28
2.0 TFSI	147 kW	2 l	06/09→	⊗ BWE; 4	5DA 193 175-921 Ignition Coil		28
2.0 TFSI	155 kW	2 l	05/10→	⊗ CDND; 4	5DA 193 175-921 Ignition Coil		28
SEAT - IBIZA I (021A)							01/89→05/93
1.2 i	52 kW	1.2 l	01/89→05/93	12/89→	5DA 006 623-191 Switch Unit, ignition system		5
SEAT - IBIZA II (6K1)							03/93→08/99
1.0	33 kW	1 l	03/93→09/96	⊗ AAU	5DA 006 623-951 Ignition Coil		9
1.0 i	37 kW	1 l	09/96→08/99	⊗ AER	5DA 006 623-951 Ignition Coil		9
1.3 i	40 kW	1.3 l	03/93→08/99	⊗ AAV; →06/96	5DA 006 623-951 Ignition Coil		9
1.4 i	44 kW	1.4 l	09/93→08/99	⊗ AEX ⊗ ABD; →06/96 ⊗ AKV / APQ; 07/96→	5DA 006 623-951 Ignition Coil		9
1.4 i 16V	74 kW	1.4 l	06/97→08/99	⊗ AFH	5DA 006 623-951 Ignition Coil		9
1.6 i	55 kW	1.6 l	03/93→08/99	⊗ ABU; →06/96 ⊗ AEE / ALM; 07/96→	5DA 006 623-951 Ignition Coil		9
1.6 i	55 kW	1.6 l	09/94→06/99	⊗ 1F	5DA 006 623-951 Ignition Coil		9
1.6 i	74 kW	1.6 l	04/96→08/99	⊗ AFT	5DA 006 623-951 Ignition Coil		9
1.8 i	66 kW	1.8 l	03/93→08/99	⊗ ADZ ⊗ ABS; →06/96	5DA 006 623-951 Ignition Coil		9
1.8 i 16V	95 kW	1.8 l	11/93→08/96	⊗ ADL	5DA 006 623-951 Ignition Coil		9
2.0 i	85 kW	2 l	03/93→08/99	⊗ 2E; →06/96 ⊗ AGG; 07/96→	5DA 006 623-951 Ignition Coil		9
2.0 i 16V	110 kW	2 l	08/96→08/99	⊗ ABF	5DA 006 623-951 Ignition Coil		9
SEAT - IBIZA III (6K1)							08/99→02/02
1.0	37 kW	1 l	08/99→02/02		5DA 358 000-171 Ignition Coil		33
1.4	44 kW	1.4 l	08/99→02/02		5DA 358 000-171 Ignition Coil		33
1.4 16V	55 kW	1.4 l	05/00→02/02		5DA 358 000-171 Ignition Coil		33
1.4 16V	74 kW	1.4 l	08/99→02/02		5DA 358 000-171 Ignition Coil		33
1.6	74 kW	1.6 l	08/99→02/02		5DA 358 000-171 Ignition Coil		33
1.6	55 kW	1.6 l	08/99→02/02	⊗ ALM; ⚡ 6K-X-400000→6K-X-499999	5DA 006 623-951 Ignition Coil		9
1.8 T 20V Cupra	115 kW	1.8 l	07/00→02/02	⊗ AYP; ⚡ 6K-1-134297→6K-2-199999; 4x	5DA 193 175-911 Ignition Coil		27
				⊗ AQX; ⚡ 6K-X-400000→6K-1-134296; 4x	5DA 193 175-981 Ignition Coil		30
SEAT - IBIZA IV (6L1)							02/02→11/09
1.2	44 kW	1.2 l	06/07→05/08	⊗ BBM; 3x	5DA 193 175-901 Ignition Coil		27
1.2	47 kW	1.2 l	02/02→06/06	⊗ AZQ / BME; ⚡ 6L-2-000001→; 3x	5DA 193 175-501 Ignition Coil		16
1.2 12V	51 kW	1.2 l	05/06→11/09	⊗ BXV; →Model 2010; 3x	5DA 193 175-501 Ignition Coil		16
1.4 16V	55 kW	1.4 l	02/02→12/07	⊗ BBY / BKY; ⚡ 6L-2-000001→; 4x	5DA 193 175-501 Ignition Coil		16
1.4 16V	63 kW	1.4 l	05/06→11/09	⊗ BXW; 4x	5DA 193 175-501 Ignition Coil		16

				13	i	412			
SEAT - IBIZA IV (6L1)							02/02→11/09		
1.4 16V	74 kW	1.4 l	02/02→11/09	⊗ BBZ; ⊗ 6L-2-000001→; →Model 2010; 4x		5DA 193 175-501 Ignition Coil	16		
						5DA 358 000-171 Ignition Coil	33		
1.6	74 kW	1.6 l	02/03→11/09			5DA 358 000-171 Ignition Coil	33		
2.0	85 kW	2 l	04/02→11/09						
1.6 16V	77 kW	1.6 l	11/06→11/09	⊗ BTS; →Model 2010; 4x		5DA 193 175-501 Ignition Coil	16		
1.8 T Cupra R	132 kW	1.8 l	01/04→02/08	⊗ BBU; ⊗ 6L-2-000001→; 4x		5DA 193 175-911 Ignition Coil	27		
1.8 T FR	110 kW	1.8 l	12/03→05/08	⊗ BKV / BJX; ⊗ 6L-2-000001→		5DA 193 175-911 Ignition Coil	27		
SEAT - IBIZA V (6J5, 6P5)							03/08→		
1.2	44 kW	1.2 l	07/09→	⊗ CGPB; ⊗ 6J-9-000001→; 3x		5DA 193 175-501 Ignition Coil	16		
1.2	51 kW	1.2 l	03/08→	⊗ BZG / CGPA; ⊗ 6J-9-000001→; →Model 2011; 3x		5DA 193 175-501 Ignition Coil	16		
1.2 TSI	63 kW	1.2 l	08/12→			5DA 358 000-171 Ignition Coil	33		
1.2 TSI	77 kW	1.2 l	09/10→						
1.4	63 kW	1.4 l	03/08→	⊗ BXW / CGGB; ⊗ 6J-9-000001→; →Model 2011; 4x		5DA 193 175-501 Ignition Coil	16		
1.4 TSI	110 kW	1.4 l	06/09→	⊗ CAVF; ⊗ 6J-9-000001→; 4x		5DA 193 175-501 Ignition Coil	16		
1.6	77 kW	1.6 l	05/08→	⊗ BTS; ⊗ 6J-9-000001→; →Model 2011; 4x		5DA 193 175-501 Ignition Coil	16		
SEAT - IBIZA V SPORTCOUPE (6J1, 6P1)							07/08→		
1.2	44 kW	1.2 l	07/09→	⊗ CGPB; ⊗ 6J-9-000001→; →Model 2011; 4x		5DA 193 175-501 Ignition Coil	16		
1.2	51 kW	1.2 l	07/08→	⊗ BZG / CGPA; ⊗ 6J-9-000001→; →Model 2011; 3x		5DA 193 175-501 Ignition Coil	16		
1.2 TSI	63 kW	1.2 l	08/12→			5DA 358 000-171 Ignition Coil	33		
1.2 TSI	77 kW	1.2 l	09/10→						
1.4	63 kW	1.4 l	07/08→	⊗ BXW / CGGB; ⊗ 6J-9-000001→; →Model 2011; 4x		5DA 193 175-501 Ignition Coil	16		
1.4 TSI	110 kW	1.4 l	06/09→	⊗ CAVF; ⊗ 6J-9-000001→; →Model 2011; 4x		5DA 193 175-501 Ignition Coil	16		
1.4 TSI Cupra	132 kW	1.4 l	06/09→	⊗ CAVE; ⊗ 6J-9-000001→; →Model 2011		5DA 193 175-501 Ignition Coil	16		
SEAT - IBIZA V ST (6J8, 6P8)							03/10→		
1.2	44 kW	1.2 l	05/10→	⊗ CGPB; ⊗ 6J-9-000001→; 3x		5DA 193 175-501 Ignition Coil	16		
1.2	51 kW	1.2 l	05/10→	⊗ CGPA; ⊗ 6J-9-000001→; 3x		5DA 193 175-501 Ignition Coil	16		
1.2 TSI	63 kW	1.2 l	09/12→			5DA 358 000-171 Ignition Coil	33		
1.2 TSI	77 kW	1.2 l	09/10→						
1.4	63 kW	1.4 l	03/10→	⊗ CGGB; ⊗ 6J-9-000001→; 4x		5DA 193 175-501 Ignition Coil	16		
SEAT - INCA (6K9)							11/95→06/03		
1.4 16V	55 kW	1.4 l	04/00→06/03			5DA 358 000-171 Ignition Coil	33		
1.4 i	44 kW	1.4 l	11/95→06/03	⊗ AEX / APQ / AKV; →06/03		5DA 006 623-951 Ignition Coil	9		
				⊗ AUD		5DA 358 000-171 Ignition Coil	33		
1.6 i	55 kW	1.6 l	11/95→05/98	⊗ 1F		5DA 006 623-951 Ignition Coil	9		
1.6 i	55 kW	1.6 l	06/97→09/00	⊗ AEE		5DA 006 623-951 Ignition Coil	9		
SEAT - LEON (1M1)							11/99→06/06		
1.4 16V	55 kW	1.4 l	11/99→06/06	⊗ BCA; Model 2002→; 4x		5DA 193 175-501 Ignition Coil	16		
				⊗ AXP / AHW / BCA		5DA 358 000-171 Ignition Coil	33		
1.6	74 kW	1.6 l	11/99→06/06			5DA 358 000-171 Ignition Coil	33		
1.8 20V	92 kW	1.8 l	11/99→06/06						
1.6	75 kW	1.6 l	10/05→06/06	⊗ BFQ		5DA 358 000-171 Ignition Coil	33		

				13	i	412			
SEAT - LEON (1M1)							11/99→06/06		
1.6 16 V	77 kW	1.6 l	09/00→06/06	⊗ AZD / BCB; Model 2002→; 4x	5DA 193 175-501 Ignition Coil	16			
				⊗ ATN / AUS	5DA 358 000-171 Ignition Coil	33			
1.8 20V T	132 kW	1.8 l	11/99→06/06	⊗ APP; →Model 2001	5DA 006 623-771 Switch Unit, ignition system	8			
				⊗ APP / AUQ; 4x	5DA 193 175-911 Ignition Coil	27			
1.8 20V T 4	132 kW	1.8 l	11/99→06/06	⊗ ARY; 4x	5DA 193 175-911 Ignition Coil	27			
				⊗ AJQ; →Model 2001; 4x	5DA 193 175-981 Ignition Coil	30			
1.8 T Cupra R	154 kW	1.8 l	02/02→06/06	⊗ AMK; 4x	5DA 193 175-911 Ignition Coil	27			
1.8 T Cupra R	165 kW	1.8 l	07/03→06/06	⊗ BAM; 4x	5DA 193 175-911 Ignition Coil	27			
SEAT - LEON (1P1)							05/05→05/10		
1.2 TSI	77 kW	1.2 l	02/10→		5DA 358 000-171 Ignition Coil	33			
1.6	75 kW	1.6 l	07/05→						
1.6 LPG	75 kW	1.6 l	12/09→						
1.6 MultiFuel	75 kW	1.6 l	11/10→						
1.4 16V	63 kW	1.4 l	06/06→	⊗ BXW; → 1P-6-000001→; →Model 2010; 4x	5DA 193 175-501 Ignition Coil	16			
1.4 TSI	92 kW	1.4 l	11/07→	⊗ CAXC; → 1P-6-000001→; 4x	5DA 193 175-501 Ignition Coil	16			
1.8 TSI	118 kW	1.8 l	06/07→	⊗ BZB / CDAA; 4	5DA 193 175-921 Ignition Coil	28			
2.0 Cupra R	195 kW	2 l	09/09→	⊗ CDLA; 4	5DA 193 175-921 Ignition Coil	28			
2.0 FSI	110 kW	2 l	07/05→05/10	⊗ BLY / BVY / BLR / BVZ; 4	5DA 193 175-921 Ignition Coil	28			
2.0 TFSI	147 kW	2 l	05/05→03/09	⊗ BWA; 4	5DA 193 175-921 Ignition Coil	28			
2.0 TFSI	155 kW	2 l	06/09→	⊗ CCZB; 4	5DA 193 175-921 Ignition Coil	28			
2.0 TFSI	177 kW	2 l	11/06→	⊗ BWJ / CDLD; 4	5DA 193 175-921 Ignition Coil	28			
SEAT - LEON (5F1)							09/12→		
1.2 TSI	63 kW	1.2 l	12/12→	⊗ CJZB; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29			
1.2 TSI	77 kW	1.2 l	01/13→	⊗ CJZA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29			
1.4 TSI	90 kW	1.4 l	11/12→	⊗ CMBA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29			
1.4 TSI	103 kW	1.4 l	09/12→	⊗ CHPA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29			
				⊗ CPTA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29			
SEAT - MALAGA (023A)							12/89→12/93		
1.2 i	52 kW	1.2 l	12/89→12/93		5DA 006 623-191 Switch Unit, ignition system	5			
SEAT - MARBELLA (28)							11/96→10/98		
0.9 CAT	30 kW	0.9 l	11/96→10/98	⊗ 08 NCB; 2	5DA 193 175-871 Ignition Coil	26			
SEAT - Mii (KF1_)							10/11→		
1.0	44 kW	1 l	10/11→	⊗ CHYA; 4 ports; 3x	5DA 193 175-951 Ignition Coil	29			
1.0	55 kW	1 l	10/11→	⊗ CHYB; 4 ports; 3x	5DA 193 175-951 Ignition Coil	29			
1.0 EcoFuel	50 kW	1 l	11/12→	⊗ CPGA; 4 ports; 3x	5DA 193 175-951 Ignition Coil	29			
SEAT - TERRA (24)							02/92→12/94		
0.9 CAT	29 kW	0.9 l	02/92→12/94	⊗ 09 NCB; 2	5DA 193 175-871 Ignition Coil	26			

				13	i	412			
SEAT - TOLEDO I (1L)							05/91→03/99		
1.6 i	52 kW	1.6 l	05/91→12/93				5DA 006 623-931 Switch Unit, ignition system	8	
							5DA 006 623-941 Switch Unit, ignition system	9	
					1F		5DA 006 623-951 Ignition Coil	9	
1.6 i	54 kW	1.6 l	05/91→03/99		1F		5DA 006 623-931 Switch Unit, ignition system	8	
					1F		5DA 006 623-941 Switch Unit, ignition system	9	
					1F		5DA 006 623-951 Ignition Coil	9	
					EZ / ABN; →06/96				
1.6 i	55 kW	1.6 l	01/93→03/99				5DA 006 623-931 Switch Unit, ignition system	8	
							5DA 006 623-941 Switch Unit, ignition system	9	
1.6 i	74 kW	1.6 l	11/96→03/99		AFT		5DA 006 623-951 Ignition Coil	9	
1.8 16V	92 kW	1.8 l	05/91→03/99		→03/94		5DA 006 623-931 Switch Unit, ignition system	8	
					PL; →1L-ZD328901→; →06/96		5DA 006 623-951 Ignition Coil	9	
1.8 16V	98 kW	1.8 l	05/91→03/99		KR; →1L-ZD328901→; →06/96		5DA 006 623-951 Ignition Coil	9	
1.8 i	65 kW	1.8 l	05/91→12/96		→11/93		5DA 006 623-931 Switch Unit, ignition system	8	
					→11/93		5DA 006 623-941 Switch Unit, ignition system	9	
					RP; →1L-ZD328901→		5DA 006 623-951 Ignition Coil	9	
1.8 i	66 kW	1.8 l	11/93→12/96		ABS / ADZ		5DA 006 623-951 Ignition Coil	9	
2.0 i	85 kW	2 l	05/91→03/99		AGG		5DA 006 623-951 Ignition Coil	9	
					2E; →06/96				
2.0 i 16V	110 kW	2 l	11/93→03/99		ABF		5DA 006 623-951 Ignition Coil	9	
SEAT - TOLEDO II Saloon (1M2)							10/98→05/06		
1.4 16V	55 kW	1.4 l	01/00→05/02		AHW / AXP / BCA		5DA 358 000-171 Ignition Coil	33	
1.6	74 kW	1.6 l	10/98→07/04				5DA 358 000-171 Ignition Coil	33	
1.8 20V	92 kW	1.8 l	10/98→07/04						
1.6 16V	77 kW	1.6 l	06/00→05/06		AZD / BCB; Model 2002→Model 2004; 4x		5DA 193 175-501 Ignition Coil	16	
					AUS		5DA 358 000-171 Ignition Coil	33	
1.8 20VT	132 kW	1.8 l	09/00→07/04		AUQ; →Model 2004; 4x		5DA 193 175-911 Ignition Coil	27	
2.3 V5 20V	125 kW	2.3 l	09/00→11/03		AQN; 5		5DA 358 000-001 Ignition Coil	30	
SEAT - TOLEDO III (5P2)							10/04→05/09		
1.6	75 kW	1.6 l	10/04→05/09				5DA 358 000-171 Ignition Coil	33	
1.8 TFSI	118 kW	1.8 l	01/07→05/09		BZB / BYT; 4		5DA 193 175-921 Ignition Coil	28	
2.0 FSI	110 kW	2 l	10/04→05/09		BLY / BLR / BVY / BVZ; 4		5DA 193 175-921 Ignition Coil	28	
2.0 TFSI	147 kW	2 l	11/05→05/09		BWA; 4		5DA 193 175-921 Ignition Coil	28	
SEAT - TOLEDO IV (KG3)							07/12→		
1.2 TSI	63 kW	1.2 l	07/12→				5DA 358 000-171 Ignition Coil	33	
1.2 TSI	77 kW	1.2 l	07/12→						

SKODA - CITIGO										10/11→			
1.0	44 kW	1 l	10/11→		CHYA; 4 ports; 3x	5DA 193 175-951 Ignition Coil				29			
1.0	55 kW	1 l	10/11→		CHYB; 4 ports; 3x	5DA 193 175-951 Ignition Coil				29			
SKODA - FABIA										12/06→12/14			
1.2	44 kW	1.2 l	12/06→12/14		BBM / CHFA; 3x	5DA 193 175-901 Ignition Coil				27			
1.2	51 kW	1.2 l	01/07→12/14		BZG / CEVA / CGPA; 5J-7-000001→; 3x	5DA 193 175-501 Ignition Coil				16			
1.2 TSI	63 kW	1.2 l	03/10→12/14			5DA 358 000-171 Ignition Coil				33			
1.2 TSI	77 kW	1.2 l	03/10→12/14										
1.4	63 kW	1.4 l	01/07→12/14		BXW; 5J-7-000001→; 4x	5DA 193 175-501 Ignition Coil				16			
1.4 TSI RS	132 kW	1.4 l	05/10→12/14		CAVE; 3x	5DA 193 175-501 Ignition Coil				16			
1.6	77 kW	1.6 l	04/07→12/14		BTS; 5J-7-000001→; 4x	5DA 193 175-501 Ignition Coil				16			
SKODA - FABIA (6Y2)										08/99→03/08			
1.0	37 kW	1 l	12/99→08/02		ARV / AQV	5DA 193 175-081 Ignition Coil				10			
1.2	40 kW	1.2 l	08/02→03/08		BMD / AWY; 3x	5DA 193 175-901 Ignition Coil				27			
1.2	47 kW	1.2 l	01/03→03/08		AZQ / BME; 3x	5DA 193 175-501 Ignition Coil				16			
1.4	44 kW	1.4 l	08/00→08/02		AZF / AZE	5DA 193 175-081 Ignition Coil				10			
1.4	50 kW	1.4 l	08/99→05/03		AME / AQW / ATZ	5DA 193 175-081 Ignition Coil				10			
1.4 16V	55 kW	1.4 l	12/99→03/08		BBY / BKY; 4x	5DA 193 175-501 Ignition Coil				16			
					BBY / AUA; →04/02	5DA 358 000-171 Ignition Coil				33			
1.4 16V	74 kW	1.4 l	12/99→03/08		BBZ; 4x	5DA 193 175-501 Ignition Coil				16			
					→04/02	5DA 358 000-171 Ignition Coil				33			
2.0	85 kW	2 l	12/99→03/08			5DA 358 000-171 Ignition Coil				33			
SKODA - FABIA Combi										10/07→12/14			
1.2	44 kW	1.2 l	10/07→11/14		BBM / CHFA; 3x	5DA 193 175-901 Ignition Coil				27			
1.2	51 kW	1.2 l	10/07→12/14		BZG / CEVA / CGPA; 5J-7-000001→; 3x	5DA 193 175-501 Ignition Coil				16			
1.2 TSI	63 kW	1.2 l	03/10→12/14			5DA 358 000-171 Ignition Coil				33			
1.2 TSI	77 kW	1.2 l	03/10→12/14										
1.4	63 kW	1.4 l	10/07→12/14		BXW; 5J-7-000001→; 4x	5DA 193 175-501 Ignition Coil				16			
1.4 TSI RS	132 kW	1.4 l	05/10→12/14		CAVE; 3x	5DA 193 175-501 Ignition Coil				16			
1.6	77 kW	1.6 l	10/07→12/14		BTS; 5J-7-000001→; 4x	5DA 193 175-501 Ignition Coil				16			
SKODA - FABIA Combi (6Y5)										04/00→12/07			
1.2	40 kW	1.2 l	07/01→12/07		AWY / BMD; 3x	5DA 193 175-901 Ignition Coil				27			
1.2	47 kW	1.2 l	01/03→12/07		AZQ / BME; 3x	5DA 193 175-501 Ignition Coil				16			
1.4	44 kW	1.4 l	04/00→03/03		AZE / AZF	5DA 193 175-081 Ignition Coil				10			
1.4	50 kW	1.4 l	04/00→05/03		AME / AQW / ATZ	5DA 193 175-081 Ignition Coil				10			
1.4 16V	55 kW	1.4 l	05/00→12/07		BBY / BKY; 4x	5DA 193 175-501 Ignition Coil				16			
					BBY / AUA; →04/02	5DA 358 000-171 Ignition Coil				33			
1.4 16V	59 kW	1.4 l	04/06→12/07		BUD; 4x	5DA 193 175-501 Ignition Coil				16			
1.4 16V	74 kW	1.4 l	04/00→12/07		BBZ; 4x	5DA 193 175-501 Ignition Coil				16			
					→04/02	5DA 358 000-171 Ignition Coil				33			

SKODA - FABIA Combi (6Y5)										04/00→12/07					
2.0	85 kW	2 l	04/00→12/07			5DA 358 000-171 Ignition Coil		33							
SKODA - FABIA Praktik										07/01→12/07					
1.2	40 kW	1.2 l	07/01→12/07	AWY / BMD; 3x		5DA 193 175-901 Ignition Coil		27							
1.2	47 kW	1.2 l	01/03→12/07	AZQ / BME; 3x		5DA 193 175-501 Ignition Coil		16							
1.4	50 kW	1.4 l	07/01→05/03	AME / AQW / ATZ		5DA 193 175-081 Ignition Coil		10							
SKODA - FABIA Saloon (6Y3)										10/99→12/07					
1.2	40 kW	1.2 l	07/01→12/07	BMD / AWY; 3x		5DA 193 175-901 Ignition Coil		27							
1.2	47 kW	1.2 l	01/03→12/07	BME / AZQ; 3x		5DA 193 175-501 Ignition Coil		16							
1.4	44 kW	1.4 l	04/00→08/02	AZE / AZF		5DA 193 175-081 Ignition Coil		10							
1.4	50 kW	1.4 l	07/01→05/03	AME / AQW / ATZ		5DA 193 175-081 Ignition Coil		10							
1.4 16V	55 kW	1.4 l	10/99→12/07	BKY / BBY; 4x		5DA 193 175-501 Ignition Coil		16							
				BBY / AUA; →04/02		5DA 358 000-171 Ignition Coil		33							
1.4 16V	59 kW	1.4 l	04/06→12/07	BUD; 4x		5DA 193 175-501 Ignition Coil		16							
1.4 16V	74 kW	1.4 l	12/99→12/07	BBZ; 4x		5DA 193 175-501 Ignition Coil		16							
				→04/02		5DA 358 000-171 Ignition Coil		33							
2.0	85 kW	2 l	12/99→12/07			5DA 358 000-171 Ignition Coil		33							
SKODA - FAVORIT (781)										01/94→09/94					
1.3 (781)	50 kW	1.3 l	01/94→09/94	136B		5DA 006 623-951 Ignition Coil		9							
SKODA - FAVORIT Forman (785)										01/94→06/95					
1.3	50 kW	1.3 l	01/94→06/95	136B		5DA 006 623-951 Ignition Coil		9							
SKODA - FAVORIT Pickup (787)										12/92→06/97					
1.3	40 kW	1.3 l	12/92→06/97	135B; →06/95		5DA 006 623-951 Ignition Coil		9							
1.3	50 kW	1.3 l	12/92→06/97	136B; →06/95		5DA 006 623-951 Ignition Coil		9							
SKODA - FELICIA I (6U1)										10/94→03/98					
1.3	40 kW	1.3 l	10/94→03/98	135B		5DA 006 623-951 Ignition Coil		9							
1.3	43 kW	1.3 l	10/94→03/98	135 L		5DA 006 623-951 Ignition Coil		9							
1.3	50 kW	1.3 l	10/94→03/98	136B		5DA 006 623-951 Ignition Coil		9							
1.6 LX	55 kW	1.6 l	08/95→03/98	AEE		5DA 006 623-951 Ignition Coil		9							
SKODA - FELICIA I Estate (6U5)										08/95→03/98					
1.3	43 kW	1.3 l	08/95→03/98	135 L		5DA 006 623-951 Ignition Coil		9							
1.3 LX	40 kW	1.3 l	08/95→03/98			5DA 006 623-951 Ignition Coil		9							
1.3 LXI	50 kW	1.3 l	08/95→03/98	136B		5DA 006 623-951 Ignition Coil		9							
1.6 GLX	55 kW	1.6 l	08/95→03/98	AEE		5DA 006 623-951 Ignition Coil		9							
SKODA - FELICIA I Fun (797)										06/97→04/02					
1.3	40 kW	1.3 l	06/97→04/02	135B / 135M; →06/01		5DA 006 623-951 Ignition Coil		9							
1.3	50 kW	1.3 l	06/97→04/02	136B / 136M; →06/01		5DA 006 623-951 Ignition Coil		9							
1.6	55 kW	1.6 l	06/97→04/02	AEE; →06/01		5DA 006 623-951 Ignition Coil		9							

SKODA - FELICIA II (6U1)						01/98→06/01
1.6	55 kW	1.6 l	01/98→06/01	⊗ AEE	5DA 006 623-951 Ignition Coil	9
SKODA - FELICIA II Estate (6U5)						01/98→06/01
1.6	55 kW	1.6 l	01/98→06/01	⊗ AEE	5DA 006 623-951 Ignition Coil	9
SKODA - OCTAVIA (1U2)						09/96→12/10
1.4	44 kW	1.4 l	04/99→03/01	⊗ AMD	5DA 193 175-081 Ignition Coil	10
1.4 16V	55 kW	1.4 l	09/00→12/10	⊗ BCA; 1U-22624899→ / 1U-28566293→; 4x	5DA 193 175-501 Ignition Coil	16
				→02/02	5DA 358 000-171 Ignition Coil	33
1.6	55 kW	1.6 l	09/96→09/04	⊗ AEE	5DA 006 623-951 Ignition Coil	9
1.6	74 kW	1.6 l	02/97→12/07		5DA 358 000-171 Ignition Coil	33
1.6	75 kW	1.6 l	11/00→12/10			
1.8	92 kW	1.8 l	09/96→07/00			
1.8 T	110 kW	1.8 l	08/97→12/10	⊗ AUM / ARX ⊗ AGU; for vehicles without e-throttle	5DA 006 623-771 Switch Unit, ignition system	8
				⊗ AUM / ARX; Model 2001→Model 2008; 4x	5DA 193 175-911 Ignition Coil	27
				⊗ ARZ; →Model 2000; 4x	5DA 193 175-981 Ignition Coil	30
				⊗ AGU	5DA 358 000-051 Ignition Coil	32
1.8 T 4x4	110 kW	1.8 l	05/01→05/06	for vehicles without e-throttle	5DA 006 623-771 Switch Unit, ignition system	8
				→Model 2008; 4x	5DA 193 175-911 Ignition Coil	27
2.0	85 kW	2 l	04/99→05/07	⊗ AQY / AEG / APK / AZH	5DA 358 000-171 Ignition Coil	33
				⊗ AZJ	5DA 358 000-181 Ignition Coil	33
RS 1.8 T	132 kW	1.8 l	05/01→01/06	⊗ AUQ	5DA 006 623-771 Switch Unit, ignition system	8
				⊗ AUQ; →Model 2008; 4x	5DA 193 175-911 Ignition Coil	27
SKODA - OCTAVIA (1Z3)						02/04→06/13
1.2 TSI	77 kW	1.2 l	02/10→06/13		5DA 358 000-171 Ignition Coil	33
1.6	75 kW	1.6 l	06/04→06/13			
1.6 LPG	75 kW	1.6 l	08/09→11/12			
1.6 MultiFuel	75 kW	1.6 l	01/08→06/13			
1.4	55 kW	1.4 l	05/04→05/06	⊗ BCA; 1Z-5-000001→; →Model 2008; 4x	5DA 193 175-501 Ignition Coil	16
1.4	59 kW	1.4 l	06/04→04/13	⊗ BUD; 1Z-5-000001→; 8x	5DA 193 175-501 Ignition Coil	16
1.4 TSI	90 kW	1.4 l	11/08→06/13	⊗ CAXA; 4x	5DA 193 175-501 Ignition Coil	16
1.6 FSI	85 kW	1.6 l	02/04→10/08	⊗ BLF; 1Z-5-000001→; →Model 2008; 4x	5DA 193 175-501 Ignition Coil	16
1.8 TSI	118 kW	1.8 l	06/07→04/13	⊗ CDAA / BZB; 4	5DA 193 175-921 Ignition Coil	28
2.0 FSI	110 kW	2 l	11/04→10/08	⊗ BVZ / BLY / BLR / BVY; 4	5DA 193 175-921 Ignition Coil	28
2.0 RS	147 kW	2 l	10/05→02/13	⊗ CCZA / BWA; 4	5DA 193 175-921 Ignition Coil	28
SKODA - OCTAVIA (5E3)						11/12→
1.2 TSI	63 kW	1.2 l	11/12→	⊗ CJZB; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
1.2 TSI	77 kW	1.2 l	11/12→	⊗ CJZA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
1.4 TSI	103 kW	1.4 l	11/12→	⊗ CHPA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
SKODA - OCTAVIA Combi (1U5)						07/98→12/10
1.4 16V	55 kW	1.4 l	08/00→12/10	⊗ BCA; 1U-22624899→ / 1U-28566293→; 4x	5DA 193 175-501 Ignition Coil	16
				→02/02	5DA 358 000-171 Ignition Coil	33









SKODA - OCTAVIA Combi (1U5)					07/98→12/10	
1.6	55 kW	1.6 l	07/98→09/04	⊗ AEE	5DA 006 623-951 Ignition Coil	9
1.6	74 kW	1.6 l	07/98→12/07		5DA 358 000-171 Ignition Coil	33
1.6	75 kW	1.6 l	09/00→12/10			
1.8 20V	92 kW	1.8 l	07/98→07/00			
1.8 T	110 kW	1.8 l	07/98→12/10	⊗ AUM / ARX ⊗ AGU; for vehicles without e-throttle	5DA 006 623-771 Switch Unit, ignition system	8
				⊗ AUM / ARX; Model 2001→Model 2008; 4x	5DA 193 175-911 Ignition Coil	27
				⊗ ARZ; →Model 2000; 4x	5DA 193 175-981 Ignition Coil	30
				⊗ AGU	5DA 358 000-051 Ignition Coil	32
1.8 T 4x4	110 kW	1.8 l	05/01→05/06	for vehicles without e-throttle	5DA 006 623-771 Switch Unit, ignition system	8
				→Model 2008; 4x	5DA 193 175-911 Ignition Coil	27
2.0	85 kW	2 l	04/99→05/07	⊗ AQY / AEG / APK / AZH	5DA 358 000-171 Ignition Coil	33
				⊗ AZJ	5DA 358 000-181 Ignition Coil	33
2.0 4x4	85 kW	2 l	08/00→09/04	⊗ AZH	5DA 358 000-171 Ignition Coil	33
				⊗ AZJ	5DA 358 000-181 Ignition Coil	33
RS 1.8 T	132 kW	1.8 l	08/02→01/06	⊗ AUQ	5DA 006 623-771 Switch Unit, ignition system	8
				⊗ AUQ; →Model 2008; 4x	5DA 193 175-911 Ignition Coil	27
SKODA - OCTAVIA Combi (1Z5)					02/04→06/13	
1.2 TSI	77 kW	1.2 l	02/10→04/13		5DA 358 000-171 Ignition Coil	33
1.6	75 kW	1.6 l	09/04→06/13			
1.6 LPG	75 kW	1.6 l	08/09→11/12			
1.6 MultiFuel	75 kW	1.6 l	01/08→06/13			
1.4	59 kW	1.4 l	05/06→06/13	⊗ BUD; ⚡ 1Z-5-000001→; 4x	5DA 193 175-501 Ignition Coil	16
1.4 TSI	90 kW	1.4 l	11/08→06/13	⊗ CAXA; 4x	5DA 193 175-501 Ignition Coil	16
1.6 FSI	85 kW	1.6 l	02/04→10/08	⊗ BLF; ⚡ 1Z-5-000001→; →Model 2008; 4x	5DA 193 175-501 Ignition Coil	16
1.8 TSI	118 kW	1.8 l	06/07→04/13	⊗ CDAA / BZB; 4	5DA 193 175-921 Ignition Coil	28
1.8 TSI 4x4	118 kW	1.8 l	11/08→02/13	⊗ CDAA; 4	5DA 193 175-921 Ignition Coil	28
2.0 FSI	110 kW	2 l	11/04→10/08	⊗ BVZ / BVY / BLR / BLY; 4	5DA 193 175-921 Ignition Coil	28
2.0 FSI 4x4	110 kW	2 l	11/04→10/08	⊗ BVX / BLX; 4	5DA 193 175-921 Ignition Coil	28
2.0 RS	147 kW	2 l	10/05→02/13	⊗ CCZA / BWA; 4	5DA 193 175-921 Ignition Coil	28
SKODA - OCTAVIA Combi (5E5)					11/12→	
1.2 TSI	63 kW	1.2 l	11/12→	⊗ CJZB; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
1.2 TSI	77 kW	1.2 l	11/12→	⊗ CJZA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
1.4 TSI	103 kW	1.4 l	11/12→	⊗ CHPA; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
SKODA - RAPID (NH3)					07/12→	
1.2 TSI	63 kW	1.2 l	07/12→		5DA 358 000-171 Ignition Coil	33
1.2 TSI	77 kW	1.2 l	07/12→			
SKODA - RAPID Spaceback (NH1)					07/12→	
1.2 TSI	63 kW	1.2 l	07/12→		5DA 358 000-171 Ignition Coil	33
1.2 TSI	77 kW	1.2 l	07/12→			
SKODA - ROOMSTER (5J)					05/06→01/07	
1.2	47 kW	1.2 l	05/06→01/07	⊗ BME; 3x	5DA 193 175-501 Ignition Coil	16
1.2	51 kW	1.2 l	01/07→	⊗ BZG / CGPA; 3x	5DA 193 175-501 Ignition Coil	16

SKODA - ROOMSTER (5J)						05/06→01/07
1.2 TSI	63 kW	1.2 l	03/10→		5DA 358 000-171 Ignition Coil	33
1.2 TSI	77 kW	1.2 l	03/10→		5DA 358 000-171 Ignition Coil	33
1.4	63 kW	1.4 l	09/06→	BXW; 4x	5DA 193 175-501 Ignition Coil	16
1.6	77 kW	1.6 l	09/06→	BTS; 4x	5DA 193 175-501 Ignition Coil	16
SKODA - ROOMSTER Praktik (5J)						03/07→
1.2	51 kW	1.2 l	03/07→	BZG / CGPA; 3x	5DA 193 175-501 Ignition Coil	16
1.2 TSI	63 kW	1.2 l	03/10→		5DA 358 000-171 Ignition Coil	33
1.4	63 kW	1.4 l	03/07→	BXW; 4x	5DA 193 175-501 Ignition Coil	16
SKODA - SUPERB (3T4)						03/08→
1.4 TSI	92 kW	1.4 l	07/08→	CAXC; 3T-8-000001→; 4x	5DA 193 175-501 Ignition Coil	16
1.8 TSI	118 kW	1.8 l	03/08→	CDAA / BZB; 4	5DA 193 175-921 Ignition Coil	28
1.8 TSI 4x4	118 kW	1.8 l	11/08→	CDAA; 4	5DA 193 175-921 Ignition Coil	28
2.0 TSI	147 kW	2 l	05/10→	CCZA; 4	5DA 193 175-921 Ignition Coil	28
SKODA - SUPERB Estate (3T5)						10/09→
1.4 TSI	92 kW	1.4 l	10/09→	CAXC; 3T-8-000001→; 4x	5DA 193 175-501 Ignition Coil	16
1.8 TSI	118 kW	1.8 l	10/09→	CDAA; 4	5DA 193 175-921 Ignition Coil	28
1.8 TSI 4x4	118 kW	1.8 l	10/09→	CDAA; 4	5DA 193 175-921 Ignition Coil	28
2.0 TSI	147 kW	2 l	05/10→	CCZA; 4	5DA 193 175-921 Ignition Coil	28
SKODA - SUPERB Saloon (3U4)						12/01→03/08
1.8 T	110 kW	1.8 l	12/01→03/08	AWT; 4x	5DA 193 175-911 Ignition Coil	27
2.0	85 kW	2 l	12/01→03/08		5DA 358 000-171 Ignition Coil	33
2.8 V6	142 kW	2.8 l	12/01→03/08	AMX	5DA 749 475-471 Ignition Coil	39
SKODA - YETI (5L)						05/09→
1.2 TSI	77 kW	1.2 l	09/09→		5DA 358 000-171 Ignition Coil	33
1.4 TSI	90 kW	1.4 l	06/10→	CAXA; 4x	5DA 193 175-501 Ignition Coil	16
1.8 TSI 4x4	112 kW	1.8 l	11/09→	CDAB; 4	5DA 193 175-921 Ignition Coil	28
1.8 TSI 4x4	118 kW	1.8 l	05/09→	CDAA; 4	5DA 193 175-921 Ignition Coil	28

				412				
SMART - CABRIO (450)				03/00→01/04				
0.6 (450.400, S1OLD2)	45 kW	0.6 l	01/01→01/04	5DA 193 175-661 Ignition Coil	19			
0.6 (450.432)	52 kW	0.6 l	06/02→01/04					
0.6 (450.433, S1OLA1)	40 kW	0.6 l	03/00→01/04					
0.7 (450.414)	55 kW	0.7 l	01/03→01/04					
0.7 (450.441, 450.442)	45 kW	0.7 l	01/03→01/04					
SMART - CITY-COUPE (450)				07/98→01/04				
0.6 (450.330, 450.332)	52 kW	0.6 l	06/02→01/04	5DA 193 175-661 Ignition Coil	19			
0.6 (450.333, 450.335)	45 kW	0.6 l	01/01→01/04					
0.6 (450.341, S1CLA1)	40 kW	0.6 l	07/98→01/04					
0.6 (450.342, S1CLB1)	33 kW	0.6 l	07/98→01/04					
0.7 (450.314)	55 kW	0.7 l	01/03→01/04					
0.7 (450.336, 450.352, 450.353)	45 kW	0.7 l	01/03→01/04					
0.7 (450.347)	37 kW	0.7 l	01/03→01/04					
SMART - CROSSBLADE (450)						06/02→12/03		
0.6 (450.418)	52 kW	0.6 l	06/02→12/03			5DA 193 175-661 Ignition Coil	19	
SMART - FORTWO Cabrio (450)				01/04→01/07				
0.7 (450.414, 450.441, 450.442, 450.443, 450.452)	45 kW	0.7 l	01/04→01/07	5DA 193 175-661 Ignition Coil	19			
0.7 (450.452)	55 kW	0.7 l	01/04→01/07					
SMART - FORTWO Coupe (450)				01/04→01/07				
0.7 (450.314)	55 kW	0.7 l	01/04→01/07	5DA 193 175-661 Ignition Coil	19			
0.7 (450.331)	37 kW	0.7 l	01/04→01/07					
0.7 (450.335, 450.336, 450.341, 450.342, 450.343...)	45 kW	0.7 l	01/04→01/07					
SMART - ROADSTER (452)				04/03→11/05				
0.7 (452.432)	45 kW	0.7 l	04/03→11/05	5DA 193 175-661 Ignition Coil	19			
0.7 (452.434)	60 kW	0.7 l	04/03→11/05					
0.7 Brabus (452.437)	74 kW	0.7 l	12/03→11/05					
SMART - ROADSTER Coupe (452)				04/03→11/05				
0.7 (452.332)	45 kW	0.7 l	06/03→11/05	5DA 193 175-661 Ignition Coil	19			
0.7 (452.334)	60 kW	0.7 l	04/03→11/05					
0.7 Brabus (452.337)	74 kW	0.7 l	12/03→11/05					








SSANGYONG - KORANDO (KJ)							01/99 →
3.2	156 kW	3.2 l	01/99→	3x	5DA 193 175-361 Ignition Coil	11	
SSANGYONG - KORANDO Cabrio (KJ)							01/99 →
3.2	156 kW	3.2 l	01/99→	3x	5DA 193 175-361 Ignition Coil	11	



 				 13		412	
TALBOT - SAMBA (51A)							01/81 → 06/86
1.1	37 kW	1.1 l	01/81 → 06/86			5DA 006 623-001 Switch Unit, ignition system	4
1.4	53 kW	1.4 l	01/81 → 06/86	 XY7		5DA 006 623-001 Switch Unit, ignition system	4



TOYOTA - AVENSIS (_T22_)													10/00→02/03		
2.0 VVT-i	110 kW	2 l	10/00→02/03	⊗ 1AZ-FSE; →12/02; 4x	5DA 193 175-941 Ignition		28		Coil						
TOYOTA - AVENSIS (T25_)													04/03→11/08		
2.0	108 kW	2 l	04/03→11/08	⊗ 1AZ-FSE; →03/06; 4x	5DA 193 175-941 Ignition		28		Coil						
2.4	120 kW	2.4 l	10/03→11/08	⊗ 2AZ-FSE; →10/08; 4x; Automatic Transmission, 5-speed	5DA 193 175-941 Ignition		28		Coil						
2.4	125 kW	2.4 l	09/03→11/08		Coil										
TOYOTA - AVENSIS Estate (T25)													04/03→12/09		
2.0	108 kW	2 l	04/03→12/09	⊗ 1AZ-FSE; 4x →03/06; for vehicles with manual transmission →10/08; + autom.	5DA 193 175-941 Ignition		28		Coil						
2.4	120 kW	2.4 l	10/03→11/08	⊗ 2AZ-FSE; →10/08; Automatic Transmission, 5-speed; 4x	5DA 193 175-941 Ignition		28		Coil						
2.4	125 kW	2.4 l	09/03→11/08		Coil										
TOYOTA - AVENSIS Liftback (_T22_)													10/00→02/03		
2.0 VVT-i	110 kW	2 l	10/00→02/03	⊗ 1AZ-FSE; 4x; →12/02	5DA 193 175-941 Ignition		28		Coil						
TOYOTA - AVENSIS Saloon (T25)													04/03→11/08		
2.0	108 kW	2 l	04/03→11/08	⊗ 1AZ-FSE; →03/06; 4x	5DA 193 175-941 Ignition		28		Coil						
2.4	120 kW	2.4 l	10/03→11/08	⊗ 2AZ-FSE; →10/08; Automatic Transmission, 5-speed; 4x	5DA 193 175-941 Ignition		28		Coil						
2.4	125 kW	2.4 l	09/03→11/08		Coil										
TOYOTA - AVENSIS Station Wagon (_T22_)													10/00→02/03		
2.0 VVT-i	110 kW	2 l	10/00→02/03	⊗ 1AZ-FSE; →12/02; 4x	5DA 193 175-941 Ignition		28		Coil						
TOYOTA - ECHO (SCP1_, NLP1_, NCP1_)													04/99→09/05		
1.0 16V	48 kW	1 l	03/03→09/05	⊗ 1SZ-FE; 4	5DA 193 175-931 Ignition		28		Coil						
1.0 16V	50 kW	1 l	04/99→09/05		Coil										
1.3	64 kW	1.3 l	04/02→09/05	⊗ 2SZ-FE; 4	5DA 193 175-931 Ignition		28		Coil						
1.3 16V	63 kW	1.3 l	11/99→09/05	⊗ 2NZ-FE; 4	5DA 193 175-931 Ignition		28		Coil						
1.5 TS	77 kW	1.5 l	01/03→09/05	⊗ 1NZ-FE; 4	5DA 193 175-931 Ignition		28		Coil						
1.5 VVT-i TS	78 kW	1.5 l	04/01→09/05		Coil										
TOYOTA - IQ (KPJ1_, NGJ1_, KGJ1_, NUJ1_)													01/09→		
1.0	50 kW	1 l	01/09→	⊗ 1KR-FE; 3	5DA 193 175-931 Ignition		28		Coil						
TOYOTA - LAND CRUISER PRADO (KDJ12_, GRJ12_)													01/03→		
4.0 (GRJ12, GRJ125)	183 kW	4 l	01/03→	⊗ 1GR-FE; 6x →07/04; Automatic Transmission, 4-speed 08/04→07/09; Automatic Transmission, 5-speed	5DA 193 175-941 Ignition		28		Coil						
TOYOTA - PRIUS C (NHP10_)													02/12→		
1.5 Hybrid	54 kW	1.5 l	02/12→	⊗ 1NZ-FXE; 4	5DA 193 175-931 Ignition		28		Coil						
TOYOTA - PRIUS Hatchback (NHW20_)													08/03→03/09		
1.5	57 kW	1.5 l	08/03→03/09	⊗ 1NZ-FXE; 4	5DA 193 175-931 Ignition		28		Coil						
TOYOTA - PRIUS Saloon (NHW11_)													05/00→01/04		
1.5 Hybrid	53 kW	1.5 l	05/00→01/04	⊗ 1NZ-FXE; 4	5DA 193 175-931 Ignition		28		Coil						
TOYOTA - YARIS (NHP13_, NSP13_, NCP13_, KSP13_, NLP13_)													03/12→		
1.5 Hybrid	55 kW	1.5 l	03/12→	⊗ 1NZ-FXE; 4	5DA 193 175-931 Ignition		28		Coil						
TOYOTA - YARIS (SCP9_, NSP9_, KSP9_, NCP9_, ZSP9_)													08/05→		
1.3 VVT-i	64 kW	1.3 l	08/05→	⊗ 2SZ-FE; 4	5DA 193 175-931 Ignition		28		Coil						
TOYOTA - YARIS VERSO (_NLP2_, _NCP2_)													08/99→09/05		
1.3 (NCP22)	62 kW	1.3 l	11/02→09/05	⊗ 2NZ-FE; 4	5DA 193 175-931 Ignition		28		Coil						
1.3 (NCP22)	63 kW	1.3 l	08/99→10/02		Coil										

							
TOYOTA - YARIS VERSO (_NLP2_, _NCP2_)							08/99 → 09/05
1.5 (NCP21)	77 kW	1.5 l	05/03 → 09/05	1NZ-FE; 4	5DA 193 175-931 Ignition	28	
1.5 (NCP21)	78 kW	1.5 l	03/00 → 09/05		Coil		



VOLVO - 240 Kombi (P245)										08/84→12/88			
2.0	76 kW	2 l	08/84→07/85							5DA 006 623-931 Switch	8		
2.3	81 kW	2.3 l	08/84→07/86							Unit, ignition system			
2.3	83 kW	2.3 l	08/86→07/87										
2.3	96 kW	2.3 l	08/84→07/85										
2.3	98 kW	2.3 l	08/84→12/88										
VOLVO - 240 Saloon (P242, P244)										08/83→07/93			
2.0	76 kW	2 l	08/84→07/85							5DA 006 623-931 Switch	8		
2.3	83 kW	2.3 l	08/86→07/87							Unit, ignition system			
2.3	98 kW	2.3 l	08/84→12/89										
2.3	81 kW	2.3 l	08/84→07/86							5DA 006 623-931 Switch	8		
										Unit, ignition system			
										B230K			
										5DA 006 623-941 Switch	9		
										Unit, ignition system			
2.3	96 kW	2.3 l	08/83→07/85	08/84→						5DA 006 623-931 Switch	8		
										Unit, ignition system			
2.3 i CAT	85 kW	2.3 l	08/86→07/93	→07/90;	B230K					5DA 006 623-941 Switch	9		
										Unit, ignition system			
VOLVO - 340-360 (343, 345)										08/82→07/84			
2.0	83 kW	2 l	08/82→07/84	→08/83						5DA 006 623-931 Switch	8		
										Unit, ignition system			
VOLVO - 340-360 Saloon (344)										08/83→07/84			
2.0	83 kW	2 l	08/83→07/84	→08/83						5DA 006 623-931 Switch	8		
										Unit, ignition system			
VOLVO - 740 Kombi (745)										09/85→07/90			
2.3	84 kW	2.3 l	09/85→07/90							5DA 006 623-201 Switch	5		
										Unit, ignition system			
VOLVO - 740 Saloon (744)										08/83→07/88			
2.0	110 kW	2 l	12/83→07/84							5DA 006 623-931 Switch	8		
2.3	95 kW	2.3 l	08/83→07/84							Unit, ignition system			
2.3	86 kW	2.3 l	08/86→07/88							5DA 006 623-201 Switch	5		
										Unit, ignition system			
VOLVO - 850 (LS)										08/93→12/96			
2.0 Turbo	155 kW	2 l	08/93→12/96	B 5204 FT						5DA 358 000-101 Ignition	32		
										Coil			
2.3 T5	166 kW	2.3 l	08/93→07/96							5DA 358 000-101 Ignition	32		
2.3 T5-R	184 kW	2.3 l	08/95→12/96							Coil			
2.5	106 kW	2.5 l	08/94→12/96										
VOLVO - 850 Estate (LW)										02/93→12/96			
2.0 Turbo	155 kW	2 l	02/93→12/96	B 5204 FT						5DA 358 000-101 Ignition	32		
										Coil			
2.3 T5	166 kW	2.3 l	02/93→12/96							5DA 358 000-101 Ignition	32		
2.3 T5-R	184 kW	2.3 l	08/95→12/96							Coil			
2.5	106 kW	2.5 l	08/94→12/96										
2.5 AWD	142 kW	2.5 l	04/96→12/96										
VOLVO - 940 II (944)										08/94→10/98			
2.3	85 kW	2.3 l	08/94→07/95							5DA 006 623-201 Switch	5		
2.3 ti	99 kW	2.3 l	01/95→10/98							Unit, ignition system			
VOLVO - 940 II Estate (945)										08/94→10/98			
2.3	85 kW	2.3 l	08/94→07/95							5DA 006 623-201 Switch	5		
2.3 ti	99 kW	2.3 l	01/95→10/98							Unit, ignition system			
VOLVO - 940 Kombi (945)										08/90→07/94			
2.0	82 kW	2 l	01/92→07/94							5DA 006 623-201 Switch	5		
2.3	85 kW	2.3 l	08/92→07/94							Unit, ignition system			
2.3	114 kW	2.3 l	08/90→07/91										
VOLVO - 940 Saloon (944)										01/92→07/94			
2.0	82 kW	2 l	01/92→07/94							5DA 006 623-201 Switch	5		
2.3	85 kW	2.3 l	08/92→07/94							Unit, ignition system			
VOLVO - C30										10/06→12/12			
1.6	74 kW	1.6 l	10/06→12/12	B 4164 S3; 1x						5DA 193 175-791 Ignition	23		
										Coil			
1.8	92 kW	1.8 l	10/06→12/12	B 4184 S11; 4						5DA 193 175-781 Ignition	23		
										Coil			

										13		412		
VOLVO - C30										10/06→12/12				
1.8 FlexFuel	92 kW	1.8 l	01/07→12/12	⊖ B 4184 S8; 4	5DA 193 175-781 Ignition Coil	23								
2.0	107 kW	2 l	10/06→12/12	⊖ B 4204 S3; 4	5DA 193 175-781 Ignition Coil	23								
2.0 FlexFuel	107 kW	2 l	01/10→12/12	⊖ B 4204 S4; 4	5DA 193 175-781 Ignition Coil	23								
2.4 i	125 kW	2.4 l	10/06→12/12	⊖ B 5244 S4; 5	5DA 193 175-801 Ignition Coil	24								
T5	162 kW	2.5 l	10/06→12/12	⊖ B 5254 T3; 5	5DA 193 175-801 Ignition Coil	24								
T5	169 kW	2.5 l	03/07→12/12	⊖ B 5254 T7; 5	5DA 193 175-801 Ignition Coil	24								
VOLVO - C70 I Convertible										03/98→10/05				
2.0	132 kW	2 l	03/98→10/05		5DA 358 000-101 Ignition Coil	32								
2.0 T	120 kW	2 l	03/00→10/05		5DA 358 000-071 Ignition Coil	32								
2.3 T5	180 kW	2.3 l	07/02→10/05		5DA 358 000-071 Ignition Coil	32								
2.4 T	147 kW	2.4 l	07/02→10/05		5DA 358 000-071 Ignition Coil	32								
2.5 T	142 kW	2.5 l	03/98→10/05		5DA 358 000-071 Ignition Coil	32								
				⊖ B 5254 T	5DA 358 000-101 Ignition Coil	32								
VOLVO - C70 I Coupe										03/97→09/02				
2.0	132 kW	2 l	03/97→09/02		5DA 358 000-101 Ignition Coil	32								
2.0 T	120 kW	2 l	03/00→09/02		5DA 358 000-071 Ignition Coil	32								
2.5	121 kW	2.5 l	03/99→09/02		5DA 358 000-071 Ignition Coil	32								
2.5	125 kW	2.5 l	05/99→09/02		5DA 358 000-071 Ignition Coil	32								
2.5 T	142 kW	2.5 l	03/97→09/02		5DA 358 000-071 Ignition Coil	32								
				⊖ B 5254 T	5DA 358 000-101 Ignition Coil	32								
VOLVO - C70 II Convertible										03/06→				
2.4	103 kW	2.4 l	03/06→	⊖ B 5244 S5; 5	5DA 193 175-801 Ignition Coil	24								
2.4 i	125 kW	2.4 l	03/06→	⊖ B 5244 S4; 5	5DA 193 175-801 Ignition Coil	24								
T5	162 kW	2.5 l	03/06→	⊖ B 5254 T3; 5	5DA 193 175-801 Ignition Coil	24								
T5	169 kW	2.5 l	03/07→	⊖ B 5254 T7; 5	5DA 193 175-801 Ignition Coil	24								
VOLVO - S40 I Saloon (VS)										07/95→12/03				
1.6	77 kW	1.6 l	09/95→08/99	⊖ B 4164 S	5DA 749 475-101 Ignition Coil	36								
				⊖ B 4164 S	5DA 749 475-201 Ignition Coil	37								
1.8	85 kW	1.8 l	07/95→08/99	⊖ B 4184 S	5DA 749 475-101 Ignition Coil	36								
				⊖ B 4184 S	5DA 749 475-201 Ignition Coil	37								
1.8	90 kW	1.8 l	03/99→12/03	⊖ B 4184 S2 / B 4184 S9; →Model 1999	5DA 749 475-101 Ignition Coil	36								
				⊖ B 4184 S2; →Model 1999	5DA 749 475-201 Ignition Coil	37								
2.0	100 kW	2 l	07/95→12/03	⊖ B 4204 S; →08/99	5DA 749 475-101 Ignition Coil	36								
				⊖ B 4204 S; →08/99	5DA 749 475-201 Ignition Coil	37								
2.0	103 kW	2 l	07/95→08/99	⊖ B 4204 S	5DA 749 475-101 Ignition Coil	36								
				⊖ B 4204 S	5DA 749 475-201 Ignition Coil	37								
VOLVO - S40 II Saloon (MS)										01/04→				
1.6	74 kW	1.6 l	01/05→	⊖ B 4164 S3; →106166	5DA 193 175-411 Ignition Coil	13								
				⊖ B 4164 S3; →106167→	5DA 193 175-791 Ignition Coil	23								
1.8	92 kW	1.8 l	04/04→	⊖ B 4184 S11; 4	5DA 193 175-781 Ignition Coil	23								

VOLVO - S40 II Saloon (MS)							01/04→
1.8 FlexFuel	92 kW	1.8 l	01/06→	⊗ B 4184 S8; 4	5DA 193 175-781 Ignition Coil	23	
2.0	107 kW	2 l	10/06→	⊗ B 4204 S3; 4	5DA 193 175-781 Ignition Coil	23	
2.0 F	107 kW	2 l	10/06→	⊗ B 4204 S4; 4	5DA 193 175-781 Ignition Coil	23	
2.4	103 kW	2.4 l	01/04→	⊗ B 5244 S5; 5	5DA 193 175-801 Ignition Coil	24	
T5	162 kW	2.5 l	01/04→	⊗ B 5254 T3; 5	5DA 193 175-801 Ignition Coil	24	
T5 AWD	162 kW	2.5 l	04/04→				
T5	169 kW	2.5 l	03/07→	⊗ B 5254 T7; 5	5DA 193 175-801 Ignition Coil	24	
T5 AWD	169 kW	2.5 l	03/07→				
VOLVO - S60 I Saloon							07/00→04/10
2.0 T	132 kW	2 l	07/00→04/10	⊗ B 5204 T5; Model 2005→; 5	5DA 193 175-801 Ignition Coil	24	
					5DA 358 000-071 Ignition Coil	32	
2.4	103 kW	2.4 l	11/00→04/10		5DA 358 000-071 Ignition Coil	32	
2.4	125 kW	2.4 l	11/00→04/10				
2.4 Bifuel (CNG)	103 kW	2.4 l	06/02→04/10				
2.4 Bifuel (LPG)	103 kW	2.4 l	06/02→04/10				
2.4 T	147 kW	2.4 l	11/00→04/10				
2.4 T AWD	147 kW	2.4 l	11/01→04/10				
2.5 T	154 kW	2.5 l	02/04→04/10				
2.5 T AWD	154 kW	2.5 l	04/04→04/10				
T5	184 kW	2.3 l	11/00→04/10				
2.4 T5	191 kW	2.4 l	04/04→04/10	⊗ B 5244 T5; 5	5DA 193 175-801 Ignition Coil	24	
					5DA 358 000-071 Ignition Coil	32	
R 2,5 T AWD	221 kW	2.5 l	03/03→04/10	⊗ B 5254 T4; 5	5DA 193 175-801 Ignition Coil	24	
					5DA 358 000-071 Ignition Coil	32	
VOLVO - S70 Saloon (LS)							11/96→11/00
2.0	93 kW	2 l	01/97→11/00	⊗ B 5202 FS	5DA 358 000-101 Ignition Coil	32	
2.0	120 kW	2 l	01/97→11/00		5DA 358 000-071 Ignition Coil	32	
2.4	103 kW	2.4 l	08/99→11/00				
2.4	125 kW	2.4 l	01/97→11/00				
2.4 AWD	103 kW	2.4 l	04/99→09/00				
2.4 AWD	121 kW	2.4 l	10/98→05/99				
2.4 AWD	125 kW	2.4 l	04/99→09/00				
2.5	121 kW	2.5 l	06/98→11/00				
2.5 Bifuel	103 kW	2.5 l	07/99→11/00				
2.0	132 kW	2 l	01/97→11/00		5DA 358 000-101 Ignition Coil	32	
2.4 AWD	106 kW	2.4 l	11/96→05/99				
2.5	106 kW	2.5 l	01/97→11/00				
2.5 Bifuel	106 kW	2.5 l	10/98→11/00				
2.4 Blu-Fuel	103 kW	2.4 l	07/97→09/00	01/99→	5DA 358 000-071 Ignition Coil	32	
2.4 Turbo	142 kW	2.4 l	01/97→11/00		5DA 358 000-071 Ignition Coil	32	
				⊗ B 5254 T	5DA 358 000-101 Ignition Coil	32	
VOLVO - S80 I Saloon (TS, XY)							05/98→07/06
2.0	120 kW	2 l	06/98→07/06		5DA 358 000-071 Ignition Coil	32	
2.0 T	166 kW	2 l	06/98→07/06				
2.4	103 kW	2.4 l	01/99→07/06				
2.4	125 kW	2.4 l	01/99→07/06				
2.4 Bifuel (CNG)	103 kW	2.4 l	09/01→07/06				
2.4 Bifuel (LPG)	103 kW	2.4 l	09/01→07/06				
2.4 T	147 kW	2.4 l	06/00→07/06				
2.4 T5 AWD	147 kW	2.4 l	04/00→09/03				
2.5 T	154 kW	2.5 l	03/03→07/06				
2.5 T AWD	154 kW	2.5 l	07/03→07/06				
2.8 T6	200 kW	2.8 l	05/98→07/06				
2.9	147 kW	2.9 l	03/99→07/06				
3.0	144 kW	3 l	06/01→07/06				
3.0 T6	200 kW	3 l	06/01→07/06				

VOLVO - S80 I Saloon (TS, XY)						05/98→07/06
2.0 T	132 kW	2 l	12/99→07/06	⊗ B 5204 T5; Model 2005→; 5	5DA 193 175-801 Ignition Coil	24
					5DA 358 000-071 Ignition Coil	32
VOLVO - S80 II Saloon (AS)						03/06→
2.0	107 kW	2 l	01/08→	⊗ B 4204 S3; 4	5DA 193 175-781 Ignition Coil	23
2.0 FlexFuel	107 kW	2 l	01/08→	⊗ B 4204 S4; 4	5DA 193 175-781 Ignition Coil	23
2.5 T	147 kW	2.5 l	03/06→	⊗ B 5254 T6; 5	5DA 193 175-801 Ignition Coil	24
2.5 T	170 kW	2.5 l	01/10→	⊗ B 5254 T10; 5	5DA 193 175-801 Ignition Coil	24
2.5 T FlexFuel	147 kW	2.5 l	05/08→	⊗ B 5254 T8; 5	5DA 193 175-801 Ignition Coil	24
2.5 T FlexFuel	170 kW	2.5 l	01/10→	⊗ B 5254 T11; 5	5DA 193 175-801 Ignition Coil	24
VOLVO - V40 Estate (VW)						07/95→06/04
1.6	77 kW	1.6 l	12/95→08/99	⊗ B 4164 S	5DA 749 475-101 Ignition Coil	36
				⊗ B 4164 S	5DA 749 475-201 Ignition Coil	37
1.6	80 kW	1.6 l	03/99→06/04	⊗ B 4164 S2; →Model 1999	5DA 749 475-101 Ignition Coil	36
				⊗ B 4164 S2; →Model 1999	5DA 749 475-201 Ignition Coil	37
1.8	85 kW	1.8 l	07/95→08/99	⊗ B 4184 S	5DA 749 475-101 Ignition Coil	36
				⊗ B 4184 S	5DA 749 475-201 Ignition Coil	37
1.8	90 kW	1.8 l	03/99→06/04	⊗ B 4184 S9 / B 4184 S2; →Model 1999	5DA 749 475-101 Ignition Coil	36
				⊗ B 4184 S9 / B 4184 S2; →Model 1999	5DA 749 475-201 Ignition Coil	37
2.0	100 kW	2 l	07/95→06/04	⊗ B 4204 S; →08/99	5DA 749 475-101 Ignition Coil	36
				⊗ B 4204 S; →08/99	5DA 749 475-201 Ignition Coil	37
2.0	103 kW	2 l	07/95→08/99	⊗ B 4204 S	5DA 749 475-101 Ignition Coil	36
				⊗ B 4204 S	5DA 749 475-201 Ignition Coil	37
VOLVO - V40 Hatchback						03/12→
T4 GTDi	132 kW	1.6 l	03/12→	⊗ B 4164 T; 4 ports; 4x	5DA 193 175-951 Ignition Coil	29
VOLVO - V50 Estate (MW)						04/04→
1.6	74 kW	1.6 l	01/05→	⊗ B 4164 S3; →105439	5DA 193 175-411 Ignition Coil	13
				⊗ B 4164 S3; 1x	5DA 193 175-791 Ignition Coil	23
1.8	92 kW	1.8 l	04/04→	⊗ B 4184 S11; 4	5DA 193 175-781 Ignition Coil	23
1.8 FlexFuel	92 kW	1.8 l	01/05→	⊗ B 4184 S8; 4	5DA 193 175-781 Ignition Coil	23
2.0	107 kW	2 l	10/06→	⊗ B 4204 S3; 4	5DA 193 175-781 Ignition Coil	23
2.0 FlexFuel	107 kW	2 l	01/10→	⊗ B 4204 S4; 4	5DA 193 175-781 Ignition Coil	23
2.4	103 kW	2.4 l	04/04→	⊗ B 5244 S5; 5	5DA 193 175-801 Ignition Coil	24
2.4	125 kW	2.4 l	04/04→	⊗ B 5244 S4; 5	5DA 193 175-801 Ignition Coil	24
T5	162 kW	2.5 l	04/04→	⊗ B 5254 T3; 5	5DA 193 175-801 Ignition Coil	24
T5 AWD	162 kW	2.5 l	04/04→			
T5	169 kW	2.5 l	03/07→	⊗ B 5254 T7; 5	5DA 193 175-801 Ignition Coil	24
T5 AWD	169 kW	2.5 l	03/07→			
VOLVO - V70 I (LV)						01/97→05/00
2.0	120 kW	2 l	01/97→03/00	01/99→	5DA 358 000-071 Ignition Coil	32

				13	i	412			
VOLVO - V70 I (LV)							01/97→05/00		
2.0	132 kW	2 l	01/97→03/00				5DA 358 000-101	Ignition	32
2.3 AWD	177 kW	2.3 l	04/97→09/98				Coil		
2.5	106 kW	2.5 l	01/97→03/00						
2.5 Bifuel	106 kW	2.5 l	10/98→08/99						
2.0 Turbo	166 kW	2 l	01/97→03/00	01/99→			5DA 358 000-071	Ignition	32
2.0 Turbo AWD	166 kW	2 l	01/97→03/00				Coil		
2.3 T-5	176 kW	2.3 l	01/97→03/00				5DA 358 000-101	Ignition	32
2.3 T-5 AWD	176 kW	2.3 l	01/97→03/00				Coil		
2.3 T AWD	184 kW	2.3 l	04/97→03/00		B 5234 T4		5DA 358 000-101	Ignition	32
							Coil		
2.4	103 kW	2.4 l	08/99→05/00				5DA 358 000-071	Ignition	32
2.4	125 kW	2.4 l	01/97→05/00				Coil		
2.4 AWD	121 kW	2.4 l	10/98→05/99						
2.4 Bifuel	103 kW	2.4 l	08/99→03/00						
2.5	121 kW	2.5 l	06/98→03/00						
2.5 AWD	195 kW	2.5 l	03/99→03/00						
2.4 Turbo	142 kW	2.4 l	01/97→03/00	01/99→			5DA 358 000-071	Ignition	32
2.5 Turbo AWD	142 kW	2.5 l	01/97→05/00				Coil		
					B 5254 T		5DA 358 000-101	Ignition	32
							Coil		
VOLVO - V70 II (SW)							03/00→08/07		
2.0 T	132 kW	2 l	07/01→08/07		B 5204 T5; Model 2005→; 5		5DA 193 175-801	Ignition	24
							Coil		
							5DA 358 000-071	Ignition	32
							Coil		
2.4	103 kW	2.4 l	03/00→08/07				5DA 358 000-071	Ignition	32
2.4	125 kW	2.4 l	03/00→08/07				Coil		
2.4 Bifuel (CNG)	103 kW	2.4 l	09/01→08/07						
2.4 Bifuel (LPG)	103 kW	2.4 l	09/01→08/07						
2.4 T	147 kW	2.4 l	03/00→08/03						
2.4 T AWD	147 kW	2.4 l	09/01→08/02						
2.5 T	154 kW	2.5 l	04/04→08/07						
2.5 T AWD	154 kW	2.5 l	09/02→08/07						
2.4 T5	191 kW	2.4 l	04/04→08/07		B 5244 T5; 5		5DA 193 175-801	Ignition	24
							Coil		
							5DA 358 000-071	Ignition	32
							Coil		
R 2,5 T AWD	221 kW	2.5 l	03/03→08/07		B 5254 T4; 5		5DA 193 175-801	Ignition	24
							Coil		
							5DA 358 000-071	Ignition	32
							Coil		
VOLVO - V70 III (BW)							08/07→		
2.0	107 kW	2 l	10/07→		B 4204 S3; 4		5DA 193 175-781	Ignition	23
							Coil		
2.0 FlexiFuel	107 kW	2 l	01/08→		B 4204 S4; 4		5DA 193 175-781	Ignition	23
							Coil		
2.5 T	147 kW	2.5 l	08/07→		B 5254 T6; 5		5DA 193 175-801	Ignition	24
							Coil		
2.5 T	170 kW	2.5 l	01/10→		B 5254 T10; 5		5DA 193 175-801	Ignition	24
							Coil		
2.5 T FlexiFuel	147 kW	2.5 l	05/08→		B 5254 T8; 5		5DA 193 175-801	Ignition	24
							Coil		
2.5 T FlexiFuel	170 kW	2.5 l	10/09→		B 5254 T11; 5		5DA 193 175-801	Ignition	24
							Coil		
VOLVO - XC70 CROSS COUNTRY Estate							11/97→08/07		
2.4 T XC AWD	142 kW	2.4 l	11/97→09/02	01/99→			5DA 358 000-071	Ignition	32
							Coil		
							5DA 358 000-101	Ignition	32
							Coil		
2.4 T XC AWD	147 kW	2.4 l	03/00→09/02				5DA 358 000-071	Ignition	32
2.5 T XC AWD	154 kW	2.5 l	09/02→08/07				Coil		
VOLVO - XC90 I Estate							10/02→		
2.5 T	154 kW	2.5 l	10/02→				5DA 358 000-071	Ignition	32
T6	200 kW	2.9 l	10/02→				Coil		

VW - AMAROK (2H_, S1B)							12/10→
2.0 TSI	118 kW	2 l	12/10→	CFPA; 4	5DA 193 175-921 Ignition Coil	28	
VW - BEETLE							10/92→07/03
1600 i (Mexico)	34 kW	1.6 l	10/92→07/03	ACD; 11-P-000001→; →06/99	5DA 006 623-951 Ignition Coil	9	
VW - BEETLE (5C1)							04/11→
2.0 TSI	147 kW	2 l	04/11→	CCZA / CCTA / CBFA	5DA 193 175-921 Ignition Coil	28	
2.5	125 kW	2.5 l	04/11→	CCCA / CBUA / CBTA; 5	5DA 193 175-921 Ignition Coil	28	
VW - BEETLE (9C1, 1C1)							01/98→09/10
1.4	55 kW	1.4 l	11/01→09/10	BCA; →Model 2010; 4x	5DA 193 175-501 Ignition Coil	16	
1.6	74 kW	1.6 l	10/99→09/00		5DA 358 000-171 Ignition Coil	33	
1.6	75 kW	1.6 l	06/00→09/10		5DA 358 000-171 Ignition Coil	33	
1.8 T	110 kW	1.8 l	10/99→09/10	APH / AVC / AWW; →Model 2001	5DA 006 623-771 Switch Unit, ignition system	8	
				AWW / APH / AWU / AVC / BKF; 1C-1-400001→ / 9C-1-600001→; →Model 2008; 4x	5DA 193 175-911 Ignition Coil	27	
				AWW / APH / AVC / AWU; →1C-Y-499000 / →9C-Y-699000; 4x	5DA 193 175-981 Ignition Coil	30	
1.8 T	132 kW	1.8 l	11/01→06/05	BNU / AWP; 4x	5DA 193 175-911 Ignition Coil	27	
2.0	85 kW	2 l	01/98→09/10	AQY / CBPA / BHP / BER / APK / AEG	5DA 358 000-171 Ignition Coil	33	
				AVH / AZG / BHP / BEJ / AZJ / BEV	5DA 358 000-181 Ignition Coil	33	
2.3 V5	125 kW	2.3 l	10/00→09/10	AQN; 5	5DA 358 000-001 Ignition Coil	30	
2.5	110 kW	2.5 l	07/05→09/10	BPR / BPS; 5	5DA 193 175-921 Ignition Coil	28	
VW - BEETLE Convertible (1Y7)							09/02→10/10
1.4	55 kW	1.4 l	01/03→09/10	BCA; 4x	5DA 193 175-501 Ignition Coil	16	
1.6	75 kW	1.6 l	01/03→09/10		5DA 358 000-171 Ignition Coil	33	
1.8 T	110 kW	1.8 l	01/03→09/10	BKF / AWU; →Model 2010; 4x	5DA 193 175-911 Ignition Coil	27	
2.0	85 kW	2 l	09/02→10/10		5DA 358 000-181 Ignition Coil	33	
2.5	110 kW	2.5 l	07/05→09/10	BPR / BPS; 5	5DA 193 175-921 Ignition Coil	28	
VW - BEETLE Convertible (5C7)							12/12→
2.0 TSI	147 kW	2 l	12/12→	CBFA / CCZA / CCTA	5DA 193 175-921 Ignition Coil	28	
VW - BORA Estate (1J6)							05/99→05/05
1.4 16V	55 kW	1.4 l	09/01→05/05	BCA; 4x	5DA 193 175-501 Ignition Coil	16	
				AHW / AXP	5DA 358 000-171 Ignition Coil	33	
1.6	74 kW	1.6 l	05/99→05/05		5DA 358 000-171 Ignition Coil	33	
1.8 4motion	92 kW	1.8 l	05/99→05/05		5DA 358 000-171 Ignition Coil	33	
1.6	75 kW	1.6 l	08/00→05/05	AVU	5DA 358 000-171 Ignition Coil	33	
1.6 16V	77 kW	1.6 l	02/00→05/05	AZD / BCB; 4x	5DA 193 175-501 Ignition Coil	16	
				ATN / AUS	5DA 358 000-171 Ignition Coil	33	
1.6 FSI	81 kW	1.6 l	01/02→05/05	BAD; 4x	5DA 193 175-501 Ignition Coil	16	
1.8 T	110 kW	1.8 l	05/00→05/05	AGU; Model 2002→	5DA 006 623-771 Switch Unit, ignition system	8	
				AUM; Model 2002→; 4x	5DA 193 175-911 Ignition Coil	27	
				AGU	5DA 358 000-051 Ignition Coil	32	

				13	i	412			
VW - BORA Estate (1J6)							05/99→05/05		
1.8 T	132 kW	1.8 l	05/02→05/05	⊗ AUQ; 4x	5DA 193 175-911	Ignition Coil	27		
2.0	85 kW	2 l	05/99→05/05	⊗ AZH / APK / AQY	5DA 358 000-171	Ignition Coil	33		
				⊗ AZJ / AZG	5DA 358 000-181	Ignition Coil	33		
2.0 4motion	85 kW	2 l	04/00→05/05	⊗ AZH	5DA 358 000-171	Ignition Coil	33		
				⊗ AZJ	5DA 358 000-181	Ignition Coil	33		
2.3 V5	125 kW	2.3 l	10/00→05/05	⊗ AQN; 5	5DA 358 000-001	Ignition Coil	30		
2.3 V5 4motion	125 kW	2.3 l	10/00→05/05						
2.8 V6 4motion	150 kW	2.8 l	05/99→05/05	⊗ AUE; ⚡ 1J-2-000001→; 6	5DA 358 000-001	Ignition Coil	30		
				⊗ BDE; 6	5DA 358 000-001	Ignition Coil	30		
VW - BORA Saloon (1J2)							10/98→05/05		
1.4 16V	55 kW	1.4 l	03/00→05/05	⊗ BCA; Model 2002→; 4x	5DA 193 175-501	Ignition Coil	16		
				⊗ AXP / APE / AKQ / AHW	5DA 358 000-171	Ignition Coil	33		
1.6	74 kW	1.6 l	10/98→05/05		5DA 358 000-171	Ignition Coil	33		
1.8 4motion	92 kW	1.8 l	02/99→05/05		5DA 358 000-171	Ignition Coil	33		
1.6	75 kW	1.6 l	08/00→05/05	⊗ AVU	5DA 358 000-171	Ignition Coil	33		
1.6 16V	77 kW	1.6 l	05/00→05/05	⊗ AZD / BCB; 4x	5DA 193 175-501	Ignition Coil	16		
				⊗ ATN / AUS	5DA 358 000-171	Ignition Coil	33		
1.6 FSI	81 kW	1.6 l	01/02→05/05	⊗ BAD; 4x	5DA 193 175-501	Ignition Coil	16		
1.8	92 kW	1.8 l	10/98→05/05	⊗ AGN	5DA 358 000-171	Ignition Coil	33		
1.8 T	110 kW	1.8 l	05/00→05/05	⊗ AGU	5DA 006 623-771	Switch Unit, ignition system	8		
				⊗ AUM; Model 2002→; 4x	5DA 193 175-911	Ignition Coil	27		
				⊗ AGU	5DA 358 000-051	Ignition Coil	32		
1.8 T	132 kW	1.8 l	03/02→05/05	⊗ AUQ; 4x	5DA 193 175-911	Ignition Coil	27		
2.0	85 kW	2 l	10/98→05/05	⊗ APK / AZH / AQY	5DA 358 000-171	Ignition Coil	33		
				⊗ AZJ / AZG	5DA 358 000-181	Ignition Coil	33		
2.0 4motion	85 kW	2 l	04/00→05/05	⊗ AZH	5DA 358 000-171	Ignition Coil	33		
				⊗ AZJ	5DA 358 000-181	Ignition Coil	33		
2.3 V5	125 kW	2.3 l	10/00→05/05	⊗ AQN; 5	5DA 358 000-001	Ignition Coil	30		
2.3 V5 4motion	125 kW	2.3 l	10/00→05/05						
2.8 V6 4motion	150 kW	2.8 l	03/99→05/05	⊗ AUE; ⚡ 1J-2-000001→; 6	5DA 358 000-001	Ignition Coil	30		
				⊗ BDE; 6	5DA 358 000-001	Ignition Coil	30		
VW - CADDY I Pickup (14)							08/85→07/92		
1.8	70 kW	1.8 l	08/85→07/92	→09/86	5DA 006 623-931	Switch Unit, ignition system	8		
				10/86→	5DA 006 623-941	Switch Unit, ignition system	9		
VW - CADDY II Box (9K9A)							11/95→01/04		
1.4	55 kW	1.4 l	08/00→01/04		5DA 358 000-171	Ignition Coil	33		
60 1.4	44 kW	1.4 l	11/95→01/04	⊗ AEX / APQ	5DA 006 623-951	Ignition Coil	9		
				⊗ AUD	5DA 358 000-171	Ignition Coil	33		
75 1.6	55 kW	1.6 l	11/95→05/97	⊗ 1F	5DA 006 623-951	Ignition Coil	9		
75 1.6	55 kW	1.6 l	11/95→09/00	⊗ AEE	5DA 006 623-951	Ignition Coil	9		

VW - CADDY II Estate (9K9B)													11/95→01/04		
1.4	44 kW	1.4 l	11/95→01/04	⊗ AEX / APQ / AKV; →06/03		5DA 006 623-951 Ignition Coil								9	
				⊗ AUD		5DA 358 000-171 Ignition Coil								33	
1.4 16V	55 kW	1.4 l	08/00→01/04			5DA 358 000-171 Ignition Coil								33	
1.6	55 kW	1.6 l	11/95→05/97	⊗ 1F		5DA 006 623-951 Ignition Coil								9	
1.6	55 kW	1.6 l	06/97→09/00	⊗ AEE		5DA 006 623-951 Ignition Coil								9	
VW - CADDY II Pickup (9U7)													06/96→12/00		
1.6	55 kW	1.6 l	06/96→12/00	⊗ AEE		5DA 006 623-951 Ignition Coil								9	
VW - CADDY III Box (2KA, 2KH, 2CA, 2CH)													04/04→08/10		
1.4 16V	59 kW	1.4 l	05/06→08/10	⊗ BUD; →2K-B-005000; 4x		5DA 193 175-501 Ignition Coil								16	
1.6	75 kW	1.6 l	04/04→			5DA 358 000-171 Ignition Coil								33	
2.0 EcoFuel	80 kW	2 l	04/06→			5DA 358 000-181 Ignition Coil								33	
VW - CADDY III Estate (2KB, 2KJ, 2CB, 2CJ)													03/04→08/10		
1.4	55 kW	1.4 l	03/04→05/06	⊗ BCA; 4x		5DA 193 175-501 Ignition Coil								16	
1.4 16V	59 kW	1.4 l	05/06→08/10	⊗ BUD; →2K-B-005000; 4x		5DA 193 175-501 Ignition Coil								16	
1.6	75 kW	1.6 l	04/04→			5DA 358 000-171 Ignition Coil								33	
2.0 EcoFuel	80 kW	2 l	04/06→			5DA 358 000-181 Ignition Coil								33	
VW - CORRADO (53I)													04/89→12/95		
1.8 16V	100 kW	1.8 l	04/89→07/92			5DA 006 623-941 Switch Unit, ignition system								9	
2.0 i	85 kW	2 l	04/93→12/95	⊗ ADY / 2E		5DA 006 623-951 Ignition Coil								9	
VW - EOS (1F7, 1F8)													03/06→05/08		
1.4 TSI	90 kW	1.4 l	11/07→	⊗ CAXA; 4x		5DA 193 175-501 Ignition Coil								16	
1.4 TSI	118 kW	1.4 l	05/08→	⊗ CAVD; 4x		5DA 193 175-501 Ignition Coil								16	
1.6 FSI	85 kW	1.6 l	06/06→05/08	⊗ BLF; →1F-B-006376; 4x		5DA 193 175-501 Ignition Coil								16	
2.0 FSI	110 kW	2 l	03/06→05/08	⊗ BVZ / BVY; 4		5DA 193 175-921 Ignition Coil								28	
2.0 TFSI	147 kW	2 l	03/06→	⊗ BPY / CAWB / CCTA / CCZA / BWA / CBFA; 4		5DA 193 175-921 Ignition Coil								28	
2.0 TSI	155 kW	2 l	11/09→	⊗ CCZB; 4		5DA 193 175-921 Ignition Coil								28	
VW - FOX (5Z1, 5Z3)													04/05→		
1.2	40 kW	1.2 l	04/05→	⊗ BMD; 3x		5DA 193 175-901 Ignition Coil								27	
1.2	44 kW	1.2 l	09/10→	⊗ CHFA; 3x		5DA 193 175-901 Ignition Coil								27	
1.4	55 kW	1.4 l	04/05→			5DA 358 000-171 Ignition Coil								33	
VW - GOLF I (17)													08/76→12/83		
1.6 GTI	81 kW	1.6 l	08/76→07/82	08/80→		5DA 006 623-931 Switch Unit, ignition system								8	
1.8 GTI	82 kW	1.8 l	08/82→12/83	⊗ DX; →07/83		5DA 006 623-931 Switch Unit, ignition system								8	
VW - GOLF I Cabriolet (155)													08/79→04/93		
1.6	55 kW	1.6 l	08/83→04/92	⊗ EW; →10/86 ⊗ HN; →07/86; →15..H..009000		5DA 006 623-931 Switch Unit, ignition system								8	
1.6	81 kW	1.6 l	08/79→07/82			5DA 006 623-931 Switch Unit, ignition system								8	
1.8	66 kW	1.8 l	08/83→09/92	→10/86; →15..H..009000		5DA 006 623-931 Switch Unit, ignition system								8	
1.8	70 kW	1.8 l	08/83→04/93			5DA 006 623-931 Switch Unit, ignition system								8	

				13	i	412	
VW - GOLF I Cabriolet (155)							08/79→04/93
1.8	72 kW	1.8 l	08/89→03/93				5DA 006 623-941 Switch Unit, ignition system 9
1.8	82 kW	1.8 l	08/82→12/89	DX; →10/86; →15..H..009000			5DA 006 623-931 Switch Unit, ignition system 8
VW - GOLF II (19E, 1G1)							08/83→12/92
1.3	40 kW	1.3 l	08/83→06/87	10/86→; MH			5DA 006 623-941 Switch Unit, ignition system 9
1.3 CAT	40 kW	1.3 l	06/86→12/92	10/86→; 2G / MH / NZ			5DA 006 623-941 Switch Unit, ignition system 9
1.6	51 kW	1.6 l	10/86→12/92	→07/92			5DA 006 623-941 Switch Unit, ignition system 9
1.6	53 kW	1.6 l	02/86→10/91	10/86→			5DA 006 623-941 Switch Unit, ignition system 9
1.6	55 kW	1.6 l	08/83→07/92				5DA 006 623-941 Switch Unit, ignition system 9
1.8	62 kW	1.8 l	08/86→01/90				5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI 16V	102 kW	1.8 l	02/86→06/90				5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI G60	118 kW	1.8 l	04/90→07/91				5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI CAT	79 kW	1.8 l	01/87→10/91				5DA 006 623-941 Switch Unit, ignition system 9
1.8 Syncro	72 kW	1.8 l	08/88→07/91				5DA 006 623-941 Switch Unit, ignition system 9
1.8	66 kW	1.8 l	08/84→10/91	10/86→05/88; GX			5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI	77 kW	1.8 l	01/85→07/85	HT			5DA 006 623-931 Switch Unit, ignition system 8
1.8 GTI	79 kW	1.8 l	08/85→10/87				5DA 006 623-931 Switch Unit, ignition system 8
							5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI	82 kW	1.8 l	08/83→10/91	01/84→07/87; EV / PB			5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI 16V	95 kW	1.8 l	02/86→10/91	→08/87			5DA 006 623-931 Switch Unit, ignition system 8
							5DA 006 623-941 Switch Unit, ignition system 9
1.8 GTI G60 Syncro	118 kW	1.8 l	08/88→12/91	1H / PG			5DA 006 623-941 Switch Unit, ignition system 9
1.8 i CAT	66 kW	1.8 l	08/87→10/91	GX; →08/87			5DA 006 623-931 Switch Unit, ignition system 8
							5DA 006 623-941 Switch Unit, ignition system 9
1.8 Syncro	66 kW	1.8 l	02/86→07/91	→09/86			5DA 006 623-931 Switch Unit, ignition system 8
							5DA 006 623-941 Switch Unit, ignition system 9
							5DA 006 623-941 Switch Unit, ignition system 9
VW - GOLF III (1H1)							10/91→08/97
1.4	40 kW	1.4 l	11/91→08/97	ABD; →06/95 AEX; 07/95→			5DA 006 623-951 Ignition Coil 9
1.4	44 kW	1.4 l	10/91→08/97	ABD; 1H-N-000001→; →06/95 AEX; 07/95→			5DA 006 623-951 Ignition Coil 9
1.6	55 kW	1.6 l	09/92→08/97	ABU; 1H-N-000001→; →06/94 AEA; 07/94→06/95 AEE; 07/95→			5DA 006 623-951 Ignition Coil 9
1.6	74 kW	1.6 l	07/95→08/97	AEK; →06/96			5DA 006 623-951 Ignition Coil 9
1.8	55 kW	1.8 l	11/91→08/97	AAM; 1H-N-000001→			5DA 006 623-951 Ignition Coil 9
1.8	66 kW	1.8 l	11/91→08/97	ABS; →06/95; 1H-N-000001→ ADZ; 07/94→			5DA 006 623-951 Ignition Coil 9
1.8 Syncro (1HX1)	66 kW	1.8 l	01/93→08/97	ADZ / ABS			5DA 006 623-951 Ignition Coil 9
2.0	85 kW	2 l	11/91→08/97	2E; 1H-N-000001→; →06/95 ADY; 07/94→ AGG; 07/95→ AKR; 07/96→			5DA 006 623-951 Ignition Coil 9
2.0 GTI 16V	110 kW	2 l	08/92→08/97	ABF; 1H-N-000001→			5DA 006 623-951 Ignition Coil 9
2.0 Syncro (1HX1)	85 kW	2 l	08/95→08/97	AGG			5DA 006 623-951 Ignition Coil 9
VW - GOLF III Cabriolet (1E7)							07/93→05/98
1.6	74 kW	1.6 l	10/94→05/98	AEK / AFT / AKS			5DA 006 623-951 Ignition Coil 9
1.8	55 kW	1.8 l	07/93→05/98	AAM			5DA 006 623-951 Ignition Coil 9

				13	i	412			
VW - GOLF III Cabriolet (1E7)							07/93→05/98		
1.8	66 kW	1.8 l	07/93→05/98	⊗ ABS / ADZ		5DA 006 623-951	Ignition	9	
						Coil			
2.0	85 kW	2 l	07/93→05/98	⊗ ADY / AGG / AKR		5DA 006 623-951	Ignition	9	
						Coil			
VW - GOLF III Variant (1H5)							07/93→04/99		
1.4	40 kW	1.4 l	07/93→04/99	⊗ ABD; →06/95		5DA 006 623-951	Ignition	9	
						Coil			
1.4	44 kW	1.4 l	07/93→04/99	⊗ ABD; →06/95 ⊗ AEX; 07/95→ ⊗ APQ; 07/96→		5DA 006 623-951	Ignition	9	
						Coil			
1.6	74 kW	1.6 l	07/94→04/99	⊗ AEK; →06/96 ⊗ AFT / AKS; 07/96→		5DA 006 623-951	Ignition	9	
						Coil			
1.8	55 kW	1.8 l	07/93→04/99	⊗ AAM ⊗ ANN; 07/96→		5DA 006 623-951	Ignition	9	
						Coil			
1.8	66 kW	1.8 l	07/93→04/99	⊗ ABS; →06/95 ⊗ ADZ; 07/94→ ⊗ ANP; 07/96→		5DA 006 623-951	Ignition	9	
						Coil			
1.8 Syncro	66 kW	1.8 l	10/94→04/99	⊗ ADZ		5DA 006 623-951	Ignition	9	
						Coil			
2.0	85 kW	2 l	07/93→04/99	⊗ 2E; →06/94 ⊗ ADY; 07/94→06/96 ⊗ AGG; 07/95→ ⊗ AKR; 07/96→		5DA 006 623-951	Ignition	9	
						Coil			
2.0 Syncro	85 kW	2 l	08/95→04/99	⊗ AGG		5DA 006 623-951	Ignition	9	
						Coil			
VW - GOLF IV (1J1)							08/97→06/05		
1.4 16V	55 kW	1.4 l	08/97→06/05	⊗ BCA; Model 2002→; 4x		5DA 193 175-501	Ignition	16	
						Coil			
				⊗ APE / AHW / AXP / AKQ		5DA 358 000-171	Ignition	33	
						Coil			
1.6	74 kW	1.6 l	08/97→05/04			5DA 358 000-171	Ignition	33	
1.8 4motion	92 kW	1.8 l	05/98→06/05			Coil			
1.6	75 kW	1.6 l	08/00→06/05	⊗ AVU / BFQ		5DA 358 000-171	Ignition	33	
						Coil			
1.6 16V	77 kW	1.6 l	02/00→06/05	⊗ AZD / BCB; 4x		5DA 193 175-501	Ignition	16	
						Coil			
				⊗ ATN / AUS		5DA 358 000-171	Ignition	33	
						Coil			
1.6 FSI	81 kW	1.6 l	01/02→06/05	⊗ BAD; 4x		5DA 193 175-501	Ignition	16	
						Coil			
1.8	92 kW	1.8 l	08/97→06/05	⊗ AGN		5DA 358 000-171	Ignition	33	
						Coil			
1.8 T	110 kW	1.8 l	08/97→06/05	⊗ AGU		5DA 006 623-771	Switch	8	
						Unit, ignition system			
				⊗ AUM / AWD; Model 2001→; 4x		5DA 193 175-911	Ignition	27	
						Coil			
				⊗ ARZ; →Model 2001; 4x ⊗ AWD; →Model 2000; 4x		5DA 193 175-981	Ignition	30	
						Coil			
				⊗ AGU		5DA 358 000-051	Ignition	32	
						Coil			
1.8 T GTI	132 kW	1.8 l	08/01→06/05	⊗ AUQ; 4x		5DA 193 175-911	Ignition	27	
						Coil			
2.0	85 kW	2 l	07/98→05/04	⊗ AQY / APK		5DA 358 000-171	Ignition	33	
						Coil			
				⊗ AZG / AZJ		5DA 358 000-181	Ignition	33	
						Coil			
2.0 4motion	85 kW	2 l	10/00→06/05	⊗ AZH		5DA 358 000-171	Ignition	33	
						Coil			
				⊗ AZJ		5DA 358 000-181	Ignition	33	
						Coil			
2.3 V5	125 kW	2.3 l	10/00→06/05	⊗ AQN; 5		5DA 358 000-001	Ignition	30	
2.3 V5 4motion	125 kW	2.3 l	10/00→06/05			Coil			
2.8 V6 4motion	150 kW	2.8 l	03/99→06/05	⊗ AUE; 6		5DA 358 000-001	Ignition	30	
						Coil			
				⊗ BDE; 6		5DA 358 000-001	Ignition	30	
						Coil			
VW - GOLF IV Cabriolet (1E7)							06/98→06/02		
1.6	74 kW	1.6 l	06/98→06/02	⊗ AFT / AKS; ⊗ 1E-X-000001→1E-2-015000		5DA 006 623-951	Ignition	9	
						Coil			
1.8	55 kW	1.8 l	06/98→06/02	⊗ AAM / ANN; ⊗ 1E-X-000001→1E-2-015000		5DA 006 623-951	Ignition	9	
						Coil			

				13	i	412			
VW - GOLF IV Cabriolet (1E7)							06/98→06/02		
1.8	66 kW	1.8 l	06/98→06/02	⊗ ADZ / ANP; ⊗ 1E-X-000001→1E-2-015000	5DA 006 623-951	Ignition Coil	9		
2.0	85 kW	2 l	06/98→06/02	⊗ AGG / AKR / ATU; ⊗ 1E-X-000001→1E-2-015000 ⊗ AWF / AWG; ⊗ 1E-X-000001→1E-2-015000; 1E-2-800001→	5DA 006 623-951	Ignition Coil	9		
VW - GOLF IV Variant (1J5)							05/99→06/06		
1.4 16V	55 kW	1.4 l	05/99→06/06	⊗ BCA; Model 2002→; 4x	5DA 193 175-501	Ignition Coil	16		
				⊗ AHW / AKQ / APE / AXP	5DA 358 000-171	Ignition Coil	33		
1.6	74 kW	1.6 l	05/99→04/02		5DA 358 000-171	Ignition Coil	33		
1.6	75 kW	1.6 l	08/00→06/06						
1.8 4motion	92 kW	1.8 l	05/99→06/06						
1.6 16V	77 kW	1.6 l	02/00→06/06	⊗ AZD / BCB; 4x	5DA 193 175-501	Ignition Coil	16		
				⊗ ATN / AUS	5DA 358 000-171	Ignition Coil	33		
1.6 FSI	81 kW	1.6 l	01/02→06/06	⊗ BAD; 4x	5DA 193 175-501	Ignition Coil	16		
1.8 T	110 kW	1.8 l	05/00→06/06	⊗ AGU	5DA 006 623-771	Switch Unit, ignition system	8		
				⊗ AWD / AUM; ⊗ 1J-1-000001→; 4x	5DA 193 175-911	Ignition Coil	27		
				⊗ ARZ; →Model 2001; 4x	5DA 193 175-981	Ignition Coil	30		
				⊗ AWD; →Model 2000; 4x					
				⊗ AGU	5DA 358 000-051	Ignition Coil	32		
2.0	85 kW	2 l	05/99→06/06	⊗ APK / AQY	5DA 358 000-171	Ignition Coil	33		
				⊗ AZJ	5DA 358 000-181	Ignition Coil	33		
2.0 4motion	85 kW	2 l	10/00→06/06	⊗ AZH	5DA 358 000-171	Ignition Coil	33		
				⊗ AZJ	5DA 358 000-181	Ignition Coil	33		
2.0 Bi-Fuel	85 kW	2 l	02/02→06/06		5DA 358 000-181	Ignition Coil	33		
2.3 V5	125 kW	2.3 l	10/00→06/06	⊗ AQN; 5	5DA 358 000-001	Ignition Coil	30		
2.3 V5 4motion	125 kW	2.3 l	10/00→06/06						
2.8 V6 4motion	150 kW	2.8 l	05/99→06/06	⊗ AUE; 6	5DA 358 000-001	Ignition Coil	30		
				⊗ BDE; 6	5DA 358 000-001	Ignition Coil	30		
VW - GOLF V (1K1)							10/03→02/09		
1.4 16V	55 kW	1.4 l	10/03→05/06	⊗ BCA; ⊗ 1K-4-000001→; →Model 2007; 4x	5DA 193 175-501	Ignition Coil	16		
1.4 16V	59 kW	1.4 l	05/06→11/08	⊗ BUD; ⊗ 1K-6-000001→1K-9-200000; 4x	5DA 193 175-501	Ignition Coil	16		
1.4 FSI	66 kW	1.4 l	10/03→07/06	⊗ BKG / BLN; ⊗ 1K-4-000001→; →Model 2007; 4x	5DA 193 175-501	Ignition Coil	16		
1.4 TSI	90 kW	1.4 l	05/07→11/08	⊗ CAXA; 4x	5DA 193 175-501	Ignition Coil	16		
1.4 TSI	103 kW	1.4 l	05/06→11/08	⊗ BMY; ⊗ 1K-6-000001→1K-9-200000; 4x	5DA 193 175-501	Ignition Coil	16		
1.4 TSI	125 kW	1.4 l	11/05→11/08	⊗ BLG; ⊗ 1K-6-000001→1K-9-200000; 4x	5DA 193 175-501	Ignition Coil	16		
1.6	75 kW	1.6 l	01/04→11/08		5DA 358 000-171	Ignition Coil	33		
1.6 FSI	85 kW	1.6 l	10/03→07/08	⊗ BLP; ⊗ 1K-4-000001→; →Model 2005; 4x	5DA 193 175-501	Ignition Coil	16		
2.0 FSI	110 kW	2 l	01/04→11/08	⊗ BVZ / BLR / BLX / BVX / BVY / AXW / BLY; 4	5DA 193 175-921	Ignition Coil	28		
2.0 FSI 4motion	110 kW	2 l	08/04→11/08	⊗ BVX / BLX; 4	5DA 193 175-921	Ignition Coil	28		
2.0 GTI	147 kW	2 l	10/04→02/09	⊗ BWA / AXX / BPY / CAWB; 4	5DA 193 175-921	Ignition Coil	28		
2.0 GTI	169 kW	2 l	09/06→12/08	⊗ BYD; 4	5DA 193 175-921	Ignition Coil	28		

				13	i	412		
VW - GOLF V Variant (1K5)								06/07→07/09
1.4	59 kW	1.4 l	06/07→07/09	☉ BUD; ☞ 1K-6-000001→; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	90 kW	1.4 l	06/07→07/09	☉ CAXA; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	103 kW	1.4 l	06/07→07/09	☉ BMY; ☞ 1-K-6-000001→; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	118 kW	1.4 l	07/08→07/09	☉ CAVD; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	125 kW	1.4 l	06/07→07/09	☉ BLG; ☞ 1K-6-000001→; 4x		5DA 193 175-501	Ignition Coil	16
1.6	75 kW	1.6 l	06/07→07/09			5DA 358 000-171	Ignition Coil	33
1.6 MultiFuel	75 kW	1.6 l	11/07→07/09					
2.0	147 kW	2 l	06/07→07/09	☉ BWA / CAWB; 4		5DA 193 175-921	Ignition Coil	28
VW - GOLF VI (5K1)								10/08→11/13
1.2 TSI	77 kW	1.2 l	05/09→11/12			5DA 358 000-171	Ignition Coil	33
1.6	75 kW	1.6 l	10/08→11/12					
1.6 MultiFuel	75 kW	1.6 l	10/08→11/12					
1.4	59 kW	1.4 l	10/08→11/12	☉ CGGA; ☞ 1K-9-400001→; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	90 kW	1.4 l	10/08→11/12	☉ CAXA; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	118 kW	1.4 l	10/08→11/12	☉ CAVD; ☞ 1K-9-400001→; 4x		5DA 193 175-501	Ignition Coil	16
1.8 TSI	118 kW	1.8 l	06/09→01/11	☉ CDAA; 4		5DA 193 175-921	Ignition Coil	28
2.0 GTi	155 kW	2 l	04/09→11/12	☉ CCZB; 4		5DA 193 175-921	Ignition Coil	28
2.0 GTi	173 kW	2 l	05/11→11/12	☉ CDLG; 4		5DA 193 175-921	Ignition Coil	28
2.0 R 4motion	188 kW	2 l	11/09→11/13	☉ CDLC; 4		5DA 193 175-921	Ignition Coil	28
2.0 R 4motion	199 kW	2 l	11/09→11/12	☉ CDLF; 4		5DA 193 175-921	Ignition Coil	28
VW - GOLF VI Convertible (517)								03/11→
1.4 TSI	118 kW	1.4 l	03/11→	☉ CAVD / CNWA; 4x		5DA 193 175-501	Ignition Coil	16
2.0 GTI	155 kW	2 l	11/11→	☉ CCZB; 4		5DA 193 175-921	Ignition Coil	28
2.0 R	195 kW	2 l	01/13→	☉ CDLA; 4		5DA 193 175-921	Ignition Coil	28
VW - GOLF VI Variant (AJ5)								07/09→07/13
1.2 TSI	77 kW	1.2 l	08/09→07/13			5DA 358 000-171	Ignition Coil	33
1.6	75 kW	1.6 l	07/09→07/13					
1.6 MultiFuel	75 kW	1.6 l	07/10→07/13					
1.4	59 kW	1.4 l	07/09→07/13	☉ BUD / CGGA; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	90 kW	1.4 l	07/09→07/13	☉ CAXA; 4x		5DA 193 175-501	Ignition Coil	16
1.4 TSI	118 kW	1.4 l	07/09→07/13	☉ CAVD; 4x		5DA 193 175-501	Ignition Coil	16
VW - GOLF VII (5G1, BE1)								08/12→
1.2 TSI	63 kW	1.2 l	08/12→	☉ CJZB; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
1.2 TSI	77 kW	1.2 l	11/12→	☉ CJZA; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
1.4 TSI	90 kW	1.4 l	11/12→	☉ CMBA / CPVA; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
1.4 TSI	103 kW	1.4 l	11/12→	☉ CHPA / CPTA; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
1.4 TSI MultiFuel	90 kW	1.4 l	04/13→	☉ CPVA; 4 ports; 4x		5DA 193 175-951	Ignition Coil	29
VW - GOLF PLUS (5M1, 521)								01/05→12/13
1.4 16V	55 kW	1.4 l	01/05→11/06	☉ BCA; →Model 2007; 4x		5DA 193 175-501	Ignition Coil	16
1.4 16V	59 kW	1.4 l	05/06→12/13	☉ BUD / CGGA; →Model 2011; 4x		5DA 193 175-501	Ignition Coil	16
1.4 FSI	66 kW	1.4 l	07/05→11/06	☉ BLN; 4x		5DA 193 175-501	Ignition Coil	16

				13	i	412		
VW - GOLF PLUS (5M1, 521)								01/05→12/13
1.4 TSI	90 kW	1.4 l	06/07→12/13	⊗ CAXA; →Model 2011; 4x			5DA 193 175-501 Ignition Coil	16
1.4 TSI	103 kW	1.4 l	05/06→06/08	⊗ BMY; Model 2008→; →1K-9-899999; 4x			5DA 193 175-501 Ignition Coil	16
1.4 TSI	118 kW	1.4 l	06/08→12/13	⊗ CAVD; →Model 2011; 4x			5DA 193 175-501 Ignition Coil	16
1.4 TSI	125 kW	1.4 l	05/06→06/08	⊗ BLG; Model 2008→; →1K-9-899999; 4x			5DA 193 175-501 Ignition Coil	16
1.6	75 kW	1.6 l	05/05→12/13	⊗ BSF / BSE / CCSA; →12/09			5DA 358 000-171 Ignition Coil	33
1.6 FSI	85 kW	1.6 l	01/05→05/08	⊗ BLF; →1K-9-899999; 4x			5DA 193 175-501 Ignition Coil	16
1.6 MultiFuel	75 kW	1.6 l	11/07→12/13	⊗ CCSA; →12/09			5DA 358 000-171 Ignition Coil	33
2.0 FSI	110 kW	2 l	05/05→06/08	⊗ BVY / BLY / BLR / BVZ; 4			5DA 193 175-921 Ignition Coil	28
VW - JETTA I Saloon (1K2)								08/05→10/10
1.4 TSI	90 kW	1.4 l	05/07→10/10	⊗ CAXA; →1K-7-000001→; →Model 2010; 4x			5DA 193 175-501 Ignition Coil	16
1.4 TSI	103 kW	1.4 l	07/06→10/10	⊗ BMY; →1K-7-000001→; →Model 2010; 4x			5DA 193 175-501 Ignition Coil	16
1.4 TSI	118 kW	1.4 l	07/08→10/10	⊗ CAVD; 4x			5DA 193 175-501 Ignition Coil	16
1.4 TSI	125 kW	1.4 l	07/06→10/10	⊗ BLG; →1K-7-000001→; →Model 2010; 4x			5DA 193 175-501 Ignition Coil	16
1.6	75 kW	1.6 l	10/05→10/10	⊗ BSF / CCSA / BSE			5DA 358 000-171 Ignition Coil	33
1.6 FSI	85 kW	1.6 l	09/05→10/10	⊗ BLF; →Model 2010; 4x			5DA 193 175-501 Ignition Coil	16
1.6 MultiFuel	75 kW	1.6 l	01/08→10/10				5DA 358 000-171 Ignition Coil	33
2.0 FSI	110 kW	2 l	08/05→10/10	⊗ BLR / BLY / BVY / BVZ; 4			5DA 193 175-921 Ignition Coil	28
2.0 TDI 16V	103 kW	2 l	08/05→10/10	⊗ CBDB; Model 2009→Model 2010; 4x			5DA 193 175-501 Ignition Coil	16
2.0 TFSI	147 kW	2 l	10/05→10/10	⊗ CBFA / CCTA / BWA / CCZA / BPY; 4			5DA 193 175-921 Ignition Coil	28
2.5 FSI	110 kW	2.5 l	01/06→10/10	⊗ BGP / BTK; 5			5DA 193 175-921 Ignition Coil	28
VW - JETTA I Saloon (16)								08/78→02/84
1.6 GLI	81 kW	1.6 l	08/78→07/82	08/80→			5DA 006 623-931 Switch Unit, ignition system	8
1.8	82 kW	1.8 l	08/82→02/84	⊗ DX; →12/83			5DA 006 623-931 Switch Unit, ignition system	8
VW - JETTA II Saloon (19E, 1G2, 165)								01/84→07/92
1.3	40 kW	1.3 l	01/84→06/87	⊗ MH; 08/85→09/86			5DA 006 623-931 Switch Unit, ignition system	8
1.3 CAT	40 kW	1.3 l	06/87→12/91	01/89→; ⊗ 2G / NZ			5DA 006 623-941 Switch Unit, ignition system	9
1.6	51 kW	1.6 l	10/86→10/91				5DA 006 623-941 Switch Unit, ignition system	9
1.8 16V	102 kW	1.8 l	06/87→12/89					
1.8 CAT	79 kW	1.8 l	01/87→10/91					
1.8 Syncro	72 kW	1.8 l	08/88→07/91					
1.6	53 kW	1.6 l	03/86→10/91	→09/86			5DA 006 623-931 Switch Unit, ignition system	8
1.8 16V	95 kW	1.8 l	08/86→10/91				5DA 006 623-941 Switch Unit, ignition system	9
1.6	55 kW	1.6 l	01/84→07/92	⊗ EZ / HM; →09/86			5DA 006 623-931 Switch Unit, ignition system	8
							5DA 006 623-941 Switch Unit, ignition system	9
1.8	62 kW	1.8 l	08/86→01/90	→09/86			5DA 006 623-931 Switch Unit, ignition system	8
1.8	79 kW	1.8 l	08/85→10/87					
1.8	66 kW	1.8 l	08/84→10/91	→09/86			5DA 006 623-931 Switch Unit, ignition system	8
							5DA 006 623-941 Switch Unit, ignition system	9
1.8	82 kW	1.8 l	01/84→10/91	⊗ GZ / EV; →09/86			5DA 006 623-931 Switch Unit, ignition system	8
							5DA 006 623-941 Switch Unit, ignition system	9

VW - JETTA II Saloon (19E, 1G2, 165)							01/84→07/92
1.8 CAT	66 kW	1.8 l	08/87→10/91	11/87→	5DA 006 623-941 Switch Unit, ignition system	9	
VW - JETTA IV (162, 163)							04/10→
2.0	85 kW	2 l	06/10→	CKJA	5DA 358 000-181 Ignition Coil	33	
2.0 TSI	147 kW	2 l	12/10→	CCZA / CCTA / CBFA; 4	5DA 193 175-921 Ignition Coil	28	
2.5 FSI	125 kW	2.5 l	04/10→	CCCA / CBUA / CBTA; 5	5DA 193 175-921 Ignition Coil	28	
VW - LT 28-35 II Bus (2DB, 2DE, 2DK)							05/96→07/06
2.3	105 kW	2.3 l	05/96→07/06	2x	5DA 193 175-361 Ignition Coil	11	
VW - LT 28-46 II Box (2DA, 2DD, 2DH)							05/96→07/06
2.3	105 kW	2.3 l	05/96→07/06	2x	5DA 193 175-361 Ignition Coil	11	
VW - LT 28-46 II Platform/Chassis (2DC, 2DF, 2DG, 2DL, 2DM)							06/96→07/06
2.3	105 kW	2.3 l	06/96→07/06	2x	5DA 193 175-361 Ignition Coil	11	
VW - LUPO (6X1, 6E1)							09/98→07/05
1.0	37 kW	1 l	09/98→07/05	AER / ALL; →06/03	5DA 006 623-951 Ignition Coil	9	
				ALD / ANV / AUC	5DA 358 000-171 Ignition Coil	33	
1.0	37 kW	1 l	10/98→05/00	AHT	5DA 193 175-081 Ignition Coil	10	
1.4	44 kW	1.4 l	10/00→07/05		5DA 358 000-171 Ignition Coil	33	
1.4 16V	74 kW	1.4 l	08/99→07/05		5DA 358 000-171 Ignition Coil	33	
1.6 GTI	92 kW	1.6 l	09/00→07/05				
1.4 16V	55 kW	1.4 l	09/98→07/05	BBY; 4x	5DA 193 175-501 Ignition Coil	16	
				AUA / AKQ / AHW / APE	5DA 358 000-171 Ignition Coil	33	
VW - PASSAT (3A2, 35I)							02/88→08/96
1.6	53 kW	1.6 l	02/88→09/91	→07/90; 1F / EZ	5DA 006 623-941 Switch Unit, ignition system	9	
1.6	55 kW	1.6 l	02/88→12/88	04/88→	5DA 006 623-941 Switch Unit, ignition system	9	
1.6	74 kW	1.6 l	10/94→08/96	AEK / AFT	5DA 006 623-951 Ignition Coil	9	
1.8	55 kW	1.8 l	08/90→08/96	AAM; 31-M-000001→	5DA 006 623-951 Ignition Coil	9	
1.8	66 kW	1.8 l	02/88→08/96	04/88→07/91; RP	5DA 006 623-941 Switch Unit, ignition system	9	
				RP; 31-M-000001→; →06/91	5DA 006 623-951 Ignition Coil	9	
				ABS; 07/91→06/93→; ADZ			
1.8	79 kW	1.8 l	04/88→07/93	→07/90	5DA 006 623-941 Switch Unit, ignition system	9	
1.8	82 kW	1.8 l	04/88→07/92		5DA 006 623-941 Switch Unit, ignition system	9	
1.8 16V	100 kW	1.8 l	04/88→12/89				
2.0	79 kW	2 l	03/95→08/96	AEP	5DA 006 623-951 Ignition Coil	9	
2.0	85 kW	2 l	02/90→08/96	2E; 31-M-000001→ / 31-M-066001→ ADY / AGG; 07/93→	5DA 006 623-951 Ignition Coil	9	
2.0 16V	110 kW	2 l	01/94→08/96	ABF	5DA 006 623-951 Ignition Coil	9	
2.0 Syncro	85 kW	2 l	10/90→08/96	2E AGG; 07/93→	5DA 006 623-951 Ignition Coil	9	
VW - PASSAT (32B)							08/80→03/88
1.6	53 kW	1.6 l	02/86→03/88	08/86→07/87	5DA 006 623-931 Switch Unit, ignition system	8	
1.8	64 kW	1.8 l	05/86→03/88				
2.2	85 kW	2.2 l	08/85→03/88				
2.2	100 kW	2.2 l	01/85→03/88				
1.6	55 kW	1.6 l	08/80→03/88	08/86→07/87	5DA 006 623-931 Switch Unit, ignition system	8	
				08/83→; DT	5DA 006 623-941 Switch Unit, ignition system	9	

VW - PASSAT (32B)							08/80→03/88
1.8	66 kW	1.8 l	01/83→03/88	08/86→07/87	5DA 006 623-931 Switch Unit, ignition system	8	
				DS	5DA 006 623-941 Switch Unit, ignition system	9	
2.0	85 kW	2 l	08/83→03/88	JS; 08/86→07/87	5DA 006 623-931 Switch Unit, ignition system	8	
VW - PASSAT (362)							08/10→12/14
1.4 TSI	90 kW	1.4 l	08/10→12/14	CAXA; 4x	5DA 193 175-501 Ignition Coil	16	
1.4 TSI EcoFuel	110 kW	1.4 l	08/10→12/14	CDGA; 4x	5DA 193 175-501 Ignition Coil	16	
1.8 TSI	118 kW	1.8 l	08/10→12/14	CDA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TSI	155 kW	2 l	11/10→12/14	CCZB; 4	5DA 193 175-921 Ignition Coil	28	
VW - PASSAT ALLTRACK (365)							01/12→
1.8 TSI	112 kW	1.8 l	01/12→	CDAB; 4	5DA 193 175-921 Ignition Coil	28	
1.8 TSI	118 kW	1.8 l	01/12→	CDA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TSI 4motion	155 kW	2 l	01/12→	CCZB; 4	5DA 193 175-921 Ignition Coil	28	
VW - PASSAT CC (357)							06/08→01/12
1.8 TSI	118 kW	1.8 l	06/08→11/10	BZB / CDA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TSI	147 kW	2 l	06/08→01/12	CBFA / CAWB / CCZA / CCTA; 4	5DA 193 175-921 Ignition Coil	28	
2.0 TSI	155 kW	2 l	11/10→01/12	CCZB; 4	5DA 193 175-921 Ignition Coil	28	
VW - PASSAT Saloon (3B2)							08/96→11/00
1.6	74 kW	1.6 l	10/96→11/00	ANA / AHL / ARM	5DA 358 000-171 Ignition Coil	33	
1.8	92 kW	1.8 l	10/96→11/00	ADR / APT / ARG; 3B-V-000001→	5DA 749 475-351 Ignition Coil	38	
1.8 Syncro/4motion	92 kW	1.8 l	10/96→11/00	ADR / APT / ARG; Model 1998→	5DA 749 475-351 Ignition Coil	38	
1.8 T	110 kW	1.8 l	10/96→11/00	AEB ANB / APU; 3B-W-045001→	5DA 006 623-771 Switch Unit, ignition system	8	
					5DA 358 000-051 Ignition Coil	32	
2.8 V6	142 kW	2.8 l	08/96→11/00	ACK / APR; 3B-V-000001→	5DA 749 475-471 Ignition Coil	39	
2.8 V6 Syncro/4motion	142 kW	2.8 l	10/96→11/00	ACK / ALG / APR / AQD; Model 1998→	5DA 749 475-471 Ignition Coil	39	
VW - PASSAT Saloon (3B3)							11/00→05/05
1.6	75 kW	1.6 l	11/00→05/05		5DA 358 000-171 Ignition Coil	33	
2.0 4motion	85 kW	2 l	11/00→05/05		5DA 358 000-171 Ignition Coil	33	
1.8 T 20V	110 kW	1.8 l	11/00→05/05	AWT; 4x	5DA 193 175-911 Ignition Coil	27	
2.0	85 kW	2 l	11/00→05/05	AZM	5DA 358 000-171 Ignition Coil	33	
2.0	96 kW	2 l	11/01→05/05	ALT; 4x	5DA 193 175-911 Ignition Coil	27	
2.3 V5	125 kW	2.3 l	11/00→05/05		5DA 193 175-181 Ignition Coil	10	
2.3 V5 4motion	125 kW	2.3 l	11/00→05/05		5DA 193 175-181 Ignition Coil	10	
2.8 4motion	142 kW	2.8 l	11/00→05/05	AMX / ATQ	5DA 749 475-471 Ignition Coil	39	
VW - PASSAT Saloon (3C2)							03/05→07/10
1.4 TSI	90 kW	1.4 l	05/07→07/10	CAXA; 4x	5DA 193 175-501 Ignition Coil	16	
1.4 TSI EcoFuel	110 kW	1.4 l	01/09→07/10	CDGA; 4x	5DA 193 175-501 Ignition Coil	16	
1.6	75 kW	1.6 l	05/05→07/10		5DA 358 000-171 Ignition Coil	33	
1.6 FSI	85 kW	1.6 l	03/05→06/08	BLF; →Model 2011; 4x	5DA 193 175-501 Ignition Coil	16	
1.8 TSI	118 kW	1.8 l	05/07→07/10	BZB / CDA; 4	5DA 193 175-921 Ignition Coil	28	

				13	i	412		
VW - PASSAT Saloon (3C2)								03/05→07/10
2.0 FSI	110 kW	2 l	03/05→07/10	⊗ BVY / BLY / BLR / BVZ; 4	5DA 193 175-921	Ignition Coil	28	
2.0 FSI	147 kW	2 l	07/05→07/10	⊗ BPY / CCTA / CCZA / BWA / CBFA / AXX; 4	5DA 193 175-921	Ignition Coil	28	
2.0 FSI 4motion	110 kW	2 l	09/05→07/10	⊗ BLX / BVX / BLY; 4	5DA 193 175-921	Ignition Coil	28	
VW - PASSAT Saloon (32B)								01/85→03/88
1.6	53 kW	1.6 l	01/85→03/88	08/86→07/87	5DA 006 623-931	Switch Unit, ignition system	8	
1.8	64 kW	1.8 l	05/86→03/88					
2.2	85 kW	2.2 l	01/85→03/88					
1.6	55 kW	1.6 l	01/85→03/88	08/86→07/87	5DA 006 623-931	Switch Unit, ignition system	8	
					5DA 006 623-941	Switch Unit, ignition system	9	
1.8	66 kW	1.8 l	01/85→03/88	08/86→07/87	5DA 006 623-931	Switch Unit, ignition system	8	
				⊗ DS	5DA 006 623-941	Switch Unit, ignition system	9	
VW - PASSAT Variant (3A5, 35I)								02/88→05/97
1.6	53 kW	1.6 l	04/88→09/91	08/88→07/90; ⊗ 1F / EZ	5DA 006 623-941	Switch Unit, ignition system	9	
1.6	55 kW	1.6 l	04/88→12/88		5DA 006 623-941	Switch Unit, ignition system	9	
1.8	79 kW	1.8 l	04/88→07/90					
1.8	82 kW	1.8 l	04/88→07/92					
1.8 16V	100 kW	1.8 l	04/88→12/89					
1.6	74 kW	1.6 l	07/94→12/95	⊗ AEK / AFT	5DA 006 623-951	Ignition Coil	9	
1.8	55 kW	1.8 l	08/90→05/97	⊗ AAM; ⚡ 31-M-000001→	5DA 006 623-951	Ignition Coil	9	
1.8	66 kW	1.8 l	02/88→05/97	04/88→07/91; ⊗ RP	5DA 006 623-941	Switch Unit, ignition system	9	
				⊗ RP; ⚡ 31-M-000001→; →06/91	5DA 006 623-951	Ignition Coil	9	
				⊗ ABS; 07/91→				
				⊗ ADZ; 07/93→				
2.0	79 kW	2 l	03/95→08/96	⊗ AEP	5DA 006 623-951	Ignition Coil	9	
2.0	85 kW	2 l	02/90→05/97	⊗ 2E; ⚡ 31-M-000001→ / 31-M-066001→	5DA 006 623-951	Ignition Coil	9	
				⊗ AGG / ADY; 07/93→				
2.0 16V	110 kW	2 l	01/94→05/97	⊗ ABF	5DA 006 623-951	Ignition Coil	9	
2.0 Syncro	85 kW	2 l	10/90→05/97	⊗ 2E	5DA 006 623-951	Ignition Coil	9	
				⊗ AGG; 07/93→				
VW - PASSAT Variant (3B5)								06/97→11/00
1.6	74 kW	1.6 l	06/97→11/00	⊗ ANA / ARM / AHL	5DA 358 000-171	Ignition Coil	33	
1.8	92 kW	1.8 l	06/97→11/00	⊗ ADR / APT / ARG; ⚡ 3B-V-000001→	5DA 749 475-351	Ignition Coil	38	
1.8 Syncro/4motion	92 kW	1.8 l	06/97→11/00	⊗ ADR / APT / ARG	5DA 749 475-351	Ignition Coil	38	
1.8 T	110 kW	1.8 l	06/97→11/00	⊗ AEB	5DA 006 623-771	Switch Unit, ignition system	8	
				⊗ ANB / APU; ⚡ 3B-W-045001→	5DA 358 000-051	Ignition Coil	32	
2.8 V6	142 kW	2.8 l	06/97→11/00	⊗ ACK / APR; ⚡ 3B-V-000001→	5DA 749 475-471	Ignition Coil	39	
2.8 V6 Syncro/4motion	142 kW	2.8 l	06/97→11/00	⊗ ACK / ALG / APR / AQD	5DA 749 475-471	Ignition Coil	39	
VW - PASSAT Variant (3B6)								11/00→05/05
1.6	75 kW	1.6 l	11/00→05/05		5DA 358 000-171	Ignition Coil	33	
2.0	85 kW	2 l	11/00→05/05					
2.0 4motion	85 kW	2 l	11/00→05/05					
1.8 T 20V	110 kW	1.8 l	11/00→05/05	⊗ AWT; 4x	5DA 193 175-911	Ignition Coil	27	
2.0	96 kW	2 l	11/01→05/05	⊗ ALT; 4x	5DA 193 175-911	Ignition Coil	27	
2.3 VR5	125 kW	2.3 l	11/00→05/05		5DA 193 175-181	Ignition Coil	10	
2.3 VR5 4motion	125 kW	2.3 l	11/00→05/05					
2.8 4motion	142 kW	2.8 l	11/00→05/05	⊗ AMX / ATQ	5DA 749 475-471	Ignition Coil	39	

				13	i	412	
VW - PASSAT Variant (3C5)							08/05→10/11
1.4 TSI	90 kW	1.4 l	05/07→11/10	⊗ CAXA; 4x		5DA 193 175-501 Ignition Coil	16
1.4 TSI EcoFuel	110 kW	1.4 l	01/09→11/10	⊗ CDGA; 4x		5DA 193 175-501 Ignition Coil	16
1.6	75 kW	1.6 l	08/05→11/10			5DA 358 000-171 Ignition Coil	33
1.6 FSI	85 kW	1.6 l	08/05→06/08	⊗ BLF; →Model 2011; 4x		5DA 193 175-501 Ignition Coil	16
1.8 TSI	118 kW	1.8 l	05/07→10/11	⊗ CDAA / BZB; 4		5DA 193 175-921 Ignition Coil	28
2.0 FSI	110 kW	2 l	08/05→11/10	⊗ BVZ / BLY / BLR / BVY; 4		5DA 193 175-921 Ignition Coil	28
2.0 FSI	147 kW	2 l	08/05→11/10	⊗ BWA / CCZA / CAWB / CCTA / AXX / BPY; 4		5DA 193 175-921 Ignition Coil	28
2.0 FSI 4motion	110 kW	2 l	09/05→11/10	⊗ BVX / BLX / BLY; 4		5DA 193 175-921 Ignition Coil	28
VW - PASSAT Variant (32B)							08/80→03/88
1.6	53 kW	1.6 l	02/86→03/88	08/86→07/87		5DA 006 623-931 Switch Unit, ignition system	8
1.8	64 kW	1.8 l	05/86→03/88				
2.2	85 kW	2.2 l	08/85→03/88				
2.2	100 kW	2.2 l	01/85→03/88				
2.2 Syncro	88 kW	2.2 l	08/85→03/88				
1.6	55 kW	1.6 l	08/80→03/88	08/86→07/87		5DA 006 623-931 Switch Unit, ignition system	8
				08/83→; ⊗ DT		5DA 006 623-941 Switch Unit, ignition system	9
1.8	66 kW	1.8 l	01/83→03/88	08/86→07/87		5DA 006 623-931 Switch Unit, ignition system	8
1.8 Syncro	66 kW	1.8 l	01/86→03/88				
				⊗ DS		5DA 006 623-941 Switch Unit, ignition system	9
2.0	85 kW	2 l	08/83→03/88	⊗ JS; 08/86→07/87		5DA 006 623-931 Switch Unit, ignition system	8
VW - PASSAT Variant (365)							08/10→12/14
1.4 TSI	90 kW	1.4 l	08/10→12/14	⊗ CAXA; 4x		5DA 193 175-501 Ignition Coil	16
1.4 TSI EcoFuel	110 kW	1.4 l	08/10→12/14	⊗ CDGA; 4x		5DA 193 175-501 Ignition Coil	16
1.8 TSI	118 kW	1.8 l	08/10→12/14	⊗ CDAA; 4		5DA 193 175-921 Ignition Coil	28
2.0 TSI	155 kW	2 l	11/10→12/14	⊗ CCZB; 4		5DA 193 175-921 Ignition Coil	28
VW - POLO (6N1)							10/94→10/99
100 1.4 16V	74 kW	1.4 l	04/96→10/99	⊗ AFH		5DA 006 623-951 Ignition Coil	9
120 1.6 16V GTI	88 kW	1.6 l	09/98→10/99			5DA 358 000-171 Ignition Coil	33
45 1.0	33 kW	1 l	10/94→09/96	⊗ AEV		5DA 006 623-951 Ignition Coil	9
50 1.0	37 kW	1 l	09/96→10/99	⊗ AER / ALL		5DA 006 623-951 Ignition Coil	9
55 1.3	40 kW	1.3 l	10/94→07/95	⊗ ADX		5DA 006 623-951 Ignition Coil	9
55 1.4	40 kW	1.4 l	08/95→10/99	⊗ AEX		5DA 006 623-951 Ignition Coil	9
60 1.4	44 kW	1.4 l	07/95→10/99	⊗ AEX / AKV / APQ		5DA 006 623-951 Ignition Coil	9
75 1.6	55 kW	1.6 l	10/94→10/99	⊗ AEA / AEE		5DA 006 623-951 Ignition Coil	9
VW - POLO (6N2)							10/99→09/01
1.0	37 kW	1 l	10/99→09/01			5DA 358 000-171 Ignition Coil	33
1.4	44 kW	1.4 l	10/99→09/01				
1.4 16V	55 kW	1.4 l	10/99→09/01				
1.6 16V GTI	92 kW	1.6 l	10/99→09/01				
1.4	40 kW	1.4 l	10/99→09/01	⊗ AKP		5DA 358 000-171 Ignition Coil	33
1.4 16V	74 kW	1.4 l	10/99→09/01	⊗ AFK / AUB		5DA 358 000-171 Ignition Coil	33

				13	i	412		
VW - POLO (6R, 6C)							06/09 →	
1.2	44 kW	1.2 l	06/09 →	CGPB; 6R-A-000001 →; 3x	5DA 193 175-501	Ignition Coil	16	
1.2	51 kW	1.2 l	06/09 →	CGPA; 6R-A-000001 →; 3x	5DA 193 175-501	Ignition Coil	16	
1.4	63 kW	1.4 l	06/09 →	CGGB; 6R-A-000001 →; 4x	5DA 193 175-501	Ignition Coil	16	
1.4 GTI	132 kW	1.4 l	05/10 →	CAVE; 6R-A-000001 →; 4x	5DA 193 175-501	Ignition Coil	16	
1.4 TSI	103 kW	1.4 l	10/12 →	CPTA; 4 ports; 4x	5DA 193 175-951	Ignition Coil	29	
2.0 R WRC	162 kW	2 l	08/13 →	CDLJ; 4	5DA 193 175-921	Ignition Coil	28	
VW - POLO (9N_)							10/01 → 11/09	
1.2	40 kW	1.2 l	01/02 → 05/07	BMD / AWY; 3x	5DA 193 175-901	Ignition Coil	27	
1.2	44 kW	1.2 l	05/07 → 11/09	BBM; 9N-5-500001 → 9N-A-050001; 3x	5DA 193 175-901	Ignition Coil	27	
1.2 12V	47 kW	1.2 l	10/01 → 07/07	AZQ / BME; 9N-2-000001 →; 3x	5DA 193 175-501	Ignition Coil	16	
1.2 12V	51 kW	1.2 l	05/07 → 11/09	BZG; 9N-5-500001 → 9N-A-050001; 3x	5DA 193 175-501	Ignition Coil	16	
1.4 16V	55 kW	1.4 l	10/01 → 05/08	BBY / BKY; 9N-2-000001 →; 4x	5DA 193 175-501	Ignition Coil	16	
					AUA	5DA 358 000-171	Ignition Coil	33
1.4 16V	59 kW	1.4 l	05/06 → 11/09	BUD; 9N-5-500001 → 9N-A-050001; 4x	5DA 193 175-501	Ignition Coil	16	
1.4 16V	74 kW	1.4 l	10/01 → 05/08	AUB / BBZ; 9N-2-000001 →; 4x	5DA 193 175-501	Ignition Coil	16	
					AUB	5DA 358 000-171	Ignition Coil	33
1.4 FSI	63 kW	1.4 l	02/02 → 07/06	AXU; 9N-2-000001 →; 4x	5DA 193 175-501	Ignition Coil	16	
1.6 16V	77 kW	1.6 l	05/06 → 11/09	BTS; 9N-5-500001 → 9N-A-050001; 4x	5DA 193 175-501	Ignition Coil	16	
1.8 GTI	110 kW	1.8 l	09/05 → 11/09	BJX; 9N-5-500001 → 9N-A-050001; 4x	5DA 193 175-911	Ignition Coil	27	
1.8 GTi Cup Edition	132 kW	1.8 l	05/06 → 11/09	BBU; 9N-5-500001 → 9N-A-050001; 4x	5DA 193 175-911	Ignition Coil	27	
VW - POLO (86C, 80)							08/83 → 09/94	
1.0	33 kW	1 l	08/85 → 01/92	→ 09/86; → 86..H..060000	5DA 006 623-931	Switch Unit, ignition system	8	
					→ 08/90	5DA 006 623-941	Switch Unit, ignition system	9
					HZ; 07/90 →	5DA 006 623-951	Ignition Coil	9
1.0 CAT	33 kW	1 l	08/89 → 09/94	01/90 → 08/90; AAK	5DA 006 623-941	Switch Unit, ignition system	9	
					ACM / AAU; 07/90 →	5DA 006 623-951	Ignition Coil	9
1.3	40 kW	1.3 l	08/83 → 07/88	MH; 08/85 → 09/86; → 86..H..060000	5DA 006 623-931	Switch Unit, ignition system	8	
					08/85 →; MH	5DA 006 623-941	Switch Unit, ignition system	9
1.3 CAT	40 kW	1.3 l	07/87 → 09/94	→ 08/90; 2G / MH / NZ	5DA 006 623-941	Switch Unit, ignition system	9	
					NZ / 2G / AAV; 07/90 →	5DA 006 623-951	Ignition Coil	9
1.3 CAT	55 kW	1.3 l	10/89 → 03/91	3F; 07/90 →	5DA 006 623-951	Ignition Coil	9	
VW - POLO Box (6NF)							05/98 → 12/99	
1.4	44 kW	1.4 l	05/98 → 12/99	APQ / AEX; → 06/00	5DA 006 623-951	Ignition Coil	9	
VW - POLO Box (86CF)							08/92 → 07/94	
1.0	33 kW	1 l	08/92 → 07/94	AAU; → 06/94	5DA 006 623-951	Ignition Coil	9	
1.3	40 kW	1.3 l	08/92 → 07/94	AAV; → 06/94	5DA 006 623-951	Ignition Coil	9	

VW - POLO CLASSIC (6KV2)				11/95→09/01		
100 1.6	74 kW	1.6 l	12/95→09/01	⚙️ AFT; →06/00 ⚙️ AUR / AKL / APF / AEH	5DA 006 623-951 Ignition Coil	9
					5DA 358 000-171 Ignition Coil	33
60 1.4	44 kW	1.4 l	12/95→09/01	⚙️ AEX; →06/00 ⚙️ APQ / AKV; 07/96→06/00 ⚙️ ANW / AKK / AUD	5DA 006 623-951 Ignition Coil	9
					5DA 358 000-171 Ignition Coil	33
75 1.4 16V	55 kW	1.4 l	10/99→09/01		5DA 358 000-171 Ignition Coil	33
75 1.6	55 kW	1.6 l	11/95→09/97	⚙️ 1F	5DA 006 623-951 Ignition Coil	9
75 1.6	55 kW	1.6 l	11/95→09/01	⚙️ AEE; →06/00 ⚙️ ALM; ⚙️ 6K-Y-502795→; 07/99→	5DA 006 623-951 Ignition Coil	9
VW - POLO CLASSIC (86C, 80)				01/85→09/94		
1.0	33 kW	1 l	01/85→09/94	⚙️ HZ; 08/85→09/86; ⚙️ →86..H..060000 08/85→	5DA 006 623-931 Switch Unit, ignition system	8
					5DA 006 623-941 Switch Unit, ignition system	9
				⚙️ HZ; 07/90→	5DA 006 623-951 Ignition Coil	9
1.3	40 kW	1.3 l	01/85→07/87	⚙️ MH; 08/85→09/86; ⚙️ →86..H..060000 08/85→; ⚙️ MH	5DA 006 623-931 Switch Unit, ignition system	8
					5DA 006 623-941 Switch Unit, ignition system	9
1.3 CAT	40 kW	1.3 l	07/87→09/94	⚙️ MH / NZ ⚙️ NZ; 07/90→	5DA 006 623-941 Switch Unit, ignition system	9
					5DA 006 623-951 Ignition Coil	9
VW - POLO Coupe (86C, 80)				08/83→09/94		
1.0	33 kW	1 l	08/85→01/92	→09/86; ⚙️ →86..H..060000 →08/90 ⚙️ HZ; 07/90→	5DA 006 623-931 Switch Unit, ignition system	8
					5DA 006 623-941 Switch Unit, ignition system	9
					5DA 006 623-951 Ignition Coil	9
1.0 CAT	33 kW	1 l	08/89→09/94	01/90→08/90; ⚙️ AAK ⚙️ AAU / ACM; 07/90→	5DA 006 623-941 Switch Unit, ignition system	9
					5DA 006 623-951 Ignition Coil	9
1.3	40 kW	1.3 l	08/83→06/87	⚙️ MH; 08/85→09/86; ⚙️ →86..H..060000 08/85→; ⚙️ MH	5DA 006 623-931 Switch Unit, ignition system	8
					5DA 006 623-941 Switch Unit, ignition system	9
1.3	57 kW	1.3 l	03/91→09/94	⚙️ 3F	5DA 006 623-951 Ignition Coil	9
1.3 G40	83 kW	1.3 l	08/90→09/94	⚙️ PY	5DA 006 623-951 Ignition Coil	9
1.3 CAT	40 kW	1.3 l	07/87→08/94	→08/90; ⚙️ 2G / MH / NZ ⚙️ NZ / 2G / AAV; 07/90→	5DA 006 623-941 Switch Unit, ignition system	9
					5DA 006 623-951 Ignition Coil	9
1.3 CAT	55 kW	1.3 l	10/89→09/94	⚙️ 3F; 07/90→	5DA 006 623-951 Ignition Coil	9
VW - POLO Saloon (9A4)				07/03→		
1.4	55 kW	1.4 l	07/03→	⚙️ BBY / BKY; →Model 2006; 4x	5DA 193 175-501 Ignition Coil	16
1.4	74 kW	1.4 l	11/03→	⚙️ BBZ; →Model 2006; 4x	5DA 193 175-501 Ignition Coil	16
VW - POLO Variant (6KV5)				05/97→09/01		
1.4	40 kW	1.4 l	12/98→09/01		5DA 358 000-171 Ignition Coil	33
1.4 16V	55 kW	1.4 l	10/99→09/01		5DA 358 000-171 Ignition Coil	33
1.4	44 kW	1.4 l	05/97→09/01	⚙️ AEX / APQ / AKV; →06/00 ⚙️ ANW / AKK / AUD	5DA 006 623-951 Ignition Coil	9
					5DA 358 000-171 Ignition Coil	33
1.6	55 kW	1.6 l	05/97→09/01	⚙️ ALM ⚙️ AEE; →06/00	5DA 006 623-951 Ignition Coil	9









				13	i	412		
VW - POLO Variant (6KV5)								05/97→09/01
1.6	74 kW	1.6 l	05/97→09/01	⊗ AFT; →6K-Y-502794	5DA 006 623-951 Ignition Coil	9		
				⊗ AEH / AUR / AKL / APF	5DA 358 000-171 Ignition Coil	33		
VW - SCIROCCO (53B)								08/82→07/92
1.6	53 kW	1.6 l	04/86→07/90	→09/86	5DA 006 623-931 Switch Unit, ignition system	8		
1.6	55 kW	1.6 l	01/83→12/89					
1.8	66 kW	1.8 l	08/83→07/92					
1.8	70 kW	1.8 l	11/85→07/92					
1.8	82 kW	1.8 l	08/82→12/89	⊗ DX; →09/86	5DA 006 623-931 Switch Unit, ignition system	8		
1.8 16V	95 kW	1.8 l	03/86→07/92	→09/86	5DA 006 623-931 Switch Unit, ignition system	8		
				10/86→	5DA 006 623-941 Switch Unit, ignition system	9		
1.8 16V	102 kW	1.8 l	10/85→07/89	→09/86	5DA 006 623-931 Switch Unit, ignition system	8		
					5DA 006 623-941 Switch Unit, ignition system	9		
VW - SCIROCCO (137, 138)								05/08→05/11
1.4 TSI	90 kW	1.4 l	08/08→	⊗ CAXA; →Model 2011; 4x	5DA 193 175-501 Ignition Coil	16		
1.4 TSI	118 kW	1.4 l	05/08→	⊗ CAVD; →Model 2011; 4x	5DA 193 175-501 Ignition Coil	16		
2.0 R	188 kW	2 l	11/09→	⊗ CDLC; 4	5DA 193 175-921 Ignition Coil	28		
2.0 R	195 kW	2 l	11/09→	⊗ CDLA; 4	5DA 193 175-921 Ignition Coil	28		
2.0 TSI	147 kW	2 l	05/08→11/09	⊗ CAWB; 4	5DA 193 175-921 Ignition Coil	28		
2.0 TSI	155 kW	2 l	11/09→05/11	⊗ CCZB; 4	5DA 193 175-921 Ignition Coil	28		
VW - SHARAN (7M8, 7M9, 7M6)								09/95→03/10
1.8 T 20V	110 kW	1.8 l	09/97→03/10	⊗ AJH; →Model 2000	5DA 006 623-771 Switch Unit, ignition system	8		
				⊗ AWC; Model 2001→Model 2010; 4x	5DA 193 175-981 Ignition Coil	30		
				⊗ AJH	5DA 358 000-051 Ignition Coil	32		
2.0	85 kW	2 l	09/95→03/10	⊗ ADY; →06/00	5DA 006 623-951 Ignition Coil	9		
				⊗ ATM; 01/01→	5DA 358 000-171 Ignition Coil	33		
2.0 LPG	85 kW	2 l	04/06→03/10		5DA 358 000-171 Ignition Coil	33		
2.8 V6 24V	150 kW	2.8 l	04/00→03/10	⊗ AYL; 6	5DA 358 000-001 Ignition Coil	30		
2.8 V6 24V 4motion	150 kW	2.8 l	04/00→03/10					
VW - SHARAN (7N1, 7N2)								05/10→
1.4 TSI	110 kW	1.4 l	05/10→	⊗ CAVA; 4x	5DA 193 175-501 Ignition Coil	16		
2.0 TSI	147 kW	2 l	12/10→	⊗ CCZA; 4	5DA 193 175-921 Ignition Coil	28		
VW - TIGUAN (5N_)								09/07→
1.4 TSI	90 kW	1.4 l	08/10→	⊗ CAXA; →Model 2011; 4x	5DA 193 175-501 Ignition Coil	16		
1.4 TSI	110 kW	1.4 l	05/08→	⊗ BWK / CAVA; →Model 2011; 4x	5DA 193 175-501 Ignition Coil	16		
1.4 TSI 4motion	110 kW	1.4 l	09/07→					
2.0 TFSI 4motion	125 kW	2 l	09/07→	⊗ CCZC / CAWA; 4	5DA 193 175-921 Ignition Coil	28		
2.0 TFSI 4motion	147 kW	2 l	09/07→	⊗ CAWB / CCTA / CCZA; 4	5DA 193 175-921 Ignition Coil	28		
2.0 TSI 4motion	132 kW	2 l	05/11→	⊗ CCZD; 4	5DA 193 175-921 Ignition Coil	28		
2.0 TSI 4motion	155 kW	2 l	05/11→	⊗ CCZB; 4	5DA 193 175-921 Ignition Coil	28		
VW - TOUAREG (7LA, 7L6, 7L7)								06/06→05/10
4.2 V8 FSI	257 kW	4.2 l	06/06→05/10	⊗ BAR; Black; 8	5DA 193 175-921 Ignition Coil	28		

				13	i	412	
VW - TOURAN (1T1, 1T2)							02/03→05/10
1.4 FSI	125 kW	1.4 l	11/06→05/10	⊗ BLG / CAVB; 4x	5DA 193 175-501	Ignition Coil	16
1.4 TSI	103 kW	1.4 l	02/06→05/10	⊗ BMY / CAVC; 4x	5DA 193 175-501	Ignition Coil	16
1.4 TSI EcoFuel	110 kW	1.4 l	05/09→05/10	⊗ CDGA; 4x	5DA 193 175-501	Ignition Coil	16
1.6	75 kW	1.6 l	07/03→05/10	⊗ BGU 01/06→; ⊗ BSE / BSF	5DA 358 000-171	Ignition Coil	33
1.6 FSI	85 kW	1.6 l	02/03→01/07	⊗ BAG / BLF / BLP; →Model 2008; 4x	5DA 193 175-501	Ignition Coil	16
2.0 EcoFuel	80 kW	2 l	02/06→05/09		5DA 358 000-181	Ignition Coil	33
2.0 FSI	110 kW	2 l	10/03→11/05	⊗ AXW / BLY / BLR / BVY / BVZ / BLX; 4	5DA 193 175-921	Ignition Coil	28
VW - TRANSPORTER / CARAVELLE III Bus							08/82→07/92
1.9	57 kW	1.9 l	08/82→07/92		5DA 006 623-941	Switch Unit, ignition system	9
2.1	64 kW	2.1 l	10/86→07/92				
2.1	70 kW	2.1 l	08/85→07/92				
2.1	82 kW	2.1 l	08/84→07/92				
2.1 CAT	70 kW	2.1 l	06/89→07/92				
1.9	61 kW	1.9 l	01/83→07/85	09/84→	5DA 006 623-931	Switch Unit, ignition system	8
1.9 Syncro	57 kW	1.9 l	02/85→07/92	→09/86	5DA 006 623-931	Switch Unit, ignition system	8
2.1 Syncro	70 kW	2.1 l	08/85→07/92				
2.1 Syncro	82 kW	2.1 l	01/86→07/92		5DA 006 623-941	Switch Unit, ignition system	9
VW - TRANSPORTER / CARAVELLE IV Bus (70XB, 70XC, 7DB, 7DW)							09/90→04/03
2.0	62 kW	2 l	09/90→04/03	⊗ AAC; →06/04	5DA 006 623-951	Ignition Coil	9
2.5	81 kW	2.5 l	11/90→04/03	⊗ AAF; →06/94 ⊗ ACU; →06/97 ⊗ AEN; 07/95→; →70-T-199000 ⊗ AEU; 07/96→06/04	5DA 006 623-951	Ignition Coil	9
2.5	85 kW	2.5 l	08/96→04/03	⊗ AET; →06/04 ⊗ APL / AVT; 07/98→06/04	5DA 006 623-951	Ignition Coil	9
2.5 Syncro	81 kW	2.5 l	11/92→04/03	⊗ AAF; →06/95 ⊗ ACU / AEU; →70-3-250000	5DA 006 623-951	Ignition Coil	9
2.5 Syncro	85 kW	2.5 l	07/96→04/03	⊗ AET / APL / AVT; →70-3-250000	5DA 006 623-951	Ignition Coil	9
2.5 TDI Syncro	75 kW	2.5 l	01/96→04/03	⊗ AXL; →70-3-250000	5DA 006 623-951	Ignition Coil	9
VW - TRANSPORTER / CARAVELLE V Bus (7HB, 7HJ, 7EB, 7EJ, 7EF)							11/03→
2.0	85 kW	2 l	11/03→		5DA 358 000-171	Ignition Coil	33
2.0 TSI	110 kW	2 l	07/12→	⊗ CJKB; 4	5DA 193 175-921	Ignition Coil	28
2.0 TSI	150 kW	2 l	05/11→	⊗ CJKA; 4	5DA 193 175-921	Ignition Coil	28
2.0 TSI 4motion	150 kW	2 l	07/11→				
VW - TRANSPORTER II Box							08/75→07/79
2.0	51 kW	2 l	08/75→07/79	09/77→04/79	5DA 006 623-931	Switch Unit, ignition system	8
VW - TRANSPORTER II Bus							08/75→04/79
2.0	51 kW	2 l	08/75→04/79	09/78→	5DA 006 623-931	Switch Unit, ignition system	8
VW - TRANSPORTER III Box							10/82→07/92
1.9	57 kW	1.9 l	10/82→07/92		5DA 006 623-941	Switch Unit, ignition system	9
2.1	70 kW	2.1 l	08/85→07/92				
2.1	82 kW	2.1 l	03/86→07/92				
1.9	61 kW	1.9 l	10/84→02/89	→07/85	5DA 006 623-931	Switch Unit, ignition system	8
1.9 Syncro	57 kW	1.9 l	11/84→07/92	02/85→09/86	5DA 006 623-931	Switch Unit, ignition system	8
					5DA 006 623-941	Switch Unit, ignition system	9
2.1 Syncro	70 kW	2.1 l	08/85→07/92	→09/86	5DA 006 623-931	Switch Unit, ignition system	8
2.1 Syncro	82 kW	2.1 l	03/86→07/92		5DA 006 623-941	Switch Unit, ignition system	9

				13	i	412			
VW - TRANSPORTER III Platform/Chassis							08/82→07/92		
1.9	57 kW	1.9 l	08/82→07/92				5DA 006 623-941	Switch Unit, ignition system	9
2.1	70 kW	2.1 l	08/85→07/92						
2.1	82 kW	2.1 l	03/86→07/92						
1.9	61 kW	1.9 l	10/84→02/89	→07/85			5DA 006 623-931	Switch Unit, ignition system	8
1.9 Syncro	57 kW	1.9 l	12/84→07/92	02/85→09/86			5DA 006 623-931	Switch Unit, ignition system	8
							5DA 006 623-941	Switch Unit, ignition system	9
2.1 Syncro	70 kW	2.1 l	08/85→07/92	→09/86			5DA 006 623-931	Switch Unit, ignition system	8
2.1 Syncro	82 kW	2.1 l	03/86→07/92				5DA 006 623-941	Switch Unit, ignition system	9
VW - TRANSPORTER IV Box (70XA)							07/90→04/03		
2.0	62 kW	2 l	07/90→04/03	⊗ AAC; →06/04; ⊗ 70-T-200001→70-T-199000			5DA 006 623-951	Ignition Coil	9
2.5	81 kW	2.5 l	11/90→04/03	⊗ AAF; →06/94 ⊗ ACU; →06/97 ⊗ AEN; →70-T-199000; 07/95→06/96 ⊗ AEU; 07/96→06/04			5DA 006 623-951	Ignition Coil	9
2.5	85 kW	2.5 l	08/96→04/03	⊗ AET; →06/04 ⊗ APL / AVT; 07/98→06/04			5DA 006 623-951	Ignition Coil	9
2.5 Syncro	81 kW	2.5 l	10/92→04/03	⊗ AAF; →06/95 ⊗ ACU; →06/04; →70-3-250000 ⊗ AEU; →70-3-250000; 07/96→06/04			5DA 006 623-951	Ignition Coil	9
2.5 Syncro	85 kW	2.5 l	08/96→04/03	⊗ AET / APL / AVT; →70-3-250000			5DA 006 623-951	Ignition Coil	9
2.5 TDI Syncro	75 kW	2.5 l	09/95→04/03	⊗ AXL; →70-3-250000; 07/96→			5DA 006 623-951	Ignition Coil	9
VW - TRANSPORTER IV Platform/Chassis (70XD)							07/90→04/03		
2.0	62 kW	2 l	07/90→04/03	⊗ AAC; →06/04; ⊗ 70-T-200001→70-T-199000			5DA 006 623-951	Ignition Coil	9
2.5	81 kW	2.5 l	11/90→04/03	⊗ AAF; →06/94 ⊗ ACU; →06/97 ⊗ AEN; 07/95→; →70-T-199000 ⊗ AEU; 07/96→06/04			5DA 006 623-951	Ignition Coil	9
2.5	85 kW	2.5 l	08/96→04/03	⊗ AET; →06/04 ⊗ APL / AVT; 07/98→06/04			5DA 006 623-951	Ignition Coil	9
2.5 Syncro	81 kW	2.5 l	10/92→04/03	01/95→; ⊗ ACU			5DA 006 623-951	Ignition Coil	9
2.5 Syncro	85 kW	2.5 l	08/96→04/03	⊗ AET / APL / AVT; →70-3-250000			5DA 006 623-951	Ignition Coil	9
2.5 TDI Syncro	75 kW	2.5 l	05/98→04/03	⊗ AXL; →70-3-250000			5DA 006 623-951	Ignition Coil	9
VW - TRANSPORTER V Box (7HA, 7HH, 7EA, 7EH)							11/03→		
2.0	85 kW	2 l	11/03→				5DA 358 000-171	Ignition Coil	33
2.0 TSI	110 kW	2 l	07/12→	⊗ CJKB; 4			5DA 193 175-921	Ignition Coil	28
2.0 TSI	150 kW	2 l	05/11→	⊗ CJKB; 4			5DA 193 175-921	Ignition Coil	28
2.0 TSI 4motion	150 kW	2 l	07/11→						
VW - TRANSPORTER V Platform/Chassis (7JD, 7JE, 7JL, 7JY, 7JZ, 7FD)							11/03→		
2.0	85 kW	2 l	11/03→				5DA 358 000-171	Ignition Coil	33
2.0 TSI	110 kW	2 l	07/12→	⊗ CJKB; 4			5DA 193 175-921	Ignition Coil	28
VW - UP							08/11→		
1.0	44 kW	1 l	08/11→	⊗ CHYA; 4 ports; 3x			5DA 193 175-951	Ignition Coil	29
1.0	55 kW	1 l	08/11→	⊗ CHYB; 4 ports; 3x			5DA 193 175-951	Ignition Coil	29
1.0 EcoFuel	50 kW	1 l	11/12→	⊗ CPGA; 4 ports; 3x			5DA 193 175-951	Ignition Coil	29
VW - VENTO Saloon (1H2)							11/91→09/98		
1.4	40 kW	1.4 l	11/91→09/98	⊗ ABD; →06/95 07/95→; ⊗ AEX			5DA 006 623-951	Ignition Coil	9
1.4	44 kW	1.4 l	11/91→09/98	⊗ ABD; →06/95			5DA 006 623-951	Ignition Coil	9
1.6	55 kW	1.6 l	09/92→09/98	⊗ AEA; 07/94→06/95 ⊗ AEE; 07/95→			5DA 006 623-951	Ignition Coil	9

				13	i	412	
VW - VENTO Saloon (1H2)				11/91→09/98			
1.6	74 kW	1.6 l	10/94→09/98	AEK; →06/96 AFT; 07/96→	5DA 006 623-951 Ignition Coil	9	
1.8	55 kW	1.8 l	11/91→09/98	AAM	5DA 006 623-951 Ignition Coil	9	
1.8	66 kW	1.8 l	11/91→09/98	ABS; →06/95 ADZ; 07/94→	5DA 006 623-951 Ignition Coil	9	
2.0	85 kW	2 l	11/91→09/98	2E; →06/95 ADY; 07/94→06/96 AGG; 07/95→ AKR; 07/97→	5DA 006 623-951 Ignition Coil	9	



       					
WARTBURG - 353					09/88→05/91
1.3	43 kW	1.3 l	09/88→05/91	5DA 006 623-941 Switch Unit, ignition system	9
WARTBURG - 353 Tourist					02/89→05/91
1.3	43 kW	1.3 l	02/89→05/91	5DA 006 623-941 Switch Unit, ignition system	9



ZASTAVA - 101 (1100)					06/73→12/93			
1.1	40 kW	1.1 l	06/73→01/90				5DA 006 623-001 Switch	4
1.1	41 kW	1.1 l	05/75→12/93				Unit, ignition system	





ALFA ROMEO

006 0750 065
116 9765 0790
116 9765 0790 1
46469863
46548037
46755605
46777288
542 1620 0000
542 1620 00000
55246099
605 0428 80
605 2299 70
60558152
605 5815 30
60562701
60586072
60805420
60809492
60809606
60810690
705 786
7648797
76487970
7793212

AUDI

004 028 149
00A 905 105
047 905 115
058 905 101 A
058 905 105 A
06A 905 115 A
06A 905 115 D
06B 905 115
06B 905 115 B
06B 905 115 E
06B 905 115 G
06B 905 115 J
06B 905 115 L
06B 905 115 M
06B 905 115 N
06B 905 115 Q
078 905 101
078 905 101 A
078 905 104
191 905 351
191 905 351 A
191 905 351 B
191 905 351 C
443 905 105 C
443 905 105 D
443 905 105 E
4A0 905 105
4A0 905 105 B
4A0 905 351
4A0 905 351 A
4D0 905 351
4D0 997 351
6N0 905 104
6N0 905 104
867 905 104
867 905 104 A
867 905 352
893 905 105
893 905 105 E
8A0 905 105
8D0 905 105
8D0 905 351
X03 967 837

BERU

0040100014
0040100029
0040100231
0040100232
0040100234
0040100242
0040100243
0040100245
0040100254
0040100255
0040100281
0040100283
0040100297
0040100302
0040100307
0040100308
0040100309
0040100315
0040100317
0040100320
0040100322
0040100338
0040100340

BERU

0040100342
0040100371
0040100387
0040100408
0040100451
0040100454
0040100476
0040100478
0040100501
0040102020
0040102021
0040102025
0040102026
0040102033
0040102043
0040102045
0040102051
0040102055
0040102059
0040102061
0040102067
0040102088
0040102126
0040102144
0040102158
0040102165
0040102167
0040103007
0040104100
0 040 401 001
0 040 401 002
0 040 401 003
0 040 401 004
0 040 401 005
0 040 401 009
0 040 401 015
0040401016
0040401018
0040401023
0040401024
0040401026
0040401027
0040401028
0040401040
0040401041
0040401045
0040401049
0040401053
0040402001
0040402009
ZM001
ZM003
ZM 004
ZM 005
ZM 009
ZM 015
ZM 016
ZM 018
ZM 023
ZM 024
ZM 026
ZM 040
ZM 045
ZM 049
ZM 061
ZM 062
ZM 063
ZS 014
ZS 029
ZS 231
ZS 232
ZS 234
ZS 236
ZS 242
ZS 243
ZS 245
ZS 254
ZS 255
ZS 281
ZS 283
ZS 297
ZS 302
ZS 307
ZS 308
ZS 309
ZS 313
ZS 315
ZS 317
ZS320
ZS322
ZS327
ZS327
ZS338
ZS 340
ZS342
ZS371
ZS375
ZS387
ZS408

BERU

ZS451
ZS454
ZS476
ZS478
ZS501
ZS507
ZSE 001
ZSE 009
ZSE020
ZSE021
ZSE 025
ZSE 026
ZSE033
ZSE043
ZSE045
ZSE051
ZSE055
ZSE059
ZSE061
ZSE063
ZSE067
ZSE088
ZSE089
ZSE126
ZSE144
ZSE158
ZSE165
ZSE167

BMW

12 13 1 247 281
12 13 1 317 585
12 13 1 402 440
12 13 1 402 713
12 13 1 703 227
12 13 1 703 228
12 13 1 703 359
12 13 1 703 825
12 13 1 712 219
12 13 1 712 223
12 13 1 720 166
12 13 1 726 176
12 13 1 726 177
12 13 1 726 178
12 13 1 727 108
12 13 1 729 842
12 13 1 730 765
12 13 1 730 766
12 13 1 731 134
12 13 1 731 884
12 13 1 748 017
12 13 1 748 018
12 13 1 748 394
12 13 1 777 666
12 13 7 523 345
12 13 7 548 553
12 13 7 551 049
12 13 7 551 260
12 13 7 559 842
12 13 7 562 744
12 13 7 562 745
12 13 7 571 643
12 13 7 571 644
12 13 7 582 627
12 13 7 594 935
12 13 7 594 938
12 13 7 599 219
12 13 7 598 477
12 13 7 703 359
12 13 9 066 468
12 13 9 067 830
12 14 1 244 089
12 14 1 244 191
12 14 1 244 226
12 14 1 244 477
12 14 1 244 481
12 14 1 266 702
12 14 1 273 217
12 14 1 273 298
12 14 1 273 298
12 14 1 274 698
12 14 1 461 441
12 14 1 466 333
1 227 030 059
1 227 030 062
1 247 281
1 266 702
1 273 217
1 273 298
1 274 698
1 404 309
1 461 441
1 466 333
1 703 227
1 703 359
1 703 825
1 712 219

BMW

5DA 358 000-031
5DA 193 175-821
5DA 193 175-971
5DA 193 175-961
5DA 193 175-891
5DA 193 175-891
5DA 006 623-951
5DA 193 175-981
5DA 193 175-741
5DA 193 175-841
5DA 193 175-581
5DA 193 175-651
5DA 193 175-921
5DA 193 175-911
5DA 193 175-731
5DA 193 175-801
5DA 193 175-911
5DA 193 175-731
5DA 193 175-701
5DA 193 175-801
5DA 193 175-591
5DA 358 000-001
5DA 193 175-991
5DA 193 175-851
5DA 358 000-001
5DA 193 175-951
5DA 193 175-711
5DA 193 175-811
5DA 193 175-931
5DA 193 175-941

BOSCH

0 221 123 217
0 221 123 336
0 221 503 001
0 221 503 003
0 221 503 006
0 221 503 007
0 221 503 010
0 221 503 014
0 221 503 022
0 221 503 024
0 221 503 025
0 221 503 035
0 221 503 036
0 221 503 407
0 221 503 421
0 221 503 472
0 221 503 485
0 221 503 489
0 221 504 456
0 221 504 471
0 221 505 423
0 221 505 437
0 221 506 002
0 221 506 003
0 221 506 444
0 221 506 445
0 221 600 002
0 221 600 005
0 221 600 007
0 221 600 009
0 221 600 010
0 221 600 012
0 221 600 013
0 221 600 014
0 221 600 015
0 221 600 016
0 221 600 017
0 221 600 050
0 221 600 052
0 221 601 003
0 221 601 004
0 221 601 005
0 221 601 006
0 221 603 002
0 221 603 003
0 221 603 004
0 221 603 931
0 221 100 023
0 221 100 024
0 221 100 029
0 221 100 043
0 221 100 102
0 221 100 110
0 221 100 111
0 221 100 112
0 221 100 114
0 221 100 115
0 221 100 121
0 221 100 122
0 221 100 123
0 221 100 124
0 221 100 124
0 221 100 126
0 221 100 129
0 221 100 136
0 221 100 137
0 221 100 140
0 221 100 145
0 221 100 148



Cross References

Manufacturer no. vs. Hella no.

BOSCH

0 227 100 149
0 227 100 200
0 227 100 201
0 227 100 202
0 227 100 204
0 227 100 209
0 227 100 210
0 227 100 211
0 227 100 212
0 227 100 213
0 227 100 215
0 986 221 000
0 986 221 000 090
0 986 221 001
0 986 221 001 090
0 986 221 003
0 986 221 003 090
0 986 221 008
0 986 221 010
0 986 221 018
0 986 221 023
0 986 221 023 090
0 986 221 024
0 986 221 025
0 986 221 025 090
0 986 221 026
0 986 221 026 090
0 986 221 030
0 986 221 030 090
0 986 221 031
0 986 221 031 090
0 986 221 033
0 986 221 034
0 986 221 034 090
0 986 221 035 090
0 986 221 036
0 986 221 041 090
0 986 221 042
0 986 221 043
0 986 221 044
0 986 221 046
0 986 221 047
0 986 221 055
0 986 221 060
0 986 221 062
0 986 221 063
0 986 221 077
0 986 221 099
0 986 JG1 211
0 986 JG1 213
0 986 JG1 213 090
1 127 020 010
1 137 010 025
1 227 010 002
1 227 010 003
1 227 010 005
1 227 010 006
1 227 010 008
1 227 010 039
1 227 020 017
1 227 022 017
1 227 022 018
1 227 022 030
1 227 022 031
1 227 030 059
1 227 030 062
1 227 030 071
1 237 010 028
1 237 010 029
1 237 010 031
1 237 010 038
9 16X 022 710
9 222 067 034
9 222 067 075
BIM034
BIM079
BIM123
BIM140
BIM200
F 000 ZS0 103
F 000 ZS0 212
F 000 ZS0 221
F 005 X10 715
F 005 X12 070
TSZ-I 2 L
TSZ-I 8 U
TSZ-I 8 Z
TZ 25 I
TZ 29 I
TZ 32 I
TZ 35 I
TZ 43 I
TZ 45 I
TZ 50 I
TZ 50 I
TZ 71
TZ 81

BOUGICORD

154301
155002
155031
155040
155072
156800
157600

BREMI

11720
11722
11723
11873
11875
11929
11930
11931
14002
14003
14022
14051
14100
14600
20130

CHRYSLER

5098138AA
A5 06 338 80
MD 11 247 9
MD 164 475

CITROËN

5927.90
5945.02
5945.03
5945.45
5945.51
5945.54
5945.55
5945.60
5963.19
5970.48
5970.49
5970.60
5970.70
5970.99
5970.A8
5970.53
5970.56
5970.64
5970.72
5970.73
5970.74
5970.78
5970.79
5970.80
5970.84
5970.87
5970.A0
5970.A5
5970.A9
79.100.351.00
91.504.912.80
91.504.944.80
91.506.338.80
91504912
91506338
94.531.304.80
94531304
96.048.070.80
96.073.612
96.073.612.80
96048070
96.062.288
96.074.054
96.165.97.080
96213086
96.228.897
96.281.58.580
96292106
9629210680
96358649
96363378
97.522.875.80
97.522.876
97.530.125
97.530.125.80
97.531.304.80
97.532.831.80
97.533.831
97522875
97531304
97532831

5DA 193 175-431
5DA 749 475-261
5DA 749 475-611
5DA 749 475-601
5DA 193 175-991
5DA 193 175-461
5DA 193 175-981

DACIA

60 01 543 604
82 00 702 693

DAEWOO

000 158 70 03
0001587503

DAF

133 25840
350 19215

DELCO REMY

1 301 0892
1 601 0892
1 894 322
9 348 922
D 190 6
D 195 7
D 195 8
D 196 1

DELPHI DIESEL

CE10001-12B1
CE10021-12B1
CE10023-12B1
CE20009-12B1
CE20010-12B1
CE20014-12B1
CE20026-12B1
CE20029-12B1
CE20030-12B1
CE20036-12B1
CE20038-12B1
CE20039-12B1
CE20040-12B1
CE20040-12B1
CE20043-12B1
CE20044-12B1
CE20046-12B1
CE20047-12B1
CE20048-12B1
CE20061-12B1
GN10177-12B1
GN10201-12B1
GN10205-12B1
GN10219
GN10219-12B1
GN10242
GN10246
GN10251-12B1
GN10256-12B1
GN10262-12B1
GN10264-12B1
GN10266-12B1
GN10294
GN10294-12B1
GN10303
GN10303-12B1
GN10330-12B1
GN10364-12B1
GN10418-12B1

DUCELLIER

245510
521007
521013

DURITE

0-350-02
0-350-04

EVOBUS

000 158 70 03
000 158 71 03
000 158 73 03
000 158 75 03
000 158 78 03
0015458632
0025451832
0025452632
0025455832
0025455932
0035451632
0035451732
0035454032
0035454132
A0015458632
A0025451832
A0025452632
A0025455832
A0025455932
A0025459032

EVOBUS

A0035451632
A0035451732
A0035454032
A0035454132

FACET

8.7401
8.7405
8.7406
8.7420
8.7428
8.7488
8.7489
8.7490
9.4001
9.4005
9.4006
9.4020
9.4072
9.6035
9.6189
9.6216
9.6245
9.6255
9.6256
9.6276
9.6277
9.6278
9.6286
9.6287
9.6297
9.6303
9.6303S
9.6317
9.6345
9.6374
9.8114

FEBI BILSTEIN

24996
27168

FEMSA

314271

FERRARI

134386
137 511
46446039
46472440
46480361
465 4356 2
465 4803 7
467 9007 3
500309816
605 0428 8
605 5815 30
605 9002 8
605 9002 9
607 5501 2
607 5509 4
608 0947 7
761 2955
762 6232
762 6232 0
764 8798
767 2018
7789346
9607405480
961 2955
9622889780
975 3012 58
994 0095

FIAT

4419628
464 46 039
46460582
464 72 440
46473849
464 80 361
46543562
46548037
46755605
46777286
46777288
46790073
500309816
55180004
55246099
60504288
60558152
605581530
60562701



5DA ...		5DA ...	
5DA 006 623-001	4	5DA 358 000-111	32
5DA 006 623-041	4	5DA 358 000-121	33
5DA 006 623-051	4	5DA 358 000-171	33
5DA 006 623-161	4	5DA 358 000-181	33
5DA 006 623-181	4	5DA 358 000-191	33
5DA 006 623-191	5	5DA 358 000-201	33
5DA 006 623-201	5	5DA 358 000-231	34
5DA 006 623-231	5	5DA 358 000-241	34
5DA 006 623-251	5	5DA 358 000-251	34
5DA 006 623-331	6	5DA 358 000-281	34
5DA 006 623-401	6	5DA 358 000-291	35
5DA 006 623-421	6	5DA 358 000-301	35
5DA 006 623-431	6	5DA 358 000-331	35
5DA 006 623-471	7	5DA 358 000-341	35
5DA 006 623-511	7	5DA 358 000-351	36
5DA 006 623-581	7	5DA 749 475-091	36
5DA 006 623-591	7	5DA 749 475-101	36
5DA 006 623-601	8	5DA 749 475-111	37
5DA 006 623-671	9	5DA 749 475-131	37
5DA 006 623-771	8	5DA 749 475-201	37
5DA 006 623-781	8	5DA 749 475-211	38
5DA 006 623-931	8	5DA 749 475-261	38
5DA 006 623-941	9	5DA 749 475-341	38
5DA 006 623-951	9	5DA 749 475-351	38
5DA 193 175-061	10	5DA 749 475-371	39
5DA 193 175-081	10	5DA 749 475-401	39
5DA 193 175-181	10	5DA 749 475-471	39
5DA 193 175-331	10	5DA 749 475-511	39
5DA 193 175-341	11	5DA 749 475-601	40
5DA 193 175-351	11	5DA 749 475-611	40
5DA 193 175-361	11	5DA 749 475-951	40
5DA 193 175-371	12	5DA 749 475-961	40
5DA 193 175-381	12	5DA 749 475-971	41
5DA 193 175-391	12		
5DA 193 175-401	13		
5DA 193 175-411	13		
5DA 193 175-421	13		
5DA 193 175-431	14		
5DA 193 175-441	14		
5DA 193 175-451	14		
5DA 193 175-461	14		
5DA 193 175-471	15		
5DA 193 175-481	15		
5DA 193 175-491	15		
5DA 193 175-501	16		
5DA 193 175-511	16		
5DA 193 175-521	16		
5DA 193 175-531	17		
5DA 193 175-541	17		
5DA 193 175-551	17		
5DA 193 175-561	18		
5DA 193 175-581	18		
5DA 193 175-591	18		
5DA 193 175-641	19		
5DA 193 175-651	19		
5DA 193 175-661	19		
5DA 193 175-671	20		
5DA 193 175-681	20		
5DA 193 175-691	20		
5DA 193 175-701	21		
5DA 193 175-711	21		
5DA 193 175-721	21		
5DA 193 175-731	22		
5DA 193 175-741	22		
5DA 193 175-751	22		
5DA 193 175-761	23		
5DA 193 175-781	23		
5DA 193 175-791	23		
5DA 193 175-801	24		
5DA 193 175-811	24		
5DA 193 175-821	24		
5DA 193 175-831	25		
5DA 193 175-841	25		
5DA 193 175-851	25		
5DA 193 175-861	26		
5DA 193 175-871	26		
5DA 193 175-881	26		
5DA 193 175-891	27		
5DA 193 175-901	27		
5DA 193 175-911	27		
5DA 193 175-921	28		
5DA 193 175-931	28		
5DA 193 175-941	28		
5DA 193 175-951	29		
5DA 193 175-961	29		
5DA 193 175-971	29		
5DA 193 175-981	30		
5DA 193 175-991	30		
5DA 358 000-001	30		
5DA 358 000-011	31		
5DA 358 000-021	31		
5DA 358 000-031	31		
5DA 358 000-041	31		
5DA 358 000-051	32		
5DA 358 000-061	32		
5DA 358 000-071	32		
5DA 358 000-101	32		

HELLA A/S

Lundsbjerg Industrivej 13
DK-6200 Aabenraa
Tel.: 0045 7330 3600
Fax: 0045 7330 3602
e-mail: info@hella.dk
www.hella.dk

HELLA Asia Singapore Pte Ltd

Regional Headquarters Asia Pacific
Independent Aftermarket
2 International Business Park
#02-12 The Strategy
Singapore 609930
Tel: +65 6854 7300
Fax: +65 6854 7302
E-mail: singapore@hella.com
Internet: www.hellaasia.com

HELLA Australia Pty. Ltd.

P.O. Box 89
Mentone, Victoria 3194 Australia
Tel.: (03) 9581 9299
Fax: (03) 9581 1838
Techline: 1800 061 729
E-Mail: custservice@ha.hella.com
Internet: www.hella.com.au

© HELLA KGaA Hueck & Co., Lippstadt
J01051/01.16

Subject to technical and price modifications