







Thule Rapid System Kit 1824

> Instructions

TOYOTA Prius, 5-dr Hatchback, 16-




TOYOTA Prius Prime, 5-dr Hatchback, 17-






ISO 11154-E

141824
C.20170519
519-1824-02


Bring your life
thule.com



x1






x1



1

	X (scale)	X (mm)	X (inch)
TOYOTA Prius , 5-dr Hatchback, 16-	40,5	1056	41 ⁵ / ₈
TOYOTA Prius Prime , 5-dr Hatchback, 17-	40,5	1056	41 ⁵ / ₈





	Y (scale)	Y (mm)	Y (inch)
TOYOTA Prius , 5-dr Hatchback, 16-	34	991	39
TOYOTA Prius Prime , 5-dr Hatchback, 17-	34	991	39


2

TOYOTA Prius, 5-dr Hatchback, 16-

TOYOTA Prius Prime, 5-dr Hatchback, 17-



3



	W (mm)	Z (mm)	W (inch)	Z (inch)
TOYOTA Prius , 5-dr Hatchback, 16-	170	775	6 ¾	30 ½
TOYOTA Prius Prime , 5-dr Hatchback, 17-	170	775	6 ¾	30 ½

