

HYGROMASTER®

HYGROMASTER®

This device should be used along with the cellar air conditioner

- Sober, discreet design in a neutral color pallet : grey
- Works easily and features just one operation setting
- Easy to install with just one integrated plug
- Delivered with a 20L water tank that is ready to be linked up
- This device is adapted to a cellar with a maximum volume of 100 cubic meters*.
- **2** year guarantee



Stop/start switch
 The Hygromaster® filling up with water, the lid is shut during this phase.

Sector connection

Humidity instructions settings

- In winter, activate the HYGROMASTER® in humidifying position (I).
- Ensure you check and fill the reservoir's water level regulary (use demineralized water).
- During the summer, cut the humidifier in order not to disturb cold production and generate excessive amounts of condensates.

REFERENCE	HYGROMASTER®
Electrical supply	230-240 V - 50Hz
Intensity used for humidification	0,2 A
Humidification capacity*	18,2g water/h at 12°C*
Dimensions	W.258 x H.140 x D.166 mm
Power used for humidification	45 W
Length of the power cable	1,5 m

*With an insulation adapted to the temperature and the volume of the cellar.



- Z.I. VIEUX-THANN 18 RUE GUY DE PLACE BP 60010 - F68801 THANN CEDEX
- Tél: +33 (0) 389 377 515
- E-mail: contact@winemaster.fr

www.winemaster.fr