

SONY®

Complete Spare Parts List

STEREO TURNTABLE SYSTEM

Model PS-X75

US Model
Canadian Model
E Model

IMPORTANT

When ordering parts, be sure to furnish the following information:

1. Part Number
2. Model Number
3. Description as contained in this parts list

Due to our use of an electronic data processing system, your orders are processed by the PART NUMBER specified by you.

Please order carefully-wrong part numbers result in wrong parts.

NOTE: Prices are subject to change without notice.

SONY CORPORATION

Complete Spare Parts List for PS-X75

US Model
 Canadian Model
 E Model

April, 1980

<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u> US\$
		E
<u>I. MECHANICAL PARTS</u>		
A-4608-144-A	BSL Motor Ass'y	13.11
X-4858-403-0	Insulator Ass'y	0.78
X-4858-431-3	Cover Ass'y, dust	8.55
	including;	
4-857-601-00	Cushion, dust cover	0.05
4-858-583-00	Hinge	0.68
X-4867-101-0	Button Ass'y, POWER	0.59
● X-4867-102-0	Holder (A) Ass'y, coil	0.97
X-4867-103-0	Plate Ass'y, lifter	0.34
X-4867-104-0	Rod (A) Ass'y, push	0.34
● X-4867-106-0	Holder Ass'y, yoke	0.88
X-4867-107-0	Button Ass'y, START	0.68
X-4867-108-0	Button Ass'y, STOP	0.68
X-4867-109-0	Button Ass'y, MOTOR ON/OFF	0.68
X-4867-110-0	Button Ass'y, ARM TRANSPORT (forward)	0.68
X-4867-111-0	Button (B) Ass'y, ARM TRANSPORT (back)	0.68
X-4867-112-0	Button Ass'y, ARM TRANSPORT (up/down)	0.68
X-4867-113-0	Arm Rest (A) Ass'y	1.36
X-4867-116-0	Screw Ass'y, pivot	1.17
X-4867-117-1	Shaft Ass'y, tonearm	0.10
2-054-624-00	Screw (B), cartridge (E1, E2 model)	0.10
2-239-707-00	Heat Sink	0.97
3-001-707-05	Holder, cord	0.15

- Items marked "●" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

US Model
 Canadian Model
 E Model

<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u> E US\$
3-491-369-00	Spring, ground	0.05
3-531-576-21	Rivet, plastic	0.03
3-537-303-00	Knob, STYLUS FORCE (ANTI SKATING)	0.05
3-701-438-21	Washer, plastic; 2.5 mm dia. (E1, E2 model)	0.03
3-701-441-11	Washer, plastic; 4 mm dia.	0.03
3-701-445-11	Washer, plastic; 7 mm dia.	0.03
3-701-505-00	SC, M 3x3	0.10
3-701-506-00	SC, M 3x4	0.10
▲ 3-701-682-00	Stopper, power-cord (US, Canadian model)	0.05
3-703-037-00	Plate, insulator	0.03
3-703-114-01	Label, main caution (US model)	0.10
3-703-114-11	Label, main caution (Canadian model)	0.10
▲ 3-703-244-00	Stopper, power-cord (AEP, UK, E1, E2 model)	0.10
3-831-441-XX	Cushion, weight	0.10
4-023-058-00	Nut, M18	0.10
4-808-459-11	Screw (B), motor lock	0.05
4-812-554-00	Washer	0.03
4-836-828-00	Emblem, SONY	0.78
4-847-059-00	Cap, drop-point adjustment hole	0.10
● 4-853-007-00	Heat Sink	0.10
4-853-222-01	Spacer	0.03
4-853-222-11	Spacer	0.03
4-855-217-21	Collar, screw	1.36
4-855-221-00	Needle, pivot	1.17
4-857-601-00	Cushion, dust cover	0.05
4-858-485-00	Shaft, lever	0.29
4-858-486-11	Lever, tonearm height adjustment	0.39
4-858-490-00	Knob, tonearm rest adjustment	0.15
4-858-513-00	Collar	0.03
4-858-522-00	Rubber, floating	0.05
● 4-858-525-00	Bracket, power transformer	0.20
● 4-858-530-00	Base (B), insulator	0.15
● 4-858-544-00	Base, insulator	0.10
● 4-858-551-00	Bracket, power cord (US, Canadian model)	0.39
4-858-583-00	Hinge	0.68

● Items marked “●” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

▲: Critical components for safety. Replace only with part number specified.

US Model
Canadian Model
E Model

E

<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u>
		USS
4-858-800-00	Spring, connector	0.10
4-858-810-00	Spring, reinforcement sleeve	0.05
4-858-811-00	Washer, connector	0.03
4-862-555-00	Yoke, shield	0.10
● 4-862-572-00	Case, shield	0.15
4-862-574-11	Pipe, tonearm	0.97
4-862-627-00	Nut, base-rest	0.05
4-862-690-00	Screw, M 3x10 (hexagon-socket)	0.03
4-867-102-00	Plate, bottom	4.81
4-867-103-00	Knob, STYLUS FORCE (ANTI SKATING)	0.25
4-867-106-00	Screw, frame	0.20
● 4-867-107-00	Yoke (A), horizontal	0.20
● 4-867-108-00	Yoke (B), horizontal	0.29
● 4-867-109-00	Shaft, yoke	0.20
● 4-867-110-00	Shutter, movable	0.15
● 4-867-111-00	Bracket, shutter	0.15
4-867-112-00	Frame (B), tonearm	1.36
4-867-113-00	Holder, solenoid	0.88
4-867-116-00	Rest, base	0.59
4-867-117-00	Frame	18.38
● 4-867-118-00	Bracket, POWER switch	0.10
● 4-867-119-00	Bracket, variable resistor	0.10
● 4-867-120-00	Holder (C), circuit board	0.10
4-867-121-00	Holder (A), lens	0.59
● 4-867-122-00	Holder (B), automatic record-size detection	0.15
4-867-123-00	Lens	0.10
● 4-867-124-00	Bracket (D), circuit board	0.10
4-867-125-00	Holder, circuit board	0.10
● 4-867-126-00	Holder, variable-resistor	0.05
4-867-127-00	Spring	0.05
4-867-128-00	Base, tonearm	2.52
4-867-129-00	Ring, scale	1.17
● 4-867-134-00	Bracket (A), circuit board	0.25
● 4-867-135-00	Bracket (B), circuit board	0.10
● 4-867-136-00	Shutter, fixed	0.49

- Items marked "●" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

US Model
Canadian Model
E Model

E

<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u>
		US\$
4-867-138-00	Lens (S)	0.05
4-867-139-00	Frame, tonearm	3.86
4-867-140-00	Base, tonearm	0.68
4-867-141-00	Weight, balance	2.13
4-867-142-00	Weight	0.34
4-867-143-00	Shaft, weight	0.59
4-867-144-00	Knob, balance	0.97
● 4-867-145-00	Yoke (A)	0.10
● 4-867-146-00	Yoke (B)	0.03
● 4-867-147-00	Yoke (C)	0.10
● 4-867-148-00	Yoke (D)	0.03
● 4-867-149-00	Yoke (E)	0.34
● 4-867-150-00	Yoke (F)	0.34
4-867-151-00	Lock Nut, pivot	0.39
4-867-152-00	Sleeve, reinforcement	0.25
4-867-155-00	Panel (B), function-switch	0.68
4-867-156-00	Plate, speed indicator	0.39
4-867-157-00	Lens, REPEAT lamp	0.10
4-867-158-00	Button, SPEED	0.34
4-867-159-00	Button, REPEAT	0.34
4-867-160-00	Spring	0.03
4-867-161-00	Panel (A), function	1.94
● 4-867-162-00	Base, panel	0.44
4-867-163-00	Plate, STYLUS FORCE dial	0.15
4-867-164-00	Plate, shield	0.15
4-867-165-00	Panel, side (R)	0.34
4-867-166-00	Panel, side (L)	0.34
4-867-167-00	Reflector	0.20
● 4-867-168-00	Holder, LED	0.10
4-867-169-00	Base, rest	2.33
4-867-170-00	Washer, rest pole	0.25
4-867-205-00	Bushing	0.10
4-867-206-00	Spacer (M)	0.03
4-867-207-00	Label, specification (AEP model)	0.10
4-867-208-00	Label, specification (US, Canadian model)	0.10

- Items marked "●" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

US Model
Canadian Model
E Model

<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u>
		E USS
4-867-209-00	Label, specification (UK model)	0.10
● 4-867-210-00	Bracket, power-cord (AEP, UK model)	0.39
4-867-211-00	Spring	0.05
● 4-867-214-00	Bracket, power-cord (E1, E2 model)	0.39
4-867-215-00	Label, specification (E1, E2 model)	0.10
4-867-302-00	Holder, spring	0.10
9-911-835-XX	Pad, knob	0.15
9-911-863-XX	Paper, shield	0.10

- Items marked "●" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

US Model
 Canadian Model
 E Model

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u> E US\$
<u>II. ELECTRICAL PARTS</u>			
<u>SEMICONDUCTORS</u>			
<u>Transistors</u>			
Q101	8-729-316-12	2SC1061	0.68
Q102, 103	8-729-663-47	2SC1364	0.15
Q104, 105	8-729-612-77	2SA1027R	0.20
Q106	8-729-317-12	2SA671	0.78
Q107	8-729-663-47	2SC1364	0.15
Q108	8-729-612-77	2SA1027R	0.20
Q109-114	8-729-663-47	2SC1364	0.15
Q115	8-729-612-77	2SA1027R	0.20
Q116	8-729-663-47	2SC1364	0.15
Q117	8-729-316-12	2SC1061	0.68
Q118	8-729-317-12	2SA671	0.78
Q119	8-729-316-12	2SC1061	0.68
Q120	8-729-317-12	2SA671	0.78
Q121	(8-729-141-43 8-760-413-10	2SD414 (AEP, UK, E model) 2SC1475 (US, Canadian model)	0.34 0.34
Q122	(8-729-154-83 8-729-468-43	2SB548 (AEP, UK, E model) 2SA684 (US, Canadian model)	0.39 0.39
Q123	8-729-663-47	2SC1364	0.15
Q124	(8-729-141-43 8-760-413-10	2SD414 (AEP, UK, E model) 2SC1475 (US, Canadian model)	0.34 0.34
Q125	(8-729-154-83 8-729-468-43	2SB548 (AEP, UK, E model) 2SA684 (US, Canadian model)	0.39 0.39
Q126	8-729-663-47	2SC1364	0.15
Q128	8-729-141-43	2SD414	0.34
Q129	8-729-154-83	2SB548	0.39
Q130	8-729-141-43	2SD414	0.34
Q131	8-729-154-83	2SB548	0.39
Q132	8-729-203-04	2SK30A	0.34
Q133-135	8-729-612-77	2SA1027R	0.20
Q301-303	8-729-101-02	PH102	0.49

US Model
Canadian Model
E Model

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u>
			US\$
Q501, 502	8-729-101-01	PH101	0.59
<u>ICs</u>			
IC101	8-759-178-05	μ PC78L05	0.49
IC102	8-759-982-09	MB8841-209L	11.30
IC103	8-759-904-69	MSM4069	0.44
IC104	8-759-145-57	μ PC4557C	0.68
IC106	8-751-930-00	CX193	5.28
IC107, 108	8-759-145-57	μ PC4557C	0.68
IC109	8-759-700-58	NJM4558DFA	0.68
IC110	8-759-145-57	μ PC4557C	0.68
IC111	8-759-240-50	TC4050BP	1.36
IC112	8-759-145-57	μ PC4557C	0.68
<u>Diodes</u>			
D101-104	Δ 8-719-200-02	10E2	0.15
D105, 106	8-719-910-75	HZ7B2L	0.15
D107-109	8-719-815-55	1S1555	0.10
D110	8-719-139-07	RD3.9E	0.15
D111-114	8-719-815-55	1S1555	0.10
D115	8-719-910-63	HZ6A3L	0.15
D116, 117	8-719-815-55	1S1555	0.10
D201-205	8-719-900-24	SLP24B	0.20
D401-403	8-719-812-31	TLR123	0.20
D601, 602	8-719-905-07	5GFMS-07F	0.78

CAPACITORS

All capacitors are in μ F. Common capacitors are omitted.

50 WV or less are not indicated except for electrolytics.

p: μ F

C101, 102	1-123-350-00	2200	35 V	elect	0.10
C133	1-102-491-00	51 p		ceramic	0.05
C137	1-161-319-00	470 p		ceramic	0.05
C201	1-130-098-00	0.022	125 V	film (Canadian model)	0.68
	1-130-230-11	0.01	300 V	metallized film	0.29
				(E1, E2 model)	

Δ : Critical components for safety. Replace only with part number specified.

US Model
Canadian Model
E Model

E

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u>
			US\$
C201	(1-130-233-00	0.033 125 V film (US model)	0.34
	1-161-744-11	0.01 400 V ceramic (AEP model)	0.29
C503	1-123-317-00	22 16 V elect	0.10

RESISTORS

All resistors are in ohms. Common ¼ W carbon resistors
are omitted. kΩ: 1000 Ω

R109, 110	1-226-434-00	100 k-B, adjustable; main motor offset	0.10
R114	△ 1-206-481-00	56 2 W metal-oxide	0.10
R238, 239 R262, 263)	△ 1-244-839-00	39 ½ W	0.03
R271	△ 1-217-395-00	47 fusible	0.20
RV101, 102	1-226-435-00	200 k-B, adjustable; slit A, B	0.10
RV103	1-226-434-00	100 k-B, adjustable; drop point	0.10
RV104	1-226-433-00	50 k-B, adjustable; stylus force	0.10
RV105	1-226-433-00	50 k-B, adjustable; speed (33 rpm)	0.10
RV106	1-226-434-00	100 k-B, adjustable; speed (45 rpm)	0.10
RV107, 108	1-226-430-00	5 k-B, adjustable; main motor gain	0.10
RV111	1-226-434-00	100 k-B, adjustable; horizontal motor offset	0.10
RV501	1-224-524-00	50 k-B, adjustable; drop-point	0.39
RV502	1-224-691-XX	10 k-B, variable; STYLUS FORCE (ANTI SKATING)	0.59

MISCELLANEOUS

L101, 102	1-407-157-XX	Coil, microinductor; 10 μH	0.10
L501	1-454-246-00	Solenoid, vertical drive	0.59
L502	1-454-247-00	Solenoid, vertical sensor	0.68
L503	1-454-245-00	Solenoid, horizontal drive (white)	0.68
L504	1-454-244-00	Solenoid, horizontal sensor (red)	0.68
L505	1-454-245-00	Solenoid, lifter drive	0.68
L506	1-454-244-00	Solenoid, lifter sensor (red)	0.68
L601, 602	A-4608-144-A	BSL Motor Ass'y	13.11
MGH	1-543-123-00	Head, turntable speed-detection	5.28
PL501, 502	1-518-305-00	Lamp, 8 V 50 mA	0.25

△: Critical components for safety. Replace only with part number specified.

US Model
Canadian Model
E Model

Ref. No.	Part No.	Description	E
			Unit Price US\$
S501	△1-552-018-00	Switch, pushbutton; POWER (US, Canadian model)	0.68
	△1-552-903-00	Switch, pushbutton; POWER (AEP, UK, E1, E2 model)	0.68
S502	1-553-195-00	Switch, miniature; lifter-up	0.78
S503	1-553-195-00	Switch, miniature; lifter-down	0.78
S504-511	1-553-235-00	Switch (START, STOP, REPEAT, SPEED, ARM TRANSPORT, MOTOR ON/OFF)	0.10
S512	1-553-195-00	Switch, miniature; muting	0.78
S601	1-552-535-00	Switch, voltage selector (E model)	0.49
T501	1-446-758-00	Transformer, power (US, Canadian model)	6.70
	1-446-759-00	Transformer, power (AEP, UK model)	6.70
	1-446-768-00	Transformer, power (E1, E2 model)	6.70
TH101	1-800-202-XX	Thermistor, S-10K	0.10
X101	1-527-380-21	Crystal	0.97
	1-452-199-00	Magnet	0.39
	1-452-200-00	Magnet	0.15
	1-452-201-00	Magnet	0.20
	△ 1-534-817-XX	Cord, power (AEP model)	1.13
	1-534-986-XX	Cord, power (US, Canadian model)	0.88
	● 1-535-115-00	Terminal with base, 2 p	0.03
	● 1-535-116-00	Terminal with base, 3 p	0.05
	● 1-535-122-00	Terminal with base, 9 p	0.10
	● 1-535-139-00	Post, base 19 mm	0.03
	△ 1-551-473-31	Cord, power (E2 model)	0.59
	△ 1-551-530-00	Cord, power (E1 model)	0.88
	1-551-546-00	Cord with plug	2.90
	△ 1-551-884-00	Cord, power (UK model)	1.36
	● 1-560-061-00	Pin, connector	0.05
	● 1-560-062-00	Pin, connector	0.10
	● 1-560-065-00	Pin, connector	0.15
	● 1-560-066-00	Pin, connector	0.15
	1-561-201-00	Connector, neck cylinder	2.71

● Items marked "●" are not stocked since they are seldom required for routine service.
Some delay should be anticipated when ordering these items.

△: Critical components for safety. Replace only with part number specified.

US Model
Canadian Model
E Model

<u>Ref. No.</u>	<u>Part No.</u>	<u>Unit Price</u>	E
		US\$	

PRINTED CIRCUIT BOARDS

♣	1-601-920-00	Control	0.39
♣	1-601-921-00	Up-switch	0.03
♣	1-601-922-00	Down Switch	0.03
♣	1-601-923-00	Muting Switch	0.03
♣	1-601-924-00	Phono	0.15
♣	1-601-925-00	Relay	0.03
♣	1-601-926-00	Relay	0.03
♣	1-601-927-00	Position-detection Light Sensor	0.25
♣	1-601-928-00	Automatic Record-size Detection Light	0.10
♣	1-601-929-00	Automatic Record-size Detection Light-Sensor	0.15
♣	1-601-930-00	Position-detecting LED	0.10
♣	1-601-931-00	Main	1.94
♣	1-601-933-00	Drop Point Control	0.10

III. ACCESSORIES & PACKING MATERIALS

A-4505-011-A	Cartridge Ass'y, XL-25A (E1, E2 model)	8.55
	including;	
A-4587-009-A	Stylus Ass'y, ND-25;	3.38
	including;	
X-2233-001-0	Cover Ass'y, stylus	0.39
X-4858-414-0	Headshell Ass'y	4.81
	including;	
1-551-559-11	Wire with terminal	
1-551-559-21	Wire with terminal	
1-551-559-31	Wire with terminal	0.15
1-551-559-41	Wire with terminal	
2-054-624-00	Screw (B), cartridge (E1, E2 model)	0.10
2-056-532-00	Screw (A), cartridge	0.10
	(US, Canadian, AEP, UK model)	
2-224-081-00	Screw, cartridge (E)	0.10
	(US, Canadian, AEP, UK model)	
2-227-313-00	Spacer	0.03
2-229-507-00	Washer, cartridge (US, Canadian, AEP, UK model) . . .	0.03

- Items marked "♣" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

US Model
 Canadian Model
 E Model

E

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Unit Price</u> US\$
	3-701-614-00	Bag, plastic	0.03
	3-701-616-00	Bag, plastic	0.03
	3-701-630-00	Bag, plastic	0.05
	3-701-634-00	Bag, plastic	0.10
	3-703-043-21	Label, main-caution (Canadian model)	0.10
	3-783-065-11	Manual, instruction (AEP, UK, E1, E2 model)	0.97
	3-783-065-21	Manual, instruction (US, Canadian model)	0.88
	3-793-815-11	Sheet, instruction (UK model)	0.10
	3-794-265-00	Note, record-player (E model)	0.10
	3-794-749-11	Card, caution (AEP, UK, E1, E2 model)	0.20
	3-794-749-21	Card, caution (US, Canadian model)	0.20
	3-794-750-11	Card, caution; rubber mat (AEP, UK, E1, E2 model)	0.12
	3-794-750-21	Card, caution; rubber mat (US, Canadian model)	0.15
	3-794-833-31	Manual, instruction (Canadian model)	3.38
	4-808-461-00	Adaptor, 45 rpm	0.78
	4-815-655-01	Nut (A), cartridge	0.05
	4-858-407-00	Adjustor, drop-point	0.10
	4-858-588-00	Bag, protector	0.05
	4-858-589-00	Plate, protector	0.05
	4-867-104-00	Sub Weight (A)	0.97
	4-867-105-00	Turntable	14.89
	4-867-137-11	Mat, turntable	8.55
	4-867-194-00	Cushion, right	0.78
	4-867-195-00	Cushion, left	0.78
	4-867-196-00	Box, accessories	0.59
	4-867-197-00	Case, accessories	0.20
	4-867-199-00	Holder, tonearm	0.15
	4-867-212-00	Carton	2.33

- Items marked "●" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

US Model
Canadian Model
E Model

11/11 (PS-X75)