

# contigo®



## AUTOSEAL® Travel Mug Care and Use Instructions



## Care and use instructions

- Careful: The beverage you are about to enjoy is very hot. For best result always use caution.
- Keep out of reach of children when filled with hot liquids.
- To properly use your AUTOSEAL® mug:



Always press button with mug in upright position away from face to release pressure before drinking



With button pressed, tilt mug to drink



Release button to seal

- Prior to drinking, check to ensure the lid is properly threaded to the body and screwed down 100%. The button should be depressed to release pressure, each time the lid is screwed on
- If filling with boiling liquids, allow liquid to cool down for at least 3 minutes before sealing with the lid.
- Avoid accidental depressing of button by keeping button free and clear of other objects.
- Do not overfill. Fill liquids to just below the threading in the body.
- Do not microwave and do not freeze.

Copyright © 2015 **contigo**, All rights reserved.

Kambukka bvba | Torenplein 7.16.1 | 3500 Hasselt | Belgium

- Do not use cleaners containing bleach, chlorine, abrasive and/or other harsh chemicals.

## USAGE RECOMMENDATIONS



- Suitable for cold and hot beverages.
- The AUTOSEAL® lid that came with your new purchase is designed to only fit your new Contigo® tumbler. It is not meant to be used on any other product.
- To screw the lid on easily and safely place lid on top of mug. Apply slight downward pressure and rotate counter clockwise until you hear a click and a lid falls into place. Proceed to rotate lid clockwise to tighten down.
- In the locked position, the AUTOSEAL button cannot be depressed. This lock feature is designed to avoid unintended depressing of the push-button when the mug is being transported full of liquid. Press down on the lock icon on the top of the lid exposing the red indicator strip. To unlock the button, press the side of the lock with no icon. Use this mug's lock feature to avoid unintended depressing of the Autoseal button.


## CLEANING INSTRUCTIONS



Closed



Opened



- Lids are Top rack dishwasher safe. Flip open the lid interior before cleaning and return lid interior to its closed position before use.
- Wash all parts with soapy water before use. Rinse thoroughly and dry. Always store with lid removed.
- If you have purchased a mug that has a brushed stainless steel body (not coloured or painted body), the body is dishwasher safe.
- If you have purchased a mug that has a coloured or painted body, it is recommended that the body be hand washed.