Pro Sport

<u>Congratulations!</u> We hope you will have many hours to use your new soccer table and enjoy the pleasure it brings to you!



PLEASE KEEP YOUR INSTRUCTIONS!

- Your Model number is needed when you contact us.
- Please read through this instruction book to familiarize yourself with all the parts and assembly steps.
- Please find the attached tables for all the parts' name, specification and quantity.



WARNING!

- Please keep the balls, lubricant and other parts out of children's reach.
- · Don't spray the lubricant to any person or animal.
- This is not a child's toy. Adult supervision is required for children playing this game.
- please take care to avoid injuring any thing or person when you push and pull the player rods.
- Please read instructions carefully. Proper use of this set can avoid damage or injury.



TOOLS REQUIRED FOR ASSEMBLY:


- Phillips and Slotted Head Screwdrivers , Power Driver or Hammar(not included)
- Roll Pin Punch(#21), Allen Key(#14) (included)

PARTS LIST

配件表

(Add a Check ($\sqrt{\ }$) to the box \square to indicate receipt of each part.)

(在□ 内打(√) 确认收到该配件)



NOTE: There are 6 sets of Bearings (#8 & #9) have already been attached on the Table Body(#1).

提示: 轴承(#8 & #9) 有6套安装好于台身(#1)上。

ADDITIONAL PRE-INSTALLED PARTS.

辅助配件及备品

_		一	
19	WRENCH	20 SOCCER BALLS 21	LUBRICANT
	内六角扳手	小球	润滑油
<i>U</i>	6mm	Ø35mm	20m1
	1 PC	15 PCS	1 PC
(22)	ROLL PIN	ROLL PIN (24)	PLAYER
	销 子	销子	球 员
	4.2*35mm	4. 2*28mm	108*35mm
	6 PCS	2 PCS	2 PCS
25)	BOLTS	ROLL PIN PUNCH 27	KEY
	螺栓	销钉工具 101	钥 匙
	10*65mm 2 PCS	4*80mm 1 PC	3 PCS
28		29 COIN 30	MATERIAL
	GAME COIN	COLLECTED BOX (30)	SAMPLE
+ (S)	游戏币	硬币整理盒	材料样品
Ψ//	Ø25*1.8mm 50 PCS	145*145*31mm 1 PC	1 PC
21		23	
31)	LOCK	(32) WRENCH (33)	TELESCOPIC ROD
	伸缩锁	内六角扳手	伸缩杆
	Ø20*38mm 1 SET	1 PC	1 PC

ASSEMBLY INSTRUCTIONS:

We recommend that two adults work together to assemble this table.

- The table must be turned over before assembling its Legs, then turn it over again to assemble player rods.
- we suggest that you use the packing EPE as a clean flat work area to protect the table.

安 装 说 明

我们建议由两个以上强壮的成年人一起安装这个球台。

- · 这个球台先要倒过来安装脚,后翻转过来装球杆。
- 我们建议您把包装材料平铺在地上作为工作区域以保护球台。





FIG.1-3: SHOW THE WAYS TO TAKE OUT THE ACCESSORIES


FIG.1: Take out the table's legs and put them to a safe place, then
take out and open the accessories box, finding the key (#24) (please
put the accessories box to a safe place).

图1-3:配件的取出方法

•如图1所示: 先取出球台的脚并放在安全的地方,取出配件箱并打开,找到钥匙(#24)(请将配件箱放到安全的地方)。



- FIG.2: use the key (#24) to open the table's two locks.
- FIG.3: open the upper body of the table and take out the player rods (NOTE: the table should be standing stably)
- Two adults at least to turn over the table and assemble the legs (NOTE: keep the locks on when turning over the table)
- •如图2所示:用钥匙(#24)把台子的两把锁打开。
- •如图3所示:打开球台的上台身,取出球杆(**注意**:球台一定是支撑稳固的)。
- •由两个以上的成年人把球台翻转过来准备安装脚(**注意**:翻转之前两侧锁一定要是锁上的)。



CAUTION: Two strong adults are recommended

- to turn the table over as shown.

 1. Lift the table off the ground.
- Turn the table over.
- 3. Place it on all four feet at the same time on the ground.



注意:建议由两个以上强壮的成年人如图来翻转球台

- 1. 抬起球台离开地面。
- 2. 翻转球台。
- 3. 放下球台时四个脚要同时着地。

FIG. 4: LEG ASSEMBLY

 Attach the Legs (#2 & #3) between the Side and End Aprons with four Bolts (#11) per Leg as shown in Fig.4.
 Use the Allen Key (#14) provided.

NOTE: Please twist the four Bolts(#11) into one leg at the same schedule when you assemble the Legs . (Don't twist the Bolts very tightly at once .)

- Insert the Leg Levelers (#12) into the bottom of the Legs (#2 & #3).
 See Fig.1.
- Lift the table assembled from the floor by two strong adults, turn it over, and set table on its legs in the location where you will play.


图. 4: 脚的安装说明

 如图4所示:用螺栓(#11)将脚(#2)安装在台身(#1)的长/短边板上。 (使用工具(#14))

注意: 在安装脚时,请保持同一进度拧一只脚的4颗螺栓 (#11),不要将其中某一螺栓一次性拧到位。

- 如图1所示:将脚盘(#12)安装在脚(#2)的底部。
- 由两个以上强壮的成年人将安装好的球台从地面抬起、翻转并把球台放在比赛的地方。





PIG.5: the assembly of the coinselect

 PIG.5: open the upper body of the table first and fix the coinselect with screw (the screw came together with the coinselect already)insert the supporting strip (#15) in the table like it showed on the picture

(**NOTE**: the table should be standing stably)

图5:投币器的安装

·如图5所示: 先打开球台的上台身。用螺丝(已装在投币) 把投币器锁紧)。 将支撑条(#15)从上往下卡在台子上。(**注意**: 球台一定是支撑稳固的)。




FIG.6: the adjustment of the coinselect (NOTE: under the coinselect meets the difficult of ball control)

• FIG.6: adjust the coinselect part of #a .

FIG.7:how to use the coinselect

FIG.7: using the key to open the coin collected box (please take care
that the key size is different with the table's outside key size) .Take
out the coin collected box according the direction which showed on
the picture.






图6:投币器的调节 (注意: 若遇到投币器控球有困难时)

·如图6所示:调节投币器上(#a)号配件。

图7. 集币盒的使用方法

如图7所示: 先用钥匙把集币盒打开(钥匙规格与球台外则的不同请注意管理)。按图中方向取出集币盒。




FIG. 7: PLAYER / BEARING / SCORER ASSEMBLY

- Carefully slide the grip end of Player Rod (#6) through the inside of Side Apron to outside (untill the Player touch the Side Apron), then slide another end of the Player Rod (#6) through the directly opposite hole in the opposite Side Apron .
- Slide the Player Rods(#4-#7) through the Side Apron in the order shown. See Fig. 7.
- Attach all the Bearings in the accessory kits to the Side Aprons as shown Bearing (#8) in Fig.7.
- Attach the Scorer Assemblies(#13) in the middle of each Top Slat Board using two Screws(#10) per Scorer.See Fig.7.
- Spray the Lubricant (#16) in a clean, soft cloth first, then use this cloth to wipe the Player Rods. See Fig.8.

图.7: 球杆、轴承、计分器的安装

- 如图中(#6)杆所示:先用装有手把的一端从球场内侧往外穿(直到小人的脚碰到边板)然后将球杆的另一端穿过轴承孔。
- 将球杆(#4-#7)按图顺序依次穿好。
- 如图中轴承(#8)所示:将配件包中的所有轴承安装好。
- 如图7中所示: 用螺钉(#10)把计分器 (#13)分别安装在面板的中间位置。
- 如图 8中所示: 先将润滑油(#16)喷洒在一块干净的布中,再用这块布擦 拭球杆的表面。

TABLE MAINTENANCE (球台的维护)			
TABLE SURFACE	Keep your table covered . If there is dust on the playfield or the aprons , use a vacuum or wipe with a clean , soft cloth to remove . Do not sit on the table and do not use the table outside .		
(球桌表面)	在不用的时候,请遮盖好球台。如果球台表面有灰,用吸尘器或是一块干净的软布清除灰尘。请不要坐到球台上,不要在室外使用球台。		
RODS	Occasionally wipe the rods with a clean , soft cloth . Never lift the table by the rods . Do not spin or press the rods too agggressively , as this may cause damage . We recommend the use of lubricant to wipe the Player Rods and Bearings from the outside of the game so as not to drip onto the playfield .		
(球杆)	请定时用干净的软布擦拭球杆,抬球台时不要提球杆。 不要过激地旋转或压球杆,因为这样可能损坏球台。 我们建议用润滑油擦拭球杆和轴承内孔(请在球台外侧擦拭,以免润滑油滴在球场上)。		
LEGS (脚)	Check that the leg bolts are tight. When moving the table, lift table off of its legs and place it down squarely on the legs, do not drag the table . (<i>NOTE</i> :pls confirm other screws of the table locked tightly enough.)		
	请确保脚上的螺栓是紧的。移动球台时请抬起球台,不要拖动球台。(注意:请确保球台其他地方的螺栓都紧的。)		

English 中文




FIG. 9: PLAYER MAINTENANCE

• PIG.9: more quick and accurate to calculate out your wealth

FIG. 10: PLAYER MAINTENANCE

 Take down the Player Rod ,knock the Roll Pin (#19) out , then attach the spare Players and Roll Pin to this Player Rod . See Fig.10.
 Use the Roll Pin Punch (#23) provided .

GAME RULES:

- To start play, flip a coin to see which team or player will serve first.
 To begin, serve the ball through the side entry cup.
- 2) Pass and score by pushing and pulling rods and twisting grips. Spinning the rods is considered illegal in tournament play. If playing as teams (more than two players total), once the ball is served, players may not change position on the rods until: one team scores; a team requests a timeout (maximum 2 per game); the ball must be served again; or between games.
- A point is scored when the ball enters the goal. A serve, by the team last scored upon, follows each goal. Teams change table sides after each game.
- 4) Intentional jarring or tipping of table during play is illegal, and reaching into the playing area during play is illegal (except for a dead ball).
- 5) A ball is considered a DEAD BALL when it has completely stopped its motion or is unreachable by any player. If a ball stops between the goal and the two-man rod, then it is put back into play by placing it in the corner that is nearest the dead ball spot. If the ball completely stops anywhere else on the playfield between both two-man rods, it is put back into play with a serve by the team that originally served the ball
- 6) If a ball leaves the playing area during play (other than through the goals), the ball is considered OUT OF PLAY. The ball is returned to play with a serve by the team which originally served the ball.
- 7) This game is meant to be played with either two of four players. We recommend that all others should stand clear of the Table Playing Area if they are not playing.

NOTE: The Game Rules have a little difference according to different Tournaments .




图.9: 财富统计

• 如图9所示: 更快捷准确的为你计算出你的财富。

图. 10: 球员维修

• 取下球杆,如图4所示用销钉工具 (#23) 把销子 (#19) 顶出后。将备用的球员或是销子换上。

比赛规则:

- 先掷硬币决定优先权。询问对方是否准备好,并获得对方认可,然后从发球口 发球。开始对阵。
- 2. 通过球杆的推拉和转动来带球、传球和射门得分。在比赛中转杆360度以上是 违反规则的。 如果是双人组队比赛、球发出后队员不可以交换位置;只有在进球得分或是中

场休息 (每场最多2分钟) 或是在两场比赛之间才可交换位置。

- 3.球进入球门一次得一分,每局的首发球权属于上局负方。在每局比赛结束后 双方交换比赛场地。
- 4. 在比赛中有冲突或是有意摇晃球台都是违反规则的。在比赛中用手到球场中碰球也是违反规则的。(除非死球)
- 5. 球静止在双方都无法碰到的区域被称为"死球"。如果在后场死球由后场所属 方用其2人杆后卫重新发球。如果其他位置死球由原发球方重新发球。
- 6. 如球被一方打出球台,由对方用其2人杆后卫重新发球。
- 7. 这个比赛可由两个或是四个选手对阵。我们建议其他人员不要离比赛区域太近, 以免影响比赛。

注意: 比赛规则根据不同赛事略有不同。