

**Multifunction Clock DVR
User Manual**


Profile

This manual introduce how to operate this product and the details information about this product. Before you start to operate it, please be sure that you read this manual and understand it completely and correctly. Wish it can bring to reasonable and favotable.

Warranty

This product is with CE, FCC and RohS.

1、 Structure



2、 Introduction

- ◇ Date and Time Display
- ◇ Alarm Function and Snooze Function, the interval (1-60minutes)
- ◇ Voice Broadcast the present time.
- ◇ Temperature Display
- ◇ Natural Sound Broadcast (Interval 10-60minutes)

3、 Time:

- ◇ In the status of time display, press and click the button, SET to reset Year. There is “2010” flashing on LCD, press the button, UP or DOWN to

choose the Year.

- ◇ Press the button, SET to reset Month-Day-Hour-Minute one by one



Time Mode

Year Reset

Month Reset



Date Reset

Hour Reset

Minute Reset

- ◇ When the resetting finishes, press and release the button, "MODE" to get out.

4、Alarm Reset

- ◇ In the status of Time, press and release the button, MODE to Alarm Reset Mode
- ◇ Press and release the button, SET one time to reset the Hour

Press and release the button, SET two times to reset the minute

Press and release the button, SET three times to

Reset the Snooze Mode (Time Interval, 1-60minutes)


Press and release the button, SET four times to reset Alarm Ring, press the button, UP or the button, DOWN to choose.



Alarm Mode Hour Reset Minute Reset



Snooze Mode Time Interval Alarm Ring

- ◇ Press and release the button, “MODE” to get out, the present time display on LCD.
- ◇ In the status of Alarm, press and release the button, UP to turn on or turn off Alarm. When the Snooze Function on, the “” will flash.



Alarm Off

Alarm On

Snooze On

- ◇ Press and release the button, “MODE” to get back to the time reset mode.

- ◇ In the time mode, press the button, "UP" to choose the time mode(12 or 24), press the button, DOWN to choose °C or °F



12Mode



24Mode



Celsius



Fahrenheit

5、Timekeeping, Natural Sound

- ◇ In the time mode, press and release the button, TALK to talk the present time.
- ◇ In any mode status, press and release the button, TIME to reset the Natural Sound(10-60minutes)



Natural Sound Time Reset

- ◇ In any mode, press the button, TALK for three seconds to Natural Sound Listening Mode, the interval time will countdown.

59:59

00:00

Natural Sound Mode Natural Sound Stop

- ◇ In the mode of Natural Sound Mode, press and release the button, TALK to pause, press and release again to choose the next Natural Sound. Press and release the button, MODE to get out.

Notice: On the Display, there are two signs, one is PM and the other is “📢”. Please pay attention to the following picture:




DV Function Introduction


This product is a multifunctional clock provides the DV functions including video, audio, motion detection, webcam, movable disc. It supports TF Card and remote control function. The max, memory can be upto 32GB, the high capacity battery provide the enough power for long time recording. Just because of this many functions and features, it can be used as home security monitor.

1、Operation

(1) Turn On






Open the right side lid of camera, insert the TF card, push the button to ON.

(2) Press the button,  on remote control until the blue indicator is burning. It enters into the Standby Status.

(3) Press the button,  to enter into the Video Status.

The Blue Indicator is off after it flashes three times.

Press the button,  again to stop video. The Blue Indicator is burning.

- (4) Press the button,  to record audio, the blue indicator will be off after it flashes three times. Press the button again to stop the recording. The blue indicator is burning.
- (5) Press the button,  to shoot a image, the blue indicator will flash one time.
- (6) Press the button, to start this function, press and release the button again to stop it. The blue indicator will be burning.
- (7) Press the button,  to turn off the camera, the blue indicator will be off.
- (8) Push the button to ON, connect the camera and PC, then, press and release the button,  on remote control.
- (9) Webcam
Install the software in CD
Push the button to ON
Press the button,  to turn on the camera
Connect Camera and PC with original cable

(10) Charge

Push the button to off

Connect the camera and power source

The red indicator is burning

During charging, the red indicator is burning

When it is full, the red indicator is off

Notice, PC also can provide the power to it.

(11) Reset


Because of the wrong operation or any other unknown reasons, there is no any feedback from the camera, please push the button to OFF and push it to ON again.

(12) Low Power

When it is low power, the blue indicator will flash quickly.

(13) UPDate

- ◇ When the programe lost, please install the drive proramme in CD
- ◇ Click the STK02NU
- ◇ Press update
- ◇ Choose 0x35 behind of ①DRAM Timing
- ◇ Choose 8M behind of ②DRAM Size
- ◇ Press and release the button, OK

- (14) File Storage and replay
 Pus the button to ON
 Connect the camera and PC with USB Cable
 Press and release the button, 
 The blue indicator is burning
 Copy the file to PC
 Replay the file in software, Media player/KM
 player

2、Specifications

Pixels	5. 0 Mega CMOS
Video Resolution	1280*960
Video Form	AVI
FPS	30fps
View Angle	140°
Motion Detection Distance	Direct 6 meters
Low Illumination	1LUX
Battery Capacity	4800MA
Recording Time	More than 24 hours
Remote Control Distance	18m
Recording Audio Area	40m ²
Power Consumption	150MA/3. 7V
Store Tempreture	-20-80℃

Operation Temperature	-10-60°C
Operation Humidity	15-85%RH
Memory	TF Card
Max.	32GB
Software	Media player/KMplayer
Data Transfer Interface	USB1.1/2.0
Operation System	2000/XP/Visat32
Memory Consumption	1GB/40min
Charge Time	About 8 hours

Notice

Place of using:It can not be used in the illegal place,before use it,please pay attention to the law.

Software Update:The factory will improve the software in order to improve the service and using feels of this products.Please try to contact your seller to get the newest software.

Working Temperature:Please use it in the suitable temperature which the man can bear.

Working Humidity:Please do not use it in humidity place.

LUX:Please use it in the place with enough light,please

do not make the lens straight to strong light source.
Clearance:Please do not use it in the dirty place,please clear it with soft cloth and clear it smoothly.Please do not use it in strong magnetic field or strong electric field.