


SAFETY AND OPERATING INSTRUCTIONS

10.02 ARCWATER II TORCH



СваркаРУ.рф

Item No.	Part No.	Description
1	94-370-174	Torch Handle
2	94-168-018	Collet Ring
3	96-130-234	Cable Assembly
4	94-433-177	Tip Insulator
5	94-921-063	Valve & Lever Assembly
6	97-373-001	Set Screw (2 per)

Item No.	Part No.	Description
7	94-158-049	Collet Chuck Assembly
8	94-695-037	Blowback Retainer
9	94-105-021	Boot
10	94-940-097	Washer
11	94-940-105	Washer
12	94-940-098	Washer