


## Инструкция пользователя

Apollo B6 - Bluetooth колонка СТЕРЕО, радио FM, с аккумулятором, для использования в помещении

Артикул: Apollo B6

**FOR PUBLIC  
RELEASE**



**FOR PUBLIC  
RELEASE**

## Foreword

Thank you for purchasing and using our products. In order to let you operate this machine as quickly as possible, please read this booklet carefully before you start using it.

This machine is a stylish and portable wireless speaker. This machine supports wireless protocol. It supports smart phones, tablets, and notebooks. It is a device that waits for wireless audio functions. It allows you to completely get rid of wireless shackles and enjoy music without any restrictions. It also supports TF card, U disk and Bluetooth-free mobile phone, laptop, mp3, mp4 and other audio input playback.

## Precautions

- Do not hit the main unit seriously.
- Do not touch benzene, thinner lamp chemicals.
- Please do not use near strong magnetic fields and electric fields.
- Please avoid direct light spot heating appliances.
- Do not disassemble, repair or modify it yourself.
- When riding a bicycle or driving a car or a motorcycle, do not use the player to avoid danger.
- Do not listen for a long time at a large volume to avoid adverse effects on your hearing.
- Do not clean the unit with water. Use a slightly damp cloth to cut the surface of the unit.
- When using low voltage, the sound may be distorted and please charge it in time. Please disconnect the power when not in use for a long time.
- Bluetooth is compatible with popular smartphones, tablets, etc., but some features may not be supported depending on the device or application you are using.

## 一. BT MODE

1. Turn the knob clockwise 45° to turn it on. After the power is turned on, the sound will sound. The blue light of the wireless indicator flashes quickly, enters the BT mode, and the speaker emits a BT mode tone.
2. The blue light flashes into the pairing state. At this time, the BT device is searched for device name confirmation to connect. If the password is required, input (0000). After the connection is successful, the blue light is always on, the speaker emits a prompt tone, music. The blue light flashes slowly during playback. The paired BT device first turns on BT, and then turns on the speaker to automatically connect back.
3. Support BT hands-free calling function. When Bluetooth calls, the

speaker will announce the number by voice and can answer/hang up the call.

Press ►IM key answers/hangs up the phone, long press to reject, double click to redial the previous call.

## 二. TF card U disk mode

1. In the BT mode, insert the TF card or U disk to automatically enter the TF card or U disk to play.
2. During the playback, the indicator light flashes slowly, and the blue light is paused.

## 三. Audio input mode

In the power-on state, the Line in line is inserted, and the other end is inserted into the output of other audio devices, and automatically enters the Line in audio input mode.

## 四. FM mode

1. Press and hold the mode to switch to the FM radio mode.
2. After entering the FM radio mode, press "►IM" to enter the search status. At this time, the blue indicator flashes quickly.
3. After the search is completed, short press the "◀/▶" button to switch the radio, and rotate the button clockwise from small to large.


## 五. Charging

1. Plug the USB cable into the speaker to connect to the 5V charger or computer to charge the speaker's internal battery.
2. When charging, the "Charging" indicator lights up red, and when it is full, the red light is off.


六. The power-on volume of all the modes in this mode defaults to 60% of the total volume. When the battery voltage is lower than 3.2V, the speaker will automatically detect and emit a low-power alarm sound. When the battery voltage is lower than 3.0V, the speaker will sound and automatically shut down.

**FOR PUBLIC  
RELEASE**

**FOR PUBLIC RELEASE**




Front



Back

**5. Button function list**

NO.	Button name	MODE			
		BT	TF/U-disk	Line in	FM
1	▶IM	HOLD:mode switch Press:play/pause Calling: Press:answer/hang up Hold:refuse double-click:redial the tail number	HOLD: mode switch Press: play/pause	HOLD: mode switch Press: play/pause	HOLD: mode switch Press: Automatic search.
2	◀	Press>last	Press>last		Press>last FM
3	▶	Press>next	Press>next		Press>next FM



**Note:**  
Turn the rotary button clockwise to turn it on “-” / “+” to adjust the volume.

**8. Technical specifications**

1. BT version: version 4.2
2. Output: BT TF U disk AUX output
3. Charging source interface: MIRCO interface
4. Rated power: 3Ω, 5W
5. Speaker power: 5W X 2
6. Frequency response: 150Hz - 20KHz
7. Noise ratio: 80dB
8. BT transmission distance: 10 meters or more (accessible)
9. Power input: DC 5V, 1800 MA



Part name	Toxic or hazardous substance or element					
	Lead (pb)	mercury (Hg)	cadmium (Cd)	hexavalent chromium (Cr(VI))	Polybrominated biphenyl (PBB)	Polybrominated diphenyl ether (PBDE)
Circuit Board	x	o	o	o	o	o
Battery	x	o	o	o	o	o
Plastic	o	o	o	o	o	o

o: Indicates that the content of this toxic and hazardous substance in all homogeneous materials of this part is below the limit requirement specified in SJ/T 11363-2006.

x: Indicates that the content of the toxic and harmful substance in at least one of the homogeneous materials of the part exceeds the Lenovo requirement specified in SJ/T 11363-2006; the part marked with “x” in the above table cannot be replaced due to technical reasons, and the subsequent step will gradually Covered.

**FOR PUBLIC RELEASE**

I thank you for using!

Спасибо за совершённую покупку в нашем магазин

**Наслаждайтесь пользованием.**