## **CPF905 Quick Installation Guide**



Hi, thank you for purchasing CPF905. The following is the operation instructions of CPF905, it can help you solve the setting problem.


CPF905 Router with powerful signal with antenna , Internet access to Internet via HSPA/LTE Data SIM Card. or Internet access/PPPoE work mode , if you don have 4G sim card , you can use connect to modem work as Gateway mode.




When you receive the product, please unpack the product. Mount the product's antenna on the product.



Please insert the SIM card first, and then connect the product to the power supply.




The next step is to connect the SSID, please follow the instructions in the picture. The password for the SSID is 1234567890.



After you connect to the SSID, your devices can connect to the network if there is no accident. If your device cannot connect to the network normally, please check if your SIM card's frequency band is compatible with the product. If it is compatible, we suggest that you disable the SIM card's PIN code or modify the SIM card's APN.


## About the setting method of PIN:



You need to click on "APN" in "network settings" and then click on "add new".

	45 🛜 46 CPE	LTE CU 📶 🌐 🏌 🗢		
	Home	APN		
	Information Download Driver SMS Phonebook	Current APN Profile Profile Name *		
	Settings	APN *	a suite state of the second seco	
	Network Settings     Dial-up Settings	mnc *		
_	Network Selection     APN	Authentication User Name	NONE	
	Ethernet Wi-Fi Settings	Password		
	Device Settings	?		
	Copyright @ 2016-2018			

Please fill in "Profile Name", "APN", "mcc" and "mnc" and click "Apply".



If signal is unstable, you can also manage the settings page, lock 4G or 3G network, can effectively improve the stability of the network.

45 🛜 4G CPE	LTE CU11  111 - Logout
Home Information Download Driver SMS Phonebook Settings • Dial-up Settings • Access Settings • Access Settings • Merent Wi-Fi Settings Device Settings Undate	Network Selection Network Selection Automatic USB 20 USB 2
11gm © 2016-2018	FOR PUBLIC RELEASE

You can change the username and password of the SSID at will:

	4/5 🤶 4G CPE		LTE CU .11 @11 👁	
			English • Logout	
	Home	Assount Management		
	Information	Account Management		
	Download Driver	Current Username * admin		
	SMS	New Username *		
	Phonebook	Confirm Username *		
	Settings		Apply Cancel	
	Network Settings Ethernet	Current Password *		
	Wi-Fi Settings	New Password *		
	Device Settings	Confirm New Password *		
	Account Management     PIN Management		Apply Cancel	
	> Reset	?		
	▶ Restart	Ψ.		
	Update			
	Copyright ©			
		FOR PUB		
		RELEAS		
_				
		_		
	o2o\//	IFICAM.RU		
	<b>FLFVV</b>			
		SEC.RU		
-				
		BV_BII		
This is the setting o	potion for the ne	etwork cable:	_	
	ption for the ite			
-	4G CPE			
-	<b>4</b> 도 중 4G CPE		LTE CU att   #14 V	
-	<b>4</b> 중 4G CPE		LTE CU "III @ti v English • Logout	
-	<b>4</b> ⊊ ॡ 4G CPE Home	Ethernet Settings		
-		Ethernet Settings		
-	Home	Ethernet Settings		
-	Home Information	Connection type : Auto		
-	Home Information Download Driver	Connection type : Auto	English • Logout	
-	Home Information Download Driver SMS	Connection type : Auto Auto PPPOE Dynamic IP	English • Logout	
-	Home Information Download Driver SMS Phonebook Settings Network Settings	Connection type : Auto Auto PPPOE Dynamic IP	English • Logout	
-	Home Information Download Driver SMS Phonebook Settings	Connection type : Auto Auto PPPOE Dynamic IP LNN	English • Logout	
-	Home Information Download Driver SMS Phonebook Settings Network Settings	Connection type : Auto Auto PPPOE Dynamic IP LNN	English • Logout	
-	Home Information Download Driver SMS Phonebook Settings Network Settings Ethernet + Ethernet Settings	Connection type : Auto Auto PPPOE Dynamic IP LAN	English • Logout	ר ו
-	Home Information Download Driver SMS Phonebook Settings Network Settings Ethernet + Ethernet Status	Connection type : Auto Auto PPPOE Dynamic IP LAN	English • Logout	1
-	Home Information Download Driver SMS Phonebook Settings Network Settings Ethernet > Ethernet Settings > Ethernet Settings	Connection type : Auto Auto PPPOE Dynamic IP LAN	English • Logout	
-	Home Information Download Driver SMS Phonebook Settings Network Settings Ethernet Ethernet Satus Wi-Fi Settings Device Settings	Connection type : Auto Auto PPPOE Dynamic IP LAN	English • Logout	]
	Home Information Download Driver SMS Phonebook Settings Network Settings Ethernet Ethernet Satus Wi-Fi Settings Device Settings	Connection type : Auto Auto PPPOE Dynamic IP LAN	English • Logout	]

If you follow our instructions to set up and the product still does not work properly, please feel free to contact us. We will provide you with a solution.

Thank you.



## P2pWiFicnm.ru ((WiFisec.ru))) Divary.ru