

## OVERVIEW



# SPECIFICATIONS

Motor .	External Rotor Brushless Motor	Material	Aircraft aluminum
Stroke Length	3.5 mm	Operating Voltage	5.0 - 12 V DC
Rpm	9000rpm ± 10%	Switch Frequency	60 - 150 Hz
Needle Protrusion	0 - 4,5 mm	Dimensions(Ø X L)	33 x 135 mm
Weight	6.96 oz (197g) with power pack	Power pack Working Time	Approx. Up to 450 Minutes
Battery Capacity	1600 mAh	Recharging Time	3.5 Hours

THANK YOU FOR YOUR PURCHASE!

WWW.EZTATTOOSUPPLY.COM



#### BASIC OPERATION

#### Power ON/ OFF

Press and Hold the | button for two seconds to turn EvoTech on. Press and Hold the E button for two seconds to power EvoTech off.

#### Power Start/ Stop

Clik button to turn your machine Stop/ Go.

**Adjusting Voltage** 

Press or to adjust in 0.1V increments. Press and Long Hold or to quickly adjust the voltage in 0.1V increments.

#### **Changing Voltage Presets**

DblClick button EvoTech will toggle between the voltage presets.

1. Screen display "Lnr" preset LINER voltage.

2. Screen display "Shd" preset SHADER voltage.

Note: The EvoTech will adjust the voltage to the saved voltage setting you stop on. the machine startup voltage is the preset for the last shutdown.

#### Push Mode

Press and button at the same time, Screen LOGO solid, the machine

ACTIVE the strong start mode.

Press and button at the same time. Screen LOGO at flashes, the machine push mode OFF. Note: In push mode the initial voltage output is 12V lasts for 1 second and then returns to normal voltage after.

#### Memory Function The EvoTech will adjust the voltage to the saved voltage setting you stop on The startu

preset voltage for the last shutdown.

### Start/Stop Timer

Press button to active your machine ON, the timing mode start. Note: timer mode record in minutes the maximum recording time is 999 minutes. The timer will reset the count when the EvoTech Power pack is being restarted.

#### INCLUEDS:

User Guide, EvoTech X1, Extra Grip X1, Ping plug RCA connector, RCA female connector, Battery Type-C charging cable.

NOTICE to reduce the risk of injury, the user must read and understand the User manual before using this product. Save these instructions for future reference.

We recommended that use the included charging cable.

-This device don't support fast charging/super fast charging.

fast charging may get damage the battery.

WWW FZTATTOOSUPPLY COM



#### BATTERY PROTECTION

The battery circuitry protects the battery pack from extreme temperature, overdischarge, and over-charge. To protect the battery from diamage and prolong its life, the battery packcircuitry will turn off the battery pack if it becomes overloaded or if the temperature becomes too high during use. This may happen in extremely high torque, binding, and stalling situations. The battery pack will shut down for 10s when its operating temperature exceeds 158°F (70°C), and will begin normal operation when it returns to 152°F (6°C).

**NOTICE:** A significantly reduced run time after fully charging the battery pack indicates that the batteries are near the end of their usable life and must be replaced.

**NOTICE:** Lithium-Ion battery packs are shipped partially charged. Before using it the first time, fully charge the battery pack.

#### WARRANTY INFORMATION

If you find that the product is malfunctioning during the warranty period, EZ provides a one-year warranty for the Evo Tech Wireless Pen Machine purchased in our online store or authorized distributors worldwide from the date of purchase. Please contact our After-Sales Team Email: sales@eratatooing.com.

Damage to the product due to a human factor

Product damage due to external electrical failure or any accider

# WARRANTY CARD

# DATE OF PURCHASE : WHERE PURCHASED : ADDRESS : EMAIL :

MY SIGNATURE BELOW ACKNOWLEDGES THAT I HAVE READ, FULLY UNDERSTAND, AND ACCEPT THIS LIMITED WARRANTY AGREEMENT.

SIGNATURE : \_\_\_\_\_DATE : \_

SENT THIS COPY TO: EZTATTOO - AFTER-SALES DEPARTMENT 4/F BUILDING 7/TDONG), NO.289 FAHUA NORTH ROAD, JINYI DUSHI NEW DISTRICT, JINHUA 321036 ZHEJJANG CHINA

TEL: +86-153-9755-3908 Email:sales@eztattooing.com

RODUCT NAME