


GRADO

Grado GW100

Wireless Series

Overview



Power



— **Long Press:** Power On / Off

Battery Saver: If unpaired for 5 minutes, GW100 will power off.



● **Blue:** Fully Charged



● **Blue:** Powered On



● **Red:** Charging



● **Red:** Low Battery



— **Charging:** Plug the Micro USB cable into the charging port and connect the other end to a compatible USB port of a computer or wall charger.

Connect



—— **Long Press:** From the off state press and hold until charging light flashes blue and red.

On your device, navigate to settings and turn on Bluetooth.

After a few seconds, you will see “Grado GW100”. Tap to pair.

When the paired device’s Bluetooth is turned off or out of range, the GW100 can connect to a second device.



—— **Blue & Red:** Ready to Pair

Volume / Music



—— **Short Press:** Play / Pause



—— **Short Press:** Increase Volume

Long Press: Next Song



—— **Short Press:** Decrease Volume

Long Press: Previous Song

Phone / Voice



———— **Short Press:** Answer / Hang Up
Long Press: Reject Call
Double Press: Voice Assistant



———— **Short Press:** Increase Volume



———— **Short Press:** Decrease Volume

Specifications

Bluetooth Version: 4.2 with apt-X

Battery Capacity: 320mAh

Working Distance: 10m

Battery Life: 15 hours*

Charging Time: 2 hours

Frequency Response: 20Hz~20KHz

Mic Sensitivity: 42dB +/- 3dB

Battery Capacity: 320mAh

Methods of pairing to Bluetooth may vary depending on the specific device. Please refer to the device's manual for further details.

*Battery life will vary depending on the listening volume and genre of music played.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

